# YASKAWA

# $\Sigma$ -7-Series AC Servo Drive $\Sigma$ -7W SERVOPACK with MECHATROLINK-III **Communications References Product Manual**

Model: SGD7W-DDDA20ADDDDDD



2	
3	
Λ	
4	
5	
6	
7	
8	
U	
9	
10	
11	
12	

**SERVOPACKs** 

SERVOPACKš

Trial Operation and Actual Operation

Tuning

Monitoring

Maintenance

Appendices

Parameter Lists

Copyright © 2014 YASKAWA ELECTRIC CORPORATION

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, or by any means, mechanical, electronic, photocopying, recording, or otherwise, without the prior written permission of Yaskawa. No patent liability is assumed with respect to the use of the information contained herein. Moreover, because Yaskawa is constantly striving to improve its high-quality products, the information contained in this manual is subject to change without notice. Every precaution has been taken in the preparation of this manual. Nevertheless, Yaskawa assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained in this publication.

### About this Manual

This manual provides information required to select  $\Sigma$ -7W SERVOPACKs with MECHATROLINK-III Communications References for  $\Sigma$ -7-Series AC Servo Drives, and to design, perform trial operation of, tune, operate, and maintain the Servo Drives.

Read and understand this manual to ensure correct usage of the  $\Sigma\text{-}7\text{-}Series$  AC Servo Drives.

Keep this manual in a safe place so that it can be referred to whenever necessary.

### **Outline of Manual**

The contents of the chapters of this manual are described in the following table.

Refer to these chapters as required.

Chapter	Chapter Title	Contents
1	Basic Information on SERVOPACKs	Provides information required to select SERVOPACKs, such as SER- VOPACK models and combinations with Servomotors.
2	Selecting a SERVOPACK	Provides information required to select SERVOPACKs, such as specifi- cations, block diagrams, dimensional drawings, and connection exam- ples.
3	SERVOPACK Installation	Provides information on installing SERVOPACKs in the required loca- tions.
4	Wiring and Connecting SERVOPACKs	Provides information on wiring and connecting SERVOPACKs to power supplies and peripheral devices.
5	Basic Functions That Require Set- ting before Operation	Describes the basic functions that must be set before you start servo system operation. It also describes the setting methods.
6	Application Functions	Describes the application functions that you can set before you start servo system operation. It also describes the setting methods.
7	Trial Operation and Actual Operation	Provides information on the flow and procedures for trial operation and convenient functions to use during trial operation.
8	Tuning	Provides information on the flow of tuning, details on tuning functions, and related operating procedures.
9	Monitoring	Provides information on monitoring SERVOPACK product information and SERVOPACK status.
10	Maintenance	Provides information on the meaning of, causes of, and corrections for alarms and warnings.
11	Parameter Lists	Provides information on the parameters.
12	Appendices	Provides information on interpreting panel displays and tables of corre- sponding SERVOPACK and SigmaWin+ function names.

### **Related Documents**

The relationships between the documents that are related to the Servo Drives are shown in the following figure. The numbers in the figure correspond to the numbers in the table on the following pages. Refer to these documents as required.



Classification	Document Name	Document No.	Description
① Machine Controller and Servo Drive General Catalog	Machine Controller and AC Servo Drive Solutions Catalog	KAEP S800001 22	Describes the features and application examples for combinations of MP3000-Series Machine Controllers and $\Sigma$ -7-Series AC Servo Drives.
② MP3300 Catalog	Machine Controller MP3300	KAEP C880725 03	Provides detailed information on MP3300 Machine Controllers, including features and specifica- tions.
<ul> <li>③</li> <li>Σ-7-Series Catalog</li> </ul>	AC Servo Drives Σ-7 Series	KAEP S800001 23	Provides detailed information on $\Sigma$ - 7-Series AC Servo Drives, including features and specifications.
@ MP3000-Series Manuals	Machine Controller MP3000 Series MP3300 Product Manual	SIEP C880725 21	Describes the functions, specifica- tions, operating methods, mainte- nance, inspections, and troubleshooting of the MP3000- series MP3300 Machine Control- lers.
	$\Sigma$ -7-Series AC Servo Drive $\Sigma$ -7S and $\Sigma$ -7W SERVOPACK Safety Precautions	TOMP C710828 00	Provides detailed information for the safe usage of $\Sigma$ -7-Series SERVOPACKs.
	$\begin{array}{l} \Sigma \text{-V-Series} \\ \text{for Large-Capacity Models/} \\ \Sigma \text{-7-Series} \\ \text{Safety Precautions} \\ \text{Option Module} \end{array}$	TOBP C720829 00	Provides detailed information for the safe usage of Option Modules.
	Σ-V-Series/Σ-V-Series for Large-Capacity Models/ Σ-7-Series Installation Guide Command Option Module	TOBP C720829 01	Provides detailed procedures for installing a Command Option Mod- ule in a SERVOPACK.
ග Enclosed Documents	$\begin{array}{l} \Sigma \text{-V-Series} \\ \text{for Large-Capacity Models/} \\ \Sigma \text{-7-Series} \\ \text{Installation Guide} \\ \text{Fully-closed Module} \end{array}$	TOBP C720829 03	Provides detailed procedures for installing the Fully-closed Module in a SERVOPACK.
	$\Sigma$ -V-Series/ $\Sigma$ -V-Series for Large-Capacity Models/ $\Sigma$ -7-Series Installation Guide Safety Module	TOBP C720829 06	Provides detailed procedures for installing the Safety Module in a SERVOPACK.
	$\Sigma$ -V-Series/ $\Sigma$ -V-Series for Large-Capacity Models/ $\Sigma$ -7-Series Installation Guide Indexer Module	TOBP C720829 02	Provides detailed procedures for installing the Indexer Module in a SERVOPACK.
	Σ-V-Series/Σ-V-Series for Large-Capacity Models/ Σ-7-Series Installation Guide DeviceNet Module	TOBP C720829 07	Provides detailed procedures for installing the DeviceNet Module in a SERVOPACK.

Continued on next page.

		T	Continued from previous page.	
Classification	Document Name	Document No.	Description	
	$\Sigma$ -7-Series AC Servo Drive $\Sigma$ -7S SERVOPACK with MECHATROLINK-III Communications References Product Manual	SIEP S800001 28		
	$\Sigma$ -7-Series AC Servo Drive $\Sigma$ -7S SERVOPACK with MECHATROLINK-II Communications References Product Manual	SIEP S800001 27		
6 Σ-7-Series Σ-75/Σ-7///	$\Sigma$ -7-Series AC Servo Drive $\Sigma$ -7S SERVOPACK with Analog Voltage/Pulse Train References Product Manual	SIEP S800001 26	Provide detailed information on selecting $\Sigma$ -7-Series SERVO-PACKs and information on install-	
Σ-7S/Σ-7W SERVOPACK Product Manuals	$\Sigma$ -7-Series AC Servo Drive $\Sigma$ -7S SERVOPACK Command Option Attachable Type with Indexer Module Product Manual	SIEP S800001 64	ing, connecting, setting, performing trial operation for, tuning, and mon itoring the Servo Drives.	
	$\Sigma$ -7-Series AC Servo Drive $\Sigma$ -7S SERVOPACK Command Option Attachable Type with DeviceNet Module Product Manual	SIEP S800001 70		
	$\Sigma$ -7-Series AC Servo Drive $\Sigma$ -7W SERVOPACK with MECHATROLINK-III Communications References Product Manual	This manual (SIEP S800001 29)		
$\bigcirc$ $\Sigma$ -7-Series $\Sigma$ -7S/ $\Sigma$ -7W SERVOPACK with	$\Sigma$ -7-Series AC Servo Drive $\Sigma$ -7S/ $\Sigma$ -7W SERVOPACK with Hardware Option Specifications Dynamic Brake Product Manual	SIEP S800001 73	Provides detailed information on Hardware Options for $\Sigma_2$ -Series	
SERVOPACK with Hardware Option Specifications Product Manuals	$\begin{array}{l} \Sigma\text{-}7\text{-}Series \ AC \ Servo \ Drive} \\ \Sigma\text{-}7W \ SERVOPACK \ with \\ Hardware \ Option \ Specifications \\ HWBB \ Function \\ Product \ Manual \end{array}$	SIEP S800001 72	Haroware Uptions for $\Sigma$ -7-Series SERVOPACKs.	
⑧ Enclosed Documents	AC Servo Drive Rotary Servomotor Safety Precautions	TOBP C230260 00	Provides detailed information for the safe usage of Rotary Servomo- tors and Direct Drive Servomotors.	
	osed Documents AC Servomotor Linear Σ Series Safety Precautions		Provides detailed information for the safe usage of Linear Servomo- tors.	

Continued on next page.

Classification **Document Name** Document No. Description 9 Σ-7-Series AC Servo Drive  $\Sigma$ -7-Series Rotary Servomotor SIEP S800001 36 Rotary Servomotor Product Manual Product Manual 10  $\Sigma$ -7-Series AC Servo Drive Provide detailed information on  $\Sigma$ -7-Series Linear Servomotor SIEP S800001 37 selecting, installing, and connecting Linear Servomotor the  $\Sigma$ -7-Series Servomotors. Product Manual Product Manual N  $\Sigma$ -7-Series AC Servo Drive  $\Sigma$ -7-Series Direct Drive Servomotor SIEP S800001 38 **Direct Drive** Product Manual Servomotor Product Manual 12 Σ-7-Series AC Servo Drive  $\Sigma$ -7-Series Describes the peripheral devices Peripheral Device SIEP S800001 32 Peripheral Device for a  $\Sigma$ -7-Series Servo System. Selection Manual Selection Manual Σ-7-Series AC Servo Drive Provides detailed information on MECHATROLINK-II the MECHATROLINK-II communi-SIEP S800001 30 Communications cations commands that are used **Command Manual** for a  $\Sigma$ -7-Series Servo System.  $\Sigma$ -7-Series MECHATROLINK  $\Sigma$ -7-Series AC Servo Drive Communications Provides detailed information on **Command Manuals** MECHATROLINK-III the MECHATROLINK-III communi-SIEP \$800001 31 Communications cations standard servo profile com-Standard Servo Profile mands that are used for a  $\Sigma$ -7-Command Manual Series Servo System. Σ-7-Series AC Servo Drive Describes the operating proce-**Digital Operator** SIEP S800001 33 dures for a Digital Operator for a **Operating Manual** Σ-7-Series Servo System.  $\Sigma$ -7-Series **Operation Interface Operating Manuals** AC Servo Drive Provides detailed operating proce-**Engineering Tool** dures for the SigmaWin+ Engineer-SIET S800001 34 SigmaWin+ ing Tool for a  $\Sigma$ -7-Series Servo **Operation Manual** System.  $\Sigma$ -V-Series/ $\Sigma$ -V-Series Provides details information for Large-Capacity Models/  $\Sigma$ -7-Series SIEP C720829 06 required for the design and mainte-**Option Module** 

User's Manual

Safety Module

User's Manual

Continued from previous page.

nance of a Safety Module.

# **Using This Manual**

### ◆ Technical Terms Used in This Manual

The following terms are used in this manual.

Term	Meaning
Servomotor	A $\Sigma$ -7-Series Rotary Servomotor, Direct Drive Servomotor, or Linear Servomotor.
Rotary Servomotor	A generic term used for a $\Sigma$ -7-Series Rotary Servomotor (SGM7J, SGM7A, SGM7P, or SGM7G) or a Direct Drive Servomotor (SGMCS or SGMCV). The descriptions will specify when Direct Drive Servomotors are excluded.
Linear Servomotor	A Σ-7-Series Linear Servomotor (SGLG, SGLF, SGLT, or SGLC).
SERVOPACK	A $\Sigma$ -7-Series $\Sigma$ -7W Servo Amplifier with MECHATROLINK-III Communications References.
Servo Drive	The combination of a Servomotor and SERVOPACK.
Servo System	A servo control system that includes the combination of a Servo Drive with a host controller and peripheral devices.
servo ON	Supplying power to the motor.
servo OFF	Not supplying power to the motor.
base block (BB)	Shutting OFF the power supply to the motor by shutting OFF the base current to the power transistor in the SERVOPACK.
servo lock	A state in which the motor is stopped and is in a position loop with a position reference of 0.
Main Circuit Cable	One of the cables that connect to the main circuit terminals, including the Main Circuit Power Supply Cable, Control Power Supply Cable, and Servomotor Main Circuit Cable.
SigmaWin+	The Engineering Tool for setting up and tuning Servo Drives or a computer in which the Engineering Tool is installed.

### Differences in Terms for Rotary Servomotors and Linear Servomotors

There are differences in the terms that are used for Rotary Servomotors and Linear Servomotors. This manual primarily describes Rotary Servomotors. If you are using a Linear Servomotor, you need to interpret the terms as given in the following table.

Rotary Servomotors	Linear Servomotors
torque	force
moment of inertia	mass
rotation	movement
forward rotation and reverse rotation	forward movement and reverse movement
CW and CCW pulse trains	forward and reverse pulse trains
rotary encoder	linear encoder
absolute rotary encoder	absolute linear encoder
incremental rotary encoder	incremental linear encoder
unit: min <sup>-1</sup>	unit: mm/s
unit: N⋅m	unit: N

### Notation Used in this Manual

#### Notation for Reverse Signals

The names of reverse signals (i.e., ones that are valid when low) are written with a forward slash (/) before the signal abbreviation.

#### Notation Example

BK is written as /BK.

#### Notation for Parameters

The notation depends on whether the parameter requires a numeric setting (parameter for numeric setting) or requires the selection of a function (parameter for selecting functions).

#### · Parameters for Numeric Settings



#### Notation Example

Notation Examples for Pn002

	Digit Notation			Numeric Value Notation
n.0 0 0 0	Notation	Meaning	Notation	Meaning
	Pn002 = n.□□□X	Indicates the first digit from the right in Pn002.	Pn002 = n.□□□1	Indicates that the first digit from the right in Pn002 is set to 1.
	Pn002 = n.□□X□	Indicates the second digit from the right in Pn002.	Pn002 = n.□□1□	Indicates that the second digit from the right in Pn002 is set to 1.
	Pn002 = n.□X□□	Indicates the third digit from the right in Pn002.	Pn002 = n.⊡1⊡⊡	Indicates that the third digit from the right in Pn002 is set to 1.
►	Pn002 = n.X□□□	Indicates the fourth digit from the right in Pn002.	Pn002 = n.1□□□	Indicates that the fourth digit from the right in Pn002 is set to 1.

### ◆ Engineering Tools Used in This Manual

This manual uses the interfaces of the SigmaWin+ for descriptions.

#### ♦ Trademarks

- QR code is a trademark of Denso Wave Inc.
- MECHATROLINK is a trademark of the MECHATROLINK Members Association.
- Other product names and company names are the trademarks or registered trademarks of the respective company. "TM" and the ® mark do not appear with product or company names in this manual.

### Visual Aids

The following aids are used to indicate certain types of information for easier reference.



Indicates precautions or restrictions that must be observed. Also indicates alarm displays and other precautions that will not result in machine damage.



Indicates definitions of difficult terms or terms that have not been previously explained in this manual.



ple Indicates operating or setting examples.

Information Indicates supplemental information to deepen understanding or useful information.

# **Safety Precautions**

### ♦ Safety Information

To prevent personal injury and equipment damage in advance, the following signal words are used to indicate safety precautions in this document. The signal words are used to classify the hazards and the degree of damage or injury that may occur if a product is used incorrectly. Information marked as shown below is important for safety. Always read this information and heed the precautions that are provided.

### \Lambda DANGER

• Indicates precautions that, if not heeded, are likely to result in loss of life, serious injury, or fire.

# 

• Indicates precautions that, if not heeded, could result in loss of life, serious injury, or fire.

# 

• Indicates precautions that, if not heeded, could result in relatively serious or minor injury, or in fire.

# NOTICE

• Indicates precautions that, if not heeded, could result in property damage.

### Safety Precautions That Must Always Be Observed

General Precautions

### 

- Read and understand this manual to ensure the safe usage of the product.
- Keep this manual in a safe, convenient place so that it can be referred to whenever necessary. Make sure that it is delivered to the final user of the product.
- Do not remove covers, cables, connectors, or optional devices while power is being supplied to the SERVOPACK.

There is a risk of electric shock, operational failure of the product, or burning.

### 

- Use a power supply with specifications (number of phases, voltage, frequency, and AC/DC type) that are appropriate for the product. There is a risk of burning, electric shock, or fire.
- Connect the ground terminals on the SERVOPACK and Servomotor to ground poles according to local electrical codes (100  $\Omega$  or less for a SERVOPACK with a 100-VAC or 200-VAC power supply, and 10  $\Omega$  or less for a SERVOPACK with a 400-VAC power supply). There is a risk of electric shock or fire.
- Do not attempt to disassemble, repair, or modify the product. There is a risk of fire or failure. The warranty is void for the product if you disassemble, repair, or modify it.

### 

- The SERVOPACK heat sinks, regenerative resistors, External Dynamic Brake Resistors, Servomotors, and other components can be very hot while power is ON or soon after the power is turned OFF. Implement safety measures, such as installing covers, so that hands and parts such as cables do not come into contact with hot components. There is a risk of burn injury.
- For a 24-VDC power supply, use a power supply device with double insulation or reinforced insulation.

There is a risk of electric shock.

- Do not damage, pull on, apply excessive force to, place heavy objects on, or pinch cables. There is a risk of failure, damage, or electric shock.
- Do not use the product in an environment that is subject to water, corrosive gases, or flammable gases, or near flammable materials.
   There is a risk of electric shock or fire.

### NOTICE

- Do not attempt to use a SERVOPACK or Servomotor that is damaged or that has missing parts.
- Install external emergency stop circuits that shut OFF the power supply and stops operation immediately when an error occurs.
- In locations with poor power supply conditions, install the necessary protective devices (such as AC reactors) to ensure that the input power is supplied within the specified voltage range. There is a risk of damage to the SERVOPACK.
- Use a Noise Filter to minimize the effects of electromagnetic interference. Electronic devices used near the SERVOPACK may be affected by electromagnetic interference.
- Always use a Servomotor and SERVOPACK in one of the specified combinations.
- Do not touch a SERVOPACK or Servomotor with wet hands. There is a risk of product failure.

#### Storage Precautions



• Do not place an excessive load on the product during storage. (Follow all instructions on the packages.)

There is a risk of injury or damage.

# NOTICE

- Do not install or store the product in any of the following locations.
  - · Locations that are subject to direct sunlight
  - · Locations that are subject to ambient temperatures that exceed product specifications
  - · Locations that are subject to relative humidities that exceed product specifications
  - · Locations that are subject to condensation as the result of extreme changes in temperature
  - · Locations that are subject to corrosive or flammable gases
  - · Locations that are near flammable materials
  - Locations that are subject to dust, salts, or iron powder
  - Locations that are subject to water, oil, or chemicals
  - · Locations that are subject to vibration or shock that exceeds product specifications
  - · Locations that are subject to radiation
  - If you store or install the product in any of the above locations, the product may fail or be damaged.

#### Transportation Precautions

# 

- Transport the product in a way that is suitable to the mass of the product.
- Do not use the eyebolts on a SERVOPACK or Servomotor to move the machine. There is a risk of damage or injury.
- When you handle a SERVOPACK or Servomotor, be careful of sharp parts, such as the corners. There is a risk of injury.
- Do not place an excessive load on the product during transportation. (Follow all instructions on the packages.)

There is a risk of injury or damage.

### NOTICE

- Do not hold onto the front cover or connectors when you move a SERVOPACK. There is a risk of the SERVOPACK falling.
- A SERVOPACK or Servomotor is a precision device. Do not drop it or subject it to strong shock. There is a risk of failure or damage.
- Do not subject connectors to shock. There is a risk of faulty connections or damage.
- If disinfectants or insecticides must be used to treat packing materials such as wooden frames, plywood, or pallets, the packing materials must be treated before the product is packaged, and methods other than fumigation must be used.

Example: Heat treatment, where materials are kiln-dried to a core temperature of 56°C for 30 minutes or more.

If the electronic products, which include stand-alone products and products installed in machines, are packed with fumigated wooden materials, the electrical components may be greatly damaged by the gases or fumes resulting from the fumigation process. In particular, disinfectants containing halogen, which includes chlorine, fluorine, bromine, or iodine can contribute to the erosion of the capacitors.

• Do not overtighten the eyebolts on a SERVOPACK or Servomotor. If you use a tool to overtighten the eyebolts, the tapped holes may be damaged.

#### Installation Precautions

### 

- Install the Servomotor or SERVOPACK in a way that will support the mass given in technical documents.
- Install SERVOPACKs, Servomotors, regenerative resistors, and External Dynamic Brake Resistors on nonflammable materials.
- Installation directly onto or near flammable materials may result in fire.
- Provide the specified clearances between the SERVOPACK and the control panel as well as with other devices.
  - There is a risk of fire or failure.
- Install the SERVOPACK in the specified orientation. There is a risk of fire or failure.
- Do not step on or place a heavy object on the product. There is a risk of failure, damage, or injury.
- Do not allow any foreign matter to enter the SERVOPACK or Servomotor. There is a risk of failure or fire.

### NOTICE

- Do not install or store the product in any of the following locations.
  - · Locations that are subject to direct sunlight
  - · Locations that are subject to ambient temperatures that exceed product specifications
  - Locations that are subject to relative humidities that exceed product specifications
  - · Locations that are subject to condensation as the result of extreme changes in temperature
  - · Locations that are subject to corrosive or flammable gases
  - · Locations that are near flammable materials
  - · Locations that are subject to dust, salts, or iron powder
  - Locations that are subject to water, oil, or chemicals
  - · Locations that are subject to vibration or shock that exceeds product specifications
  - · Locations that are subject to radiation
  - If you store or install the product in any of the above locations, the product may fail or be damaged.
- Use the product in an environment that is appropriate for the product specifications. If you use the product in an environment that exceeds product specifications, the product may fail or be damaged.
- A SERVOPACK or Servomotor is a precision device. Do not drop it or subject it to strong shock. There is a risk of failure or damage.
- Always install a SERVOPACK in a control panel.
- Do not allow any foreign matter to enter a SERVOPACK or a Servomotor with a Cooling Fan and do not cover the outlet from the Servomotor's cooling fan. There is a risk of failure.

#### Wiring Precautions

### 🛕 DANGER

• Do not change any wiring while power is being supplied. There is a risk of electric shock or injury.

### 

- Wiring and inspections must be performed only by qualified engineers. There is a risk of electric shock or product failure.
- Check all wiring and power supplies carefully. Incorrect wiring or incorrect voltage application to the output circuits may cause short-circuit failures. If a short-circuit failure occurs as a result of any of these causes, the holding brake will not work. This could damage the machine or cause an accident that may result in death or injury.
- Connect the AC and DC power supplies to the specified SERVOPACK terminals.
  - Connect an AC power supply to the L1, L2, and L3 terminals and the L1C and L2C terminals on the SERVOPACK.
  - Connect a DC power supply to the B1/ $\oplus$  and  $\ominus$  2 terminals and the L1C and L2C terminals on the SERVOPACK.
  - There is a risk of failure or fire.
- If you use a SERVOPACK with the Dynamic Brake Hardware Option, connect an External Dynamic Brake Resistor that is suitable for the machine and equipment specifications to the specified terminals.

There is a risk of unexpected operation, machine damage, burning, or injury when an emergency stop is performed.

# 

• Wait for at least six minutes after turning OFF the power supply (with a SERVOPACK for a 100-VAC input, wait for at least nine minutes) and then make sure that the CHARGE indicator is not lit before starting wiring or inspection work. Do not touch the power supply terminals while the CHARGE lamp is lit after turning OFF the power supply because high voltage may still remain in the SERVOPACK.

There is a risk of electric shock.

• Observe the precautions and instructions for wiring and trial operation precisely as described in this document.

Failures caused by incorrect wiring or incorrect voltage application in the brake circuit may cause the SERVOPACK to fail, damage the equipment, or cause an accident resulting in death or injury.

- Check the wiring to be sure it has been performed correctly. Connectors and pin layouts are sometimes different for different models. Always confirm the pin layouts in technical documents for your model before operation. There is a risk of failure or malfunction.
- Connect wires to power supply terminals and motor connection terminals securely with the specified methods and tightening torque.
   Insufficient tightening may cause wires and terminal blocks to generate heat due to faulty contact, possibly resulting in fire.
- Use shielded twisted-pair cables or screened unshielded multi-twisted-pair cables for I/O Signal Cables and Encoder Cables.
- Observe the following precautions when wiring the SERVOPACK's main circuit terminals.
  - Turn ON the power supply to the SERVOPACK only after all wiring, including the main circuit terminals, has been completed.
  - If a connector is used for the main circuit terminals, remove the main circuit connector from the SER-VOPACK before you wire it.
  - Insert only one wire per insertion hole in the main circuit terminals.
  - When you insert a wire, make sure that the conductor wire (e.g., whiskers) does not come into contact with adjacent wires.
- Install molded-case circuit breakers and other safety measures to provide protection against short circuits in external wiring. There is a risk of fire or failure.

### NOTICE

- Whenever possible, use the Cables specified by Yaskawa. If you use any other cables, confirm the rated current and application environment of your model and use the wiring materials specified by Yaskawa or equivalent materials.
- Securely tighten cable connector screws and lock mechanisms. Insufficient tightening may result in cable connectors falling off during operation.
- Do not bundle power lines (e.g., the Main Circuit Cable) and low-current lines (e.g., the I/O Signal Cables or Encoder Cables) together or run them through the same duct. If you do not place power lines and low-current lines in separate ducts, separate them by at least 30 cm. If the cables are too close to each other, malfunctions may occur due to noise affecting the low-current lines.
- Install a battery at either the host controller or on the Encoder Cable. If you install batteries both at the host controller and on the Encoder Cable at the same time, you will create a loop circuit between the batteries, resulting in a risk of damage or burning.
- When connecting a battery, connect the polarity correctly. There is a risk of battery rupture or encoder failure.

#### Operation Precautions

### 

• Before starting operation with a machine connected, change the settings of the switches and parameters to match the machine.

Unexpected machine operation, failure, or personal injury may occur if operation is started before appropriate settings are made.

- Do not radically change the settings of the parameters. There is a risk of unstable operation, machine damage, or injury.
- Install limit switches or stoppers at the ends of the moving parts of the machine to prevent unexpected accidents.

There is a risk of machine damage or injury.

- For trial operation, securely mount the Servomotor and disconnect it from the machine. There is a risk of injury.
- Forcing the motor to stop for overtravel is disabled when the Jog (Fn002), Origin Search (Fn003), or Easy FFT (Fn206) utility function is executed. Take necessary precautions. There is a risk of machine damage or injury.
- When an alarm occurs, the Servomotor will coast to a stop or stop with the dynamic brake according to the SERVOPACK Option and settings. The coasting distance will change with the moment of inertia of the load and the resistance of the External Dynamic Brake Resistor. Check the coasting distance during trial operation and implement suitable safety measures on the machine.
- Do not enter the machine's range of motion during operation. There is a risk of injury.
- Do not touch the moving parts of the Servomotor or machine during operation. There is a risk of injury.

•	Design the system to ensure safety even when problems, such as broken signal lines, occur. For example, the P-OT and N-OT signals are set in the default settings to operate on the safe side if a signal line breaks. Do not change the polarity of this type of signal.
•	When overtravel occurs, the power supply to the motor is turned OFF and the brake is released. If you use the Servomotor to drive a vertical load, set the Servomotor to enter a zero-clamped state after the Servomotor stops. Also, install safety devices (such as an external brake or counterweight) to prevent the moving parts of the machine from falling.
•	<ul> <li>Always turn OFF the servo before you turn OFF the power supply. If you turn OFF the main circuit power supply or control power supply during operation before you turn OFF the servo, the Servomotor will stop as follows:</li> <li>If you turn OFF the main circuit power supply during operation without turning OFF the servo, the</li> </ul>
	<ul> <li>Servomotor will stop abruptly with the dynamic brake.</li> <li>If you turn OFF the control power supply without turning OFF the servo, the stopping method tha used by the Servomotor depends on the model of the SERVOPACK. For details, refer to the man for the SERVOPACK</li> </ul>
	<ul> <li>If you use a SERVOPACK with the Dynamic Brake Hardware Option, the Servomotor stopping metods will be different from the stopping methods used without the Option or with other Hardware Options. For details, refer to the <i>Σ</i>-7-Series AC Servo Drive <i>Σ</i>-7S/<i>Σ</i>-7W SERVOPACK with Dynam Brake Hardware Option Specifications Product Manual.</li> </ul>
•	Do not use the dynamic brake for any application other than an emergency stop. There is a risk of failure due to rapid deterioration of elements in the SERVOPACK and the risk of unexpected operation, machine damage, burning, or injury.
	NOTICE
•	When you adjust the gain during system commissioning, use a measuring instrument to monitor the torque waveform and speed waveform and confirm that there is no vibration. If a high gain causes vibration, the Servomotor will be damaged quickly.
•	Do not frequently turn the power supply ON and OFF. After you have started actual operation, allow at least one hour between turning the power supply ON and OFF (as a guideline). Do not use the product in applications that require the power supply to be turned ON and OFF frequently.
•	The elements in the SERVOPACK will deteriorate quickly. An alarm or warning may occur if communications are performed with the host controller while
	the SigmaWin+ or Digital Operator is operating.
•	After you complete trial operation of the machine and facilities, use the SigmaWin+ to back up the settings of the SERVOPACK parameters. You can use them to reset the parameters after
	If you do not copy backed up parameter settings, normal operation may not be possible after a faulty SERVOPACK is replaced, possibly resulting in machine or equipment damage.
Mai	ntenance and Inspection Precautions
•	Do not change any wiring while power is being supplied. There is a risk of electric shock or injury.

# • Wiring and inspections must be performed only by qualified engineers. There is a risk of electric shock or product failure.

# 

• Wait for at least six minutes after turning OFF the power supply (with a SERVOPACK for a 100-VAC input, wait for at least nine minutes) and then make sure that the CHARGE indicator is not lit before starting wiring or inspection work. Do not touch the power supply terminals while the CHARGE lamp is lit after turning OFF the power supply because high voltage may still remain in the SERVOPACK.

There is a risk of electric shock.

 Before you replace a SERVOPACK, back up the settings of the SERVOPACK parameters. Copy the backed up parameter settings to the new SERVOPACK and confirm that they were copied correctly.

If you do not copy backed up parameter settings or if the copy operation is not completed normally, normal operation may not be possible, possibly resulting in machine or equipment damage.

### NOTICE

 Discharge all static electricity from your body before you operate any of the buttons or switches inside the front cover of the SERVOPACK. There is a risk of equipment damage.

#### Troubleshooting Precautions

### 

• If the safety device (molded-case circuit breaker or fuse) installed in the power supply line operates, remove the cause before you supply power to the SERVOPACK again. If necessary, repair or replace the SERVOPACK, check the wiring, and remove the factor that caused the safety device to operate.

There is a risk of fire, electric shock, or injury.

### 

• The product may suddenly start to operate when the power supply is recovered after a momentary power interruption. Design the machine to ensure human safety when operation restarts. There is a risk of injury.

#### When an alarm occurs, remove the cause of the alarm and ensure safety. Then reset the alarm or turn the power supply OFF and ON again to restart operation. There is a risk of injury or machine damage. • If the Servo ON signal is input to the SERVOPACK and an alarm is reset, the Servomotor may suddenly restart operation. Confirm that the servo is OFF and ensure safety before you reset an alarm. There is a risk of injury or machine damage. Always insert a magnetic contactor in the line between the main circuit power supply and the main circuit power supply terminals on the SERVOPACK so that the power supply can be shut OFF at the main circuit power supply. If a magnetic contactor is not connected when the SERVOPACK fails, a large current may flow, possibly resulting in fire. If an alarm occurs, shut OFF the main circuit power supply. There is a risk of fire due to a regenerative resistor overheating as the result of regenerative transistor failure. Install a ground fault detector against overloads and short-circuiting or install a molded-case circuit breaker combined with a ground fault detector. There is a risk of SERVOPACK failure or fire if a ground fault occurs. • The holding brake on a Servomotor will not ensure safety if there is the possibility that an external force (including gravity) may move the current position and create a hazardous situation when power is interrupted or an error occurs. If an external force may cause movement, install an external braking mechanism that ensures safety.

#### Disposal Precautions

• When disposing of the product, treat it as ordinary industrial waste. However, local ordinances and national laws must be observed. Implement all labeling and warnings as a final product as required.

#### General Precautions

- Figures provided in this document are typical examples or conceptual representations. There may be differences between them and actual wiring, circuits, and products.
- The products shown in illustrations in this document are sometimes shown without covers or protective guards. Always replace all covers and protective guards before you use the product.
- If you need a new copy of this document because it has been lost or damaged, contact your nearest Yaskawa representative or one of the offices listed on the back of this document.
- This document is subject to change without notice for product improvements, specifications changes, and improvements to the manual itself. We will update the document number of the document and issue revisions when changes are made.
- Any and all quality guarantees provided by Yaskawa are null and void if the customer modifies the product in any way. Yaskawa disavows any responsibility for damages or losses that are caused by modified products.

### Warranty

#### Details of Warranty

#### Warranty Period

The warranty period for a product that was purchased (hereinafter called the "delivered product") is one year from the time of delivery to the location specified by the customer or 18 months from the time of shipment from the Yaskawa factory, whichever is sooner.

#### Warranty Scope

Yaskawa shall replace or repair a defective product free of charge if a defect attributable to Yaskawa occurs during the above warranty period.

This warranty does not cover defects caused by the delivered product reaching the end of its service life and replacement of parts that require replacement or that have a limited service life.

This warranty does not cover failures that result from any of the following causes.

- Improper handling, abuse, or use in unsuitable conditions or in environments not described in product catalogs or manuals, or in any separately agreed-upon specifications
- · Causes not attributable to the delivered product itself
- Modifications or repairs not performed by Yaskawa
- Use of the delivered product in a manner in which it was not originally intended
- Causes that were not foreseeable with the scientific and technological understanding at the time
   of shipment from Yaskawa
- Events for which Yaskawa is not responsible, such as natural or human-made disasters

#### Limitations of Liability

- Yaskawa shall in no event be responsible for any damage or loss of opportunity to the customer that arises due to failure of the delivered product.
- Yaskawa shall not be responsible for any programs (including parameter settings) or the results of program execution of the programs provided by the user or by a third party for use with programmable Yaskawa products.
- The information described in product catalogs or manuals is provided for the purpose of the customer purchasing the appropriate product for the intended application. The use thereof does not guarantee that there are no infringements of intellectual property rights or other proprietary rights of Yaskawa or third parties, nor does it construe a license.
- Yaskawa shall not be responsible for any damage arising from infringements of intellectual property rights or other proprietary rights of third parties as a result of using the information described in catalogs or manuals.

### ♦ Suitability for Use

- It is the customer's responsibility to confirm conformity with any standards, codes, or regulations that apply if the Yaskawa product is used in combination with any other products.
- The customer must confirm that the Yaskawa product is suitable for the systems, machines, and equipment used by the customer.
- Consult with Yaskawa to determine whether use in the following applications is acceptable. If use in the application is acceptable, use the product with extra allowance in ratings and specifications, and provide safety measures to minimize hazards in the event of failure.
  - Outdoor use, use involving potential chemical contamination or electrical interference, or use in conditions or environments not described in product catalogs or manuals
  - Nuclear energy control systems, combustion systems, railroad systems, aviation systems, vehicle systems, medical equipment, amusement machines, and installations subject to separate industry or government regulations
  - Systems, machines, and equipment that may present a risk to life or property
  - Systems that require a high degree of reliability, such as systems that supply gas, water, or electricity, or systems that operate continuously 24 hours a day
  - · Other systems that require a similar high degree of safety
- Never use the product for an application involving serious risk to life or property without first ensuring that the system is designed to secure the required level of safety with risk warnings and redundancy, and that the Yaskawa product is properly rated and installed.
- The circuit examples and other application examples described in product catalogs and manuals are for reference. Check the functionality and safety of the actual devices and equipment to be used before using the product.
- Read and understand all use prohibitions and precautions, and operate the Yaskawa product correctly to prevent accidental harm to third parties.

### Specifications Change

The names, specifications, appearance, and accessories of products in product catalogs and manuals may be changed at any time based on improvements and other reasons. The next editions of the revised catalogs or manuals will be published with updated code numbers. Consult with your Yaskawa representative to confirm the actual specifications before purchasing a product.

# Compliance with UL Standards and EU Directives

Certification marks for the standards for which the product has been certified by certification bodies are shown on nameplate. Products that do not have the marks are not certified for the standards.

### North American Safety Standards (UL)

Product	Model	North American Safety Standards (UL File No.)
SERVOPACKs	SGD7W	UL 61800-5-1 (E147823) CSA C22.2 No.274
Rotary Servomotors	• SGMMV • SGM7A • SGM7J • SGM7P • SGM7G	UL 1004-1 UL 1004-6 (E165827)
Direct Drive	SGMCS	UL 1004-1 UL 1004-6 (E165827)
Servomotors	SGMCV*1	UL 1004-1 UL 1004-6
Linear Servomotors	• SGLGW • SGLFW • SGLFW2 <sup>*2</sup> • SGLTW	UL 1004 (E165827)

\*1. Certification is scheduled for December 2015.

\*2. Certification is scheduled for March 2016.

### ♦ European Directives



Product	Model	European Directive	Harmonized Standards
SERVOPACKs	SGD7W	EMC Directive 2004/108/EC	EN 55011 group 1, class A EN 61000-6-2 EN 61000-6-4 EN 61800-3
		Low Voltage Directive 2006/95/EC	EN 50178 EN 61800-5-1
Rotary Servomotors	SGMMV     SGM7J     SGM7A     SCM7D	EMC Directive 2004/108/EC	EN 55011 group 1, class A EN 61000-6-2 EN 61000-6-4 EN 61800-3
	• SGM7P • SGM7G	Low Voltage Directive 2006/95/EC	EN 60034-1 EN 60034-5
Direct Drive Servomotors	SGMCS-     DD, DDC,     DD, DDE     (Small-Capacity, Coreless     Servomotors)     SGMCV	EMC Directive 2004/108/EC	EN 55011 group 1, class A EN 61000-6-2 EN 61800-3 <sup>*1</sup>
		Low Voltage Directive 2006/95/EC	EN 60034-1 EN 60034-5
Linear Servomotors	• SGLG • SGLF • SGLFW2 <sup>*2</sup> • SGLT • SGLC	EMC Directive 2004/108/EC	EN 55011 group 1, class A EN 61000-6-2 EN 61000-6-4
		Low Voltage Directive 2006/95/EC	EN 60034-1

\*1. Only the SGMCV is certified.

\*2. Certification is scheduled for December 2015.

Note: We declared the CE Marking based on the harmonized standards in the above table.

# Contents

About this Manual		 ii
Outline of Manual		 iii
Related Documents		 iv
Using This Manual		 viii
Safety Precautions		 xi
Warranty		 xx
Compliance with UL Standards and EU Directives	3	 

### **Basic Information on SERVOPACKs**

1.1	The Σ	-7 Series 1-2
1.2	Interp	preting the Nameplate 1-3
1.3	Part N	James
1.4	Mode 1.4.1 1.4.2	I Designations       1-6         Interpreting SERVOPACK Model Numbers       1-6         Interpreting Servomotor Model Numbers       1-7
1.5	Comb 1.5.1 1.5.2 1.5.3	Dinations of SERVOPACKs and Servomotors       1-8         Combinations of Rotary Servomotors and SERVOPACKs       1-8         Combinations of Direct Drive Servomotors and SERVOPACKs       1-9         Combinations of Linear Servomotors and SERVOPACKs       1-10
1.6	Funct	ions



1

### Selecting a SERVOPACK

2.1	Ratin	gs and Specifications 2-2
	2.1.1 2.1.2 2.1.3	Ratings2-2SERVOPACK Overload Protection Characteristics2-3Specifications2-4
2.2	Block	Diagrams 2-7
	2.2.1 2.2.2	SGD7W-1R6A and -2R8A
2.3	Exter	nal Dimensions 2-9
	2.3.1 2.3.2	Front Cover Dimensions and Connector Specifications
2.4	Exampl	es of Standard Connections between SERVOPACKs and Peripheral Devices 2-12

S S	ERVOPACK Installation
U	
3.1	Installation Precautions 3-2
3.2	Mounting Types and Orientation 3-3
3.3	Mounting Hole Dimensions 3-4
3.4	Mounting Interval 3-5
	3.4.1Installing One SERVOPACK in a Control Panel3-53.4.2Installing More Than One SERVOPACK in a Control Panel3-5
3.5	Monitoring the Installation Environment
36	Derating Specifications 3-7
3.0	
3.7	EMC Installation Conditions 3-8
	living and Connecting SERV/ORACKs
4	
4.1	Wiring and Connecting SERVOPACKs
	4.1.1       General Precautions       4-3         4.1.2       Countermeasures against Noise       4-5
	4.1.3 Grounding
4.2	Basic Wiring Diagrams
4.3	Wiring the Power Supply to the SERVOPACK 4-10
	4.3.1 Terminal Symbols and Terminal Names
	4.3.2         Wining Proceedure for Main Circuit Connector         4-11           4.3.3         Power ON Sequence         4-12
	4.3.4 Power Supply Wiring Diagrams
	4.3.6       Wiring Reactors for Harmonic Suppression
4.4	Wiring Servomotors 4-19
	4.4.1 Terminal Symbols and Terminal Names
	4.4.2 Pin Arrangement of Encoder Connectors (CN2A and CN2B)
	4.4.4 Wiring the SERVOPACK to the Holding Brake
4.5	I/O Signal Connections 4-31
	4.5.1 I/O Signal Connector (CN1) Names and Functions
	4.5.2 I/O Signal Wiring Examples
	4.5.4 I/O Circuits
4.6	Connecting MECHATROLINK Communications Cables 4-38
4.7	Connecting the Other Connectors 4-39
	4.7.1 Serial Communications Connector (CN3) 4-39
	4.7.2         Computer Connector (CN7)

5

### Basic Functions That Require Setting before Operation

5.1	Manip	oulating Parameters (Pn□□□)5-3	3
	5.1.1 5.1.2 5.1.3 5.1.4 5.1.5	Parameter Classification.       5-4         Notation for Parameters       5-4         Parameter Setting Methods       5-4         Write Prohibition Setting for Parameters       5-4         Initializing Parameter Settings       5-4	3 4 5 6 9
5.2	MECH	HATROLINK-III Communications Settings	1
	5.2.1 5.2.2 5.2.3	Communications Settings.       .5-1         Setting the Station Address       .5-1         Extended Address Setting       .5-1	1 1 2
5.3	Power	r Supply Type Settings for the Main Circuit and Control Circuit5-13	3
	5.3.1 5.3.2	AC Power Supply Input/DC Power Supply Input Setting	3 4
5.4	Autor	natic Detection of Connected Motor 5-18	5
5.5	Moto	r Direction Setting 5-16	6
5.6	Settin	ng the Linear Encoder Pitch	7
5.7	Writin	ng Linear Servomotor Parameters	8
5.8	Selec	ting the Phase Sequence for a Linear Servomotor 5-23	3
5.9	Polar	ity Sensor Setting	5
5.10	Polar	ity Detection 5-26	6
5.10	Polar 5.10.1 5.10.2 5.10.3	ity Detection       5-26         Restrictions       .5-26         Using the SV_ON (Servo ON) Command to Perform Polarity Detection       .5-27         Using a Tool Function to Perform Polarity Detection       .5-28	6 7 8
5.10	Polar 5.10.1 5.10.2 5.10.3 Overt	ity Detection       5-26         Restrictions       .5-26         Using the SV_ON (Servo ON) Command to Perform Polarity Detection       .5-27         Using a Tool Function to Perform Polarity Detection       .5-28         travel and Related Settings       5-29	6 7 8 9
5.10	Polar 5.10.1 5.10.2 5.10.3 <b>Overt</b> 5.11.1 5.11.2 5.11.3 5.11.4	ity Detection       5-26         Restrictions       .5-26         Using the SV_ON (Servo ON) Command to Perform Polarity Detection       .5-27         Using a Tool Function to Perform Polarity Detection       .5-26         travel and Related Settings       5-26         Overtravel Signals       .5-26         Setting to Enable/Disable Overtravel       .5-36         Motor Stopping Method for Overtravel       .5-36         Overtravel Warnings       .5-37	6 7 8 9 0 2
5.10	Polar 5.10.1 5.10.2 5.10.3 Overt 5.11.1 5.11.2 5.11.3 5.11.4 Holdi	ity Detection5-26Restrictions.5-26Using the SV_ON (Servo ON) Command to Perform Polarity Detection.5-27Using a Tool Function to Perform Polarity Detection.5-26ravel and Related Settings5-29Overtravel Signals.5-29Setting to Enable/Disable Overtravel.5-30Motor Stopping Method for Overtravel.5-30Overtravel Warnings.5-33ng Brake5-33	6 6 7 8 9 0 0 2 3
5.11	Polar 5.10.1 5.10.2 5.10.3 <b>Overt</b> 5.11.1 5.11.2 5.11.3 5.11.4 <b>Holdi</b> 5.12.1 5.12.2 5.12.3 5.12.4	ity Detection5-26Restrictions.5-26Using the SV_ON (Servo ON) Command to Perform Polarity Detection.5-27Using a Tool Function to Perform Polarity Detection.5-28ravel and Related Settings5-29Overtravel Signals.5-29Setting to Enable/Disable Overtravel.5-30Motor Stopping Method for Overtravel.5-30Overtravel Warnings.5-32Brake5-33Brake.5-33Output Timing of /BK (Brake) Signal When the Servomotor Is Stopped.5-33Output Timing of /BK (Brake) Signal When the Servomotor Is Operating.5-33	6 6 7 8 9 0 0 2 3 3 4 5 5
5.10 5.11 5.12	Polar 5.10.1 5.10.2 5.10.3 Overt 5.11.1 5.11.2 5.11.3 5.11.4 Holdi 5.12.1 5.12.2 5.12.3 5.12.4 Moto	ity Detection5-26Restrictions.5-20Using the SV_ON (Servo ON) Command to Perform Polarity Detection.5-21Using a Tool Function to Perform Polarity Detection.5-23travel and Related Settings5-29Overtravel Signals.5-29Setting to Enable/Disable Overtravel.5-30Motor Stopping Method for Overtravel.5-33Overtravel Warnings.5-33Ing Brake.5-33Brake Operating Sequence5-33Output Timing of /BK (Brake) Signal When the Servomotor Is Stopped.5-33Output Timing of /BK (Brake) Signal When the Servomotor Is Operating.5-33Ing Stopping Methods for Servo OFF and Alarms.5-37	6 6 7 8 9 0 0 2 3 4 5 5 7
5.10 5.11 5.12	Polar 5.10.1 5.10.2 5.10.3 Overt 5.11.1 5.11.2 5.11.3 5.11.4 Holdi 5.12.1 5.12.2 5.12.3 5.12.4 Moto 5.13.1 5.13.2	ity Detection5-26Restrictions.5-26Using the SV_ON (Servo ON) Command to Perform Polarity Detection.5-27Using a Tool Function to Perform Polarity Detection.5-28travel and Related Settings.5-28Overtravel Signals.5-29Setting to Enable/Disable Overtravel.5-30Motor Stopping Method for Overtravel.5-31Overtravel Warnings.5-32Brake.5-33Output Timing of /BK (Brake) Signal When the Servomotor Is Stopped.5-33Output Timing of /BK (Brake) Signal When the Servomotor Is Operating.5-33Stopping Method for Servo OFF.5-33Stopping Method for Servo OFF.5-33Stopping Method for Servo OFF.5-33Servomotor Stopping Method for Alarms.5-33Servomotor Stopping Method for Alarms.5-34	6 678 9002 3455 7 78
5.10 5.11 5.12 5.13 5.14	Polar 5.10.1 5.10.2 5.10.3 Overt 5.11.1 5.11.2 5.11.3 5.11.4 Holdi 5.12.1 5.12.2 5.12.3 5.12.4 Moto 5.13.1 5.13.2 Moto	ity Detection5-26Restrictions.5-20Using the SV_ON (Servo ON) Command to Perform Polarity Detection.5-21Using a Tool Function to Perform Polarity Detection.5-21travel and Related Settings.5-22Overtravel Signals.5-22Setting to Enable/Disable Overtravel.5-30Motor Stopping Method for Overtravel.5-30Overtravel Warnings.5-33Ing Brake.5-33Brake Operating Sequence5-33Output Timing of /BK (Brake) Signal When the Servomotor Is Stopped.5-33Output Timing of /BK (Brake) Signal When the Servomotor Is Operating.5-33Stopping Methods for Servo OFF and Alarms.5-33Stopping Method for Alarms.5-33Servomotor Stopping Method for Alarms.5-34Output Timing of /BK (Brake) Signal When the Servomotor Is Operating.5-34Output Timing of /BK (Brake) Signal When the Servomotor Is Operating.5-34Output Timing of /BK (Brake) Signal When the Servomotor Is Operating.5-34Stopping Method for Servo OFF.5-33Servomotor Stopping Method for Alarms.5-34Servomotor Stopping Method for Alarms.5-34 </th <th>6 6 7 8 9 0 0 2 3 4 5 5 7 7 8 0 0 2 3 4 5 5 7 7 8 0 0 0 2 3 4 5 5 7 7 8 7 7 8 7 9 0 0 2 7 7 8 7 7 8 7 7 9 0 0 2 7 7 7 7 8 7 7 7 7 7 8 7 7 7 7 8 7</th>	6 6 7 8 9 0 0 2 3 4 5 5 7 7 8 0 0 2 3 4 5 5 7 7 8 0 0 0 2 3 4 5 5 7 7 8 7 7 8 7 9 0 0 2 7 7 8 7 7 8 7 7 9 0 0 2 7 7 7 7 8 7 7 7 7 7 8 7 7 7 7 8 7

5.15	Electi	ronic Gear Settings 5-4	12
	5.15.1 5.15.2	Electronic Gear Ratio Settings	43 45
5.16	Reset	tting the Absolute Encoder 5-4	16
	5.16.1 5.16.2 5.16.3 5.16.4	Precautions on Resetting.       5         Preparations       5         Applicable Tools       5         Operating Procedure       5	46 46 47 47
5.17	Settin	ng the Origin of the Absolute Encoder 5-4	19
	5.17.1 5.17.2	Absolute Encoder Origin Offset	49 49
5.18	Settin	ng the Regenerative Resistor Capacity	52



### **Application Functions**

6.1	I/O Si	ignal Allocations 6-3
	$\begin{array}{c} 6.1.1 \\ 6.1.2 \\ 6.1.3 \\ 6.1.4 \\ 6.1.5 \\ 6.1.6 \\ 6.1.7 \\ 6.1.8 \\ 6.1.9 \\ 6.1.10 \end{array}$	Input Signal Allocations6-3Output Signal Allocations6-6ALM (Servo Alarm) Signal6-9/WARN (Warning) Signal6-9/TGON (Rotation Detection) Signal6-10/S-RDY (Servo Ready) Signal6-11/V-CMP (Speed Coincidence Detection) Signal6-11/COIN (Positioning Completion) Signal6-13/NEAR (Near) Signal6-14Speed Limit during Torque Control6-15
6.2	Opera	ation for Momentary Power Interruptions
6.3	SEMI	F47 Function
6.4	Settin	ng the Motor Maximum Speed
6.5	Softw	vare Limits
	6.5.1 6.5.2 6.5.3	Setting to Enable/Disable Software Limits6-21Setting the Software Limits6-21Software Limit Check for References6-21
6.6	Selec	ting Torque Limits 6-22
	6.6.1 6.6.2 6.6.3	Internal Torque Limits6-22External Torque Limits6-23/CLT (Torque Limit Detection) Signal6-26
6.7	Abso	lute Encoders
	6.7.1 6.7.2 6.7.3 6.7.4 6.7.5	Connecting an Absolute Encoder6-27Structure of the Position Data of the Absolute Encoder6-28Reading the Position Data from the Absolute Encoder6-28Multiturn Limit Setting6-28Multiturn Limit Disagreement Alarm (A.CC0)6-30

6.8	Abso	lute Linear Encoders 6-33
	6.8.1	Connecting an Absolute Linear Encoder
	6.8.2 6.8.3	Structure of the Position Data of the Absolute Linear Encoder
60	Coffu	vere Depet
0.9	5011W	Broparationa 6.24
	6.9.1 6.9.2	Applicable Tools
	6.9.3	Operating Procedure
6.10	Initial	izing the Vibration Detection Level
	6.10.1	Preparations
	6.10.2 6.10.3	Applicable loois
	6.10.4	Related Parameters
6.11	Adjus	ting the Motor Current Detection Signal Offset 6-41
	6.11.1	Automatic Adjustment
	6.11.2	Manual Adjustment
6.12	Forci	ng the Motor to Stop 6-45
	6.12.1	FSTP (Forced Stop Input) Signal
	6.12.2	Resetting Method for Forced Stops
Tr	ial Op	peration and Actual Operation
7 1	Flow	of Trial Operation 7.2
1.1	7 1 1	Flow of Trial Operation for Botary Servomotors
	7.1.2	Flow of Trial Operation for Linear Servomotors
7.2	Inspe	ctions and Confirmations before Trial Operation 7-6
	mepe	
7.3	Trial (	Operation for the Servomotor without a Load
	7.3.1	Preparations
	7.3.3	Operating Procedure
7.4	Trial (	Operation with MECHATROLINK-III Communications 7-10
7.5	Trial C	Operation with the Servomotor Connected to the Machine7-12
	7.5.1	Precautions

7.5.2 7.5.3

7.6.1

7.6.2

7.6.3

7.6

7.7

8	Tuning	
8.	1 Over	view and Flow of Tuning 8-4
	8.1.1 8.1.2	Tuning Functions    8-5      Diagnostic Tool    8-6
8.	2 Moni	toring Methods 8-7
8.	3 Preca	autions to Ensure Safe Tuning 8-8
	8.3.1 8.3.2 8.3.3 8.3.4 8.3.5	Overtravel Settings8-8Torque Limit Settings8-8Setting the Position Deviation Overflow Alarm Level8-8Vibration Detection Level Setting8-10Setting the Position Deviation Overflow Alarm Level at Servo ON8-10
8.	4 Tunir	ng-less Function
	8.4.1 8.4.2 8.4.3 8.4.4 8.4.5 8.4.6	Application Restrictions.8-12Operating Procedure8-13Troubleshooting Alarms8-14Parameters Disabled by Tuning-less Function8-15Automatically Adjusted Function Setting8-15Related Parameters8-15
8.	5 Estin	nating the Moment of Inertia8-16
	8.5.1 8.5.2 8.5.3 8.5.4	Outline.8-16Restrictions.8-17Applicable Tools8-17Operating Procedure.8-18
8.	6 Auto	tuning without Host Reference
	8.6.1 8.6.2 8.6.3 8.6.4 8.6.5 8.6.6 8.6.7	Outline.8-24Restrictions.8-25Applicable Tools8-26Operating Procedure.8-26Troubleshooting Problems in Autotuning without a Host Reference.8-30Automatically Adjusted Function Settings8-31Related Parameters.8-34
8.	7 Auto	tuning with a Host Reference
	8.7.1 8.7.2 8.7.3 8.7.4 8.7.5 8.7.6 8.7.7	Outline.8-35Restrictions.8-36Applicable Tools8-36Operating Procedure.8-36Troubleshooting Problems in Autotuning with a Host Reference8-40Automatically Adjusted Function Settings8-41Related Parameters.8-41
8.	8 Cust	om Tuning
	8.8.1 8.8.2 8.8.3 8.8.4 8.8.5 8.8.6 8.8.7	Outline.8-42Preparations8-42Applicable Tools8-43Operating Procedure8-43Automatically Adjusted Function Settings8-48Tuning Example for Tuning Mode 2 or 38-48Related Parameters8-49

8.9	Anti-F	Resonance Control Adjustment	-50
	8.9.1 8.9.2 8.9.3 8.9.4 8.9.5 8.9.6	Outline       8         Preparations       8         Applicable Tools       8         Operating Procedure       8         Related Parameters       8         Suppressing Different Vibration Frequencies with       8         Anti-resonance Control       8	3-50 3-50 8-51 8-51 8-53 8-53
8.10	Vibrat	tion Suppression	-55
	8.10.1 8.10.2 8.10.3 8.10.4 8.10.5 8.10.6	Outline	3-55 3-56 8-56 8-56 8-58 8-59
8.11	Speed	d Ripple Compensation	-60
	8.11.1 8.11.2 8.11.3	Outline	3-60 3-60 8-64
8.12	Addit	ional Adjustment Functions	-66
	8.12.1 8.12.2 8.12.3 8.12.4 8.12.5 8.12.6 8.12.7	Gain Switching       8         Friction Compensation       8         Current Control Mode Selection       8         Current Gain Level Setting       8         Speed Detection Method Selection       8         Speed Feedback Filter       8         Backlash Compensation       8	3-66 3-70 8-71 8-72 8-72 8-72 8-72
8.13	Manu	al Tuning	-79
	8.13.1 8.13.2	Tuning the Servo Gains.       8         Compatible Adjustment Functions       8	3-79 8-89
8.14	Diagn	nostic Tools	-93
	8.14.1 8.14.2	Mechanical Analysis	3-93 8-95

# 9

Monitoring

9.1	Monit	toring Product Information	9-2
	9.1.1 9.1.2	Items That You Can Monitor	.9-2 .9-2
9.2	Monit	toring SERVOPACK Status	9-3
	9.2.1 9.2.2 9.2.3	Servo Drive Status Monitoring Status and Operations I/O Signal Monitor	.9-3 .9-3 .9-5
9.3	Monit	coring Machine Operation Status and Signal Waveforms	9-6
	9.3.1 9.3.2 9.3.3	Items That You Can Monitor	.9-6 .9-7 .9-8

9.4	Monit	toring Product Life	9-13
	9.4.1 9.4.2 9.4.3	Items That You Can Monitor Operating Procedure Preventative Maintenance	9-13 9-14 9-15
9.5	Alarm	n Tracing	9-16

### Maintenance

10.	1 Inspections and Part Replacement 10-2
	10.1.1 Inspections
	10.1.2    Guidelines for Part Replacement    10-2      10.1.3    Replacing the Battery    10-3
10.	2 Alarm Displays 10-5
	10.2.1 List of Alarms
	10.2.2         Resetting Alarms         10-10           10.2.3         Resetting Alarms         10-37
	10.2.4 Displaying the Alarm History       10-37         10.2.5 Clearing the Alarm History       10-38
	10.2.6 Resetting Motor Type Alarms
10.	3 Warning Displays 10-41
	10.3.1         List of Warnings
10.	4 Monitoring Communications Data during Alarms or Warnings10-50
10.	5 Troubleshooting Based on the Operation and Conditions of the Servomotor 10-51
11	Parameter Lists
11.	1 List of Servo Parameters 11-2

11.1	List of Servo Parameters	11-2
	11.1.1       Interpreting the Parameter Lists         11.1.2       List of Servo Parameters	11-2 11-3
11.2	List of MECHATROLINK-III Common Parameters	11-53
	11.2.1       Interpreting the Parameter Lists         11.2.2       List of MECHATROLINK-III Common Parameters	11-53 11-53
11.3	Parameter Recording Table	11-62

12-	Appendices			
12.	1 Interpreting Panel Displays 12-2			
	12.1.1Interpreting Status Displays12-212.1.2Alarm and Warning Displays12-212.1.3Overtravel Display12-212.1.4Forced Stop Display12-2			
12.	12.2 Corresponding SERVOPACK and SigmaWin+ Function Names.			
	12.2.1       Corresponding SERVOPACK Utility Function Names			
_				

### Index

**Revision History** 

# Basic Information on SERVOPACKs

This chapter provides information required to select SERVOPACKs, such as SERVOPACK models and combinations with Servomotors.

1.1	The $\Sigma$ -7 Series				
1.2	Interpreting the Nameplate1-3				
1.3	Part Names1-4				
1.4	Model Designations1-6				
	1.4.1 1.4.2	Interpreting SERVOPACK Model Numbers 1-6 Interpreting Servomotor Model Numbers 1-7			
1.5	Combinations of SERVOPACKs and Servomotors 1-8				
	1.5.1 1.5.2 1.5.3	Combinations of Rotary Servomotors and SERVOPACKs			
1.0	<b>E</b> ura el	Liona 1 11			
1.0	Func	uons			

### **1.1** The $\Sigma$ -7 Series

The  $\Sigma$ -7-series SERVOPACKs are designed for applications that require frequent high-speed and high-precision positioning. The SERVOPACK will make the most of machine performance in the shortest time possible, thus contributing to improving productivity.

The  $\Sigma$ -7-series SERVOPACKs include  $\Sigma$ -7S SERVOPACKs for single-axis control and  $\Sigma$ -7W SERVOPACKs for two-axis control.

Information In this manual, the axes are called axis A and axis B.

However, they are displayed as "axis 1," "axis 2," "AXIS#00," or "AXIS#01" on the Engineering Tool.

# 1.2 Interpreting the Nameplate

#### The following basic information is provided on the nameplate.



1

# 1.3 Part Names



No.	Name	Description	Reference	
1	Front Cover	_	_	
2	Input Voltage	_	_	
3	Nameplate	Indicates the SERVOPACK model and ratings.	page 1-3	
4	Model	The model of the SERVOPACK.	page 1-6	
5	QR Code	The QR code that is used by the MechatroCloud service.	_	
6	CHARGE	Lit while the main circuit power is being supplied. Note: Even if you turn OFF the main circuit power supply, this indi- cator will be lit as long as the internal capacitor remains charged. Do not touch the main circuit or motor terminals while this indicator is lit. Doing so may result in electric shock.	-	
Ø	Main Circuit Terminals	The terminals depend on the main circuit power supply input specifications of the SERVOPACK.	page 4-10	
8	Servomotor Terminals (Axis A: UA, VA, and WA, Axis B: UB, VB, and WB)	The connection terminals for the Servomotor Main Circuit Cable (power line).	page 4-19	
9	Ground Terminal ()	The ground terminals to prevent electric shock. Always connect this terminal.	_	
0	MECHATROLINK-III Com- munications Connector (CN6A and CN6B)	Connects to MECHATROLINK-III-compatible devices.	page 4-38	
1	Serial Communications Con- nector (CN3)	Connects to the Digital Operator (a peripheral device) or a computer (RS-422).	page 4-39	
(12)	Computer Connector (CN7)	A USB connector to connect a computer.	page 4-39	
13	I/O Signal Connector (CN1)	Connects to sequence I/O signals.	page 4-31	
1	Encoder Connectors (Axis A: CN2A, Axis B: CN2B)	<ul> <li>Rotary Servomotor: Connects to the encoder in the Servomotor.</li> <li>Linear Servomotor: Connects to a Serial Converter Unit or linear encoder.</li> </ul>	page 4-19	
(15)	Serial Number	_	_	
16	DIP Switch (S3)	Used to set MECHATROLINK-III communications.	nage 5-11	
17	Rotary Switches (S1 and S2)	Used to set the MECHATROLINK station address.	page 5-11	
18	PWR	Lights when the control power is being supplied.	_	
19	L1, L2	Lights during MECHATROLINK communications.	_	
20	CN	Lights when the SERVOPACK normally receives a CON- NECT command.	_	

Continued on next page.
			1 0
No.	Name	Description	Reference
21)	Analog Monitor Connector (CN5)	You can use a special cable (peripheral device) to monitor the motor speed, torque reference, or other values.	page 4-39
22	Panel Display for Axis A	Displays the serve status with a seven-segment display	_
23	Panel Display for Axis B	Displays the servo status with a seven-segment display.	_

#### Continued from previous page.

1.4.1 Interpreting SERVOPACK Model Numbers



	•
None	Nono
000	None

14th digit BTO Specification\*6

Code	Specification
None	None
В	BTO specification

- \*1. You can use these models with either a single-phase or three-phase input.
- \*2. If you use the Servomotor with a single-phase 200-VAC power supply input, derate the load ratio to 65%. An example is given below. If the load ratio of the first axis is 90%, use a load ratio of 40% for the second axis so that average load ratio for both axes is 65%. ((90% + 40%)/2 = 65%)
- \*3. The same SERVOPACKs are used for both Rotary Servomotors and Linear Servomotors.
- \*4. Refer to the following manual for details.
- Ω Σ-7-Series AC Servo Drive Σ-7S/Σ-7W SERVOPACK with Dynamic Brake Hardware Option Specifications Product Manual (Manual No.: SIEP S800001 73)
- \*5. Refer to the following manual for details.

   Ω-7-Series AC Servo Drive Σ-7W SERVOPACK with Hardware Option Specifications HWBB Function Product Manual (Manual No.: SIEP S800001 72)
- \*6. The BTO specification indicates if the SEVOPACK is customized by using the MechatroCloud BTO service. You need a BTO number to order SERVOPACKs with customized specifications.
   Refer to the following catalog for details on the BTO specification.
   AC Servo Drives Σ-7 Series (Manual No.: KAEP S800001 23)

#### 1.4.2 Interpreting Servomotor Model Numbers

#### 1.4.2 Interpreting Servomotor Model Numbers

This section outlines the model numbers of  $\Sigma$ -7-series Servomotors. Refer to the relevant manual in the following list for details.

- $\prod \Sigma$ -7-Series Rotary Servomotor Product Manual (Manual No.: SIEP S800001 36)
- $\square$   $\Sigma$ -7-Series Linear Servomotor Product Manual (Manual No.: SIEP S800001 37)
- Ω Σ-7-Series Direct Drive Servomotor Product Manual (Manual No.: SIEP S800001 38)



The specifications for the 3rd digit on depend on the Servomotor type.

1.5.1 Combinations of Rotary Servomotors and SERVOPACKs

## 1.5 Combinations of SERVOPACKs and Servomotors

### 1.5.1 Combinations of Rotary Servomotors and SERVOPACKs

Deterry Comuser	ator Madal	Conseitu	SERVOPACK Model	
Rotary Servom	lotor Model	Capacity	SGD7W-	
SGMMV Models	SGMMV-A1A	10 W	1D64* or 2D94*	
(Low inertia, ultra-	SGMMV-A2A	20 W	THUA: UI ZHOA:	
3,000 min <sup>-1</sup>	SGMMV-A3A	30 W	1R6A or 2R8A*	
	SGM7J-A5A	50 W	1D64* or 0D04*	
	SGM7J-01A	100 W	INDAT UT ZHOAT	
SGM7J Models	SGM7J-C2A	150 W		
(Medium Inertia,	SGM7J-02A	200 W	I NOA UI ZNOA'	
Small Capacity), 3,000 min <sup>-1</sup>	SGM7J-04A	400 W	2R8A, 5R5A*, or 7R6A*	
	SGM7J-06A	600 W	EDEA or 7DEA	
	SGM7J-08A	750 W	SROA ULI ROA	
	SGM7A-A5A	50 W	1D6A* or 2D8A*	
	SGM7A-01A	100 W	INUA: UI ZNOA:	
SGM7A Models	SGM7A-C2A	150 W	1D64 or 2D84*	
(Low Inertia, Small	SGM7A-02A	200 W		
Capacity), 3,000 min <sup>-1</sup>	SGM7A-04A	400 W	2R8A, 5R5A*, or 7R6A*	
	SGM7A-06A	600 W		
	SGM7A-08A	750 W		
SGM7P Models	SGM7P-01A	100 W	1R6A* or 2R8A*	
(Medium Inertia,	SGM7P-02A	200 W	2R8A, 5R5A*, or	
Flat),	SGM7P-04A	400 W	7R6A*	
3,000 min <sup>-</sup> '	SGM7P-08A	750 W	5R5A or 7R6A	
SGM7G Models	SGM7G-03A	300 W	5R5A* or 7R6A*	
(Medium Inertia, Medium Canacity)	SGM7G-05A	450 W	UTION OF THUA	
$1,500 \text{ min}^{-1}$	SGM7G-09A	850 W	7R6A	

\* If you use this combination, performance may not be as good, e.g., the control gain may not increase, in comparison with using a Σ-7S SERVOPACK. 1.5.2 Combinations of Direct Drive Servomotors and SERVOPACKs

# 1.5.2 Combinations of Direct Drive Servomotors and SERVOPACKs

		Bated Torque	Instantaneous	SERVOPACK Model	
Direct Drive Servomotor Model		[N·m]	Maximum Torque [N·m]	SGD7W-	
	SGMCS-02B	2	6		
	SGMCS-05B	5	15		
	SGMCS-07B	7	21		
	SGMCS-04C	4	12		
Small Capacity,	SGMCS-10C	10	30	2R8A	
Coreless	SGMCS-14C	14	42		
(SGMCS)	SGMCS-08D	8	24		
	SGMCS-17D	17	51	EDEA	
	SGMCS-25D	25	75		
	SGMCS-16E	16	48		
	SGMCS-35E	35	105	JUDA	
Medium Capacity, With Core (SGMCS)	SGMCS-45M	45	135	7R6A	
	SGMCV-04B	4	12	0004	
	SGMCV-10B	10	30	2004	
	SGMCV-14B	14	42	5R5A	
Small Capacity,	SGMCV-08C	8	24	2R8A	
(SGMCV)	SGMCV-17C	17	51	5R5A	
· · · ·	SGMCV-25C	25	75	7R6A	
	SGMCV-16D	16	48	5R5A	
_	SGMCV-35D	35	105	7R6A*	

\* Use derated values for this combination. Refer to the following catalog for information on derating values.  $\square$ AC Servo Drives  $\Sigma$ -7 Series (Manual No.: KAEP S800001 23)

1.5.3 Combinations of Linear Servomotors and SERVOPACKs

## 1.5.3 Combinations of Linear Servomotors and SERVOPACKs

		Bated Torque	Instantaneous	SERVOPACK Model
Linear Servomotor Model		[N]	Maximum Torque [N]	SGD7W-
	SGLGW-30A050C	12.5	40	
	SGLGW-30A080C	25	80	1864
SGLG	SGLGW-40A140C	47	140	11104
(Coreless Models),	SGLGW-40A253C	93	280	
dard-Force Mag-	SGLGW-40A365C	140	420	2R8A
netic Way	SGLGW-60A140C	70	220	1R6A
	SGLGW-60A253C	140	440	2R8A
	SGLGW-60A365C	210	660	5R5A
	SGLGW-40A140C	57	230	1R6A
SGLG	SGLGW-40A253C	114	460	2R8A
(Coreless Models),	SGLGW-40A365C	171	690	5R5A
Force Magnetic	SGLGW-60A140C	85	360	1R6A
Way	SGLGW-60A253C	170	720	5R5A
	SGLGW-60A365C	255	1080	7R6A
	SGLFW-20A090A	25	86	
	SGLFW-20A120A	40	125	1R6A
	SGLFW-35A120A	80	220	
	SGLFW-35A230A	160	440	
SGLF	SGLFW-50A200B	280	600	- SRSA
(IVIODEIS WITH F-Type Iron Cores)	SGLFW2-30A070A	45	135	1004
	SGLFW2-30A120A	90	270	ΙΚόΑ
		180	540	_
	SGLFW2-30A230A*	170	500	2R8A
	SGLFW2-45A200A	280	840	5R5A
	SGLTW-20A170A	130	380	5R5A
	SGLTW-20A320A	250	760	7R6A
SGLT	SGLTW-20A460A	380	1140	_
(IVIODEIS WITH I-Type Iron Cores)	SGLTW-35A170A	220	660	
	SGLTW-35A170H	300	600	5R5A
	SGLTW-50A170H	450	900	
	SGLC-D16A085A	17	60	
	SGLC-D16A115A	25	90	
	SGLC-D16A145A	34	120	1R6A
	SGLC-D20A100A	30	150	-
	SGLC-D20A135A	45	225	-
SGLC	SGLC-D20A170A	60	300	2R8A
(Cylinder Models)	SGLC-D25A125A	70	280	1R6A
	SGLC-D25A170A	105	420	2R8A
	SGLC-D25A215A	140	560	5R5A
	SGLC-D32A165A	90	420	2R8A
	SGLC-D32A225A	135	630	
	SGLC-D32A285A	180	840	5K5A

\* The force depends on the SERVOPACK that is used with the Servomotor.

## 1.6 Functions

This section lists the functions provided by SERVOPACKs. Refer to the reference pages for details on the functions.

· Functions Related to the Machine

Function	Reference
Power Supply Type Settings for the Main Circuit and Control Circuit	page 5-13
Automatic Detection of Connected Motor	page 5-15
Motor Direction Setting	page 5-16
Linear Encoder Pitch Setting	page 5-17
Writing Linear Servomotor Parameters	page 5-18
Selecting the Phase Sequence for a Linear Servomotor	page 5-23
Polarity Sensor Setting	page 5-25
Polarity Detection	page 5-26
Overtravel Function and Settings	page 5-29
Holding Brake	page 5-33
Motor Stopping Methods for Servo OFF and Alarms	page 5-37
Resetting the Absolute Encoder	page 5-46
Setting the Origin of the Absolute Encoder	page 5-49
Setting the Regenerative Resistor Capacity	page 5-52
Operation for Momentary Power Interruptions	page 6-17
SEMI F47 Function	page 6-18
Setting the Motor Maximum Speed	page 6-20
Software Limits and Settings	page 6-21
Multiturn Limit Setting	page 6-28
Adjustment of Motor Current Detection Signal Offset	page 6-41
Forcing the Motor to Stop	page 6-45
Speed Ripple Compensation	page 8-60
Current Gain Level Setting	page 8-72
Speed Detection Method Selection	page 8-72
External Latches	-

#### • Functions Related to the Host Controller

Function	Reference
Extended Address Setting	page 5-12
Electronic Gear Settings	page 5-42
I/O Signal Allocations	page 6-3
Servo Alarm (ALM) Signal	page 6-9
Warning Output (/WARN) Signal	page 6-9
Rotation Detection (/TGON) Signal	page 6-10
/S-RDY (Servo Ready) Signal	page 6-11
Speed Coincidence Detection (/V-CMP) Signal	page 6-11
Positioning Completion (/COIN) Signal	page 6-13
Near (/NEAR) Signal	page 6-14
Speed Limit during Torque Control	page 6-15
Speed Limit Detection (/VLT) Signal	page 6-15
Selecting Torque Limits	page 6-22
Vibration Detection Level Initialization	page 6-37
Alarm Reset	page 10-37
Replacing the Battery	page 10-3
Setting the Position Deviation Overflow Alarm Level	page 8-8

#### Functions to Achieve Optimum Motions

Function	Reference
Tuning-less Function	page 8-12
Automatic Adjustment without a Host Reference	page 8-24
Automatic Adjustment with a Host Reference	page 8-35
Custom Adjustment	page 8-42
Anti-Resonance Control Adjustment	page 8-50
Vibration Suppression	page 8-55
Gain Selection	page 8-66
Friction Compensation	page 8-70
Backlash Compensation	page 8-73
Model Following Control	page 8-86
Compatible Adjustment Functions	page 8-89
Mechanical Analysis	page 8-93
Easy FFT	page 8-95

#### Functions for Trial Operation during Setup

Function	Reference
Software Reset	page 6-34
Trial Operation of Servomotor without a Load	page 7-7
Program Jogging	page 7-14
Origin Search	page 7-19
Test without a Motor	page 7-21
Monitoring Machine Operation Status and Signal Waveforms	page 9-6

Function	Reference
Write Prohibition Setting for Parameters	page 5-6
Initializing Parameter Settings	page 5-9
Automatic Detection of Connected Motor	page 5-15
Monitoring Product Information	page 9-2
Monitoring Product Life	page 9-2
Alarm History Display	page 10-37
Alarm Tracing	page 9-16

#### • Functions for Inspection and Maintenance

1

1-13

# Selecting a SERVOPACK

This chapter provides information required to select SERVOPACKs, such as specifications, block diagrams, dimensional drawings, and connection examples.

2.1	Rating	gs and Specifications2-2
	2.1.1 2.1.2	Ratings
	2.1.3	Specifications
2.2	Block	Diagrams 2-7
	2.2.1 2.2.2	SGD7W-1R6A and -2R8A
2.3	Extern	nal Dimensions2-9
	2.3.1	Front Cover Dimensions and Connector Specifications
	2.3.2	SERVOPACK External Dimensions
2.4	Examples of	of Standard Connections between SERVOPACKs and Peripheral Devices2-12

2.1.1 Ratings

## 2.1 Ratings and Specifications

This section gives the ratings and specifications of SERVOPACKs.

## 2.1.1 Ratings

#### Three-Phase, 200 VAC

	Model SGD7W-		1R6A	2R8A	5R5A	7R6A
Maximum Appli	cable Motor Capacity p	oer Axis [kW]	0.2	0.4	0.75	1.0
Continuous Ou	tput Current per Axis [A	rms]	1.6	2.8	5.5	7.6
Instantaneous Maximum Output Current per Axis [Arms]			5.9	9.3	16.9	17.0
Main Cinevit	Power Supply		200 VAC to	240 VAC, -15	% to +10%, 5	0 Hz/60 Hz
Main Circuit	Input Current [Arms]*		2.5	4.7	7.8	11
Control Power Supply			200 VAC to	240 VAC, -15	% to +10%, 5	0 Hz/60 Hz
Power Supply Capacity [kVA]*			1.0	1.9	3.2	4.5
	Main Circuit Power Lo	24.0	43.3	78.9	94.2	
	Control Circuit Power	17	17	17	17	
Power Loss <sup>*</sup>	Built-in Regenerative Power Loss [W]	8	8	16	16	
	Total Power Loss [W]	49.0	68.3	111.9	127.2	
	Built-In Regenera-	Resistance $[\Omega]$	40	40	12	12
Regenerative Resistor	tive Resistor	Capacity [W]	40	40	60	60
	Minimum Allowable External Resistance $[\Omega]$		40	40	12	12
Overvoltage Ca	tegory			l		

\* This is the net value at the rated load.

#### Single-Phase, 200 VAC

	Model SGD7W-	1R6A	2R8A	5R5A <sup>*1</sup>	
Maximum Appli	cable Motor Capacity per Axis [kW]	0.2	.2 0.4		
Continuous Out	tput Current per Axis [Arms]	1.6	2.8	5.5	
Instantaneous I [Arms]	Maximum Output Current per Axis	5.9	9.3	16.9	
Main Circult	Power Supply	200 VAC to 240	200 VAC to 240 VAC, -15% to +10%, 50 Hz/60 Hz		
Main Circuit	Input Current [Arms] <sup>*2</sup>	5.5	11	12	
Control Power	Supply	200 VAC to 240 VAC, -15% to +10%, 50 Hz/60 Hz			
Power Supply (	Capacity [kVA] <sup>*2</sup>	1.3	2.4	2.7	
	Main Circuit Power Loss [W]	24.1	43.6	54.1	
Power Loss*2	Control Circuit Power Loss [W]	17	17	17	
	Built-in Regenerative Resistor Power Loss [W]	8	8	16	
	Total Power Loss [W]	49.1	68.6	87.1	

Continued on next page.

#### 2.1.2 SERVOPACK Overload Protection Characteristics

				Continued in	sin previous page.
Model SGD7W-			1R6A	2R8A	5R5A <sup>*1</sup>
	Built-In Regenera-	Resistance $[\Omega]$	40	40	12
Regenerative Resistor	tive Resistor	Capacity [W]	40	40	60
	Minimum Allowable E tance $[\Omega]$	xternal Resis-	40	40	12
Overvoltage Category				III	

Continued from previous page.

\*1. If you use the SGD7W-5R5A with a single-phase 200-VAC power supply input, derate the load ratio to 65%. An example is given below. If the load ratio of the first axis is 90%, use a load ratio of 40% for the second axis so that average load ratio for both axes is 65%. ((90% + 40%)/2 = 65%)

\*2. This is the net value at the rated load. However, a load ratio of 65% was used for the SGD7W-5R5A.

#### 270 VDC

	Model SGD7W-	1R6A	2R8A	5R5A	7R6A	
Maximum Appli	cable Motor Capacity per Axis [kW]	0.2	0.4	0.75	1.0	
Continuous Out	put Current per Axis [Arms]	1.6	2.8	5.5	7.6	
Instantaneous N [Arms]	Maximum Output Current per Axis	5.9	5.9 9.3 16.9		17.0	
Main Circuit	Power Supply	270 VDC to 324 VDC, -15% to +10%				
Main Circuit	Input Current [Arms]*	3.0	5.8	9.7	14	
Control Power	Supply	270 VDC to 324 VDC, -15% to +10%				
Power Supply (	Capacity [kVA]*	1.2 2 3.2 4.6			4.6	
	Main Circuit Power Loss [W]	18.7	33.3	58.4	73.7	
Power Loss*	Control Circuit Power Loss [W]	17	17	17	17	
	Total Power Loss [W]	35.7	50.3	75.4	90.7	
Overvoltage Ca	voltage Category III					

\* This is the net value at the rated load.

### 2.1.2 SERVOPACK Overload Protection Characteristics

The overload detection level is set for hot start conditions with a SERVOPACK surrounding air temperature of 55°C.

An overload alarm (A.710 or A.720) will occur if overload operation that exceeds the overload protection characteristics shown in the following diagram (i.e., operation on the right side of the applicable line) is performed.

The actual overload detection level will be the detection level of the connected SERVOPACK or Servomotor that has the lower overload protection characteristics.

In most cases, that will be the overload protection characteristics of the Servomotor.

#### 2.1.3 Specifications



Note: The above overload protection characteristics do not mean that you can perform continuous duty operation with an output of 100% or higher.

For a Yaskawa-specified combination of SERVOPACK and Servomotor, maintain the effective torque within the continuous duty zone of the torque-motor speed characteristic of the Servomotor.

## 2.1.3 Specifications

	Item	Specification			
Control Met	hod	IGBT-based PWM control, sine wave current drive			
Feedback	With Rotary Servomotor	Serial encoder: 17 bits (absolute encoder) 20 bits or 24 bits (incremental encoder/absolute encoder) 22 bits (absolute encoder)			
	With Linear Servomotor	<ul> <li>Absolute linear encoder (The signal resolution depends on the absolute linear encoder.)</li> <li>Incremental linear encoder (The signal resolution depends on the incremental linear encoder or Serial Converter Unit.)</li> </ul>			
	Surrounding Air Tem- perature	-5°C to 55°C (With derating, usage is possible between 55°C and 60°C.) Refer to the following section for derating specifications. 3.6 Derating Specifications on page 3-7			
	Storage Temperature	-20°C to 85°C			
	Surrounding Air Humidity	95% relative humidity max. (with no freezing or condensation)			
	Storage Humidity	95% relative humidity max. (with no freezing or condensation)			
	Vibration Resistance	4.9 m/s <sup>2</sup>			
Environ-	Shock Resistance	19.6 m/s <sup>2</sup>			
mental	Degree of Protection	IP20			
Conditions	Pollution Degree	<ul><li>2</li><li>Must be no corrosive or flammable gases.</li><li>Must be no exposure to water, oil, or chemicals.</li><li>Must be no dust, salts, or iron dust.</li></ul>			
	Altitude	1,000 m max. (With derating, usage is possible between 1,000 m and 2,000 m.) Refer to the following section for derating specifications.			
	Others	Do not use the SERVOPACK in the following locations: Locations subject to static electricity noise, strong electromagnetic/magnetic fields, or radioactivity			
Applicable S	Standards	Refer to the following section for details.			
Mounting		Base-mounted or rack-mounted			

Continued on next page.

2.1.3 Specifications

Continued from previous page.

Item			Specification
	Speed Con	trol Range	1:5000 (At the rated torque, the lower limit of the speed control range must not cause the Servomotor to stop.)
			$\pm 0.01\%$ of rated speed max. (for a load fluctuation of 0% to 100%)
	Coefficient	of Speed	0% of rated speed max. (for a voltage fluctuation of $\pm 10\%$ )
Perfor- mance	Fluctuation	•	$\pm 0.1\%$ of rated speed max. (for a temperature fluctuation of 25°C $\pm 25^{\circ}\text{C}$ )
	Torque Cor sion (Repea	ntrol Preci- atability)	±1%
	Soft Start T Setting	ime	0 s to 10 s (Can be set separately for acceleration and deceleration.)
	Linear Serv Overheat P Signal Inpu	omotor rotection t	Number of input points: 2 Input voltage range: 0 V to +5 V
			Allowable voltage range: 24 VDC ±20% Number of input points: 12
	Sequence	Input Signals That Can	Input method: Sink inputs or source inputs Input Signals • /DEC (Origin Return Deceleration Switch) signal
	nals	Be Allo- cated	<ul> <li>/EXT1 to /EXT3 (External Latch Input 1 to 3) signals</li> <li>P-OT (Forward Drive Prohibit) and N-OT (Reverse Drive Prohibit) signals</li> </ul>
			A signal can be allocated and the positive and negative logic can be changed.
		Fixed	Allowable voltage range: 5 VDC to 30 VDC
I/O Signals		Output	Number of output points: 2 Output signal: Al M (Servo Alarm) signal
	Sequence Output Signals	uence ut Output als Signals That Can Be Allo-	Allowable voltage range: 5 VDC to 30 VDC Number of output points: 5 (A photocoupler output (isolated) is used.)
			Output Signals • /COIN (Positioning Completion) signal • /V-CMP (Speed Coincidence Detection) signal • /TGON (Rotation Detection) signal • /S-RDY (Servo Ready) signal • /CLT (Torque Limit Detection) signal All T (Cread Limit Detection) signal
			<ul> <li>/VL1 (Speed Limit Detection) signal</li> <li>/BK (Brake) signal</li> <li>/WARN (Warning) signal</li> <li>/NEAR (Near) signal</li> <li>A signal can be allocated and the positive and negative logic can be</li> </ul>
		Inter-	changed. Digital Operator (JUSP-OP05A-1-E) and personal computer (with Sig-
		faces	maWin+)
	RS-422A Communi- cations	1:N Commu- nications	Up to N = 15 stations possible for RS-422A port
Communi- cations	(CN3)	Axis Address Settings	03 to EF hex (maximum number of slaves: 62) The rotary switches (S1 and S2) are used to set the station address.
	USB	Interface	Personal computer (with SigmaWin+)
	Communi- cations (CN7)	Commu- nica- tions Standard	Conforms to USB2.0 standard (12 Mbps).
Displays/Ind	icators		CHARGE, PWR, CN, L1, and L2 indicators, and two, one-digit seven- segment displays

Continued on next page.

#### 2.1 Ratings and Specifications

#### 2.1.3 Specifications

Continued from previous page.

	Item	Specification
	Communications Pro- tocol	MECHATROLINK-III
MECHA- TROLINK-III Communi- cations	Station Address Settings	03 to EF hex (maximum number of slaves: 62) The rotary switches (S1 and S2) are used to set the station address.
	Extended Address Setting	Axis A: 00 hex, Axis B: 01 hex
	Transmission Speed	100 Mbps
	Transmission Cycle	250 μs, 500 μs, 750 μs, 1.0 ms to 4.0 ms (multiples of 0.5 ms)
	Number of Transmis- sion Bytes	32 or 48 bytes/station A DIP switch (S3) is used to select the transmission speed.
Reference Method	Performance	Position, speed, or torque control with MECHATROLINK-III communi- cations
	Reference Input	MECHATROLINK-III commands (sequence, motion, data setting, data access, monitoring, adjustment, etc.)
	Profile	MECHATROLINK-III standard servo profile
MECHATRO	LINK-III Communica-	Rotary switch (S1 and S2) positions: 16
tions Setting	Switches	Number of DIP switch (S3) pins: 4
Analog Monitor (CN5)		Number of points: 2 Output voltage range: ±10 VDC (effective linearity range: ±8 V) Resolution: 16 bits Accuracy: ±20 mV (Typ) Maximum output current: ±10 mA Settling time (±1%): 1.2 ms (Typ)
Dynamic Brake (DB)		Activated when a servo alarm or overtravel (OT) occurs, or when the power supply to the main circuit or servo is OFF.
Regenerative	e Processing	Built-in
Overtravel (OT) Prevention		Stopping with dynamic brake, deceleration to a stop, or coasting to a stop for the P-OT (Forward Drive Prohibit) or N-OT (Reverse Drive Prohibit) signal
Protective Functions		Overcurrent, overvoltage, low voltage, overload, regeneration error, etc.
Utility Function	ons	Gain adjustment, alarm history, jogging, origin search, etc.
Applicable O	ption Modules	None

\* The coefficient of speed fluctuation for load fluctuation is defined as follows:

Coefficient of speed fluctuation = <u>No-load motor speed - Total-load motor speed</u> × 100% Rated motor speed

2.2.1 SGD7W-1R6A and -2R8A

## 2.2 Block Diagrams

## 2.2.1 SGD7W-1R6A and -2R8A



2.2.2 SGD7W-5R5A and -7R6A

## 2.2.2 SGD7W-5R5A and -7R6A



2.3.1 Front Cover Dimensions and Connector Specifications

## 2.3 External Dimensions

## 2.3.1 Front Cover Dimensions and Connector Specifications

The front cover dimensions and panel connector section are the same for all models. Refer to the following figures and table.

#### Front Cover Dimensions



#### Connector Specifications

Connec- tor No.	Model	Number of Pins	Manufacturer
CN1	10236-59A3MB	36	3M Japan Limited
CN2A, CN2B	3E106-2230KV	6	3M Japan Limited
CN3	HDR-EC14LFDTN- SLD-PLUS	14	Honda Tsushin Kogyo Co., Ltd.
CN6A, CN6B	1981386-1	8	Tyco Electronics Japan G.K.
CN7	2172034-1	5	Tyco Electronics Japan G.K.

Note: The above connectors or their equivalents are used for the SERVOPACKs.

2.3.2 SERVOPACK External Dimensions

## 2.3.2 SERVOPACK External Dimensions

#### **Base-mounted SERVOPACKs**

Three-phase, 200 VAC: SGD7W-1R6A and -2R8A





· Three-phase, 200 VAC: SGD7W-5R5A and -7R6A



Approx. mass: 2.3 kg Unit: mm

#### **Rack-mounted SERVOPACKs**

Hardware Option Code: 001

• Three-phase, 200 VAC: SGD7W-1R6A and -2R8A



• Three-phase, 200 VAC: SGD7W-5R5A and -7R6A



## 2.4 Examples of Standard Connections between SERVOPACKs and Peripheral Devices



\*1. External Regenerative Resistors are not provided by Yaskawa.

\*2. The power supply for the holding brake is not provided by Yaskawa. Select a power supply based on the holding brake specifications.

If you use a 24-V brake, install a separate power supply for the 24-VDC power supply from other power supplies, such as the one for the I/O signals of the CN1 connector. If the power supply is shared, the I/O signals may malfunction.



#### Linear Servomotors

\* External Regenerative Resistors are not provided by Yaskawa.

# SERVOPACK Installation

This chapter provides information on installing SERVO-PACKs in the required locations.

3.1	Installation Precautions						
3.2	Mounting Types and Orientation3-3						
3.3	Mour	nting Hole Dimensions					
3.4	Mour	nting Interval					
	3.4.1 3.4.2	Installing One SERVOPACK in a Control Panel3-5 Installing More Than One SERVOPACK in a Control Panel					
3.5	Moni	toring the Installation Environment 3-6					
3.6	Derat	ting Specifications					
3.7	EMC	Installation Conditions3-8					

## 3.1 Installation Precautions

Refer to the following section for the ambient installation conditions. (2) 2.1.3 Specifications on page 2-4

#### Installation Near Sources of Heat

Implement measures to prevent temperature increases caused by radiant or convection heat from heat sources so that the ambient temperature of the SERVOPACK meets the ambient conditions.

#### Installation Near Sources of Vibration

Install a vibration absorber on the installation surface of the SERVOPACK so that the SERVO-PACK will not be subjected to vibration.

#### Other Precautions

Do not install the SERVOPACK in a location subject to high temperatures, high humidity, water drops, cutting oil, excessive dust, excessive dirt, excessive iron powder, corrosive gasses, or radioactivity.

## 3.2 Mounting Types and Orientation

The SERVOPACKs come in the following mounting types: base-mounted and rack-mounted types. Regardless of the mounting type, mount the SERVOPACK vertically, as shown in the following figures.

Also, mount the SERVOPACK so that the front panel is facing toward the operator.

Note: Prepare three or four mounting holes for the SERVOPACK and mount it securely in the mounting holes. (The number of mounting holes depends on the capacity of the SERVOPACK.)

Base-mounted SERVOPACK



Rack-mounted SERVOPACK



# 3.3 Mounting Hole Dimensions

Use mounting holes to securely mount the SERVOPACK to the mounting surface.

Note: To mount the SERVOPACK, you will need to prepare a screwdriver that is longer than the depth of the SER-VOPACK.



SERVOPACK Model		Dimensions (mm)							Screw	Number	
		А	В	С	D	Е	F	G	н	Size	of Screws
SGD7W-	1R6A, 2R8A	168	5	160±0.5	70	5	60±0.5	65	-	M4	3
	5R5A, 7R6A	168	5	160±0.5	100	5	90±0.5	95	-	M4	3

3.4.1 Installing One SERVOPACK in a Control Panel

## **Mounting Interval**

 $\Theta$ 

#### Installing One SERVOPACK in a Control Panel 3.4.1

Provide the following spaces around the SERVOPACK.



\* For this dimension, ignore items protruding from the main body of the SERVOPACK.

#### Installing More Than One SERVOPACK in a Control 3.4.2 Panel

Provide the following intervals between the SERVOPACKs and spaces around the SERVO-PACKs.

Install cooling fans above the SERVOPACKs so that hot spots do not occur around the SERVO-PACKs. Provide sufficient intervals and spaces as shown in the following figure to enable cooling by the fans and natural convection. Important



\* For this dimension, ignore items protruding from the main body of the SERVOPACK.

The space required on the right side of a SERVOPACK (when looking at the SERVOPACK from the front) depends on the SERVOPACK models. Refer to the following table.

	Space on	Cooling Fan Installation Conditions	
SERVOFACK Model	Right Side	10 mm above SERVOPACK's Top Surface	
SGD7W-1R6A, 2R8A, 5R5A, 7R6A	5 mm min.	Air speed: 0.5 m/s min.	

## 3.5 Monitoring the Installation Environment

You can use the SERVOPACK Installation Environment Monitor parameter to check the operating conditions of the SERVOPACK in the installation environment.

You can check the SERVOPACK installation environment monitor with either of the following methods.

- Using the SigmaWin+: Life Monitor Installation Environment Monitor SERVOPACK
- Panel Operator or Digital Operator: Un025 (Installation Environment Monitor [%])

Implement one or more of the following actions if the monitor value exceeds 100%.

- Lower the surrounding temperature.
- Decrease the load.

Information The value of the SERVOPACK Installation Environment Monitor parameter will increase by about 10% for each 10°C increase in the ambient temperature.



Always observe the surrounding air temperature given in the SERVOPACK environment conditions. Even if the monitor value is 100% or lower, you cannot use a SERVOPACK in a location that exceeds the specified surrounding air temperature.

# 3.6 Derating Specifications

If you use the SERVOPACK at a surrounding air temperature of 55°C to 60°C or at an altitude of 1,000 m to 2,000 m, you must apply the derating rates given in the following graphs.

• SGD7W-1R6A, -2R8A, -5R5A, and -7R6A



Surrounding air temperature

Altitude

Surrounding air temperature and altitude

## 3.7 EMC Installation Conditions

This section gives the installation conditions that were used for EMC certification testing.

The EMC installation conditions that are given here are the conditions that were used to pass testing criteria at Yaskawa. The EMC level may change under other conditions, such as the actual installation structure and wiring conditions. These Yaskawa products are designed to be built into equipment. Therefore, you must implement EMC measures and confirm compliance for the final equipment.

The applicable standards are EN 55011 group 1 class A, EN 61000-6-2, EN 61000-6-4, and EN 61800-3 (category C2, second environment).

#### Shield box Brake power supply Brake power supply SERVOPACK Clamp Clamp Brake UA, VA, and WA Clamp Power supply: Noise (=) L1, L2, and L3 Three-phase, 200 VAC filter 2 Servomotor 6 Clamp Encoder L1C and L2C CN2A Surge 3 absorber Clamp (<del>\_</del> (\_\_ ΡE PE UB. VB. Clamp Clamp Clamp MECHATROLINK-III Brake and WB CN6A Controller and CN6B 1 (± Servomotor 4 Clamp Encoder CN2B Clamp 5 I/O CN1 controller 1 Clamp (= ΡE

•	Three-Phase	200	VAC
•	THEE-FHASE,	200	VAC

Symbol	Cable Name	Specification
0	I/O Signal Cable	Shielded cable
2	Motor Main Circuit Cable for axis A	Shielded cable
3	Encoder Cable for axis A	Shielded cable
4	Motor Main Circuit Cable for axis B	Shielded cable
5	Encoder Cable for axis B	Shielded cable
6	Main Circuit Power Cable	Shielded cable
Ø	MECHATROLINK-III Communications Cable	Shielded cable

# Wiring and Connecting SERVOPACKs

This chapter provides information on wiring and connecting SERVOPACKs to power supplies and peripheral devices.

4.1	Wiring and Connecting SERVOPACKs 4-3	
	4.1.1 4.1.2 4.1.3	General Precautions4-3Countermeasures against Noise4-5Grounding4-8
4.2	Basic	Wiring Diagrams4-9
4.3	Wiring	the Power Supply to the SERVOPACK 4-10
	4.3.1 4.3.2 4.3.3 4.3.4 4.3.5 4.3.6	Terminal Symbols and Terminal Names4-10Wiring Procedure for Main Circuit Connector4-11Power ON Sequence4-12Power Supply Wiring Diagrams4-13Wiring Regenerative Resistors4-17Wiring Reactors for Harmonic Suppression4-18
4.4	Wiring	g Servomotors 4-19
	4.4.1 4.4.2 4.4.3 4.4.4	Terminal Symbols and Terminal Names4-19Pin Arrangement of Encoder Connectors(CN2A and CN2B)Wiring the SERVOPACK to the EncoderWiring the SERVOPACK to the Holding Brake4-20

4.5	I/O S	I/O Signal Connections4-31	
	4.5.1	I/O Signal Connector (CN1) Names and	
		Functions 4-31	
	4.5.2	I/O Signal Connector (CN1) Pin Arrangement 4-33	
	4.5.3	I/O Signal Wiring Examples4-34	
	4.5.4	I/O Circuits	
4.6	Conne	cting MECHATROLINK Communications Cables 4-38	
4.7	Conn	ecting the Other Connectors4-39	
	4.7.1 4.7.2	Serial Communications Connector (CN3)4-39 Computer Connector (CN7)4-39	

 4.7.2
 Computer Connector (CN7)
 4-39

 4.7.3
 Analog Monitor Connector (CN5)
 4-39

4.1.1 General Precautions

## 4.1 Wiring and Connecting SERVOPACKs

## 4.1.1 General Precautions

## \Lambda DANGER

• Do not change any wiring while power is being supplied. There is a risk of electric shock or injury.



#### 4.1.1 General Precautions

<ul> <li>Wai</li> <li>CH/</li> <li>pow</li> <li>bec</li> <li>The</li> </ul>	It for six minutes after turning OFF the power supply and then make sure that the ARGE indicator is not lit before starting wiring or inspection work. Do not touch the ver supply terminals while the CHARGE lamp is lit after turning OFF the power supply asuse high voltage may still remain in the SERVOPACK. re is a risk of electric shock.
<ul> <li>Obsides</li> <li>des</li> <li>Failu</li> <li>caus</li> <li>or in</li> </ul>	serve the precautions and instructions for wiring and trial operation precisely as cribed in this document. ures caused by incorrect wiring or incorrect voltage application in the brake circuit may se the SERVOPACK to fail, damage the equipment, or cause an accident resulting in death njury.
Che Cor pin The	eck the wiring to be sure it has been performed correctly. nnectors and pin layouts are sometimes different for different models. Always confirm the layouts in technical documents for your model before operation. re is a risk of failure or malfunction.
Cor spe Insu tact	nnect wires to power supply terminals and motor connection terminals securely with the cified methods and tightening torque. Ifficient tightening may cause wires and terminal blocks to generate heat due to faulty con- c, possibly resulting in fire.
Use Sigr	e shielded twisted-pair cables or screened unshielded multi-twisted-pair cables for I/O nal Cables and Encoder Cables.
<ul> <li>Obs</li> <li>Ti m</li> <li>If</li> <li>SI</li> <li>In</li> <li>W</li> <li>co</li> </ul>	Serve the following precautions when wiring the SERVOPACK's main circuit terminals. Jurn ON the power supply to the SERVOPACK only after all wiring, including the main circuit ter- linals, has been completed. a connector is used for the main circuit terminals, remove the main circuit connector from the ERVOPACK before you wire it. Issert only one wire per insertion hole in the main circuit terminals. /hen you insert a wire, make sure that the conductor wire (e.g., whiskers) does not come into ontact with adjacent wires.
Inst aga The	all molded-case circuit breakers and other safety measures to provide protection inst short circuits in external wiring. re is a risk of fire or failure.



#### 4.1.2 Countermeasures against Noise



 Use a molded-case circuit breaker (1QF) or fuse to protect the main circuit. The SERVOPACK connects directly to a commercial power supply; it is not isolated through a transformer or other device. Always use a molded-case circuit breaker (1QF) or fuse to protect the servo system from accidents involving different power system voltages or other accidents.

- Install an earth leakage breaker. The SERVOPACK does not have a built-in ground fault protective circuit. To configure a safer system, install a ground fault detector against overloads and short-circuiting, or install a ground fault detector combined with a molded-case circuit breaker.
  - Do not turn the power supply ON and OFF more than necessary.Do not use the SERVOPACK for applications that require the power supply to turn ON and
  - OFF frequently. Such applications will cause elements in the SERVOPACK to deteriorate. • After you have started actual operation, allow at least one hour between turning the power
    - supply ON and OFF (as a guideline).

To ensure safe, stable application of the servo system, observe the following precautions when wiring.

• Use the cables specified by Yaskawa. Design and arrange the system so that each cable is as short as possible.

Refer to the following manual for information on the specified cables.  $\square \Sigma$ -7-Series Peripheral Device Selection Manual (Manual No.: SIEP S800001 32)

• The signal cable conductors are as thin as 0.2 mm<sup>2</sup> or 0.3 mm<sup>2</sup>. Do not subject them to excessive bending stress or tension.

#### 4.1.2 Countermeasures against Noise

The SERVOPACK is designed as an industrial device. It therefore provides no measures to prevent radio interference. The SERVOPACK uses high-speed switching elements in the main circuit. Therefore peripheral devices may be affected by switching noise.

Important If the equipment is to be used near private houses or if radio interference is a problem, take countermeasures against noise.

The SERVOPACK uses microprocessors. Therefore, it may be affected by switching noise from peripheral devices.

To prevent the noise from the SERVOPACK or the peripheral devices from causing malfunctions of any devices, take the following countermeasures against noise as required.

- Install the input reference device and Noise Filter as close to the SERVOPACK as possible.
- Always install a Surge Absorber for relays, solenoids, and Magnetic Contactor coils.
- Do not place the following cables in the same duct or bundle them together. Also, separate the cables from each other by at least 30 cm.

•Main Circuit Cables and I/O Signal Cables

- •Main Circuit Cables and Encoder Cables
- Do not share the power supply with an electric welder or electrical discharge machine. If the SERVOPACK is placed near a high-frequency generator, install Noise Filters on the input side on the Main Circuit Power Supply Cable and Control Power Supply Cable even if the same power supply is not shared with the high-frequency generator. Refer to the following section for information on connecting Noise Filters.
   Noise Filters on page 4-6
- Implement suitable grounding measures. Refer to the following section for information on grounding measures.

4.1.3 Grounding on page 4-8

4.1.2 Countermeasures against Noise

#### **Noise Filters**

You must attach Noise Filters in appropriate places to protect the SERVOPACK from the adverse effects of noise. The following is an example of wiring for countermeasures against noise.



- \*1. For the ground wire, use a wire with a thickness of at least 2.0 mm<sup>2</sup> (preferably, flat braided copper wire).
- \*2. Whenever possible, use twisted-pair wires to wire all connections marked with  $\underline{\frown}$ .
- \*3. Refer to the following section for precautions when using Noise Filters. *Noise Filter Wiring and Connection Precautions* on page 4-7
4.1.2 Countermeasures against Noise

### **Noise Filter Wiring and Connection Precautions**

Always observe the following precautions when wiring or connecting Noise Filters.

• Separate input lines from output lines. Do not place input lines and output lines in the same duct or bundle them together.



• Separate the Noise Filter ground wire from the output lines. Do not place the Noise Filter ground wire, output lines, and other signal lines in the same duct or bundle them together.



• Connect the Noise Filter ground wire directly to the grounding plate. Do not connect the Noise Filter ground wire to other ground wires.



#### 4.1.3 Grounding

• If a Noise Filter is located inside a control panel, first connect the Noise Filter ground wire and the ground wires from other devices inside the control panel to the grounding plate for the control panel, then ground the plate.



## 4.1.3 Grounding

Implement grounding measures as described in this section. Implementing suitable grounding measures will also help prevent malfunctions, which can be caused by noise.

Observe the following precautions when wiring the ground cable.

- Ground the SERVOPACK to a resistance of 100  $\Omega$  or less.
- Be sure to ground at one point only.
- Ground the Servomotor directly if the Servomotor is insulated from the machine.

## Motor Frame Ground or Motor Ground

If you ground the Servomotor through the machine, switching noise current can flow from the main circuit of the SERVOPACK through the stray capacitance of the Servomotor. To prevent this, always connect the motor frame terminal (FG) or ground terminal (FG) of the Servomotor to the ground terminal ) on the SERVOPACK. Also be sure to ground the ground terminal ).

Ground both the Moving Coil and Magnetic Way of a Linear Servomotor.

### Noise on I/O Signal Cables

If noise enters the I/O Signal Cable, connect the shield of the I/O Signal Cable to the connector shell to ground it. If the Servomotor Main Circuit Cable is placed in a metal conduit, ground the conduit and its junction box. For all grounding, ground at one point only.

# 4.2 Basic Wiring Diagrams

This section provide the basic wiring diagrams. Refer to the reference sections given in the diagrams for details.



FG Connect shield to connector shell. Frame ground

- \*1.  $\checkmark$  represents twisted-pair wires.
- \*2. Connect these when using an absolute encoder. If the Encoder Cable with a Battery Case is connected, do not connect a backup battery.
- \*3. The 24-VDC power supply is not provided by Yaskawa. Use a 24-VDC power supply with double insulation or reinforced insulation.

Note: 1. You can use parameter settings to change some of the I/O signal allocations. Refer to the following section for details.

6.1 I/O Signal Allocations on page 6-3

- If you use a 24-V brake, install a separate power supply for the 24-VDC power supply from other power supplies, such as the one for the I/O signals of the CN1 connector. If the power supply is shared, the I/O signals may malfunction.
- 3. Default settings are given in parentheses.

4.3.1 Terminal Symbols and Terminal Names

# 4.3 Wiring the Power Supply to the SERVOPACK

## 4.3.1 Terminal Symbols and Terminal Names

Use the main circuit connector on the SERVOPACK to wire the main circuit power supply and control circuit power supply to the SERVOPACK.

# 

• Wire all connections correctly according to the following table and specified reference information. There is a risk of SERVOPACK failure or fire if incorrect wiring is performed.

The SERVOPACKs have the following three types of main circuit power supply input specifications.

#### • Three-Phase, 200-VAC Power Supply Input

Terminal Symbols	Terminal Name	Specifications and Reference
L1, L2, L3	Main circuit power supply input terminals for AC power supply input	Three-phase, 200 VAC to 240 VAC, -15% to +10%, 50 Hz/60 Hz
L1C, L2C	Control power supply termi- nals	Single-phase, 200 VAC to 240 VAC, -15% to +10%, 50 Hz/60 Hz
	Regenerative Resistor termi- nals	4.3.5 Wiring Regenerative Resistors on page 4-17
B1/⊕, B2, B3		If the internal regenerative resistor is insufficient, remove the lead or short bar between B2 and B3 and connect an External Regenerative Resistor between B1/⊕ and B2. The External Regenerative Resistor is not included. Purchase it separately.
⊖1, ⊖2	DC Reactor terminals for	<ul> <li>4.3.6 Wiring Reactors for Harmonic Suppression on page 4- 18</li> </ul>
	suppression	These terminals are used to connect a DC Reactor for power supply harmonic suppression or power factor improvement.
Θ	-	None. (Do not connect anything to this terminal.)

#### Single-Phase, 200-VAC Power Supply Input

Terminal Symbols	Terminal Name	Specifications and Reference
L1, L2	Main circuit power supply input terminals for AC power supply input	Single-phase, 200 VDC to 240 VDC, -15% to +10%, 50 Hz/ 60 Hz
L1C, L2C	Control power supply termi- nals	Single-phase, 200 VDC to 240 VDC, -15% to +10%, 50 Hz/ 60 Hz
B1/⊕, B2, B3	Regenerative Resistor termi- nals	4.3.5 Wiring Regenerative Resistors on page 4-17
		If the internal regenerative resistor is insufficient, remove the lead or short bar between B2 and B3 and connect an External Regenerative Resistor between B1/⊕ and B2. The External Regenerative Resistor is not included. Obtain it separately.
⊖1, ⊝2	DC Reactor terminals for	<ul> <li>4.3.6 Wiring Reactors for Harmonic Suppression on page 4-</li> <li>18</li> </ul>
	suppression	These terminals are used to connect a DC Reactor for power supply harmonic suppression or power factor improvement.
L3, ⊖	_	None. (Do not connect anything to these terminals.)

You can use a single-phase, 200-VAC power supply input with the following models.

• SGD7W-1R6A, -2R8A, -5R5A

#### 4.3.2 Wiring Procedure for Main Circuit Connector

If you use a single-phase, 200-VAC power supply input for the SERVOPACK's main circuit power supply, set parameter Pn00B to n. 11 (Use a three-phase power supply input as a single-phase power supply input). Refer to the following section for details.

#### • DC Power Supply Input

Terminal Symbols	Terminal Name	Specifications and Reference
L1C, L2C	Control power supply termi-	L1C: 270 VDC to 324 VDC, -15% to +10%, L2C: 0 VDC Or
	11015	L2C: 270 VDC to 324 VDC, -15% to +10%, L1C: 0 VDC
B1/⊕	Main circuit power supply	270 VDC to 324 VDC, -15% to +10%
⊖2	power supply input	0 VDC
L1, L2, L3,		
B2, B3, ⊖1,	-	None. (Do not connect anything to these terminals.)
$\Theta$		

If you use a DC power supply input to the SERVOPACK, make sure to set parameter Pn00E to n. DDD1 (DC power supply input supported) before inputting the power supply. Refer to the following section for details.

5.3.1 AC Power Supply Input/DC Power Supply Input Setting on page 5-13

### 4.3.2 Wiring Procedure for Main Circuit Connector

#### · Required Items

Required Item	Remarks
Spring Opener or Flat-	<ul> <li>Spring Opener SERVOPACK accessory (You can also use model 1981045-1 from Tyco Electronics Japan G.K.)</li> </ul>
blade Screwdriver	<ul> <li>Flat-blade screwdriver</li> <li>Commercially available screwdriver with tip width of 3.0 mm to 3.5 mm</li> </ul>

1. Remove the main circuit connector and motor connector from the SERVOPACK.



2. Remove the sheath from the wire to connect.



#### 4.3.3 Power ON Sequence

**3.** Open the wire insertion hole on the terminal connector with the tool. There are the following two ways to open the insertion hole. Use either method.

①Using a Spring Opener	<sup>2</sup> Using a Flat-blade Screwdriver
Open the insertion hole with the Spring Opener as shown in the figure.	Firmly insert a flat-blade screwdriver into the screwdriver insertion hole to open the wire insertion hole.
Spring Opener Wire	

- 4. Insert the conductor into the wire insertion hole. Then, remove the Spring Opener or flatblade screwdriver.
- 5. Make all other connections in the same way.
- 6. When you have completed wiring, attach the connectors to the SERVOPACK.

### 4.3.3 Power ON Sequence

Consider the following points when you design the power ON sequence.

• The ALM (Servo Alarm) signal is output for up to five seconds when the control power supply is turned ON. Take this into consideration when you design the power ON sequence, and turn ON the main circuit power supply to the SERVOPACK when the ALM signal is OFF (alarm cleared).



- Design the power ON sequence so that main circuit power supply is turned OFF when an ALM (Servo Alarm) signal is output.
- Make sure that the power supply specifications of all parts are suitable for the input power supply.
- Allow at least 1 s after the power supply is turned OFF before you turn it ON again.



Turn ON the control power supply and the main circuit power supply at the same time or turn ON the control power supply before the main circuit power supply. Turn OFF the main circuit power supply first, and then turn OFF the control power supply.



• Even after you turn OFF the power supply, a high residual voltage may still remain in the SERVOPACK. To prevent electric shock, do not touch the power supply terminals after you turn OFF the power. When the voltage is discharged, the CHARGE indicator will turn OFF. Make sure the CHARGE indicator is OFF before you start wiring or inspection work.

## 4.3.4 Power Supply Wiring Diagrams

## Using Only One SERVOPACK

#### Wiring Example for Three-Phase, 200-VAC Power Supply Input

The following diagram shows the wiring to stop both Servomotors when there is an alarm for one axis.



#### • Wiring Example for Single-Phase, 200-VAC Power Supply Input

The following diagram shows the wiring to stop both Servomotors when there is an alarm for one axis.



#### • Wiring Example for DC Power Supply Input

The following diagram shows the wiring to stop both Servomotors when there is an alarm for one axis.



### Using More Than One SERVOPACK

Connect the ALM (Servo Alarm) output for these SERVOPACKs in series to operate the alarm detection relay (1RY).

When a SERVOPACK alarm is activated, the ALM output signal transistor turns OFF.

The following diagram shows the wiring to stop all of the Servomotors when there is an alarm for any one SERVOPACK.

More than one SERVOPACK can share a single Noise Filter. However, always select a Noise Filter that has a large enough capacity to handle the total power supply capacity of all the SERVOPACKs. Be sure to consider the load conditions.



4.3.5 Wiring Regenerative Resistors

## 4.3.5 Wiring Regenerative Resistors

This section describes how to connect External Regenerative Resistors.

Refer to the following manual to select External Regenerative Resistors.  $\square \Sigma$ -7-Series Peripheral Device Selection Manual (Manual No.: SIEP S800001 32)



## **Connecting Regenerative Resistors**

1. Remove the lead from between the B2 and B3 terminals on the SERVOPACK.



2. Connect the External Regenerative Resistor between the B1/ $\oplus$  and B2 terminals.



 Set Pn600 (Regenerative Resistor Capacity) and Pn603 (Regenerative Resistance). Refer to the following section for details on the settings.
 5.18 Setting the Regenerative Resistor Capacity on page 5-52

4.3.6 Wiring Reactors for Harmonic Suppression

## 4.3.6 Wiring Reactors for Harmonic Suppression

You can connect a reactor for harmonic suppression to the SERVOPACK when power supply harmonic suppression is required. Refer to the following manual for details on harmonic reactors.

Ω Σ-7-Series Peripheral Device Selection Manual (Manual No.: SIEP S800001 32)

Refer to the following figures to connect reactors.



Note: 1. Connection terminals  $\ominus$  1 and  $\ominus$  2 for a DC Reactor are connected when the SERVOPACK is shipped. Remove the lead wire and connect a DC Reactor.

2. Reactors are optional products. (Purchase them separately.)

3. You cannot connect a DC Reactor to a SERVOPACK with a single-phase, 100-VAC power supply input.

4.4.1 Terminal Symbols and Terminal Names

# 4.4 Wiring Servomotors

## 4.4.1 Terminal Symbols and Terminal Names

The SERVOPACK terminals or connectors that are required to connect the SERVOPACK to a Servomotor are given below.

Terminal/Connector Symbols	Terminal/Connector Name	Remarks
UA, VA, and WA	Servomotor terminals for axis A	Refer to the following section for the wiring proce- dure.
UB, VB, and WB	Servomotor terminals for axis B	4.3.2 Wiring Procedure for Main Circuit Connector on page 4-11
	Ground terminal	-
CN2A	Encoder connector for axis A	_
CN2B	Encoder connector for axis B	

## 4.4.2 Pin Arrangement of Encoder Connectors (CN2A and CN2B)

#### • When Using a Rotary Servomotor

Pin No.	Signal	Function
1	PG5V	Encoder power supply +5 V
2	PG0V	Encoder power supply 0 V
3	BAT (+)*	Battery for absolute encoder (+)
4	BAT (-)*	Battery for absolute encoder (-)
5	PS	Serial data (+)
6	/PS	Serial data (-)
Shell	Shield	-

\* You do not need to wire these pins for an incremental encoder.

#### · When Using a Direct Drive Servomotor

Pin No.	Signal	Function
1	PG5V	Encoder power supply +5 V
2	PG0V	Encoder power supply 0 V
3	_	– (Do not use.)
4	-	– (Do not use.)
5	PS	Serial data (+)
6	/PS	Serial data (-)
Shell	Shield	-

#### • When Using a Linear Servomotor

Pin No.	Signal	Function
1	PG5V	Linear encoder power supply +5 V
2	PG0V	Linear encoder power supply 0 V
3	-	– (Do not use.)
4	-	– (Do not use.)
5	PS	Serial data (+)
6	/PS	Serial data (-)
Shell	Shield	-

## 4.4.3 Wiring the SERVOPACK to the Encoder

### When Using an Absolute Encoder

If you use an absolute encoder, use an Encoder Cable with a JUSP-BA01-E Battery Case or install a battery on the host controller.

Refer to the following section for the battery replacement procedure. *10.1.3 Replacing the Battery* on page 10-3

• Wiring Example When Using an Encoder Cable with a Battery Case



\*1. The absolute encoder pin numbers for wiring the connector depend on the Servomotor that you use.

\*2. represents a shielded twisted-pair cable.



#### • Wiring Example When Installing a Battery on the Host Controller

- \*1. The absolute encoder pin numbers for wiring the connector depend on the Servomotor that you use.
- \*2. represents a shielded twisted-pair cable.

 When Installing a Battery on the Encoder Cable Use the Encoder Cable with a Battery Case that is specified by Yaskawa. Refer to the following manual for details.
 Σ-7-Series Peripheral Device Selection Manual (Manual No.: SIEP S800001 32)
 When Installing a Battery on the Host Controller Insert a diode near the battery to prevent reverse current flow. Wiring and Connecting SERVOPACKs

#### SERVOPACK Incremental encoder CN2A \*1 5 PS /PS 6 UA (ENC Μ VAČ PG5V 1 WA **PG0V** 2 ŧ Connector shell (Shell) Shield $( \square )$ Incremental encoder CN2B \*1 PS 5 UB VB /PS 6 Μ (ENC WB PG5V 1 ŧ PG0V 2 Connector shell (Shell) Shield Ŧ

## When Using an Incremental Encoder

- \*1. The incremental encoder pin numbers for wiring the connector depend on the Servomotor that you use.
- \*2. represents a shielded twisted-pair cable.

## When Using an Absolute Linear Encoder

The wiring depends on the manufacturer of the linear encoder.

#### Connections to Linear Encoder from Mitutoyo Corporation



\* represents a shielded twisted-pair cable.

### Connections to Absolute Linear Encoder from Magnescale Co., Ltd.

#### SR77 and SR87



## When Using an Incremental Linear Encoder

The wiring depends on the manufacturer of the linear encoder.

### Connections to Linear Encoder from Heidenhain Corporation



\* represents a shielded twisted-pair cable.



### Connections to Linear Encoder from Renishaw PLC

\* represents a shielded twisted-pair cable.

### ◆ Connections to Linear Encoder from Magnescale Co., Ltd.

If you use a linear encoder from Magnescale Co., Ltd., the wiring will depend on the model of the linear encoder.

#### SR75 and SR85



\* represents a shielded twisted-pair cable.

#### ■ SL700, SL710, SL720, SL730, and SQ10

• PL101-RY, MQ10-FLA, or MQ10-GLA Interpolator The following table gives the Linear Encoder and Interpolator combinations.

Linear Encoder Model	Interpolator Model
SL700, SL710, SL720, and SL730	PL101-RY <sup>*1</sup>
SO10	MQ10-FLA*2
0010	MQ10-GLA*2

- \*1. This is the model of the Head with Interpolator.
- \*2. This is the model of the Interpolator.



\* represents a shielded twisted-pair cable.

#### 4.4.4 Wiring the SERVOPACK to the Holding Brake



## 4.4.4 Wiring the SERVOPACK to the Holding Brake



- If you use a Rotary Servomotor, select a Surge Absorber according to the brake current and brake power supply. Refer to the following manual for details.
   No. 7. 2 String Parish and Parish Selection Manual (Manual National Context)
- Ω Σ-7-Series Peripheral Device Selection Manual (Manual No.: SIEP S800001 32)
   After the Surge Absorber is connected, check the time required to brake in your application.
- The Surge Absorber may affect the time required to brake. Configure the relay circuit to activate the holding brake for an emergency stop.



• You can change the output signal allocation of the /BK signal. Refer to the following section for details.

Allocating the /BK (Brake) Signal on page 5-34

• If you use a 24-V brake, install a separate power supply for the 24-VDC power supply from other power supplies, such as the one for the I/O signals of the CN1 connector. If the power supply is shared, the I/O signals may malfunction.

#### 4.4.4 Wiring the SERVOPACK to the Holding Brake



\* Install the surge absorber near the brake terminals on the Servomotor.

# 4.5 I/O Signal Connections

## 4.5.1 I/O Signal Connector (CN1) Names and Functions

The following table gives the pin numbers, names, and functions the I/O signal pins for the default settings.

## **Input Signals**

Default settings are given in parentheses.

Signal	Pin No.	Name	Function	Reference
/SI01* (P-OT_A) /SI07*	3	General-purpose Sequence Inputs 1 and 7 (Forward Drive Prohibit	You can allocate the input signals to use with parameters. (Stops Servomotor drive (to prevent	
(P-OT_B)	9	Input)	overtravel) when the moving part of	page 5-29
/SI02* (N-OT_A)	4	General-purpose Sequence Inputs 2 and 8	movement.)	
/SI08* (N-OT_B)	10	(Reverse Drive Prohibit Input)	For A axis: /SI01 and /SI02     For B axis: /SI07 and /SI08	
/SI03* (/DEC_A)	5	General-purpose Sequence Inputs 3 and 9	You can allocate the input signals to use with parameters. (Connects the deceleration limit	_
/SI09* (/DEC_B)	11	(Origin Return Decelera- tion Switch Input)	switch for origin return.) • For A axis: /SI03 • For B axis: /SI09	
/SI04* (/EXT_A1)	6	General-purpose		
/SI10* (/EXT_B1)	12	(External Latch Input 1)	You can allocate the input signals to use with parameters.	
/SI05* (/EXT_A2)	7	General-purpose	(Connect the external signals that latch the current feedback pulse	
/SI11* (/EXT_B2)	13	(External Latch Input 2)	<ul> <li>counter.)</li> <li>For A axis: /SI04, /SI05, and /</li> <li>SI06</li> </ul>	-
/SI06* (/EXT_A3)	8	General-purpose Sequence Inputs 6 and 12	• For B axis: /SI10, /SI11, and / SI12	
/SI12* (/EXT_B3)	14	(External Latch Input 3)		
+24VIN	1	Sequence Input Signal Power Supply Input	Inputs the sequence input signal power supply. Allowable voltage range: 24 VDC ±20% The 24-VDC power supply is not provided by Yaskawa.	-
BAT_A+	17	Battery for Absolute	Connecting nin for the absolute	
BAT_B+	35	Encoder (+)	<ul> <li>both the absolute</li> <li>encoder backup battery.</li> <li>Do not connect these pins if you</li> <li>use the Encoder Cable with a Battery Case.</li> <li>For A axis: BAT_A+ and BAT_A-</li> </ul>	_
BAT_A-	18	Battery for Absolute		
BAT_B-	36	Encoder (-)		
TH_A	33	Linear Servomotor Over-	Inputs the overheat protection sig- nal from a Linear Servomotor.	_
TH_B	34	heat Protection Signal	<ul><li>For A axis: TH_A</li><li>For B axis: TH_B</li></ul>	

\* You can change the allocations. Refer to the following section for details.

<sup>6.1.1</sup> Input Signal Allocations on page 6-3

#### 4.5.1 I/O Signal Connector (CN1) Names and Functions

Note: If forward drive prohibition or reverse drive prohibition is used, the SERVOPACK is stopped by software con-trols. If the application does not satisfy the safety requirements, add external safety circuits as required.

## **Output Signals**

Default settings are given in parentheses.

Signal	Pin No.	Name	Function	Reference
ALM_A+	19	Convo Alorm Quitout	Turns OFF (opens) when an error is detected.	page 6-9
ALM_A-	20			
ALM_B+	21		• For B axis: ALM B+ and ALM B-	
ALM_B-	22			
/SO1+* (/BK_A+)	23	General-purpose	You can allocate the output signal to use with	page 5-33
/SO1-* (/BK_A-)	24	(Brake Output)	a parameter. (Controls the brake. The brake is released	
/SO2+* (/BK_B+)	25	General-purpose	<ul> <li>when the signal turns ON (closes).)</li> <li>For A axis: /BK_A+ and /BK_A-</li> <li>For B axis: /BK_B+ and /BK_B-</li> </ul>	
/SO2-* (/BK_B-)	26	(Brake Output)		
/SO3+*	27	General-purpose	Used for general-purpose outputs. Set the parameters to allocate functions.	_
/SO3-*	28	Sequence Output 3		
/SO4+*	29	General-purpose		
/SO4-*	30	Sequence Output 4		
/SO5+*	31	General-purpose		
/SO5-*	32	Sequence Output 5		
SG	16 15	Signal ground	This is the 0-V signal for the control circuits.	-
FG	Shell	Frame ground	Connected to the frame ground if the shield of the I/O Signal Cable is connected to the connector shell.	-

\* You can change the allocations. Refer to the following section for details. 2 6.1.2 Output Signal Allocations on page 6-6

4.5.2 I/O Signal Connector (CN1) Pin Arrangement

## 4.5.2 I/O Signal Connector (CN1) Pin Arrangement

The following figure gives the pin arrangement of the of the I/O signal connector (CN1) for the default settings.

						Sequence						Sanio
Pin 1 Pin 2 Pin 17 Pin 20 Pin 17 Pin 35 Pin 18 Pin 36 The above view is from the direc- tion of the follow- ing arrow without the connector shell attached.	2	_	-	1	+24VIN	Input Sig- nal Power Supply Input	20	ALM_A-	Servo Alarm Output for	19	ALM_A+	Alarm Output for Axis A
	4	/SI02 (N-OT A)	General- purpose Sequence	3	/SI01 (P-OT_A)	General- purpose Sequence Input 1	22	ALM_B-	Servo Alarm Output for	21	ALM_B+	Servo Alarm Output for Axis B
	6	/SI04	Input 2 General- purpose Sequence	5	/SI03 (/DEC_A)	General- purpose Sequence Input 3	24	/SO1- (/BK A-)	Axis B General- purpose Sequence	23	/SO1+ (/BK_A+)	General- purpose Sequence Output 1
	8	/SI06	Input 4 General- purpose	7	/SI05 (/EXT_A2)	General- purpose Sequence Input 5	26	/SO2-	Output 1 General- purpose	25	/SO2+ (/BK_B+)	General- purpose Sequence Output 2
	10	/SI08	Input 6 General- purpose	9	/SI07 (P-OT_B)	General- purpose Sequence Input 7	28	/SO3-	Output 2 General- purpose Sequence	27	/SO3+	General- purpose Sequence Output 3
	12	/SI10 (/EXT	Input 8 General- purpose	11	/SI09 (/DEC_B)	General- purpose Sequence Input 9	30	/SO4-	Output 3 General- purpose	29	/SO4+	General- purpose Sequence Output 4
	1/	_B1) /SI12	Input 10 General- purpose	13	/SI11 (/EXT _B2)	General- purpose Sequence	30	/\$05-	Output 4 General- purpose	31	/SO5+	General- purpose Sequence
	14	_B3)	Sequence Input 12	/		52	/303-	Sequence Output 5			Linear Servomo-	
	16	SG	Signal Ground	15	SG	Signal Ground	34	TH_B	Servomo- tor Over- heat Protec- tion Input	33	TH_A	tor Over- heat Protec- tion Input for Axis A
	18		Battery for Abso- lute Encoder (-) for Axis	17	BAT_A+	Here and the second sec	36		for Axis B Battery for Abso- lute Encoder (-) for Axis		5 BAT_B+	Battery for Abso- lute Encoder (+) for Axis B
		18 BAT_A-						BAT_B-		35		
			A						В			

4.5.3 I/O Signal Wiring Examples

#### I/O Signal Wiring Examples 4.5.3

## Using a Rotary Servomotor



Frame ground

- \*1 represents twisted-pair wires.
- Connect these when using an absolute encoder. If the Encoder Cable with a Battery Case is connected, do not \*2. connect a backup battery.
- \*3. The 24-VDC power supply is not provided by Yaskawa. Use a 24-VDC power supply with double insulation or reinforced insulation.
- Note: 1. You can use parameter settings to change some of the I/O signal allocations. Refer to the following section for details.

#### 6.1 I/O Signal Allocations on page 6-3

2. If you use a 24-V brake, install a separate power supply for the 24-VDC power supply from other power supplies, such as the one for the I/O signals of the CN1 connector. If the power supply is shared, the I/O signals may malfunction.

#### 4.5.3 I/O Signal Wiring Examples

## Using a Linear Servomotor



- \* The 24-VDC power supply is not provided by Yaskawa. Use a 24-VDC power supply with double insulation or reinforced insulation.
- Note: 1. You can use parameter settings to change some of the I/O signal allocations. Refer to the following section for details.
  - 6.1 I/O Signal Allocations on page 6-3
  - 2. If you use a 24-V brake, install a separate power supply for the 24-VDC power supply from other power supplies, such as the one for the I/O signals of the CN1 connector. If the power supply is shared, the I/O signals may malfunction.

4.5.4 I/O Circuits

## 4.5.4 I/O Circuits

## **Sequence Input Circuits**

### Photocoupler Input Circuits

This section describes CN1 connector terminals 1 and 3 to 14.



Note: The 24-VDC external power supply capacity must be 100 mA minimum.

The SERVOPACK input circuits use bidirectional photocouplers. Select either a sink circuit or source circuit according to the specifications required by the machine.

Note: The connection examples in 4.5.3 I/O Signal Wiring Examples on page 4-34 are for sink circuit connections.



4.5.4 I/O Circuits

## **Sequence Output Circuits**

Incorrect wiring or incorrect voltage application to the output circuits may cause short-circuit failures.

0 If a short-circuit failure occurs as a result of any of these causes, the holding brake will not work. Important This could damage the machine or cause an accident that may result in death or injury.

### Photocoupler Output Circuits

Photocoupler output circuits are used for the ALM (Servo Alarm), /S-RDY (Servo Ready), and other sequence output signals. Connect a photocoupler output circuit to a relay or line-receiver circuit.



Note: The maximum allowable voltage and current range for photocoupler output circuits are as follows:

- Maximum allowable voltage: 30 VDC
- Current range: 5 mA to 50 mA DC

# 4.6 Connecting MECHATROLINK Communications Cables

Connect the MECHATROLINK-III Communications Cables to the CN6A and CN6B connectors.



Note: The length of the cable between stations (L1, L2, ... Ln) must be 50 m or less.

Use the following procedure to remove the MECHATROLINK-III Communications Cable connectors from the SERVOPACK.



Note: The MECHATROLINK-III Communications Cable connector may be damaged if it is removed without being unlocked.

4.7.1 Serial Communications Connector (CN3)

## 4.7 Connecting the Other Connectors

## 4.7.1 Serial Communications Connector (CN3)

To use a Digital Operator or to connect a computer with an RS-422 cable, connect CN3 on the SERVOPACK.

Refer to the following manual for the operating procedures for the Digital Operator.  $\square \Sigma$ -7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)

## 4.7.2 Computer Connector (CN7)

To use the SigmaWin+ Engineering Tool, connect the computer on which the SigmaWin+ is installed to CN7 on the SERVOPACK.

Refer to the following manual for the operating procedures for the SigmaWin+. AC Servo Drive Engineering Tool SigmaWin+ Operation Manual (Manual No.: SIET S800001 34)

### 4.7.3 Analog Monitor Connector (CN5)

To use an analog monitor, connect CN5 on the SERVOPACK.

• Wiring Example



\* The measuring instrument is not provided by Yaskawa.

Refer to the following section for information on the monitoring methods for an analog monitor. (3) 9.3 Monitoring Machine Operation Status and Signal Waveforms on page 9-6

# Basic Functions That Require Setting before Operation

5

This chapter describes the basic functions that must be set before you start servo system operation. It also describes the setting methods.

5.1	Manip	oulating Parameters (Pn $\Box\Box\Box$ )5-3				
	5.1.1 5.1.2 5.1.3 5.1.4 5.1.5	Parameter Classification5-3Notation for Parameters5-4Parameter Setting Methods5-5Write Prohibition Setting for Parameters5-6Initializing Parameter Settings5-9				
5.2	MECH	ATROLINK-III Communications Settings 5-11				
	5.2.1 5.2.2 5.2.3	Communications Settings5-11Setting the Station Address5-11Extended Address Setting5-12				
5.3	Power Supply Type Settings for the Main Circuit and Control Circuit 5-13					
	5.3.1 5.3.2	AC Power Supply Input/DC Power Supply Input Setting				
5.4	Auton	natic Detection of Connected Motor5-15				
5.5	Motor	Direction Setting 5-16				
5.6	Settin	g the Linear Encoder Pitch5-17				
5.7	Writin	g Linear Servomotor Parameters 5-18				
5.8	Selectin	g the Phase Sequence for a Linear Servomotor5-23				

5.9	Polari	ity Sensor Setting5-25
5.10	Polari	tv Detection
	5.10.1 5.10.2	Restrictions
	5.10.3	Using a Tool Function to Perform Polarity Detection
5.11	Overt	ravel and Related Settings5-29
	5.11.1 5.11.2 5.11.3 5.11.4	Overtravel Signals
5.12	Holdi	ng Brake5-33
	5.12.1 5.12.2 5.12.3	Brake Operating Sequence
	5.12.4	Output Timing of /BK (Brake) Signal When the Servomotor Is Operating
5.13	Motor	Stopping Methods for Servo OFF and Alarms5-37
	5.13.1 5.13.2	Stopping Method for Servo OFF
5.14	Motor	r Overload Detection Level5-40
	5.14.1	Detection Timing for Overload Warnings (A 910) 5-40
	5.14.2	Detection Timing for Overload Alarms (A.720)5-41
5.15	Electr	ronic Gear Settings5-42
	5.15.1 5.15.2	Electronic Gear Ratio Settings
5.16	Reset	ting the Absolute Encoder5-46
	5.16.1 5.16.2 5.16.3 5.16.4	Precautions on Resetting
5.17	Settin	g the Origin of the Absolute Encoder . 5-49
	5.17.1 5.17.2	Absolute Encoder Origin Offset
5.18	Setting	g the Regenerative Resistor Capacity 5-52

5.1.1 Parameter Classification

# 5.1 Manipulating Parameters (PnDDD)

This section describes the classifications, notation, and setting methods for the parameters given in this manual.

## 5.1.1 Parameter Classification

There are the following two types of SERVOPACK parameters.

Classification	Meaning			
Setup Parameters	Parameters for the basic settings that are required for operation.			
Tuning Parameters	Parameters that are used to adjust servo performance.			

Information The tuning parameters are not displayed by default when you use the Digital Operator. To display and set the tuning parameters, set Pn00B to n.□□□1 (Display all parameters).

F	Parameter	Meaning	When Enabled	Classification	
Pn00B	n.□□□0 (default setting)	Display only setup parameters.	After restart	Setup	
	n.0001	Display all parameters.			

The setting method for each type of parameter is described below.

## **Setup Parameters**

You can use the Digital Operator or SigmaWin+ to set the setup parameters individually.

Information We recommend that you use the Setup Wizard of the SigmaWin+ to easily set the required setup parameters by setting the operating methods, machine specifications, and I/O signals according to on-screen Wizard instructions.


5.1.2 Notation for Parameters

### **Tuning Parameters**

Normally the user does not need to set the tuning parameters individually.

Use the various SigmaWin+ tuning functions to set the related tuning parameters to increase the response even further for the conditions of your machine. Refer to the following sections for details.

3.6 Autotuning without Host Reference on page 8-24

3.7 Autotuning with a Host Reference on page 8-35

🕼 8.8 Custom Tuning on page 8-42

You can also set the tuning parameters individually to make adjustments. Refer to the following section for details.

3.13 Manual Tuning on page 8-79

## 5.1.2 Notation for Parameters

There are two types of notation used for parameters that depend on whether the parameter requires a numeric setting (parameter for numeric setting) or requires the selection of a function (parameter for selecting a function).

### · Parameters for Numeric Settings



## 5.1.3 Parameter Setting Methods

You can use the SigmaWin+ or a Digital Operator to set parameters. Use the following procedure to set the parameters.

## Setting Parameters with the SigmaWin+

- 1. Click the 🔎 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- 2. Select Edit Parameters in the Menu Dialog Box. The Parameter Editing Dialog Box will be displayed.
- **3.** Click the cell of the parameter to edit.

If the parameter to edit is not displayed in the Parameter Editing Dialog Box, click the 🔺 or 💌 Button to display the parameter to edit.

<b>A</b>			YASKAWA SigmaWin+ Ver.	7		- @ ×
💾 🚆 🖼	Edit Parameters Category	SERVOPACK				★ \$ ×
001-56075 -890A00A H88 P-0T POWER ESTP N-0T	All constant number Function Selection(Pn0xx-) Gain(Pn1xx-) Position(Pn2xx-) Speed(Pn3xx-) Torque(Pn4xx-)	Edited Parameters Pa Read from	All Edited All Parameters Servo Write to Servo	import Ex	Project Project Function Disp	Dove from &
	Sequence(Pn5xx-) I/O Sign	No.	Name	Unit	001-SGD75-R90	í.
	Display Settings	Pn000.0	Direction Selection	-	0 : Use CCW as t	
	Hierarchy:	Pn000.1	Control Method Selection	-	1 : Position contr····	
	Descriptions:	Pn000.2	Reserved parameter (Do not chang	-	0 : Reserved para···	
		Pn000.3	Rotary/Linear Startup Selection Wh	-	0 : Start as a rota	
		Pn001.0	Servo OFF or Alarm Group 1 Stoppi	-	0 : Stop the moto	
		Pn001.1	Overtravel Stopping Method	-	0 : Apply the dyn…	
		Pn001.2	Main Circuit Power Supply AC/DC Ir	-	0 : Input AC pow…	
		Pn001.3	Warning Code Output Selection	-	0 : Output only al···	
		Pn002.0	Speed/Position Control Option (T-R	-	0 : Do not use T-···	
		Pn002.1	Torque Control Option (V-REF Inpu	-	0 : Do not use V-···	
		Pn002.2	Absolute Encoder Usage	-	2 : Uses absolute…	
		Pn002.3	External Encoder Usage	-	0 : Do not use an…	
		Pn006.0-1	Analog Monitor 1 Signal Selection	-	02 : Torque refer···	
		Pn006.2	Reserved parameter (Do not chang	-	0 : Reserved para…	
		Pn006.3	Reserved parameter (Do not chang	-	0 : Reserved para…	
	1	Pn007.0-1	Analog Monitor 2 Signal Selection	-	00 : Motor speed…	
		Pn007.2	Reserved parameter (Do not chang	-	0 : Reserved para…	
		Pn007.3	Reserved parameter (Do not chang	-	0 : Reserved para…	
		Pn008.0	Low Battery Voltage Alarm/Warning	-	0 : Output alarm…	
		Pn008.1	Function Selection for Undervoltage	-	0 : Do not detect…	
		Pn008.2	Warning Detection Selection	-	0 : Detect warnin…	
		Pn008.3	Reserved parameter (Do not chang	-	0 : Reserved para…	
º, - ₩,		Pn009.0	Reserved parameter (Do not chang	-	0 : Reserved para…	

### 4. Change the setting of the parameter.

Information

1. For a parameter for a numeric setting, input the numeric setting.

If the parameter requires selection of a function, select the function from the list of selections.

### 5. Press the Enter Key.

The background of the edited parameter cell will change to green.

5.1.4 Write Prohibition Setting for Parameters

<b>A</b>			YASKAWA SigmaWin+ Ver.	7			- 6 ×
	Edit Parameters	_					• 0 ×
	Category	SERVOPACK					۵
001-SGD75 -R90A00A HES P-0T 	Conscience number     Function Selection(Pn0xx+)     Gain(Pn1xx-)     Position(Pn2xx-)     Speed(Pn3xx-)     Torque(Pn4xx-)	Edited Parameters P Read from	All Edited Parameters	import Ex	save to Project	Initialize Compare	Remove Servo from List Display
	Sequence(Pn5xx-) I/O Sign	No.	Name	Unit	001-SGD7S-R90		į.
	Display Settings	Pn000.0	Direction Selection	-	0 : Use CCW as t		1
	Hierarchy:	Pn000.1	Control Method Selection	-	1 : Position contr···		
	Descriptions:	Pn000.2	Reserved parameter (Do not chang	-	0 : Reserved para…		
		Pn000.3	Rotary/Linear Startup Selection Wh	-	0 : Start as a rota···		
		Pn001.0	Servo OFF or Alarm Group 1 Stoppi	-	0 : Stop the moto…		
		Pn001.1	Overtravel Stopping Method	-	0 : Apply the dyn…		
		Pn001.2	Main Circuit Power Supply AC/DC Ir	-	0 : Input AC pow…		
		Pn001.3	Warning Code Output Selection	-	0 : Output only al···		
		Pn002.0	Speed/Position Control Option (T-R	-	0 : Do not use T-···		
		Pn002.1	Torque Control Option (V-REF Input	-	0 : Do not use V-···		
		Pn002.2	Absolute Encoder Usage	-	2 : Uses absolute…		
		Pn002.3	External Encoder Usage	-	0 : Do not use an…		
		Pn006.0-1	Analog Monitor 1 Signal Selection	-	02 : Torque refer…		
		Pn006.2	Reserved parameter (Do not chang	-	0 : Reserved para…		
		Pn006.3	Reserved parameter (Do not chang	-	0 : Reserved para…		
		Pn007.0-1	Analog Monitor 2 Signal Selection	-	00 : Motor speed…		
		Pn007.2	Reserved parameter (Do not chang	-	0 : Reserved para…		
		Pn007.3	Reserved parameter (Do not chang	-	0 : Reserved para…		
		Pn008.0	Low Battery Voltage Alarm/Warning	-	0 : Output alarm…		
		Pn008.1	Function Selection for Undervoltage	-	0 : Do not detect…		
		Pn008.2	Warning Detection Selection	-	0 : Detect warnin…		
		Pn008.3	Reserved parameter (Do not chang	-	0 : Reserved para…		
₩. ·		Pn009.0	Reserved parameter (Do not chang	-	0 : Reserved para…		

6. Select Edited Parameters in the Write to Servo Group.

The edited parameters are written to the SERVOPACK and the backgrounds of the cells change to white.

### 7. Click the OK Button.



**8.** To enable changes to the settings, turn the power supply to the SERVOPACK OFF and ON again.

This concludes the procedure to set the parameters.

### Setting Parameters with a Digital Operator

Refer to the following manual for information on setting the parameters with a Digital Operator.  $\square \Sigma$ -7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)

## 5.1.4 Write Prohibition Setting for Parameters

You can prohibit writing parameters from the Digital Operator. Even if you do, you will still be able to change parameter settings from the SigmaWin+.



The write prohibition setting for parameters applies to both axes A and B. If you change the setting, the new setting will be applied to both axes.

### Preparations

No preparations are required.

## **Applicable Tools**

The following table lists the tools that you can use to change the Write Prohibition Setting and the applicable tool functions.

Tool	Function	Reference
Digital Operator	Fn010	Ω Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Setup - Write Prohibited Setting	Jervice Contracting Procedure on page 5-7

## **Operating Procedure**

Use the following procedure to prohibit or permit writing parameter settings.

- 1. Click the 🔎 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Write Prohibition Setting in the Menu Dialog Box. The Write Prohibition Setting Dialog Box will be displayed.
- **3.** Press the ▼ or ▲ for the rightmost digit and set one of the following. 0000: Writing is permitted (default setting). 0001: Writing is prohibited.

G Write Prohibition Setting AXIS#00	×
Write Prohibition Setting is OFF.	
Setting	

4. Click the Setting Button.



5. Click the OK Button.

The setting will be written to the SERVOPACK.

Write Pro	hibition Setting
<b></b>	Write Prohibition Setting has changed. The setting will be enabled the next power ON.
	ОК

6. To enable the new setting, turn the power supply to the SERVOPACK OFF and ON again.

This concludes the procedure to prohibit or permit writing parameter settings.

5.1.4 Write Prohibition Setting for Parameters

### Restrictions

If you prohibit writing parameter settings, you will no longer be able to execute some functions. Refer to the following table.

SigmaWin+		Digital Operator		When Writ-	
Menu Bar Button	SigmaWin+ Function Name	Fn No.	Utility Function Name	ing Is Pro- hibited	Reference
	Origin Search	Fn003	Origin Search	Cannot be executed.	page 7-19
	Absolute Encoder Reset	Fn008	Reset Absolute Encoder	Cannot be executed.	page 5-47
	Adjusting the Analog Moni-	Fn00C	Adjust Analog Monitor Output Offset	Cannot be executed.	page 9-8
	tor Output	Fn00D	Adjust Analog Monitor Output Gain	Cannot be executed.	page 9-8
	Motor Current Detection	Fn00E	Autotune Motor Current Cannot & Detection Signal Offset executed		page 6-41
	Offset Adjustment	Fn00F	Manually Adjust Motor Cur- rent Detection Signal Offset executed.		page 0-41
Setup	Multiturn Limit Setting	Fn013	Multiturn Limit Setting after Multiturn Limit Disagreement Alarm	Cannot be executed.	page 6-30
	Vibration Detection Level Initialization	Fn01B	Initialize Vibration Detection Level	Cannot be executed.	page 6-37
	Set Origin	Fn020	Set Absolute Linear Encoder Origin	Cannot be executed.	page 5-49
	Software Reset	Fn030	Software Reset	Can be executed.	page 6-34
	Polarity Detection	Fn080	Polarity Detection	Cannot be executed.	page 5-28
	Tuning-less Level Setting	Fn200	Tuning-less Level Setting	Cannot be executed.	page 8-16
	EasyFFT	Fn206	Easy FFT	Cannot be executed.	page 8-95
Parameters	Initialize*	Fn005	Initialize Parameters	Cannot be executed.	page 5-9
	Autotuning without Refer- ence Input	Fn201	Advanced Autotuning with- out Reference	Cannot be executed.	page 8-24
	Autotuning with Reference Input	Fn202	Advanced Autotuning with Reference	Cannot be executed.	page 8-35
Tuning	Custom Tuning	Fn203	One-Parameter Tuning	Cannot be executed.	page 8-42
	Anti-Resonance Control Adjustment	Fn204	Adjust Anti-resonance Con- trol	Cannot be executed.	page 8-50
	Vibration Suppression	Fn205	Vibration Suppression	Cannot be executed.	page 8-55
		Fn011	Display Servomotor Model	Can be executed.	nage 9-2
Monitor	Product Information	Fn012	Display Software Version	Can be executed.	
		Fn01E	Display SERVOPACK and Servomotor IDs	Can be executed.	page 9-2
Test Opera-	Jogging	Fn002	Jog	Cannot be executed.	page 7-7
tion	Program Jogging	Fn004	Jog Program	Cannot be executed.	page 7-14

Continued on next page.

5.1.5 Initializing Parameter Settings

Continued from previous page.

SigmaWin+		Digital Operator		When Writ-		
Menu Bar Button	SigmaWin+ Function Name	Fn No.	Utility Function Name ing Is hibi		Reference	
Alarm	Display Alarm	Fn000	Display Alarm History	Can be executed.	page 10-37	
		Fn006	Clear Alarm History	Cannot be executed.	page 10-38	
	Reset Motor Type Alarm	Fn021	Reset Motor Type Alarm	Cannot be executed.	page 5-15	

\* An Initialize Button will be displayed in the Parameter Editing Dialog Box.

## 5.1.5 Initializing Parameter Settings

You can return the parameters to their default settings. You can specify the axis or axes to initialize.

This function will not initialize the settings of the parameters that are adjusted for the Fn00C, Fn00D, Fn00E, and Fn00F utility functions.



To enable the new settings, turn the power supply to the SERVOPACK OFF and ON again after you complete the operation.

### Preparations

Always check the following before you initialize the parameter settings.

- The parameters must not be write prohibited.
- The servo must be OFF.

## **Applicable Tools**

The following table lists the tools that you can use to initialize the parameter settings and the applicable tool functions.

Tool	Function	Reference
Digital Operator	Fn005	Ω Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Parameters - Edit Parameters	Gerating Procedure on page 5-9

## **Operating Procedure**

Use the following procedure to initialize the parameter settings.

- 1. Click the <u>Servo</u> Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Edit Parameters in the Menu Dialog Box. The Parameter Editing Dialog Box will be displayed.
- 3. Select any parameter of the axis to initialize.

### 5.1.5 Initializing Parameter Settings

4. Click the Initialize Button.

<b>a</b>		YASKAWA SigmaWin+ Ver.7			-	. 5 ×
	t Parameters egony Il constant number					• ¶ × ⇔
0001-SV2 -020L2 -020L2 H68 P-0T FOWER ESTP N-0T	unction Selection(Pn0xx-) ein(Pn1xx-) Desition(Pn2xc-) peed(Pn3xc-) rque(Pn3xc-) Read from	All arameters Parameters Parameters Servo Write to Servo	import Exp	Save to Project Project Project	Initialize Compare Function	Display
Se I/d	equence(Pn5xx-) O Sign NO. echatrolink(Pn8xy-)	Name	Unit	0001-SV2-020L2     Axis A		Â
C	ommon Parameters(PnAxx-) Pn000.0	Direction Selection	-	0 : Use CCW as t…		
Disp	play Settings Pn000.1	Reserved parameter (Do not chang	-	0 : Reserved para…		
	Hierarchy: on Pn000.2	Reserved parameter (Do not chang	-	0 : Reserved para…		
	Descriptions: Pn000.3	Rotary/Linear Startup Selection Wh	-	0 : Start as a rota…		
	Pn001.0	Servo OFF or Alarm Group 1 Stoppi	-	0 : Stop the moto…		
	< Pn001.1	Overtravel Stopping Method	-	1 : Decelerate the…		
	Pn001.2	Main Circuit Power Supply AC/DC In	-	0 : Input AC pow…		
	Pn001.3	Reserved parameter (Do not chang	-	0 : Reserved para…		
	Pn002.0	MECHATROLINK Command Position	-	1 : Use TLIM as t…		
	Pn002.1	Torque Control Option	-	1 : Use the speed…		
	Pn002.2	Absolute Encoder Usage	-	1 : Use the absol…		
	Pn002.3	External Encoder Usage	-	0 : Do not use an…		
	Pn006.0-1	Analog Monitor 1 Signal Selection	-	02 : Torque refer…		
	Pn006.2	Reserved parameter (Do not chang	-	0 : Reserved para…		
	Pn006.3	Reserved parameter (Do not chang	-	0 : Reserved para…		
	Pn007.0-1	Analog Monitor 2 Signal Selection	-	00 : Motor speed…		
	Pn007.2	Reserved parameter (Do not chang	-	0 : Reserved para…		
	Pn007.3	Reserved parameter (Do not chang	-	0 : Reserved para…		-

5. Click the OK Button.

YASKAWA SigmaWin+ Ver.7
Caution If you restore the default settings, the settings may no longe agree with the current machine settings.
The SERVOPACK parameters will be returned to the default settings.OK?
OK Cancel

Click the Cancel Button to cancel initialization. The Parameter Editing Dialog Box will return.

6. Click the OK Button.



7. Turn the power supply to the SERVOPACK OFF and ON again after the parameter settings have been initialized.

This concludes the procedure to initialize the parameter settings.

5.2.1 Communications Settings

## 5.2 MECHATROLINK-III Communications Settings

The settings for MECHATROLINK-III communications are made with the DIP switch (S3). The station address is set using the rotary switches (S1 and S2).



## 5.2.1 Communications Settings

Use the DIP switch (S3) to make the communications settings.

Din No.	Function		Default			
FILLINO.		1	2	Description	Setting	
1, 2 Se tra		OFF	OFF	Reserved. (Do not change.)	1: OFF	
	Sets the number of transmission bytes.	ON	OFF	32 bytes		
		OFF	ON	48 bytes	2: ON	
		ON	ON	Reserved. (Do not change.)		
3	Reserved. (Do not cha	nge.)			OFF	
4	Reserved. (Do not cha	nge.)			OFF	
	•					



• If you will use the MECHATROLINK-III standard servo profile, set the number of transmission bytes to either 32 or 48.

• To enable the new setting, turn the power supply to the SERVOPACK OFF and ON again after you change the communications switches (S1, S2, and S3).

## 5.2.2 Setting the Station Address

Use the rotary switches (S1 and S2) to set the station address.

Station Address	S1	S2
00 to 02 hex: Disabled (Do not set.)	0	0 to 2
03 hex (default setting)	0	3
04 hex	0	4
:		:
EF hex	Е	F
F0 to FF hex: Disabled (Do not set.)	F	0 to F

5.2.3 Extended Address Setting

## 5.2.3 Extended Address Setting

The extended addresses are given in the following table.

Axis	Extended Address	Servomotor Termi- nals	Encoder Connector
Axis A	00 hex	UA, VA, and WA	CN2A
Axis B	01 hex	UB, VB, and WB	CN2B
			Axis A Axis B

5.3.1 AC Power Supply Input/DC Power Supply Input Setting

## 5.3 Power Supply Type Settings for the Main Circuit and Control Circuit

A SERVOPACK can be operated on either an AC power supply input or DC power supply input to the main and control circuits. If you select an AC power supply input, you can operate the SERVOPACK on either a single-phase power supply input or a three-phase power supply input. This section describes the settings related to the power supplies.

## 5.3.1 AC Power Supply Input/DC Power Supply Input Setting

Set  $Pn001 = n.\Box X \Box \Box$  (Main Circuit Power Supply AC/DC Input Selection) to specify whether to use an AC or DC power supply input for the main circuit power supply to the SERVOPACK.

If the setting of  $Pn001 = n.\Box X \Box \Box$  does not agree with the actual power supply input, an A.330 alarm (Main Circuit Power Supply Wiring Error) will occur.

Example Examples of When an A.330 Alarm (Main Circuit Power Supply Wiring Error) Occurs

- A DC power supply is connected between the B1/⊕ and ⊝2 terminals, but an AC power supply input is specified (Pn001 = n.□0□□).
- An AC power supply is input to the L1, L2, and L3 terminals, but a DC power supply is specified (Pn001 = n.□1□□).

Para	meter	Meaning	When Enabled	Classification			
Pn001 All Axes	n.□0□□ (default set- ting)	Use an AC power supply input.	After restart	Setup			
	n.0100	Use a DC power supply input.					
	<b>WARNING</b>						
<ul> <li>Con</li> <li>Cath</li> <li>Cath</li> <li>Cath</li> <li>Cath</li> <li>Cath</li> <li>Cath</li> <li>Alway</li> <li>the</li> <li>If yoon</li> <li>Alway</li> <li>the</li> <li>If yoon</li> <li>With</li> <li>suppow</li> <li>Instant</li> <li>The</li> <li>with</li> <li>tive</li> </ul>	nect the AC o ponnect an AC p e SERVOPACK onnect a DC por e SERVOPACK re is a risk of fa ays specify a I main circuit por u input DC pow 1 III), the SEF pment. a DC power s ply is turned C rer supply is tu all fuses on the Servomotor re a DC power s energy at the	r DC power supplies to the specified SERVC power supply to the L1, L2, and L3 terminals a curve supply to the B1/⊕ and $\ominus$ 2 terminals a dilure or fire. DC power supply input (Pn001 = n.□1□□) to ower supply. Wer without specifying a DC power supply input avoPACK's internal elements may burn and m supply input, time is required to discharge el iFF. A high residual voltage may remain in the irrned OFF. Be careful not to get an electric s e power supply line if you use DC power. eturns regenerative energy to the power sup supply input, regenerative energy is not proc power supply.	DPACK terminals. and the L1C and L and the L1C and L before you input E at (i.e., without sett ay cause fire or d lectricity after the le SERVOPACK a shock. ply. If you use a S cessed. Process t	2C terminals on 2C terminals on 2C power for ting Pn001 to amage to the main power fter the SERVOPACK he regenera-			

Refer to the following section for information on wiring the SERVOPACK. (3) 4.3.4 Power Supply Wiring Diagrams on page 4-13

5.3.2 Single-phase AC Power Supply Input/Three-phase AC Power Supply Input Setting

# 5.3.2 Single-phase AC Power Supply Input/Three-phase AC Power Supply Input Setting

Some models of Three-phase 200-VAC SERVOPACKs can also operate on a single-phase 200-VAC power supply.

You can use a single-phase, 200-VAC power supply input with the following models. • SGD7W-1R6A, -2R8A, and -5R5A

If you use a single-phase, 200-VAC power supply input for the SERVOPACK's main circuit power supply, set parameter Pn00B to n.  $\Box 1 \Box \Box$  (Use a three-phase power supply input as a single-phase power supply input).

Parameter		Meaning	When Enabled	Classification
Pn00B	n.□0□□ (default setting)	Use a three-phase power supply input.	Aftor rostart	Satur
All Axes	n.0100	Use a three-phase power supply input as a single-phase power supply input.	Aller residit	Gerup

1. If you use a single-phase power supply input without specifying a signal-phase AC power supply (Pn00B = n.□1□□), an A.F10 alarm (Power Supply Line Open Phase) will occur.



3. If you use a single-phase 200-VAC power supply input, the torque-motor speed characteristic of the Servomotor will not be the same as for a three-phase AC power supply input. Decide whether to use a single-phase or three-phase AC power supply input after checking the characteristics given in the Servomotor manual or catalog.

Refer to the following section for information on wiring a single-phase AC power supply input to the SERVOPACK.

• Wiring Example for Single-Phase, 200-VAC Power Supply Input on page 4-14

## 5.4 Automatic Detection of Connected Motor

You can use a SERVOPACK to operate either a Rotary Servomotor or a Linear Servomotor. If you connect the Servomotor encoder to the CN2A or CN2B connector on the SERVOPACK, the SERVOPACK will automatically determine which type of Servomotor is connected. Therefore, you normally do not need to specify the motor type.

Information If an encoder is not connected, e.g., for a test without a motor, you can specify a Rotary Servomotor or a Linear Servomotor in Pn000 = n.X□□□ (Rotary/Linear Servomotor Startup Selection When Encoder Is Not Connected). If you specify either a Rotary or Linear Servomotor, only the parameters, monitors, alarms, and functions for the specified motor type will be enabled.

Parameter		Meaning	When Enabled	Classification
Pn000 n. <sup>1</sup>	n.0□□□ (default setting)	When an encoder is not connected, start as SERVOPACK for Rotary Servo- motor.	After restart	Catura
	n.1000	When an encoder is not connected, start as SERVOPACK for Linear Servo- motor.	- After restart	Setup

## 5.5 Motor Direction Setting

You can reverse the direction of Servomotor rotation by changing the setting of  $Pn000 = n.\Box\Box\BoxX$  (Direction Selection) without changing the polarity of the speed or position reference.

Rotary Servomotors

The default setting for forward rotation is counterclockwise (CCW) as viewed from the load end of the Servomotor.

Parameter		Forward/Reverse Reference	Motor Direction	Applicable Overtravel Signal (OT)
Pn000	n.□□□0 Use CCW as the forward direction. (default setting)	Forward reference	Torque reference	P-OT (For- ward Drive Prohibit) signal
		Reverse reference	Torque reference Time CW Motor speed	N-OT (Reverse Drive Prohibit) signal
	n.□□□1 Use CW as the forward direc- tion. (Reverse Rota- tion Mode)	Forward reference	CW + Torque reference Time Motor speed	P-OT (For- ward Drive Prohibit) signal
		Reverse reference	CCW Torque reference	N-OT (Reverse Drive Prohibit) signal

Note: The trace waveforms of the SigmaWin+ are shown in the above table for the torque reference and motor speed diagrams. If you measure them on a measuring instrument, e.g., with an analog monitor, the polarity will be reversed.

#### • Linear Servomotors

Before you set this parameter, make sure that  $Pn080 = n.\Box\BoxX\Box$  (Motor Phase Sequence Selection) is set correctly.

Parameter		Forward/Reverse Reference	Motor Moving Direction	Applicable Overtravel Signal (OT)
Pn000	n.□□□0 Use the direc- tion in which the linear encoder counts up as the for- ward direction. (default setting)	Forward reference	Moves in the count-up direction.	P-OT (For- ward Drive Prohibit) signal
		Reverse reference	Moves in the count-down direction.	N-OT (Reverse Drive Prohibit) signal
	n.□□□1 Use the direc- tion in which the linear encoder counts down as the forward direc- tion.	Forward reference	Moves in the count-down direction.	P-OT (For- ward Drive Prohibit) signal
		Reverse reference	Moves in the count-up direction.	N-OT (Reverse Drive Prohibit) signal

Note: The trace waveforms of the SigmaWin+ are shown in the above table for the force reference and motor speed diagrams. If you measure them on a measuring instrument, e.g., with an analog monitor, the polarity will be reversed.

#### Setting the Linear Encoder Pitch 5.6

If you connect a linear encoder to the SERVOPACK through a Serial Converter Unit, you must set the scale pitch of the linear encoder in Pn282.

If a Serial Converter Unit is not connected, you do not need to set Pn282.

#### Serial Converter Unit

The Serial Converter Unit converts the signal from the linear encoder into a form that can be read by the SERVOPACK.

#### Scale Pitch

Term

A linear encoder has a scale for measuring lengths (positions). The length of one division on this scale is the scale pitch.

Linear Encoder Scale Pitch				Speed Po	osition Force
Pn282	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 6,553,600	0.01 µm	0	After restart	Setup

You will not be able to control the Linear Servomotor if Pn282 is not set correctly. Check the above table and always set the correct value before you operate the Linear Servomotor.

Type of Linear Encoder	Manufacturer	Model	Serial Converter Unit Model	Linear Encoder Pitch [µm]
Incremental	Heidenhain Corporation	LIDA480	JZDP-H003-DDD-E	20
			JZDP-J003-DD-E	
		LIF48□	JZDP-H003-DD-E	4
			JZDP-J003-DD-E	
		RGH22B	JZDP-H005-DDD-E	20
	Nehishaw FLU		JZDP-J005-DDD-E	20

The first time you supply power to the SERVOPACK, the panel display on the front of the Servomotor will display an A.080 alarm (Linear Encoder Pitch Setting Error). The A.080 alarm is displayed because the setting of Pn282 has not been changed. The A.080 alarm will be cleared when you change the setting of Pn282 and then turn the power supply OFF and ON again.

#### Linear Encoder Pitch Information

If you do not use a Serial Converter Unit, the linear encoder pitch is automatically set. It is not necessary to set Pn282. You can use the SigmaWin+ to check the linear encoder pitch that was automatically set. Refer to the following section for details.

I 9.1 Monitoring Product Information on page 9-2

## 5.7 Writing Linear Servomotor Parameters

If you connect a linear encoder to the SERVOPACK without going through a Serial Converter Unit, you must use the SigmaWin+ to write the motor parameters to the linear encoder. The motor parameters contain the information that is required by the SERVOPACK to operate the Linear Servomotor.



• Check the motor and linear encoder information before you write the motor parameters. If you do not write the correct motor parameters, the motor may run out of control or burning may occur, possibly resulting in equipment damage or fire.





Serial number information is not included in the motor parameters. You cannot use the monitor functions of the SERVOPACK to monitor the serial number. If you attempt to monitor the serial number, \*\*\*\*\*\*\*\*\* will be displayed.

### Precautions

- If the encoder parameters are not written to the linear encoder, an A.CAO alarm (Encoder Parameter Error) will occur. Consult the manufacturer of the linear encoder.
- If the motor parameters are not written to the linear encoder, an A.CAO alarm (Encoder Parameter Error) will not occur, but the following alarms will occur.
- A.040 (Parameter Setting Error), A.041 (Encoder Output Pulse Setting Error),
- A.050 (Combination Error), A.051 (Unsupported Device Alarm),
- A.550 (Maximum Speed Setting Error), A.710 (Instantaneous Overload),
- A.720 (Continuous Overload), and A.C90 (Encoder Communications Error)

## Applicable Tools

The following table lists the tools that you can use to write the parameters to the Linear Servomotor and the applicable tool functions.

Tool Function		Reference	
Digital Operator	You cannot write Linear Servomotor parameters from the Digital Operator.		
SigmaWin+	Setup – Motor Parameter Scale Write	G Operating Procedure on page 5-19	

## **Operating Procedure**

Use the following procedure to write the motor parameters to the Linear Encoder.

- 1. Prepare the motor parameter file to write to the linear encoder.
- 2. Click the *P* Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **3.** Select Motor Parameter Scale Write in the Menu Dialog Box. The Motor Parameter Scale Write Dialog Box will be displayed.
- 4. Click the OK Button.

Motor parameter scale write
This function rewrites data in the scale. If the data which does not suit the connected motor is rewritten, the motor may not work normally, resulting in motor overrun, etc., and it is very dangerous. Be sure that the data written in the scale suits the connected motor.
OK Cacnel

Click the **Cancel** Button to cancel writing the motor parameters to the linear encoder. The Main Window will return.

If the write is completed normally, the Motor Parameter Scale Write - File Select Dialog Box will be displayed.

5. Click the Ref. Button.

Motor parameter scale write - File Select	×
Motor Parameter File	$\frown$
	Ref.
Motor parameter file information	
**	
Outline	

6. Select the motor parameter file that you prepared and click the Open Button.



7. Confirm that the motor parameter file information that is displayed is suitable for your motor, and then click the Next Button.



Click the **Cancel** Button to cancel writing the motor parameters to the linear encoder. The Main Window will return.

### 8. Click the Write Button.

🚵 Motor par	ameter scale write - Scale write		×					
The motor parameter is written in the scale. Please confirm the motor which connects is corresponding to the following information.								
Motor para	meter file information							
SGLTV	/-35A170AP							
TRACK C	Outline ContForce							
	Alt	220 ContCurrent	[N]					
	17.64	PeakForce	[Anna]					
	12 1 12	660	[N]					
		PeakCurrent 11.3	[Arms]					
<u>T</u> ype:	Iron-core ,sW The Iron-core TW linear motors are com	posed	*					
Aspect:	EYaskawa's unique construction princip @the TW linear motors negate the effec	les of ts of	* *					
<u>R</u> emarks:			*					
	< <u>B</u> ack	Complete	Cancel					

9. Click the Yes Button.



Click the No Button to cancel writing the motor parameters to the linear encoder.

If you click the Yes Button, writing the motor parameter scale will start.

#### 10. Click the Complete Button.

🚠 Motor para	ameter scale write - Scale write		X
The motor par Please confirr the following	ameter is written in the scale. n the motor which connects is correspond information.	ling to	Write
- Motor parar	meter file information		
SGLTW	/-35A170AP		
and the second		Outline ContForce 220 ContCurrent 3.3 PeakForce 660 PeakCurrent 11.3	[N] [Arms] [N] [Arms]
<u>T</u> ype:	Iron-core ,sW The Iron-core TW linear motors are comp	posed	*
<u>A</u> spect:	EYaskawa's unique construction princip @the TW linear motors negate the effec	les of ts of	* *
<u>R</u> emarks:			*
	< Back	Complete	Cancel

11. Click the OK Button.



### **12.** Turn the power supply to the SERVOPACK OFF and ON again.

This concludes the procedure to write the motor parameters.

## Confirming If the Motor Parameters Have Been Written

After you write the motor parameters, you can use a monitor function to confirm that the motor parameters are in the encoder.

If the motor parameters have not been written, no information on the Servomotor will be displayed.

9.1 Monitoring Product Information on page 9-2

## 5.8 Selecting the Phase Sequence for a Linear Servomotor

You must select the phase sequence of the Linear Servomotor so that the forward direction of the Linear Servomotor is the same as the encoder's count-up direction.

Before you set the Linear Servomotor phase sequence (Pn080 =  $n.\Box\Box X\Box$ ), check the following items.

- Confirm that the signal from the linear encoder is being received normally.
- Make sure that the forward direction of the Linear Servomotor and the count-up direction of the linear encoder are in the same direction.

If you do not confirm the above items before you attempt to operate the motor, the motor may not operate or it may run out of control. Always confirm these items before you operate the motor.

### **Related Parameters**

Parameter		Meaning	When Enabled	Classification
Pn080	n.□□0□ (default setting)	Set a phase-A lead as a phase sequence of U, V, and W. After restart Set		Setup
	n.🗆 🗆 1 🗆	Set a phase-B lead as a phase sequence of U, V, and W.		

### **Operating Procedure**

Use the following procedure to select the phase sequence for a Linear Servomotor.

- 1. Set Pn000 to n. DDD (Set a phase-A lead as a phase sequence of U, V, and W). This setting is to make following confirmation work easier to understand.
- 2. Select Monitor in the Menu Dialog Box.

The Operation Panel will be displayed so that you can check the feedback pulse counter. To check the feedback pulse counter with the Digital Operator, use Un00D (Feedback Pulse Counter).

**3.** Manually move the Moving Coil from one end to the other of the stroke and confirm that only the correct number of feedback pulses is returned.

If the correct number and only the correct number of pulses is returned, the signal is being received correctly from the linear encoder.

In this example, assume that a linear encoder with a scale pitch of 20  $\mu$ m and a resolution of 256 is used. If you manually move the Moving Coil 1 cm in the count-up direction of the linear encoder, the number of feedback pulses would be as follows: 1 cm/(20  $\mu$ m/256) = 128,000 pulses



If there are 128,000 pulses on the feedback pulse counter after you manually move the Moving Coil in the direction of the cable, you have completed the confirmation.

Note: The actual monitor display will be offset by the error in the travel distance. There is no problem as long as the above value is close to the calculated value.

Example

Information If the correct value is not displayed for the feedback pulse counter, the following conditions may exist. Check the situation and correct any problems.

- The linear encoder pitch is not correct. If the scale pitch that is set in Pn282 does not agree with the actual scale pitch, the expected number of feedback pulses will not be returned. Check the specifications of the linear encoder.
- The linear encoder is not adjusted properly. If the linear encoder is not adjusted properly, the output signal level from the linear
- encoder will drop and the correct number of pulses will not be counted. Check the adjustment of the linear encoder. Contact the manufacturer of the linear encoder for details.
- There is a mistake in the wiring between the linear encoder and the Serial Converter Unit.

If the wiring is not correct, the correct number of pulses will not be counted. Correct the wiring.

4. Manually move the Moving Coil in the direction of the cable and check the value of the feedback pulse counter in the Operation Panel to confirm that it is counting up. If the pulses are counted up, the forward direction of the Linear Servomotor is the same as the count-up direction of the linear encoder.



Coil in the direction of the cable, you have completed the confirmation.

- 5. If the feedback pulse counter counts down, set a phase-B lead as a phase sequence of U, V, and W (Pn080 = n.□□1□) and turn the power supply OFF and ON again.
- **6.** If necessary, return  $Pn000 = n.\Box\Box\BoxX$  (Direction Selection) to its original setting.

This concludes the procedure to set the phase sequence of the Linear Servomotor.

## 5.9 Polarity Sensor Setting

The polarity sensor detects the polarity of the Servomotor. You must set a parameter to specify whether the Linear Servomotor that is connected to the SERVOPACK has a polarity sensor. Specify whether there is a polarity sensor in Pn080 =  $n.\square\square\squareX$  (Polarity Sensor Selection).

If the Linear Servomotor has a polarity sensor, set Pn080 to n.  $\Box\Box\Box$  (Use polarity sensor) (default setting).

If the Linear Servomotor does not have a polarity sensor, set Pn080 to n.  $\Box\Box\Box$  1 (Do not use polarity sensor). Turn the power supply OFF and ON again to enable the new setting.

Parameter		Meaning	When Enabled	Classification	
Pn080	n.□□□0 (default setting)	n.□□□0 (default setting) Use polarity sensor.		Setup	
	n.0001	Do not use polarity sensor.			

5.10.1 Restrictions

## 5.10 Polarity Detection

If you use a Linear Servomotor that does not have a polarity sensor, then you must detect the polarity.

Detecting the polarity means that the position of the electrical phase angle on the electrical angle coordinates of the Servomotor is detected. The SERVOPACK cannot control the Servomotor correctly unless it accurately knows the position of the electrical angle coordinate of the Servomotor.

The execution timing and execution method for polarity detection depend on the encoder specification as described in the following table.

Encoder Specification	Polarity Detection Execution Timing	Polarity Detection Execution Method
Incremental encoder	Each time the control power supply to the SERVOPACK is turned ON (Even after you execute polarity detec- tion, the position of the polarity will be lost the next time the control power supply to the SERVOPACK is turned	<ul> <li>Use the SV_ON (Servo ON) command.</li> <li>Use the polarity detection function of the SigmaWin+.</li> <li>Execute the Fn080 (Polarity Detection) utility function from the Digital Operator.</li> </ul>
Absolute encoder	Only for initial setup, or after the SER- VOPACK, linear encoder, or motor has been replaced (The results of polarity detection is stored in the absolute encoder, so the polarity position is not lost when the control power supply is turned OFF.)	<ul> <li>Use the polarity detection function of the SigmaWin+.</li> <li>Execute the Fn080 (Polarity Detection) utility function from the Digital Opera- tor.</li> <li>Use Pn587 (Polarity Detection Execu- tion Selection for Absolute Linear Encoder).</li> </ul>

Information If you use a Linear Servomotor that does not have a polarity sensor, you will not be able to turn ON the servo until polarity detection has been completed.

## 5.10.1 Restrictions

## **Assumed Conditions**

The Servomotor will move when you execute polarity detection. The following conditions must be met before you start.

- It must be OK to move the Moving Coil about 10 mm.
- (If polarity detection fails, the Moving Coil may move approximately 5 cm. The amount of movement depends on conditions.)
- The linear encoder pitch must be 100  $\mu m$  or less. (We recommend a pitch of 40  $\mu m$  or less for an incremental encoder.)
- As much as possible, the motor must not be subjected to an imbalanced external force. (We recommend 5% or less of the rated force.)
- The mass ratio must be 50x or less.
- The axis must be horizontal.
- There must be friction equivalent to a few percent of the rated force applied to the guides. (Air sliders cannot be used.)

## Preparations

Always check the following before you execute polarity detection.

- Not using a polarity sensor must be specified (Pn080 = n.□□□1).
- The servo must be OFF.
- The main circuit power supply must be ON.
- There must be no alarms except for an A.C22 alarm (Phase Information Disagreement).
- The parameters must not be write prohibited. (This item applies only when using the SigmaWin+ or Digital Operator.)
- The test without a motor function must be disabled (Pn00C =  $n.\Box\Box\Box$ ).
- There must be no overtravel.
- If the motor parameters have been written or the origin of the absolute linear encoder has been set, the power supply to the SERVOPACK must be turned OFF and ON again after completion of the writing or setting operation.



1. Power is supplied to the Servomotor during polarity detection. Be careful not to get an electric shock. Also, the Moving Coil of the Linear Servomotor may greatly move during detection. Do not approach the moving parts of the Servomotor.

2. Polarity detection is affected by many factors.

For example, polarity detection may fail if the mass ratio or friction is too large or the cable tension is too strong.

## 5.10.2 Using the SV\_ON (Servo ON) Command to Perform Polarity Detection

You can use the SV\_ON (Servo ON) command to perform polarity detection only with an incremental linear encoder.

Polarity detection will be performed when you turn the control power supply to the SERVO-PACK OFF and then ON again, and then send the SV\_ON (Servo ON) command. As soon as polarity detection is completed, the /S-RDY (Servo Ready) signal will turn ON.

Polarity detection will start simultaneously with execution of the SV\_ON (Servo ON) command. As soon as polarity detection is completed, the /S-RDY will turn ON and the servo will remain ON.



5.10.3 Using a Tool Function to Perform Polarity Detection

## 5.10.3 Using a Tool Function to Perform Polarity Detection

### **Applicable Tools**

The following table lists the tools that you can use to perform polarity detection and the applicable tool functions.

Tool	Function	Reference
Digital Operator	Fn080	Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Setup - Polarity Detection	Gerating Procedure on page 5-28

### **Operating Procedure**

Use the following procedure to perform polarity detection.

- 1. Click the 🔎 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Polarity Detection in the Menu Dialog Box. The Polarity Detection Dialog Box will be displayed.
- 3. Click the Continue Button.

Polarity Detection
During execution of this function, power will be supplied to the motor. Take care to avoid electric shock. The motor may move widely. Do not approach the motor movable parts.
Do you want to continue the polarity detection?
Continue Cancel

Click the Cancel Button to cancel polarity detection. The Main Window will return.

### 4. Click the Start Button.

Polarity detection will be executed.



This concludes the polarity detection procedure.

## **Overtravel and Related Settings**

Overtravel is a function of the SERVOPACK that forces the Servomotor to stop in response to a signal input from a limit switch that is activated when a moving part of the machine exceeds the safe range of movement.

The overtravel signals include the P-OT (Forward Drive Prohibit) and the N-OT (Reverse Drive Prohibit) signals.

You use the P-OT and N-OT signals to stop the machine by installing limit switches at the positions where you want to stop the machine that is operated by the Servomotor.

A SERVOPACK wiring example is provided below.



Using the overtravel function is not necessary for rotating applications such as rotary tables and conveyors. No wiring for overtravel input signals is required.

This section describes the parameters settings related to overtravel.



#### 5.11.1 **Overtravel Signals**

The overtravel signals include the P-OT (Forward Drive Prohibit) and the N-OT (Reverse Drive Prohibit) signals.

Туре	Signal	Connector Pin No.	Signal Status	Meaning
Input P-OT		Axis A: CN1-3 Axis B: CN1-9	ON	Forward drive is enabled (actual operation).
	P-OT		OFF	Forward drive is prohibited (forward overtravel).
			ON	Reverse drive is enabled (actual operation).
	N-OT Axis A: CN1-4 Axis B: CN1-4	Axis B: CN1-10	OFF	Reverse drive is prohibited (reverse overtravel).

You can operate the Servomotor in the opposite direction during overtravel by inputting a reference.

5.11.2 Setting to Enable/Disable Overtravel

## 5.11.2 Setting to Enable/Disable Overtravel

You can use  $Pn50A = n.X\square\square\square$  (P-OT (Forward Drive Prohibit) Signal Allocation) and  $Pn50B = n.\square\square\squareX$  (N-OT (Reverse Drive Prohibit) Signal Allocation) to enable and disable the overtravel function.

You do not need to wire the overtravel input signals if you are not going to use the overtravel function.

Parameter		Meaning	When Enabled	Classification	
Pn50A	n.1□□□ (default setting)	The forward overtravel function is enabled and the P-OT (Forward Drive Prohibit) signal is input from CN1-3 for axis A and CN1-9 for axis B.			
	n.8000	The reverse overtravel function is disabled. Forward drive is always enabled.	After restart	Catura	
Pn50B	n.□□□2 (default setting)	The reverse overtravel function is enabled and the N-OT (Reverse Drive Prohibit) signal is input from CN1-4 for axis A and CN1-10 for axis B.	Alter restart	Seruh	
	n.0008	The reverse overtravel function is disabled. Reverse drive is always enabled.	1		

You can also use Pn590 (P-OT (Forward Drive Prohibit) Signal Allocation) and Pn591 (N-OT (Reverse Drive Prohibit) Signal Allocation) to enable and disable the overtravel function. Refer to the following sections for details.

6.1.1 Input Signal Allocations on page 6-3

11.1.2 List of Servo Parameters on page 11-3

You can allocate the P-OT and N-OT signals to other connector pins. Refer to the following section for details.

3 6.1.1 Input Signal Allocations on page 6-3

## 5.11.3 Motor Stopping Method for Overtravel

You can set the stopping method of the Servomotor when overtravel occurs in Pn001 =  $n.\Box\BoxXX$  (Motor Stopping Method for Servo OFF and Group 1 Alarms and Overtravel Stopping Method).

P	arameter	Motor Stopping Method <sup>*</sup>	Status after Stopping	When Enabled	Classification
Pn001	n.□□00 (default setting)	Dynamic brake			Setup
	n.□□01	,	Coasting	After restart	
	n.□□02	Coasting			
	n.0010	Deceleration according to setting of Pn406	Zero clamp		
	n.□□2□		Coasting		
	n.🗆 🗆 3 🗆	Deceleration	Zero clamp		
	n.0040	according to setting of Pn30A	Coasting		

\* You cannot decelerate a Servomotor to a stop during torque control. For torque control, the Servomotor will be stopped with the dynamic braking or coast to a stop (according to the setting of Pn001 = n.  $\square$  (Motor Stopping Method for Servo OFF and Group 1 Alarms)), and then the Servomotor will enter a coasting state.

Refer to the following section for information on stopping methods other than those for overtravel.

5.13.1 Stopping Method for Servo OFF on page 5-37

5.11.3 Motor Stopping Method for Overtravel

### Stopping the Servomotor by Setting Emergency Stop Torque

To stop the Servomotor by setting emergency stop torque, set Pn406 (Emergency Stop Torque).

If  $Pn001 = n.\Box\BoxX\Box$  is set to 1 or 2, the Servomotor will be decelerated to a stop using the torque set in Pn406 as the maximum torque.

The default setting is 800%. This setting is large enough to allow you to operate the Servomotor at the maximum torque. However, the maximum emergency stop torque that you can actually use is the maximum torque of the Servomotor.

	Emergency Stop Torque			Speed Positio	n Torque
Pn406	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 800	1%*	800	Immediately	Setup

\* Set a percentage of the motor rated torque.

## Stopping the Servomotor by Setting the Deceleration Time

To specify the Servomotor deceleration time and use it to stop the Servomotor, set Pn30A (Deceleration Time for Servo OFF and Forced Stops).

	Deceleration Time f	or Servo OFF and Fo	Speed Position	1	
Pn30A	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 10,000	1 ms	0	Immediately	Setup

If you set Pn30A to 0, the Servomotor will be stopped with a zero speed.

The deceleration time that you set in Pn30A is the time to decelerate the motor from the maximum motor speed.



Important

5.11.4 Overtravel Warnings

## 5.11.4 Overtravel Warnings

You can set the system to detect an A.9A0 warning (Overtravel) if overtravel occurs while the servo is ON. This allows the SERVOPACK to notify the host controller with a warning even when the overtravel signal is input only momentarily. An alarm occurs only if overtravel occurs while the servo is ON. An overtravel warning will not be detected when the servo is OFF, even if overtravel occurs.

1. The occurrence of an A.9A0 warning will not stop the motor or have any affect on host controller motion operations. The next step (e.g., the next motion or command) can be executed even if an overtravel warning exists.

- However, depending on the processing specifications and programming for warnings in the host controller, operation may be affected when an overtravel warning occurs (e.g., motion may stop or not stop). Confirm the specifications and programming in the host controller.
- 2. When overtravel occurs, the SERVOPACK will perform stop processing for overtravel. Therefore, when an A.9A0 warning occurs, the Servomotor may not reach the target position specified by the host controller. Check the feedback position to make sure that the axis is stopped at a safe position.

The following parameter is set for this function.

Parameter		Meaning	When Enabled	Classification	
Pn00D	n.0□□□ (default setting)	Do not detect overtravel warnings.	Immediately	Setup	
	n.1000	Detect overtravel warnings.			

A timing chart for warning detection is provided below.



Information

- 1. Warnings are detected for overtravel in the same direction as the reference.
  - 2. Warnings are not detected for overtravel in the opposite direction from the reference. Example: A warning will not be output for a forward reference even if the N-OT signal turns ON.
  - 3. A warning can be detected in either the forward or reverse direction if there is no reference.
  - 4. A warning will not be detected when the servo is turned ON even if overtravel status exists.
  - 5. You can use the ALM\_CLR (Clear Alarms and Warnings) command to clear the warning regardless of the servo ON/OFF status and overtravel signal status.
  - 6. If you clear the warning with the ALM\_CLR (Clear Alarms and Warnings) command during overtravel status, a warning will not be detected again until the overtravel status is left.
  - 7. An overtravel warning will be detected even when the software limit has been detected.

## 5.12 Holding Brake

A holding brake is used to hold the position of the moving part of the machine when the SER-VOPACK is turned OFF so that moving part does not move due to gravity or an external force. You can use the brake that is built into a Servomotor with a Brake, or you can provide one on the machine.

The holding brake is used in the following cases.





The brake built into a Servomotor with a Brake is a de-energization brake. It is used only to hold the Servomotor and cannot be used for braking. Use the holding brake only to hold a Servomotor that is already stopped.

## 5.12.1 Brake Operating Sequence

You must consider the time required to release the brake and the time required to brake to determine the brake operation timing, as described below.

Term

#### Time Required to Release Brake

The time from when the /BK (Brake) signal is turned ON until the brake is actually released.

#### Time Required to Brake

The time from when the /BK (Brake) signal is turned OFF until the brake actually operates.



\*1. Rotary Servomotors: The brake delay times for Servomotors with Holding Brakes are given in the following table. The operation delay times in the following table are examples for when the power supply is switched on the DC side. You must evaluate the actual brake delay times on the actual equipment before using the application.

#### 5.12 Holding Brake

#### 5.12.2 /BK (Brake) Signal

Model	Voltage	Time Required to Release Brake [ms]	Time Required to Brake [ms]
SGM7J-A5 to -04		60	
SGM7J-06 and -08		80	100
SGM7A-A5 to -04		60	100
SGM7A-06 and -08		80	
SGM7P-01	24 VDC	20	
SGM7P-02 and -04		40	100
SGM7P-08		20	
SGM7G-03 to -09		100	80

Linear Servomotors: The brake delay times depend on the brake that you use. Set the parameters related to /BK signal output timing according to the delay times for the brake that you will actually use.

\*2. Before you output a reference from the host controller to the SERVOPACK, wait for at least 50 ms plus the time required to release the brake after you send the SV\_ON command.

\*3. Use the following parameters to set the timing of when the brake will operate and when the servo will be turned OFF.

Rotary Servomotors: Pn506 (Brake Reference-Servo OFF Delay Time), Pn507 (Brake Reference Output Speed Level), and Pn508 (Servo OFF-Brake Command Waiting Time)
 Linear Servomotors: Pn506 (Brake Reference-Servo OFF Delay Time), Pn508 (Servo OFF-Brake Command

 Linear Servomotors: Pn506 (Brake Reference-Servo OFF Delay Time), Pn508 (Servo OFF-Brake Command Waiting Time), and Pn583 (Brake Reference Output Speed Level)

### **Connection Examples**

Refer to the following section for information on brake wiring. *4.4.4 Wiring the SERVOPACK to the Holding Brake* on page 4-29

## 5.12.2 /BK (Brake) Signal

The following settings are for the output signal that controls the brake. You can change the connector pin that is allocated. For details, refer to *Allocating the /BK (Brake) Signal.* The /BK signal is turned OFF (to operate the brake) when the servo is turned OFF or when an alarm is detected. You can adjust the timing of brake operation (i.e., the timing of turning OFF the /BK signal) with the servo OFF delay time (Pn506).

Туре	Signal	Connector Pin No.	Signal Status	Meaning
		Axis A: CN1-23 and	ON (closed)	Releases the brake.
Output	/BK	CN1-24 Axis B: CN1-25 and CN1-26	OFF (open)	Activates the brake.

Information The /BK signal will remain ON during overtravel. The brake will not be applied.

## Allocating the /BK (Brake) Signal

Set the allocation for the /BK signal in Pn50F =  $n.\Box X \Box \Box$  (/BK (Brake Output) Signal Allocation).

Axis A

Parameter		Connector Pin No.		Maaning	When	Classification
		+ Pin	- Pin	Meaning	Enabled	Classification
Pn50F	n.0000	-	-	The /BK signal is not used.		
	n.□1□□ (default set- ting)	CN1-23	CN1-24	The /BK signal is output from CN1-23 and CN1-24.	After restart	Setup
	n.0200	CN1-27	CN1-28	The /BK signal is output from CN1-27 and CN1-28.		

#### 5.12.3 Output Timing of /BK (Brake) Signal When the Servomotor Is Stopped

### Axis B

Parameter		Connector Pin No.		Mooning	When	Classification
		+ Pin	- Pin	Meaning	Enabled	Classification
Pn50F	n.0000	_	_	The /BK signal is not used.		
	n.□1□□ (default set- ting)	CN1-25	CN1-26	The /BK signal is output from CN1-25 and CN1-26.	After restart	Setup
	n.0200	CN1-29	CN1-30	The /BK signal is output from CN1-29 and CN1-30.	Ť	

If you allocate more than one signal to the same output connector pin, a logical OR of the signals is output. Allocate the /BK signal to its own output connector pin, i.e., do not use the same output terminal for another signal.

For example, never allocate the /TGON (Rotation Detection) signal and /BK signal to the same Important output connector pin. If you did so, the /TGON signal would be turned ON by the falling speed on a vertical axis, and the brake would not operate.

### 5.12.3 Output Timing of /BK (Brake) Signal When the Servomotor Is Stopped

When the Servomotor is stopped, the /BK signal turns OFF as soon as the SV OFF (Servo OFF) command is received. Use the servo OFF delay time (Pn506) to change the timing to turn OFF power supply to the motor after the SV OFF command is input.

Pn506	Brake Reference-Se	ervo OFF Delay Time	Speed Position	on Torque	
	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 50	10 ms	0	Immediately	Setup

- When the Servomotor is used to control a vertical axis, the machine moving part may move slightly due to gravity or an external force. You can eliminate this slight motion by setting the servo OFF delay time (Pn506) so that power supply to the motor is stopped after the brake is applied.
- SV OFF (Servo OFF) Servo ON Servo OFF command input ON (Brake OFF (Brake applied.) /BK signal released.) Power supplied Power not Motor power status to motor supplied to motor. Pn506
- This parameter sets the timing of stopping power supply to the Servomotor while the Servomotor is stopped.

Power supply to the Servomotor will be stopped immediately when an alarm occurs, regardless of the setting of this parameter. The machine moving part may move due to gravity or an external force before the brake is applied. Important

### 5.12.4 Output Timing of /BK (Brake) Signal When the Servomotor Is Operating

If an alarm occurs while the Servomotor is operating, the Servomotor will start stopping and the /BK signal will be turned OFF. You can adjust the timing of /BK signal output by setting the brake reference output speed level (Rotary Servomotors: Pn507, Linear Servomotors: Pn583) and the Servo OFF-Brake Command Waiting Time (Pn508).

Note: If zero-speed stopping is set as the stopping method for alarms, the setting of Pn506 (Brake Reference-Servo OFF Delay Time) is used after the motor stops.

#### 5.12.4 Output Timing of /BK (Brake) Signal When the Servomotor Is Operating

• Rotary Servomotors

Pn507	Brake Reference Ou	utput Speed Level	Speed Positi	on Torque	
	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 10,000	1 min <sup>-1</sup>	100	Immediately	Setup
Pn508	Servo OFF-Brake C	ommand Waiting Tir	Speed Positi	on Torque	
	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	10 to 100	10 ms	50	Immediately	Setup

Linear Servomotors

Pn583	Brake Reference Ou	utput Speed Level	Speed Positi	on Force	
	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 10,000 1 mm/s 10		10	Immediately	Setup
Pn508	Servo OFF-Brake C	ommand Waiting Ti	Speed Positi	on Force	
	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	10 to 100	10 ms	50	Immediately	Setup

The brake operates when either of the following conditions is satisfied:

• When the Motor Speed Goes below the Level Set in Pn507 for a Rotary Servomotor or in Pn583 for a Linear Servomotor after the Power Supply to the Motor Is Stopped



• When the Time Set In Pn508 Elapses after the Power Supply to the Motor Is Stopped



Important

The Servomotor will be limited to its maximum speed even if the brake reference output speed level (Rotary Servomotor: Pn507, Linear Servomotor: Pn583) is higher than the maximum speed.

5.13.1 Stopping Method for Servo OFF

## 5.13 Motor Stopping Methods for Servo OFF and Alarms

You can use the following methods to stop the Servomotor when the servo is turned OFF or an alarm occurs.

There are the following four stopping methods.

Motor Stopping Method	Meaning
Stopping by Applying the Dynamic Brake	The electric circuits are internally connected to stop the Servomotor quickly.
Coasting to a Stop	The motor stops naturally due to friction during operation.
Zero Clamping	The speed reference is set to 0 to stop the Servomotor quickly.
Decelerating to a Stop	Emergency stop torque is used to decelerate the motor to a stop.

There are the following three conditions after stopping.

Status after Stopping	Meaning
Dynamic Brake Applied	The electric circuits are internally connected to hold the Servomotor.
Coasting	The SERVOPACK does not control the Servomotor. (The machine will move in response to a force from the load.)
Zero Clamping	A position loop is created and the Servomotor remains stopped at a position reference of 0. (The current stop position is held.)

È CON	• The dynamic brake is used for emergency stops. The dynamic brake circuit will operate fre- quently if the power supply is turned ON and OFF or the servo is turned ON and OFF while a reference input is applied to start and stop the Servomotor. This may result in deterioration of the internal elements in the SERVOPACK. Use speed input references or position references to start and stop the Servomotor.
	<ul> <li>If you turn OFF the main circuit power supply or control power supply during operation before you turn OFF the servo, the Servomotor will stop with the dynamic brake. You cannot change this by setting a parameter.</li> </ul>
	• If the Servomotor must be stopped by coasting rather than with the dynamic brake when the main circuit power supply or the control power supply is turned OFF before the servo is turned OFF, use a Servomotor that has the dynamic brake option.
	• To minimize the coasting distance of the Servomotor to come to a stop when an alarm occurs, zero-speed stopping is the default method for alarms to which it is applicable. However, depending on the application, stopping with the dynamic brake may be more suitable than

zero-speed stopping. For example, when coupling two shafts (twin-drive operation), machine damage may occur if a zero-speed stopping alarm occurs for one of the coupled shafts and the other shaft stops with a dynamic brake. In such cases, change the stopping method to the dynamic brake.

## 5.13.1 Stopping Method for Servo OFF

Set the stopping method for when the servo is turned OFF in Pn001 =  $n.\Box\Box\BoxX$  (Motor Stopping Method for Servo OFF and Group 1 Alarms).

Parameter		Servomotor Stop- ping Method	Status after Servo- motor Stops	When Enabled	Classifi- cation
D=001	n.□□□0 (default setting)	Dynamic brake	Dynamic brake	After restart	
Phuui	n.0001		Coasting	After restart	Setup
	n.□□□2	Coasting	Coasting		

Note: If Pn001 is set to n. DDD (Stop the motor by applying the dynamic brake) and the Servomotor is stopped or operates at a low speed, braking force may not be generated, just like it is not generated for coasting to a stop.

5.13.2 Servomotor Stopping Method for Alarms

## 5.13.2 Servomotor Stopping Method for Alarms

There are two types of alarms, group 1 (Gr. 1) alarms and group 2 (Gr. 2) alarms. A different parameter is used to set the stopping method for alarms for each alarm type.

Refer to the following section to see which alarms are in group 1 and which are in group 2. (3) 10.2.1 List of Alarms on page 10-5

## Motor Stopping Method for Group 1 Alarms

When a group 1 alarm occurs, the Servomotor will stop according to the setting of  $Pn001 = n.\Box\Box\BoxX$ . The default setting is to stop by applying the dynamic brake.

Refer to the following section for details.

5.13.1 Stopping Method for Servo OFF on page 5-37

## Motor Stopping Method for Group 2 Alarms

When a group 2 alarm occurs, the Servomotor will stop according to the settings of the following three parameters. The default setting is for zero clamping.

- Pn001 = n. DDDX (Motor Stopping Method for Servo OFF and Group 1 Alarms)
- Pn00A = n. DDDX (Motor Stopping Method for Group 2 Alarms)
- Pn00B = n. DDXD (Motor Stopping Method for Group 2 Alarms)

However, during torque control, the group 1 stopping method is always used. If you set Pn00B to n.  $\Box\Box$ 1 $\Box$  (Apply dynamic brake or coast Servomotor to a stop), you can use the same stopping method as group 1. If you are coordinating a number of Servomotors, you can use this stopping method to prevent machine damage that may result because of differences in the stopping method.

The following table shows the combinations of the parameter settings and the resulting stopping methods.

#### 5.13.2 Servomotor Stopping Method for Alarms

Parameter			Servomotor	Status after	When	
Pn00B	Pn00A	Pn001	Stopping Method	Servomotor Stops	Enabled	Classification
n.□□0□ (default setting)	-	n.□□□0 (default setting)	Zero-speed stop- ping	Dynamic brake		
		n.□□□1		Coasting		
		n.0002				
n.0010	-	n.□□□0 (default setting)	Dynamic brake     Dynamic brake       Coasting     Coasting	Dynamic brake		
		n.□□□1		Coasting		
		n.🗆 🗆 🗠 2				
n.0020	n.ロロロ0 (default setting)	n.□□□0 (default setting)	Dynamic brake	Dynamic brake	- After restart	Setup
		n.0001		Coacting		
		n.🗆 🗆 🗠 2	Coasting	Coasting		
	n.0001	n.□□□0 (default setting)	Motor is deceler- ated using the torque set in Pn406 as the maximum torque.	Dynamic brake		
		n.0001		Coasting		
		n.🗆 🗆 🗠 2				
	n.0002	n.□□□0 (default setting)		Coasting		
		n.0001				
		n.0002				
	n.□□□3	n.□□□0 (default setting)	Motor is deceler- ated according to setting of Pn30A.	Dynamic brake		
		n.🗆 🗆 🗆 1		Coasting		
		n.□□□2				
	n.0004	n.□□□0 (default setting)		Coasting		
		n.0001				
		n.0002				

Note: 1. The setting of Pn00A is ignored if Pn001 is set to n. DDD or n. DD1D.

2. The setting of Pn00A = n. TIMEX is enabled for position control and speed control. During torque control, the setting of Pn00A = n. TIMEX will be ignored and only the setting of Pn001 = n. TIMEX will be used.

3. Refer to the following section for details on Pn406 (Emergency Stop Torque).

Stopping the Servomotor by Setting Emergency Stop Torque on page 5-31

4. Refer to the following section for details on Pn30A (Deceleration Time for Servo OFF and Forced Stops). Stopping the Servomotor by Setting the Deceleration Time on page 5-31
5.14.1 Detection Timing for Overload Warnings (A.910)

# 5.14 Motor Overload Detection Level

The motor overload detection level is the threshold used to detect overload alarms and overload warnings when the Servomotor is subjected to a continuous load that exceeds the Servomotor ratings.

It is designed to prevent Servomotor overheating.

You can change the detection timing for A.910 warnings (Overload) and A.720 alarms (Continuous Overload). You cannot change the detection level for A.710 alarms (Instantaneous Overload).

# 5.14.1 Detection Timing for Overload Warnings (A.910)

With the default setting for overload warnings, an overload warning is detected in 20% of the time required to detect an overload alarm. You can change the time required to detect an overload warning by changing the setting of the overload warning level (Pn52B). You can increase safety by using overload warning detection as an overload protection function matched to the system.

The following graph shows an example of the detection of overload warnings when the overload warning level (Pn52B) is changed from 20% to 50%. An overload warning is detected in half of the time required to detect an overload alarm.



	Overload Warning Level			Speed Position	Torque
Pn52B	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	1 to 100	1%	20	Immediately	Setup

5.14.2 Detection Timing for Overload Alarms (A.720)

# 5.14.2 Detection Timing for Overload Alarms (A.720)

If Servomotor heat dissipation is insufficient (e.g., if the heat sink is too small), you can lower the overload alarm detection level to help prevent overheating.

To reduce the overload alarm detection level, change the setting of Pn52C (Base Current Derating at Motor Overload Detection).

	Base Current Derating at Motor Overload Detection         Speed         Position				
Pn52C	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	10 to 100	1%	100	After restart	Setup

An A.720 alarm (Continuous Overload) can be detected earlier to protect the Servomotor from overloading.



Note: The gray areas in the above graph show where A.710 and A.720 alarms occur.

Refer to the relevant manual given below for a diagram that shows the relationships between the motor heat dissipation conditions (heat sink size, surrounding air temperature, and derating). You can protect the motor from overloads more effectively by setting this derating value in Pn52C.

 $\square$   $\Sigma$ -7-Series Rotary Servomotor Product Manual (Manual No.: SIEP S800001 36)

Ω Σ-7-Series Linear Servomotor Product Manual (Manual No.: SIEP S800001 37)

Ω Σ-7-Series Direct Drive Servomotor Product Manual (Manual No.: SIEP S800001 38)

# 5.15 Electronic Gear Settings

The minimum unit of the position data that is used to move a load is called the reference unit. The reference unit is used to give travel amounts, not in pulses, but rather in distances or other physical units (such as  $\mu$ m or °) that are easier to understand.

The electronic gear is used to convert the travel distances that are specified in reference units to pulses, which are required for actual movements.

With the electronic gear, one reference unit is equal to the workpiece travel distance per reference pulse input to the SERVOPACK. In other words, if you use the SERVOPACK's electronic gear, pulses can be read as reference units.

Note: If you set an electronic gear in the host controller, normally set the electronic gear ratio in the SERVOPACK to 1:1.

The difference between using and not using the electronic gear is shown below.

#### Rotary Servomotors

In this example, the following machine configuration is used to move the workpiece 10 mm.



When the Electronic Gear Is Not Used



Calculating the number of reference pulses for each reference is troublesome.

When the Electronic Gear Is Used

If you use reference units to move the workpiece when one reference unit is set to 1  $\mu$ m, the travel distance is 1  $\mu$ m per pulse. To move the workpiece 10 mm (10,000  $\mu$ m), 10,000 ÷ 1 = 10,000 pulses, so 10,000 pulses would be input.

Calculating the number of reference pulses for each reference is not necessary.

#### Linear Servomotors

In this example, the following machine configuration is used to move the load 10 mm. We'll assume that the resolution of the Serial Converter Unit is 256 and that the linear encoder pitch is 20  $\mu$ m.

inear encoder

When the Electronic Gear Is Not Used





Calculating the number of reference pulses for each reference is trouble-some.

When the Electronic Gear Is Used

To use reference units to move the load 10 mm: If we set the reference unit to 1  $\mu$ m, the travel distance is 1  $\mu$ m per pulse. To move the load 10 mm (10,000  $\mu$ m), 10,000/1 = 10,000 pulses, so 10,000 pulses would be input as the reference.

Calculating the number of reference pulses for each reference is not necessary.

## 5.15.1 Electronic Gear Ratio Settings

Set the electronic gear ratio using Pn20E and Pn210.

<ul> <li>Pn040 = n.□□0□ (Use the encoder resolution of the connected motor.) Set the electronic gear ratio within the following range. 0.001 ≤ Electronic gear ratio (B/A) ≤ 64,000 If the electronic gear ratio is outside of this range, an A.040 alarm (Parameter Setting Error) with occur.</li> <li>Pn040 = n.□□1□ (Use a resolution of 20 bits when connected to an SGM7J, SGM7A, or SGM7G motor.) Set the electronic gear ratio within the following range. 0.001 ≤ Electronic gear ratio (B/A) ≤ 4,000 If the electronic gear ratio is outside of this range, an A.040 alarm (Parameter Setting Error) work of the electronic gear ratio is outside of this range, an A.040 alarm (Parameter Setting Error) work of the electronic gear ratio is outside of this range, an A.040 alarm (Parameter Setting Error) work of the electronic gear ratio is outside of this range, an A.040 alarm (Parameter Setting Error) work of the electronic gear ratio is outside of this range, an A.040 alarm (Parameter Setting Error) work of the electronic gear ratio is outside of the range, an A.040 alarm (Parameter Setting Error) work of the electronic gear ratio is outside of the range, an A.040 alarm (Parameter Setting Error) work of the electronic gear ratio is outside of the range, an A.040 alarm (Parameter Setting Error) work of the electronic gear ratio is outside of the range, and A.040 alarm (Parameter Setting Error) work of the electronic gear ratio is outside of the range, and A.040 alarm (Parameter Setting Error) work of the electronic gear ratio is outside of the range, and A.040 alarm (Parameter Setting Error) work of the electronic gear ratio is outside of the range, and A.040 alarm (Parameter Setting Error) work of the electronic gear ratio is outside of the range, and A.040 alarm (Parameter Setting Error) work of the electronic gear ratio is outside of the range of th</li></ul>	Important	<ul> <li>The setting range of the electronic gear depends on the setting of Pn040 = n.□□X□ (Encoder Resolution Compatibility Selection).</li> <li>Pn040 = n.□□0□ (Use the encoder resolution of the connected motor.) Set the electronic gear ratio within the following range.</li> <li>0.001 ≤ Electronic gear ratio (B/A) ≤ 64,000 If the electronic gear ratio is outside of this range, an A.040 alarm (Parameter Setting Error) will occur.</li> <li>Pn040 = n.□□1□ (Use a resolution of 20 bits when connected to an SGM7J, SGM7A, or SGM7G motor.) Set the electronic gear ratio within the following range.</li> <li>0.001 ≤ Electronic gear ratio (B/A) ≤ 4,000 If the electronic gear ratio within the following range.</li> <li>0.001 ≤ Electronic gear ratio within the following range.</li> <li>0.001 ≤ Electronic gear ratio (B/A) ≤ 4,000 If the electronic gear ratio is outside of this range, an A.040 alarm (Parameter Setting Error) will occur.</li> </ul>
---	-----------	---

	Electronic Gear Rati	io (Numerator)		Position	I	
Pn20E	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	1 to 1,073,741,824	1	16	After restart	Setup	
	Electronic Gear Ratio (Denominator)			Position		
Pn210	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	1 to 1,073,741,824	1	1	After restart	Setup	

### Calculating the Settings for the Electronic Gear Ratio

#### Rotary Servomotors

If the gear ratio between the Servomotor shaft and the load is given as n/m, where n is the number of load rotations for m Servomotor shaft rotations, the settings for the electronic gear ratio can be calculated as follows:

Electronic gear ratio  $\frac{B}{A} = \frac{Pn20E}{Pn210} = \frac{Encoder resolution}{Travel distance per load shaft revolution (reference units)} \times \frac{m}{n}$ 

#### Encoder Resolution

You can check the encoder resolution in the Servomotor model number.

SGM7J, SGM7A,

SGM7P, or SGM7G -

 Code	Specification	Encoder Resolution
7	24-bit multiturn absolute encoder	16,777,216
F	24-bit incremental encoder	16,777,216

#### 

 Code	Specification	Encoder Resolution
3	20-bit single-turn absolute encoder	1,048,576
D	20-bit incremental encoder	1,048,576

 Code	Specification	Encoder Resolution
Е	22-bit single-turn absolute encoder	4,194,304
I	22-bit multiturn absolute encoder	4,194,304

5.15.1 Electronic Gear Ratio Settings

#### Linear Servomotors

You can calculate the settings for the electronic gear ratio with the following equation: When Not Using a Serial Converter Unit

Use the following formula if the linear encoder and SERVOPACK are connected directly or if a linear encoder that does not require a Serial Converter Unit is used.

 $Electronic \ gear \ ratio \frac{B}{A} = \frac{Pn20E}{Pn210} = \frac{Travel \ distance \ per \ reference \ unit \ (reference \ units) \times Linear \ encoder \ resolution}{Linear \ encoder \ pitch \ (the \ value \ from \ the \ following \ table)}$ 

When Using a Serial Converter Unit

Electronic gear ratio  $\frac{B}{A} = \frac{Pn20E}{Pn210} = \frac{Travel distance per reference unit (reference units) × Resolution of the Serial Converter Unit Linear encoder pitch (setting of Pn282)$ 

#### Feedback Resolution of Linear Encoder

The linear encoder pitches and resolutions are given in the following table. Calculate the electronic gear ratio using the values in the following table.

Type of Linear Encoder	Manufacturer	Linear Encoder Model	Linear Encoder Pitch [µm]	Model of Serial Con- verter Unit or Model of Interpolator	Resolution	Resolution
			20	JZDP-H003- <b>DDD</b> -E <sup>*1</sup>	256	0.078 μm
	Heidenhain		20	JZDP-J003- <b>DD</b> -E <sup>*1</sup>	4,096	0.0049 µm
	Corporation		4	JZDP-H003- <b>DDD</b> -E <sup>*1</sup>	256	0.016 µm
			4	JZDP-J003- <b>DD</b> -E <sup>*1</sup>	4,096	0.00098 µm
	Renishaw	DOUDOD	20	JZDP-H005- <b>DDD</b> -E <sup>*1</sup>	256	0.078 μm
	PLC	RGHZZD	20	JZDP-J005- <b>DDD</b> -E*1	4,096	0.0049 µm
Incremen-		SR75-DDDDDLF	80	_	8,192	0.0098 µm
tal		SR75-DDDDDMF	80	-	1,024	0.078 μm
		SR85-DDDDDLF	80	-	8,192	0.0098 µm
	Magnescale Co., Ltd.	SR85-DDDDDMF	80	-	1,024	0.078 μm
		SL700, SL710, SL720 <sup>,</sup> SL730	800	PL101-RY*2 MJ620-T13*3	0.100	0.0077
			800		0,192	0.0977 µm
		SQ10	400	MQ10-FLA*3	0100	0.0488 µm
				MQ10-GLA*3	0192	
	Heidenhain	LIC4100 Series	20.48	EIB3391Y*3	4,096	0.005 μm
	Corporation	LC115	40.96	EIB3381Y*3	4,096	0.01 µm
		ST781A/ST781AL	256	_	512	0.5 µm
		ST782A/ST782AL	256	-	512	0.5 µm
		ST783/ST783AL	51.2	-	512	0.1 µm
	Mitutoyo	ST784/ST784AL	51.2	-	512	0.1 µm
Absolute	Corporation	ST788A/ST788AL	51.2	_	512	0.1 µm
Absolute		ST789A/ST789AL	25.6	_	512	0.05 μm
		ST1381	5.12	_	512	0.01 µm
		ST1382	0.512	_	512	0.001 µm
		SR77-DDDDDLF	80	-	8,192	0.0098 µm
	Magnescale	SR77-DDDDDMF	80	_	1,024	0.078 μm
	Co., Ltd.	SR87-DDDDDLF	80	-	8,192	0.0098 μm
		SR87-DDDDDMF	80	_	1,024	0.078 µm

\*1. This is the model of the Serial Converter Unit.

\*2. This is the model of the Head with Interpolator.

\*3. This is the model of the Interpolator.

#### 5.15.2 Electronic Gear Ratio Setting Examples

#### Resolution Information

You can calculate the resolution that is used inside the SERVOPACK (i.e., the travel distance per feedback pulse) with the following formula.

Linear encoder pitch Resolution (travel distance per feedback pulse) =

Resolution of Serial Converter Unit or linear encoder

The SERVOPACK uses feedback pulses as the unit to control a Servomotor.



Linear encoder pitch =Distance for one cycle of the analog voltage feedback signal from the linear encoder

Linear encoder pitch

#### 5.15.2 **Electronic Gear Ratio Setting Examples**

Setting examples are provided in this section.

Rotary Servomotors

			Machine Configuration		
		Ball Screw	Rotary Table	Belt and Pulley	
Step Description		Reference unit: 0.001 mm Load shaft Load shaft Encoder: Ball screw lead: 24 bits 6 mm	Reference unit: 0.01° Gear ratio: 1/100 Load shaft Encoder: 24 bits	Reference unit: 0.005 mm Load shaft Gear ratio: 1/50 Pulley dia.: 100 mm Encoder: 24 bits	
1	Machine Specifications	<ul> <li>Ball screw lead: 6 mm</li> <li>Gear ratio: 1/1</li> </ul>	<ul> <li>Rotation angle per revolution: 360°</li> <li>Gear ratio: 1/100</li> </ul>	<ul> <li>Pulley dia.: 100 mm (Pulley circumference: 314 mm)</li> <li>Gear ratio: 1/50</li> </ul>	
2	Encoder Resolution	16,777,216 (24 bits)	16,777,216 (24 bits)	16,777,216 (24 bits)	
3	Reference Unit	0.001 mm (1 μm)	0.01°	0.005 mm (5 μm)	
4	Travel Distance per Load Shaft Revolution (Reference Units)	6 mm/0.001 mm = 6,000	360°/0.01° = 36,000	314 mm/0.005 mm = 62,800	
5	Electronic Gear Ratio	$\frac{B}{A} = \frac{16,777,216}{6,000} \times \frac{1}{1}$	$\frac{B}{A} = \frac{16,777,216}{36,000} \times \frac{100}{1}$	$\frac{B}{A} = \frac{16,777,216}{62,800} \times \frac{50}{1}$	
6	Parameters	Pn20E: 16,777,216	Pn20E: 167,772,160	Pn20E: 838,860,800	
0		Pn210: 6,000	Pn210: 3,600	Pn210: 62,800	

#### Linear Servomotors

A setting example for a Serial Converter Unit resolution of 256 is given below.

		Machine Configuration
Step	Description	Reference unit: 0.02 mm (20 µm) Forward direction
1	Linear encoder pitch	0.02 mm (20 μm)
2	Reference Unit	0.001 mm (1 μm)
3	Electronic Gear Ratio	$\frac{B}{A} = \frac{1 (\mu m)}{20 (\mu m)} \times 256$
Λ	Setting Parameters	Pn20E: 256
-	Cetting Farameters	Pn210: 20

5

5-45

5.16.1 Precautions on Resetting

# 5.16 Resetting the Absolute Encoder

In a system that uses an absolute encoder, the multiturn data must be reset at startup. An alarm related to the absolute encoder (A.810 or A.820) will occur when the absolute encoder must be reset, such as when the power supply is turned ON.

When you reset the absolute encoder, the multiturn data is reset and any alarms related to the absolute encoder are cleared.

Reset the absolute encoder in the following cases.

- When starting the system for the first time
- When an A.810 alarm (Encoder Backup Alarm) occurs
- When an A.820 alarm (Encoder Checksum Alarm) occurs
- When you want to reset the multiturn data in the absolute encoder



Information

The multiturn data will always be zero in the following cases. It is never necessary to reset the absolute encoder in these cases.

- · When you use a single-turn absolute encoder
- When the encoder is set to be used as a single-turn absolute encoder (Pn002 =  $n.\Box 2\Box \Box$ ) Also, an alarm related to the absolute encoder (A.810 or A.820) will not occur.

### 5.16.1 Precautions on Resetting

- You cannot use the ALM\_CLR (Clear Alarm) command from the SERVOPACK to clear the A.810 alarm (Encoder Backup Alarm) or the A.820 alarm (Encoder Checksum Alarm). Always use the operation to reset the absolute encoder to clear these alarms.
- If an A.8 alarm (Internal Encoder Monitoring Alarm) occurs, turn OFF the power supply to reset the alarm.

#### 5.16.2 Preparations

Always check the following before you reset an absolute encoder.

- The parameters must not be write prohibited.
- The servo must be OFF.

# 5.16.3 Applicable Tools

The following table lists the tools that you can use to reset the absolute encoder and the applicable tool functions.

Tool	Function	Reference
Digital Operator	Fn008	Ω Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Setup – Absolute Encoder Reset	I 5.16.4 Operating Procedure on page 5-47

Information You can reset the absolute encoder using the MEM\_WR (Write Memory) command. Refer to the following manual for information on the MEM\_WR (Write Memory) command.

Σ-7-Series MECHATROLINK-III Communications Standard Servo Profile Command Manual (Manual No.: SIEP S800001 31)

# 5.16.4 Operating Procedure

Use the following procedure to reset the absolute encoder.

- 1. Confirm that the servo is OFF.
- 2. Click the 🔎 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **3.** Select Absolute Encoder Reset in the Menu Dialog Box. The Absolute Encoder Reset Dialog Box will be displayed.
- 4. Click the Continue Button.

Absolute Encoder Warning
The Setup Absolute Encoder resets the multiturn amount of the connected serial-type absolute encoder as well as encoder alarms from the PC.
Upon resetting the absolute encoder multiturn to "0", the mechanical system will go to a position data system differing from that used until now.
Operating the machine in this state is extremely dangerous(In the worst case, my lead to injury to person or damage to machine). Be sure to reset the zero point of the machine after completing this process.
Continue absolute encoder setup processing?
Continue

Click the **Cancel** Button to cancel resetting the absolute encoder. The Main Window will return.

5. Click the Execute setting Button.

Absolute encoder - Setup AXIS#00	×
Perform absolute encoder setup under the following circumstance 1. At first start-up of the machine 2. When an "encoder backup alarm" has been generated 3. After the Servopack power has been turned OFF and the enco cable removed	⊧s: oder
Absolute encoder setup can only be performed with the Restart pe after setup processing is complete.	ower
Alarm name A.810 : Encoder Backup Alarm	_
Execute setting	

The current alarm code and name will be displayed in the Alarm name Box.

#### 5.16.4 Operating Procedure

6. Click the Continue Button.



Click the Cancel Button to cancel resetting the absolute encoder. The previous dialog box will return.

#### 7. Click the OK Button.

The absolute encoder will be reset.

#### When Resetting Fails

If you attempted to reset the absolute encoder when the servo was ON in the SERVOPACK, the following dialog box will be displayed and processing will be canceled.

Absolute (	encoder reset conditions error
4	Servo ON now. Tum the Servo OFF when resetting the absolute encoder.
	ОК

Click the **OK** Button. The Main Window will return. Turn OFF the servo and repeat the procedure from step 1.

#### When Resetting Is Successful

The following dialog box will be displayed when the absolute encoder has been reset.

Completion Warning Message
Absolute Encoder reset processing has been performed. The Multiturn amount in the absolute encoder has been to "0". Be sure to reset the mechanical system to "0" after restarting power.
ОК

The Main Window will return.

**8.** To enable the change to the settings, turn the power supply to the SERVOPACK OFF and ON again.

This concludes the procedure to reset the absolute encoder.

5.17.1 Absolute Encoder Origin Offset

# 5.17 Setting the Origin of the Absolute Encoder

# 5.17.1 Absolute Encoder Origin Offset

The origin offset of the absolute encoder is a correction that is used to set the origin of the machine coordinate system in addition to the origin of the absolute encoder. Set the offset between the absolute encoder origin and the machine coordinate system origin in Pn808 (Absolute Encoder Origin Offset).

After the SENS\_ON (Absolute Data Request) command is received, the position in the machine coordinate system (APOS) is set based on the absolute encoder position data and the setting of Pn808.

	Absolute Encoder Origin Offset			Position	
Pn808	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	-1,073,741,823 to 1,073,741,823	1 reference unit	0	Immediately	Setup



If the encoder position (X) is at the origin of the machine coordinate system (0), then Pn808 would be set to -X.



# 5.17.2 Setting the Origin of the Absolute Linear Encoder

You can set any position as the origin in the following Linear Encoders.

 Mitutoyo Corporation ABS ST780A Series or ST1300 Series Models: ABS ST78□A/ST78□AL/ST13□□



 After you set the origin, the /S-RDY (Servo Ready) signal will become inactive because the system position data was changed. Always turn the SERVOPACK power supply OFF and ON again.

After you set the origin, the Servomotor phase data in the SERVOPACK will be discarded. If you are using a Linear Servomotor without a Polarity Sensor, execute polarity detection again to save the Servomotor phase data in the SERVOPACK.

### Preparations

Always check the following before you set the origin of an absolute encoder.

- The parameters must not be write prohibited.
- The servo must be OFF.

5.17.2 Setting the Origin of the Absolute Linear Encoder

### **Applicable Tools**

The following table lists the tools that you can use to set the origin of the absolute linear encoder and the applicable tool functions.

Tool	Function	Reference
Digital Operator	Fn020	Ω Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Setup - Set Origin	Jervice Operating Procedure on page 5-50

#### **Operating Procedure**

Use the following procedure to set the origin of an absolute linear encoder.

- 1. Click the 🔎 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Set Origin in the Menu Dialog Box. The Set Origin Dialog Box will be displayed.
- 3. Click the Continue Button.



4. Click the Execute Button.



5.17.2 Setting the Origin of the Absolute Linear Encoder

5. Click the Continue Button.



Click the **Cancel** Button to cancel setting the origin of the absolute linear encoder. The previous dialog box will return.

6. Click the OK Button.

Set Origin
Zero-point position setting has been executed. The movement amount saved in the encoder has been reset to 0 (zero). Always turn the power to the Servopack off and then on again after execution of this function.
When using a linear motor without a hall sensor, execute polarity detection after turning the power off and then on again
ОК

- 7. Turn the power supply to the SERVOPACK OFF and ON again.
- 8. If you use a Linear Servomotor that does not have a polarity sensor, perform polarity detection.
   Refer to the following section for details on the polarity detection.
   \$\vec{2}\$ 5.10 Polarity Detection on page 5-26

This concludes the procedure to set the origin of the absolute linear encoder.

# 5.18 Setting the Regenerative Resistor Capacity

The regenerative resistor consumes regenerative energy that is generated by the Servomotor, e.g., when the Servomotor decelerates.

If an External Regenerative Resistor is connected, you must set Pn600 (Regenerative Resistor Capacity) and Pn603 (Regenerative Resistance).

- **WARNING**
- If you connect an External Regenerative Resistor, set Pn600 and Pn603 to suitable values. If a suitable value is not set, A.320 alarms (Regenerative Overload) will not be detected correctly, and the External Regenerative Resistor may be damaged or personal injury or fire may result.
- When you select an External Regenerative Resistor, make sure that it has a suitable capacity.

There is a risk of personal injury or fire.

	Regenerative Resistor Capacity			Speed Position Torque		
	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
Pn600 All Axes	0 to 2 times the SERVOPACK's maximum applica- ble motor capacity	10 W	0	Immediately	Setup	
Decoo	Regenerative Resistance			Speed Pos	sition Torque	
	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
,, 0.000	0 to 65,535	10 mΩ	0	Immediately	Setup	

Set the regenerative resistor capacity to a value that is consistent with the allowable capacity of the External Regenerative Resistor. The setting depends on the cooling conditions of the External Regenerative Resistor.

- For self-cooling (natural convection cooling): Set the parameter to a maximum 20% of the capacity (W) of the actually installed regenerative resistor.
- For forced-air cooling: Set the parameter to a maximum 50% of the capacity (W) of the actually installed regenerative resistor.



For a self-cooling 100-W External Regenerative Resistor, set Pn600 to 2 (×10 W) (100 W × 20% = 20 W).

Note: 1. An A.320 alarm will be displayed if the setting is not suitable.

2. The default setting of 0 specifies that the SERVOPACK's built-in regenerative resistor or Yaskawa's Regenerative Resistor Unit is being used.



1. When an External Regenerative Resistor is used at the normal rated load ratio, the resistor temperature increases to between 200°C and 300°C. Always apply derating. Consult the manufacturer for the resistor's load characteristics.

2. For safety, use an External Regenerative Resistor with a thermoswitch.

# Application Functions

This chapter describes the application functions that you can set before you start servo system operation. It also describes the setting methods.

6.1	I/O Si	gnal Allocations6-3
	$\begin{array}{c} 6.1.1 \\ 6.1.2 \\ 6.1.3 \\ 6.1.4 \\ 6.1.5 \\ 6.1.6 \\ 6.1.7 \\ 6.1.8 \\ 6.1.9 \end{array}$	Input Signal Allocations6-3Output Signal Allocations6-6ALM (Servo Alarm) Signal6-9/WARN (Warning) Signal6-9/TGON (Rotation Detection) Signal6-10/S-RDY (Servo Ready) Signal6-11/V-CMP (Speed Coincidence Detection)5Signal6-11/COIN (Positioning Completion) Signal6-13/NEAR (Near) Signal6-14
	6.1.10	Speed Limit during Torque Control
6.2	Opera	tion for Momentary Power Interruptions6-17
6.3	SEMI	F47 Function6-18
6.3 6.4	SEMI Settin	F47 Function6-18ag the Motor Maximum Speed6-20
6.3 6.4 6.5	SEMI Settin	F47 Function6-18ag the Motor Maximum Speed6-20vare Limits6-21
<ul><li>6.3</li><li>6.4</li><li>6.5</li></ul>	SEMI Settin Softw 6.5.1 6.5.2 6.5.3	F47 Function       6-18         ag the Motor Maximum Speed       6-20         vare Limits       6-21         Setting to Enable/Disable Software Limits       6-21         Setting the Software Limits       6-21         Software Limit Check for References       6-21
<ul><li>6.3</li><li>6.4</li><li>6.5</li><li>6.6</li></ul>	Settin Softw 6.5.1 6.5.2 6.5.3 Selec	F47 Function       6-18         ag the Motor Maximum Speed       6-20         vare Limits       6-21         Setting to Enable/Disable Software Limits       6-21         Setting the Software Limits       6-21         Software Limit Check for References       6-21         ting Torque Limits       6-22

6.7	Absol	ute Encoders6	6-27
	6.7.1 6.7.2	Connecting an Absolute Encoder Structure of the Position Data of the Absolute	.6-27 6-28
	6.7.3	Reading the Position Data from the Absolute Encoder	.6-28
	6.7.4 6.7.5	Multiturn Limit Setting	.6-28 .6-30
6.8	Absol	ute Linear Encoders	6-33
	6.8.1 6.8.2	Connecting an Absolute Linear Encoder Structure of the Position Data of the Absolute	.6-33
	6.8.3	Linear Encoder	.6-33
	o ()		
6.9	Softw	are Reset	5-34
	6.9.1 6.9.2 6.9.3	Preparations	.6-34 .6-34 .6-35
6.10	Initiali	zing the Vibration Detection Level	6-37
	6.10.1 6.10.2 6.10.3 6.10.4	Preparations Applicable Tools Operating Procedure Related Parameters	.6-37 .6-38 .6-38 .6-40
6.11	Adjustir	ng the Motor Current Detection Signal Offset	6-41
	6.11.1 6.11.2	Automatic Adjustment	.6-41 .6-43
6.12	Forcing	the Motor to Stop	6-45
	6.12.1 6.12.2	FSTP (Forced Stop Input) Signal	.6-45
	6.12.3	Stops         Resetting Method for Forced Stops	.6-45 .6-47

#### 6.1.1 Input Signal Allocations

# 6.1 I/O Signal Allocations

Functions are allocated to the pins on the I/O signal connector (CN1) in advance. You can change the allocations and the polarity for some of the connector pins. Function allocations and polarity settings are made with parameters.

This section describes the I/O signal allocations.

There are the following two methods to allocate I/O signals.

Allocation Method	Description	Benefits
Σ-7S-Compatible I/O Signal Alloca- tions	Predetermined combinations of I/O signals, pin numbers, and polarities are provided and you can specify the required combina- tion with a parameter.	Compatibility with $\Sigma$ -7S SERVOPACKs
Multi-Axis I/O Signal Allocations	You can specify the pin number to allocate for each I/O signal.	There are no restrictions in the combina- tions of I/O signals and pin numbers, allowing for flexible signal allocations.

Specify the allocation method to use in  $Pn50A = n.\Box \Box \Box X$  (I/O Signal Allocation Mode).

Parameter		Description	When Enabled	Classification
Pn50A	n.□□□1 (default set- ting)	$\Sigma$ -7S-compatible I/O signal allocations	After startup	Setup
	n.🗆 🗆 🗠 2	Multi-axis I/O signal allocations		

# 6.1.1 Input Signal Allocations

- If you change the default polarity settings for the P-OT (Forward Drive Prohibit) or N-OT (Reverse Drive Prohibit) signal, the overtravel function will not operate if there are signal line disconnections or other problems. If you must change the polarity of one of these signals, verify operation and make sure that no safety problems will exist.
  - If you allocate two or more signals to the same input circuit, a logical OR of the inputs will be used and all of the allocated signals will operate accordingly. This may result in unexpected operation.

### **Σ-7S-Compatible Input Signal Allocations**

The input signals that you can allocate to the pins on the I/O signal connector (CN1) and the related parameters are given in the following table.

Input Signal	Input Signal Name	Parameter
P-OT	Forward Drive Prohibit	Pn50A = n.X□□□
N-OT	Reverse Drive Prohibit	Pn50B = n.□□□X
/P-CL	Forward External Torque Limit	Pn50B = n.□X□□
/N-CL	Reverse External Torque Limit	Pn50B = n.X□□□
/DEC	Origin Return Deceleration Switch Input	Pn511 = n.□□□X
/EXT1	External Latch Input 1	Pn511 = n.□□X□
/EXT2	External Latch Input 2	Pn511 = n.□X□□
/EXT3	External Latch Input 3	Pn511 = n.X□□□
FSTP	Forced Stop	Pn516 = n.□□□X

6.1.1 Input Signal Allocations

#### Relationship between Parameter Settings, Allocated Pins, and Polarities

The following table shows the relationship between the input signal parameter settings, the pins on the I/O signal connector (CN1), and polarities.

Parameter	Pin No.		Description	
Setting	Axis A	Axis B	Description	
0	3	9	124.1/	
1	4	10		
2	5	11		
3	6	12	A reverse signal (a signal with "/" before the signal abbreviation, such as the /	
4	7	13	A signal that does not have "/" before the signal abbreviation (such as the P-	
5	8	14	OT signal) is active when the contacts are OFF (open).	
6	-	-	Reserved setting (Do not use.)	
7	_	_	The input signal is not allocated to a connector pin and it is always active. If the signal is processed on a signal edge, then it is always inactive.	
8	_	_	The input signal is not allocated to a connector pin and it is always inactive. Set the parameter to 8 if the signal is not used.	
9	3	9		
А	4	10		
В	5	11		
С	6	12	P-CL signal is active when the contacts are OFF (open).	
D	7	13	A signal that does not have "/" before the signal abbreviation (such as the P-	
E	8	14	OT signal) is active when the contacts are ON (closed).	
F	-	_	Reserved setting (Do not use.)	

Note: 1. You cannot allocate the /EXT\_A1 to /EXT\_A3 and /EXT\_B1 to /EXT\_B3 (External Latch Inputs 1 to 3) signals to pins 6 to 8 and 12 to 14 on the I/O signal connector (CN1).

2. Refer to the following section for details on input signal parameter settings.

If 11.1.2 List of Servo Parameters on page 11-3

#### Example of Changing Input Signal Allocations

The following example shows reversing the P-OT (Forward Drive Prohibit) signal allocated to CN1-4 and CN1-10 and the /DEC (Origin Return Deceleration Switch) signal allocated to CN1-6 and CN1-12.

Pn50A = n.1 $\square$  D1 Pn511 = n. $\square$  D3 Before change  $\downarrow$   $\downarrow$   $\downarrow$ Pn50A = n.3 $\square$  D1 Pn511 = n. $\square$  D1 After change

Refer to the following section for the parameter setting procedure. *5.1.3 Parameter Setting Methods* on page 5-5

### **Multi-Axis Input Signal Allocations**

The input signals that you can allocate to the pins on the I/O signal connector (CN1) and the related parameters are given in the following table.

Input Signal	Input Signal Name	Parameter
P-OT	Forward Drive Prohibit Input Signal	Pn590
N-OT	Reverse Drive Prohibit Signal	Pn591
/DEC	Origin Return Deceleration Switch Signal	Pn592
/EXT1	External Latch Input 1 Signal	Pn593
/EXT2	External Latch Input 2 Signal	Pn594
/EXT3	External Latch Input 3 Signal	Pn595
/P-CL	Forward External Torque Limit Signal	Pn598
/N-CL	Reverse External Torque Limit Signal	Pn599

#### Relationship between Parameter Settings, Allocated Pins, and Polarities

This section shows the relationship between the input signal parameter settings, the pins on the I/O signal connector (CN1), and the polarities using Pn592 (/DEC (Origin Return Deceleration Switch Input) Signal Allocation) as an example. Refer to the following section for information on individual input signals.

11.1.2 List of Servo Parameters on page 11-3

#### Relationship between Parameter Settings and Pin Numbers

	Parameter	Description	When Enabled	Classification	
	n.□003 (default setting for axis A)	Allocate the signal to CN1-3.			
	n.□004	Allocate the signal to CN1-4.			
	n.□005	Allocate the signal to CN1-5.			
	n.□006	Allocate the signal to CN1-6.		Satup	
	n.□007	Allocate the signal to CN1-7.			
Dn502	n.□008	Allocate the signal to CN1-8.	Aftor rootort		
Ph592	n.□009 (default setting for axis B)	Allocate the signal to CN1-9.	Aller Testart	Setup	
	n.⊡010	Allocate the signal to CN1-10.			
	n.⊡011	Allocate the signal to CN1-11.			
	n.⊡012	Allocate the signal to CN1-12.			
	n.⊡013	Allocate the signal to CN1-13.			
	n.□014	Allocate the signal to CN1-14.			

#### • Relationship between Parameter Settings and Polarities

Parameter		Description	When Enabled	Classification	
n.0□□□ (default set ting)		The signal is always inactive.		Catura	
Pn592	n.1000	Active when input signal is ON (closed).	After restart	Setup	
	n.2000	Active when input signal is OFF (open).			
	n.3000	The signal is always active.		L	

#### **Confirming Input Signals**

You can confirm the status of input signals on the I/O signal monitor. Refer to the following section for information on the I/O signal monitor.

9.2.3 I/O Signal Monitor on page 9-5

6.1.2 Output Signal Allocations

# 6.1.2 Output Signal Allocations

You can allocate the desired output signals to pins 23 to 32 on the I/O signal connector (CN1). The parameters that you use to allocate signals depend on whether you use  $\Sigma$ -7S-compatible I/O signal allocations (Pn50A = n. $\Box\Box\Box\Box$ 1) or multi-axis I/O signal allocations (Pn50A = n. $\Box\Box\Box$ 2).

### **Σ-7S-Compatible Output Signal Allocations**



- The signals that are not detected are considered to be OFF. For example, the /COIN (Positioning Completion) signal is considered to be OFF during speed control.
- Reversing the polarity of the /BK (Brake) signal, i.e., changing it to positive logic, will prevent the holding brake from operating if its signal line is disconnected. If you must change the polarity of this signal, verify operation and make sure that no safety problems will exist.
  - If you allocate more than one signal to the same output circuit, a logical OR of the signals will be output.

Output signals are allocated as shown in the following table.

Refer to *Interpreting the Output Signal Allocation Tables* and change the allocations accordingly.

Interpreting the Output Signal Allocation Tables



6.1.2 Output Signal Allocations

Output Signal Nama			CN1 Pin No.			
and Parameter	Output Signals	Axis A: 23 and 24	Axis B: 25 and 26	Axis A: 27 and 28	Axis B: 29 and 30	Used)
Positioning Completion Pn50E = n.□□□X	/COIN	-	1	2	2	0
Speed Coincidence Detection Pn50E = n.□□X□	/V-CMP	-	1	2	2	0
Rotation Detection Pn50E = n.□X□□	/TGON		1	2	2	0
Servo Ready Pn50E = n.X□□□	/S-RDY		1	2	2	0
Torque Limit Detection Pn50F = n.□□□X	/CLT		1	2	2	0
Speed Limit Detection Pn50F = n.□□X□	/VLT		1	2	2	0
Brake Pn50F = n.⊡X⊡⊡	/BK		1	2	2	0
Warning Pn50F = n.X□□□	/WARN		1	2	2	0
Near Pn510 = n.□□□X	NEAR		1	2	2	0
Preventative Mainte- nance Pn514 = n.□X□□	/PM	-	1	2	2	0
Pn512 = n.□□□1	Reverse polari CN1-2	olarity for CN1-23, CN1-24, N1-25, and CN1-26		ty for CN1-23, CN1-24, 5, and CN1-26		0 The polarity is not reversed
Pn512 = n.□□1□	Reverse po	olarity for CN1-27, CN1-28, CN1-29, and CN1-30		(in the default ) settings.		

#### Example of Changing Output Signal Allocations

The following example shows disabling the /COIN (Positioning Completion) signal allocated to CN1-27 and CN1-28 and allocating the /SRDY (Servo Ready) signal.

 $Pn50E = n.0 \square \square 2$  Before change

 $\downarrow$ 

 $Pn50E = n.2 \square \square 0$  After change

Refer to the following section for the parameter setting procedure. 5.1.3 Parameter Setting Methods on page 5-5

6.1.2 Output Signal Allocations

# **Multi-Axis Output Signal Allocations**

The output signals that you can allocate to the pins on the I/O signal connector (CN1) and the related parameters are given in the following table.

Output Signal	Output Signal Name	Parameter
/COIN	Positioning Completion Output Signal	Pn5B0
/V-CMP	Speed Coincidence Detection Output Signal	Pn5B1
/TGON	Rotation Detection Output Signal	Pn5B2
/S-RDY	Servo Ready Output Signal	Pn5B3
/CLT	Torque Limit Detection Output Signal	Pn5B4
/VLT	Speed Limit Detection Output Signal	Pn5B5
/BK	Brake Output Signal	Pn5B6
/WARN	Warning Output Signal	Pn5B7
/NEAR	Near Output Signal	Pn5B8
/PM	Preventative Maintenance Output Signal	Pn5BC

#### Relationship between Parameter Settings, Allocated Pins, and Polarities

This section shows the relationship between the output signal parameter settings, the pins on the I/O signal connector (CN1), and the polarities using Pn5B0 (/COIN (Positioning Completion Output) Signal Allocation) as an example. Refer to the following section for information on individual output signals.

11.1.2 List of Servo Parameters on page 11-3

#### Relationship between Parameter Settings and Pin Numbers

Parameter		Description	When Enabled	Classification	
	n.□000 (default set- ting)	Disable (the signal output is not used).			
Pn5B0	n.□023*	Allocate the signal to CN1-23.		Setup	
	n.□025*	Allocate the signal to CN1-25.	After restart		
	n.□027*	Allocate the signal to CN1-27.			
	n.□029*	Allocate the signal to CN1-29.			
	n.⊡031*	Allocate the signal to CN1-31.			

\* If Pn5B0 is set to n.1 [] [] (Output the signal) or n.2 [] [Invert the signal and output it) and Pn5B0 is not set to any of these values, an A.040 alarm (Parameter Setting Error) will occur.

#### Relationship between Parameter Settings and Polarities

Parameter		Description	When Enabled	Classification	
Pn5B0 n.0 (de n.1 n.2	n.0□□□ (default set- ting)	Disable (the signal output is not used).	After restart	Setup	
	n.1000	Output the signal.			
	n.2000	Invert the signal and output it.			

## **Checking Output Signal Status**

You can confirm the status of output signals on the I/O signal monitor. Refer to the following section for information on the I/O signal monitor.  $\blacksquare$  9.2.3 I/O Signal Monitor on page 9-5

6-8

6.1.3 ALM (Servo Alarm) Signal

# 6.1.3 ALM (Servo Alarm) Signal

This signal is output when the SERVOPACK detects an error.

**Important** 

Configure an external circuit so that this alarm output turns OFF the main circuit power supply to the SERVOPACK whenever an error occurs.

Туре	Signal	Connector Pin No.	Signal Status	Meaning
Output		Axis A: CN1-19 and CN1-20	ON (closed)	Normal SERVOPACK status
Output	ALIVI	Axis B: CN1-21 and CN1-22	OFF (open)	SERVOPACK alarm

### Alarm Reset Methods

Refer to the following section for information on the alarm reset methods. 10.2.3 Resetting Alarms on page 10-37

# 6.1.4 /WARN (Warning) Signal

Both alarms and warnings are generated by the SERVOPACK. Alarms indicate errors in the SERVOPACK for which operation must be stopped immediately. Warnings indicate situations that may results in alarms but for which stopping operation is not yet necessary.

The /WARN (Warning) signal indicates that a condition exists that may result in an alarm.

Туре	Signal	Connector Pin No.	Signal Status	Meaning
Output	/WARN	Must be allocated.	ON (closed)	Warning
			OFF (open)	Normal status

Note: You must allocate the /WARN signal to use it. The parameters that you use depend on the allocation method.

Allocation Method	Parameter to Use		
Σ-7S-Compatible I/O Signal Allocations	<ul> <li>Pn50A = n.□□□1 (Σ-7S-Compatible I/O Signal Allocations)</li> <li>Pn50F = n.X□□□(/WARN (Warning Output) Signal Allocation)</li> </ul>		
Multi-Axis I/O Signal Allocations	<ul> <li>Pn50A = n. DD2 (Multi-Axis I/O Signal Allocations)</li> <li>Pn5B7 (/WARN (Warning Output) Signal Allocation)</li> </ul>		
Defende the following continue for details			

Refer to the following section for details.

6.1.2 Output Signal Allocations on page 6-6

6.1.5 /TGON (Rotation Detection) Signal

# 6.1.5 /TGON (Rotation Detection) Signal

The /TGON signal indicates that the Servomotor is operating.

This signal is output when the shaft of the Servomotor rotates at the setting of Pn502 (Rotation Detection Level) or faster or the setting of Pn581 (Zero Speed Level) or faster.

Туре	Signal	Connector Pin No.	Signal Status	Servomotor	Meaning
Output	/TGON	N Must be allocated.	ON (closed)	Rotary Servomotors	The Servomotor is operating at the setting of Pn502 or faster.
				Linear Servomotors	The Servomotor is operating at the setting of Pn581 or faster.
			OFF (open)	Rotary Servomotors	The Servomotor is operating at a speed that is slower than the setting of Pn502.
				Linear Servomotors	The Servomotor is operating at a speed that is slower than the setting of Pn581.

Note: You must allocate the /TGON signal to use it. The parameters that you use depend on the allocation method.

Allocation Method	Parameter to Use
Σ-7S-Compatible I/O Signal Allocations	<ul> <li>Pn50A = n.□□□1 (Σ-7S-Compatible I/O Signal Allocations)</li> <li>Pn50E = n.□X□□ (/TGON (Rotation Detection Output) Signal Allocation)</li> </ul>
Multi-Axis I/O Signal Allocations	<ul> <li>Pn50A = n. DD2 (Multi-Axis I/O Signal Allocations)</li> <li>Pn5B2 (/TGON (Rotation Detection Output) Signal Allocation)</li> </ul>

Refer to the following section for details.

6.1.2 Output Signal Allocations on page 6-6

### Setting the Rotation Detection Level

Use the following parameter to set the speed detection level at which to output the /TGON signal.

• Rotary Servomotors

	Rotation Detection	Level	Speed Position	Torque	
Pn502	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	1 to 10,000	1 min <sup>-1</sup>	20	Immediately	Setup

• Linear Servomotors

	Zero Speed Level		Speed Position	Force	
Pn581	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	1 to 10,000	1 mm/s	20	Immediately	Setup

### 6.1.6 /S-RDY (Servo Ready) Signal

The /S-RDY (Servo Ready) signal turns ON when the SERVOPACK is ready to accept the SV\_ON (Servo ON) command.

The /S-RDY signal is turned ON under the following conditions.

- Main circuit power supply is ON.
- There are no alarms.
- If an absolute encoder is used, the SENS\_ON (Turn ON Sensor) command has been input.
- If a Servomotor without a polarity sensor is used, polarity detection has been completed.
- If an absolute encoder is used, the output of the position data from the absolute encoder to the host controller must have been completed if the SENS\_ON (Turn ON Sensor) command is being input.
- \* Do not include this condition if the SV\_ON (Servo ON) command is input for the first time after the control power supply was turned ON. In that case, when the first SV\_ON command is input, polarity detection is started immediately and the /S-RDY signal turns ON at the completion of polarity detection.

Туре	Signal	Connector Pin No.	Signal Status	Meaning
Output		Must be allocated	ON (closed)	Ready to receive the SV_ON (Servo ON) com- mand.
Output	70-1101	Musi de allocateu.	OFF (open)	Not ready to receive the SV_ON (Servo ON) command.

Note: You must allocate the /S-RDY signal to use it. The parameters that you use depend on the allocation method.

Allocation Method	Parameter to Use
Σ-7S-Compatible I/O Signal Allocations	<ul> <li>Pn50A = n.□□□1 (Σ-7S-Compatible I/O Signal Allocations)</li> <li>Pn50E = n.X□□□ (/S-RDY (Servo Ready) Signal Allocation)</li> </ul>
Multi-Axis I/O Signal Allocations	<ul> <li>Pn50A = n.</li></ul>
Defendent des falles des sectors	- Factorial and a file

Refer to the following section for details.

3 6.1.2 Output Signal Allocations on page 6-6

### 6.1.7 /V-CMP (Speed Coincidence Detection) Signal

The /V-CMP (Speed Coincidence Output) signal is output when the Servomotor speed is the same as the reference speed. This signal is used, for example, to interlock the SERVOPACK and the host controller. You can use this output signal only during speed control.

The /V-CMP signal is described in the following table.

Туре	Signal	Connector Pin No.	Signal Status	Meaning
	Must be allocated	ON (closed)	The speed coincides.	
Output	input 7V-CIVIP Must be allocated.	OFF (open)	The speed does not coincide.	

Note: You must allocate the /V-CMP signal to use it. The parameters that you use depend on the allocation method.

Allocation Method	Parameter to Use
Σ-7S-Compatible I/O Signal Allocations	<ul> <li>Pn50A = n.□□□1 (Σ-7S-Compatible I/O Signal Allocations)</li> <li>Pn50E = n.□□X□ (/V-CMP (Speed Coincidence Detection Output) Signal Allocation )</li> </ul>
Multi-Axis I/O Signal Allocations	<ul> <li>Pn50A = n.□□□2 (Multi-Axis I/O Signal Allocations)</li> <li>Pn5B1 (/V-CMP (Speed Coincidence Detection Output) Signal Allocation)</li> </ul>

Refer to the following section for details.

6.1.2 Output Signal Allocations on page 6-6

You can set the speed detection width for the /V-CMP signal in Pn503 (Speed Coincidence Detection Signal Output Width) for a Rotary Servomotor or in Pn582 (Speed Coincidence Detection Signal Output Width) for a Linear Servomotor.

#### 6.1.7 /V-CMP (Speed Coincidence Detection) Signal

• Rotary Servomotors

	Speed Coincidence	Detection Signal Ou	Speed		
Pn503	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 100	1 min <sup>-1</sup>	10	Immediately	Setup

The signal is output when the difference between the reference speed and motor speed is equal or less than the setting.

Example

If Pn503 is set to 100 and the speed reference is 2,000 min<sup>-1</sup>, the signal would be output when the motor speed is between 1,900 and 2,100 min<sup>-1</sup>.



Linear Servomotors

	Speed Coincidence	Detection Signal Ou	Speed		
Pn582	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 100	1 mm/s	10	Immediately	Setup

The signal is output when the difference between the reference speed and motor speed is equal or less than the setting.



If Pn582 is set to 100 and the speed reference is 2,000 mm/s the signal would be output when the motor speed is between 1,900 and 2,100 mm/s.



#### 6.1.8 /COIN (Positioning Completion) Signal

# 6.1.8 /COIN (Positioning Completion) Signal

The /COIN (Positioning Completion) signal indicates that Servomotor positioning has been completed during position control.

The /COIN signal is output when the difference between the reference position output by the host controller and the current position of the Servomotor (i.e., the position deviation as given by the value of the deviation counter) is equal to or less than the setting of the positioning completed width (Pn522).

Use this signal to check the completion of positioning from the host controller.

Туре	Signal	Connector Pin No.	Signal Status	Meaning
Output		Must be allocated	ON (closed)	Positioning has been completed.
	Must de allocated.	OFF (open)	Positioning has not been completed.	

Note: You must allocate the /COIN signal to use it. The parameters that you use depend on the allocation method.

Allocation Method	Parameter to Use
Σ-7S-Compatible I/O Signal Allocations	<ul> <li>Pn50A = n.□□□1 (Σ-7S-Compatible I/O Signal Allocations)</li> <li>Pn50E = n.□□□X (/COIN (Positioning Completion Output) Signal Allocation)</li> </ul>
Multi-Axis I/O Signal Allocations	<ul> <li>Pn50A = n.□□□2 (Multi-Axis I/O Signal Allocations)</li> <li>Pn5B0 (/COIN (Positioning Completion Output) Signal Allocation)</li> </ul>

Refer to the following section for details.

6.1.2 Output Signal Allocations on page 6-6

# Setting the Positioning Completed Width

The /COIN signal is output when the difference between the reference position and the current position (i.e., the position deviation as given by the value of the deviation counter) is equal to or less than the setting of the positioning completed width (Pn522).

	Positioning Complete	ted Width	Positic	n	
Pn522	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 1,073,741,824	1 reference unit	7	Immediately	Setup

The setting of the positioning completed width has no effect on final positioning accuracy.



Note: If the parameter is set to a value that is too large, the /COIN signal may be output when the position deviation is low during a low-speed operation. If that occurs, reduce the setting until the signal is no longer output.

# Setting the Output Timing of the /COIN (Positioning Completion Output) Signal

You can add a reference input condition to the output conditions for the /COIN signal to change the signal output timing.

If the position deviation is always low and a narrow positioning completed width is used, change the setting of  $Pn207 = n.X \square \square \square$  (/COIN (Positioning Completion Output) Signal Output Timing) to change output timing for the /COIN signal.

#### 6.1.9 /NEAR (Near) Signal

Parameter		Description	When Enabled	Classification
	n.0□□□ (default setting)	Output the /COIN signal when the absolute value of the position deviation is the same or less than the setting of Pn522 (Positioning Completed Width).		
Pn207	n. 1000	Output the /COIN signal when the absolute value of the position deviation is the same or less than the setting of Pn522 (Positioning Completed Width) and the reference after the position reference filter is 0.	After restart	Setup
	n. 2000	Output the /COIN signal when the absolute value of the position deviation is the same or less than the setting of Pn522 (Positioning Completed Width) and the reference input is 0.		

# 6.1.9 /NEAR (Near) Signal

The /NEAR (Near) signal indicates when positioning completion is being approached.

The host controller receives the NEAR signal before it receives the /COIN (Positioning Completion) signal, it can start preparations for the operating sequence to use after positioning has been completed. This allows you to reduce the time required for operation when positioning is completed.

The NEAR signal is generally used in combination with the /COIN signal.

Туре	Signal	Connector Pin No.	Signal Status	Meaning
Output		Must be allocated	ON (closed)	The Servomotor has reached a point near to positioning completion.
Output /NEA		EAR Must be allocated.	OFF (open)	The Servomotor has not reached a point near to positioning completion.

Note: You must allocate the /NEAR signal to use it. The parameters that you use depend on the allocation method.

Allocation Method	Parameter to Use
Σ-7S-Compatible I/O Signal Allocations	<ul> <li>Pn50A = n.□□□1 (Σ-7S-Compatible I/O Signal Allocations)</li> <li>Pn510 = n.□□□X (/NEAR (Near Output) Signal Allocation)</li> </ul>
Multi-Axis I/O Signal Allocations	<ul> <li>Pn50A = n.□□□2 (Multi-Axis I/O Signal Allocations)</li> <li>Pn5B8 (/NEAR (Near Output) Signal Allocation)</li> </ul>

Refer to the following section for details.

3 6.1.2 Output Signal Allocations on page 6-6

### /NEAR (Near) Signal Setting

You set the condition for outputting the /NEAR (Near) signal (i.e., the near signal width) in Pn524 (Near Signal Width). The /NEAR signal is output when the difference between the reference position and the current position (i.e., the position deviation as given by the value of the deviation counter) is equal to or less than the setting of the near signal width (Pn524).



Note: Normally, set Pn524 to a value that is larger than the setting of Pn522 (Positioning Completed Width).

### 6.1.10 Speed Limit during Torque Control

You can limit the speed of the Servomotor to protect the machine.

When you use a Servomotor for torque control, the Servomotor is controlled to output the specified torque, but the motor speed is not controlled. Therefore, if a reference torque is input that is larger than the machine torque, the speed of the Servomotor may increase greatly. If that may occur, use this function to limit the speed.

Note: The actual limit of motor speed depends on the load conditions on the Servomotor.



### /VLT (Speed Limit Detection) Signal

The signal that is output when the motor speed is being limited by the speed limit is described in the following table.

Туре	Signal	Connector Pin No.	Signal Status	Meaning
			ON (closed)	The Servomotor speed is being limited.
Output	/VLT	Must be allocated.	OFF (open)	The Servomotor speed is not being lim- ited.

Note: You must allocate the /VLT signal to use it. The parameters that you use depend on the allocation method.

Allocation Method	Parameter to Use
Σ-7S-Compatible I/O Signal Allocations	<ul> <li>Pn50A = n.□□□1 (Σ-7S-Compatible I/O Signal Allocations)</li> <li>Pn50F = n.□□X□ (/VLT (Speed Limit Detection) Signal Allocation)</li> </ul>
Multi-Axis I/O Signal Allocations	<ul> <li>Pn50A = n.□□□2 (Multi-Axis I/O Signal Allocations)</li> <li>Pn5B5 (/VLT (Speed Limit Detection) Signal Allocation)</li> </ul>

Refer to the following section for details.

6.1.2 Output Signal Allocations on page 6-6

### Selecting the Speed Limit

The smaller of the external speed limit and internal speed limit will be used.

Parameter		Meaning	When Enabled	Classification
	n.🗆 🗆 🗆 🗆	Reserved settings (Do not use.)		
Pn002	n.□□1□ (default setting)	Use the speed limit from the VLIM (Limit Speed for Torque Control) command as the speed limit. (Use external speed limiting.)	After restart	Setup

6.1.10 Speed Limit during Torque Control

#### Internal Speed Limiting

Set the speed limit for the motor in Pn407 (Speed Limit during Torque Control) or Pn480 (Speed Limit during Force Control).

Also set  $Pn408 = n.\square\squareX\square$  (Speed Limit Selection) to specify using the maximum motor speed or the overspeed alarm detection speed as the speed limit. Select the overspeed alarm detection speed to limit the speed to the equivalent of the maximum motor speed.

Parameter		Meaning	When Enabled	Classification
Pp/08	n.□□0□ (default setting)	Use the smaller of the maximum motor speed and the setting of Pn407 or Pn480 as the speed limit.	Aftor rostart	Sotup
Pn408	n.0010	Use the smaller of the overspeed alarm detec- tion speed and the setting of Pn407 or Pn480 as the speed limit.	Aller Testart	Gerup

Note: If you are using a Rotary Servomotor, set Pn407 (Speed Limit during Torque Control). If you are using a Linear Servomotor, set Pn480 (Speed Limit during Force Control).

Rotary Servomotors

	Speed Limit during Torque Control					
Pn407	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 10,000	1 min <sup>-1</sup>	10000	Immediately	Setup	

#### Linear Servomotors

	Speed Limit during	Force			
Pn480	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 10,000	1 mm/s	10000	Immediately	Setup

Note: If the parameter setting exceeds the maximum speed of the Servomotor, the Servomotor's maximum speed or the overspeed alarm detection speed will be used.

#### External Speed Limiting

The motor speed will be limited by VLIM (Limit Speed for Torque Control). Refer to the following manual for details.

Ω Σ-7-Series MECHATROLINK-III Communications Standard Servo Profile Command Manual (Manual No.: SIEP S800001 31)

# 6.2 **Operation for Momentary Power Interruptions**

Even if the main power supply to the SERVOPACK is interrupted momentarily, power supply to the motor (servo ON status) will be maintained for the time set in Pn509 (Momentary Power Interruption Hold Time).

D=500	Momentary Power Interruption Hold Time			Speed Position	Torque
	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
/ 11 / 000	20 to 50,000	1 ms	20	Immediately	Setup

If the momentary power interruption time is equal to or less than the setting of Pn509, power supply to the motor will be continued. If it is longer than the setting, power supply to the motor will be stopped. Power will be supplied to the motor again when the main circuit power supply recovers.



- Information 1. If the momentary power interruption time exceeds the setting of Pn509, the /S-RDY (Servo Ready) signal will turn OFF.
  - 2. If uninterruptible power supplies are used for the control power supply and main circuit power supply, the SERVOPACK can withstand a power interruption that lasts longer than 50,000 ms.
  - 3. The holding time of the SERVOPACK control power supply is approximately 100 ms. If control operations become impossible during a momentary power interruption of the control power supply, the setting of Pn509 will be ignored and the same operation will be performed as for when the power supply is turned OFF normally.



The holding time of the main circuit power supply depends on the output from the SERVOPACK. If the load on the Servomotor is large and an A.410 alarm (Undervoltage) occurs, the setting of Pn509 will be ignored.

# 6.3 SEMI F47 Function

The SEMI F47 function detects an A.971 warning (Undervoltage) and limits the output current if the DC main circuit power supply voltage to the SERVOPACK drops to a specified value or lower because the power was momentarily interrupted or the main circuit power supply voltage was temporarily reduced.

This function complies with the SEMI F47 standards for semiconductor manufacturing equipment.

You can combine this function with the momentary power interruption hold time (Pn509) to allow the Servomotor to continue operating without stopping for an alarm or without recovery work even if the power supply voltage drops.

#### **Execution Sequence**

This function can be executed either with the host controller or with the SERVOPACK. Use  $Pn008 = n.\square\squareX\square$  (Function Selection for Undervoltage) to specify whether the function is executed by the host controller or by the SERVOPACK.

#### • Execution with the Host Controller (Pn008 = $n.\Box\Box1\Box$ )

The host controller limits the torque in response to an A.971 warning (Undervoltage).

The host controller removes the torque limit after the Undervoltage warning is cleared.



#### • Execution with the SERVOPACK (Pn008 = $n.\Box\Box2\Box$ )

The torque is limited in the SERVOPACK in response to an Undervoltage warning. The SERVOPACK controls the torque limit for the set time after the Undervoltage warning is cleared.



# Setting for A.971 Warnings (Undervoltage)

You can set whether or not to detect A.971 warnings (Undervoltage).

Parameter		Meaning	When Enabled	Classification
Pn008	n.□□0□ (default setting)	Do not detect undervoltage warning.		Setup
	n.0010	Detect undervoltage warning and limit torque at host controller.	After restart	
	n.0020	Detect undervoltage warning and limit torque with Pn424 and Pn425 (i.e., only in SERVOPACK).		

#### Related Parameters

The following parameters are related to the SEMI F47 function.

	Torque Limit at Mair	n Circuit Voltage Dro	Speed Position	Torque	
Pn424	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 100	1%*	50	Immediately	Setup
	Release Time for To	rque Limit at Main C	ircuit Voltage Drop	Speed Position	Torque
Pn425	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 1,000	1 ms	100	Immediately	Setup
D=500	Momentary Power I	nterruption Hold Tim	e	Speed Position	Torque
All Axes	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
/ / 0.00	20 to 50,000	1 ms	20	Immediately	Setup

\* Set a percentage of the motor rated torque.

Note: If you will use the SEMI F47 function, set the time to 1,000 ms.



• This function handles momentary power interruptions for the voltage and time ranges stipulated in SEMI F47. An uninterruptible power supply (UPS) is required as a backup for momentary power interruptions that exceed these voltage and time ranges.

 Set the host controller or SERVOPACK torque limit so that a torque reference that exceeds the specified acceleration torque will not be output when the power supply for the main circuit is restored.

• For a vertical axis, do not limit the torque to a value that is lower than the holding torque.

- This function limits torque within the range of the SERVOPACK's capability for power interruptions. It is not intended for use under all load and operating conditions. Set the parameters while monitoring operation on the actual machine.
- You can set the momentary power interruption hold time to increase the amount of time from when the power supply is turned OFF until power supply to the motor is stopped. To stop the power supply to the motor immediately, use the SV\_OFF (Servo OFF) command.

# 6.4 Setting the Motor Maximum Speed

You can set the maximum speed of the Servomotor with the following parameter. • Rotary Servomotors

	Maximum Motor Sp	beed	Speed Positi	on Torque		
Pn316	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 65,535	1 min <sup>-1</sup>	10,000	After restart	Setup	

Linear Servomotors

	Maximum Motor Speed			Speed Positi	on Force
Pn385	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	1 to 100	100 mm/s	50	After restart	Setup

You can achieve the following by lowering the maximum speed of the Servomotor.

• If the motor speed exceeds the setting, an A.510 alarm (Overspeed) will occur.

Changing the setting of the parameter is effective in the following cases.

- To protect the machine by stopping machine operation with an alarm when the set speed is reached or exceeded
- To limit the speed so that the load is not driven beyond the allowable moment of inertia Refer to relevant manual from the following list for the relationship between the speed and the allowable moment of inertia.
  - $\bigcap ~\Sigma$ -7-Series Rotary Servomotor Product Manual (Manual No.: SIEP S800001 36)
  - Ω Σ-7-Series Direct Drive Servomotor Product Manual (Manual No.: SIEP S800001 38)
  - $\bigcap$   $\Sigma$ -7-Series Linear Servomotor Product Manual (Manual No.: SIEP S800001 37)

#### 6.5.1 Setting to Enable/Disable Software Limits

# 6.5 Software Limits

You can set limits in the software for machine movement that do not use the overtravel signals (P-OT and N-OT). If a software limit is exceeded, an emergency stop will be executed in the same way as it is for overtravel.

You must make the following settings to use the software limits.

- You must enable the software limit function.
- You must set the software limits.

## 6.5.1 Setting to Enable/Disable Software Limits

You can use  $Pn801 = n.\square\square\squareX$  (Software Limit Selection) to enable and disable the software limit function. One of following commands must be executed to define the origin of the machine coordinate system before the software limits will operate. Otherwise, the software limit function will not operate even if a software limit is exceeded.

- The ZRET command has been executed.
- The POS\_SET command has been executed with REFE set to 1.
- If an absolute encoder is used, the SENS\_ON (Turn ON Sensor) command must have been completed.

Parameter		Meaning	When Enabled	Classification
Pn801	n.□□□0	Enable both forward and reverse soft- ware limits.		Setup
	n.0001	Disable forward software limit.	Immediately	
	n.0002	Disable reverse software limit.		
	n.□□□3 (default setting)	Disable both forward and reverse soft- ware limits.		

# 6.5.2 Setting the Software Limits

Software limits are set in both the forward and reverse directions.

The reverse software limit must be less than the forward software limit to set a limit in each direction.

	Forward Software Limit			Position		
Pn804	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	-1,073,741,823 to 1,073,741,823	1 reference unit	1,073,741,823	Immediately	Setup	
Pn806	Reverse Software Limit			Position		
	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	-1,073,741,823 to 1,073,741,823	1 reference unit	-1,073,741,823	Immediately	Setup	

## 6.5.3 Software Limit Check for References

You can enable or disable software limit checks for commands that have target position references, such as POSING or INTERPOLATE. If the target position exceeds a software limit, a deceleration stop will be performed from the position set as the software limit.

Parameter		Meaning	When Enabled	Classification
Pn801	n.□0□□ (defaultsetting)	Do not perform software limit checks for references.	Immodiately	Satup
111001	n.0100	Perform software limit checks for references.	Intinectately	Getup

6.6.1 Internal Torque Limits

# 6.6 Selecting Torque Limits

You can limit the torque that is output by the Servomotor.

There are four different ways to limit the torque. These are described in the following table.

Limit Method	Outline	Control Method	Reference
Internal Torque Limits	The torque is always limited with the setting of a parameter.	Speed control,	6.6.1
External Torque Limits	The torque is limited with an input signal from the host computer.	torque control	6.6.2
Limiting Torque with TLIM Data in Commands <sup>*</sup>	The TLIM data in a command is used to set the required torque limits.	Speed control or position control	_
Torque Limiting with P_CL and N_CL in the Servo Command Output Signals (SVCMD_IO)*	The P_CL and N_CL signals in the servo command output signals (SVCMD_IO) are used to set the required limits.	Speed control or position control	_

\* Refer to the following manual for details.

Σ-7-Series MECHATROLINK-III Communications Standard Servo Profile Command Manual (Manual No.: SIEP S800001 31)

Note: If you set a value that exceeds the maximum torque of the Servomotor, the torque will be limited to the maximum torque of the Servomotor.

### 6.6.1 Internal Torque Limits

If you use internal torque limits, the maximum output torque will always be limited to the specified forward torque limit (Pn402) and reverse torque limit (Pn403).

Rotary Servomotors

	Forward Torque Lim	it	Speed Positio	n Torque	
Pn402	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 800	1%*	800	Immediately	Setup
	Reverse Torque Limit			Speed Positio	n Torque
Pn403	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 800	1%*	800	Immediately	Setup

\* Set a percentage of the rated motor torque.

Note: If the setting of Pn402 or Pn403 is too low, the torque may be insufficient for acceleration or deceleration of the Servomotor.



6.6.2 External Torque Limits

• Linear Servomotors

	Forward Force Limit		Speed Positio	n Force	
Pn483	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 800	1%*	30	Immediately	Setup
	Reverse Force Limit			Speed Positio	n Force
Pn484	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 800	1%*	30	Immediately	Setup

\* Set a percentage of the rated motor force.

Note: If the setting of Pn483 or Pn484 is too low, the force may be insufficient for acceleration or deceleration of the Servomotor.



### 6.6.2 External Torque Limits

You can limit the torque only when required by the operating conditions of the machine by turning a signal ON and OFF.

You can use this for applications such as stopping on physical contact, or holding a workpiece with a robot.

#### **External Torque Limit Reference Signals**

The /P-CL (Forward External Torque Limit) and /N-CL (Reverse External Torque Limit) signals are used as the external torque limit reference signals. The /P-CL signal is used for the forward torque limit and the /N-CL signal is used for the reverse torque limit.

Туре	Signal	Connector Pin No.	Signal Status	Meaning
Input	/P-CL	Must be allocated.	ON (closed)	Applies the forward external torque limit. The torque is limited to the smaller of the set- tings of Pn402 <sup>*1</sup> and Pn404.
			OFF (open)	Cancels the forward external torque limit. The torque is limited to the setting of Pn402 <sup>*1</sup> .
Input	/N-CL	N-CL Must be allocated.	ON (closed)	Applies the reverse external torque limit. The torque is limited to the smaller of the set- tings of Pn403 <sup>*2</sup> and Pn404.
			OFF (open)	Cancels the reverse external torque limit. The torque is limited to the setting of Pn403 <sup>*2</sup> .

\*1. Pn483 is used for a Linear Servomotor.

\*2. Pn484 is used for a Linear Servomotor.

Note: You must allocate the /P-CL and /N-CL signals to use them. The parameters that you use depend on the allocation method.
#### 6.6.2 External Torque Limits

Allocation Method	Parameter to Use		
Σ-7S-Compatible I/O Signal Allocations	<ul> <li>Pn50A = n.□□□1 (Σ-7S-Compatible I/O Signal Allocations)</li> <li>Pn50B = n.□X□□ (/P-CL (Forward External Torque Limit Input) Signal Allocation)</li> <li>Pn50B = n.X□□□ (/N-CL (Reverse External Torque Limit Input) Signal Allocation)</li> </ul>		
Multi-Axis I/O Signal Allocations	<ul> <li>Pn50A = n.□□□2 (Multi-Axis I/O Signal Allocations)</li> <li>Pn598 (/P-CL (Forward External Torque Limit Input) Signal Allocation)</li> <li>Pn599 (/N-CL (Reverse External Torque Limit Input) Signal Allocation)</li> </ul>		

Refer to the following section for details on allocations.

(2) 6.1.1 Input Signal Allocations on page 6-3

#### Setting the Torque Limits

The parameters that are related to setting the torque limits are given below.

• Rotary Servomotors

If the setting of Pn402 (Forward Torque Limit), Pn403 (Reverse Torque Limit), Pn404 (Forward External Torque Limit), or Pn405 (Reverse External Torque Limit) is too low, the torque may be insufficient for acceleration or deceleration of the Servomotor.

	Forward Torque Lim	it		Speed Positio	n Torque
Pn402	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 800	1%*	800	Immediately	Setup
	Reverse Torque Lim	it		Speed Positio	n Torque
Pn403	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 800	1%*	800	Immediately	Setup
	Forward External To	orque Limit		Speed Positio	n Torque
Pn404	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 800	1%*	100	Immediately	Setup
	Reverse External To	Speed Positio	n Torque		
Pn405	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 800	1%*	100	Immediately	Setup

\* Set a percentage of the rated motor torque.

#### • Linear Servomotors

If the setting of Pn483 (Forward Force Limit), Pn484 (Reverse Force Limit), Pn404 (Forward External Force Limit), or Pn405 (Reverse External Force Limit) is too low, the force may be insufficient for acceleration or deceleration of the Servomotor.

	Forward Force Limit	:		Speed Positio	n Force
Pn483	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 800	1%*	30	Immediately	Setup
	Reverse Force Limit			Speed Positio	n Force
Pn484	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 800	1%*	30	Immediately	Setup
	Forward External Fo	orce Limit		Speed Positio	n Force
Pn404	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 800	1%*	100	Immediately	Setup
	Reverse External Fo	orce Limit	Speed Positio	n Force	
Pn405	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 800	1%*	100	Immediately	Setup

\* Set a percentage of the rated motor force.

#### Changes in the Output Torque for External Torque Limits

The following table shows the changes in the output torque when the internal torque limit is set to 800%.

Rotary Servomotors

In this example, the Servomotor direction is set to  $Pn000 = n.\Box\Box\Box$  (Use CCW as the forward direction).



#### Linear Servomotors

In this example, the Servomotor direction is set to  $Pn000 = n.\Box\Box\Box\Box$  (Use the direction in which the linear encoder counts up as the forward direction).



6.6.3 /CLT (Torque Limit Detection) Signal

#### /CLT (Torque Limit Detection) Signal 6.6.3

This section describes the /CLT signal, which indicates the status of limiting the motor output torque.

Туре	Signal	Connector Pin No.	Signal Status	Meaning
Output			ON (closed)	The motor output torque is being limited.
Output		Widst be anocated.	OFF (open)	The motor output torque is not being limited.

Note: You must allocate the /CLT signal to use it. The parameters that you use depend on the allocation method.

Allocation Method	Parameter to Use	
Σ-7S-Compatible I/O Signal Allocations	<ul> <li>Pn50A = n.□□□1 (Σ-7S-Compatible I/O Signal Allocations)</li> <li>Pn50F = n.□□□X (/CLT (Torque Limit Detection Output) Signal Allocation )</li> </ul>	
Multi-Axis I/O Signal Allocations	<ul> <li>Pn50A = n.□□□2 (Multi-Axis I/O Signal Allocations)</li> <li>Pn5B4 (/CLT (Torque Limit Detection Output) Signal Allocation)</li> </ul>	
Refer to the following section for details		

Refer to the following section for details. **6.1.2** *Output Signal Allocations* on page 6-6

## 6.7 Absolute Encoders

The absolute encoder records the current position of the stop position even when the power supply is OFF.

With a system that uses an absolute encoder, the host controller can monitor the current position. Therefore, it is not necessary to perform an origin return operation when the power supply to the system is turned ON.

There are three types of encoders for Rotary Servomotors. The usage of the encoder is specified in  $Pn002 = n.\Box X \Box \Box$ .

Refer to the following section for encoder models.

Image ■ Encoder Resolution on page 5-43

#### · Parameter Settings When Using an Incremental Encoder

Parameter		Meaning	When Enabled	Classification
	n.□0□□ (default setting)	Use the encoder as an incremental encoder. A battery is not required.		
Pn002 n.□1□□		Use the encoder as an incremental encoder. A battery is not required.		Setup
	n.0200	Use the encoder as a single-turn absolute encoder. A battery is not required.		

#### · Parameter Settings When Using a Single-Turn Absolute Encoder

Parameter		Meaning	When Enabled	Classification
	n.□0□□ (default setting)	Use the encoder as a single-turn absolute encoder. A battery is not required.		
Pn002 n.□1□□		Use the encoder as an incremental encoder. A battery is not required.	After restart	Setup
	n.0200	Use the encoder as a single-turn absolute encoder. A battery is not required.	1	

#### · Parameter Settings When Using a Multiturn Absolute Encoder

Parameter		Meaning	When Enabled	Classification
	n.□0□□ (default setting)	Use the encoder as a multiturn absolute encoder. A battery is required.		
Pn002 n.□1□□		Use the encoder as an incremental encoder. A battery is not required.	After restart Setur	
	n.0200	Use the encoder as a single-turn absolute encoder. A battery is not required.		

## NOTICE

• Install a battery at either the host controller or on the Encoder Cable. If you install batteries both at the host controller and on the Encoder Cable at the same time, you will create a loop circuit between the batteries, resulting in a risk of damage or burning.

#### 6.7.1 Connecting an Absolute Encoder

You can get the position data from the absolute encoder with MECHATROLINK communications.

Refer to the following section for information on connecting absolute encoders. *4.4.3 Wiring the SERVOPACK to the Encoder* on page 4-20

6.7.2 Structure of the Position Data of the Absolute Encoder

## 6.7.2 Structure of the Position Data of the Absolute Encoder

The position data of the absolute encoder is the position coordinate from the origin of the absolute encoder.

The position data from the absolute encoder contains the following two items.

- The number of rotations from the origin of the encoder coordinate system (called the multiturn data)
- The position (number of pulses) within one rotation

The position data of the absolute encoder is as follows:

Position data of absolute encoder = Multiturn data  $\times$  Number of pulses within one encoder rotation (encoder resolution) + Position (number of pulses) within one rotation.

For a single-turn absolute encoder, the multiturn data is 0.

## 6.7.3 Reading the Position Data from the Absolute Encoder

The SENS\_ON (Turn ON Sensor) command is used to read the position data from the absolute encoder.

## 6.7.4 Multiturn Limit Setting

The multiturn limit is used in position control for a turntable or other rotating body. For example, consider a machine that moves the turntable shown in the following diagram in only one direction.



Because the turntable moves in only one direction, the upper limit to the number of revolutions that can be counted by an absolute encoder will eventually be exceeded.

The multiturn limit is used in cases like this to prevent fractions from being produced by the integral ratio of the number motor revolutions and the number of turntable revolutions.

For a machine with a gear ratio of n:m, as shown above, the value of m minus 1 will be the setting for the multiturn limit setting (Pn205).

Multiturn limit (Pn205) = m - 1

The relationship between the number of turntable revolutions and the number of motor revolutions is shown in the following graph for when m is 100 and n is 3.

Set Pn205 to 99. Pn205 = 100 - 1 = 99

6.7.4 Multiturn Limit Setting



	Multiturn Limit			Speed Positic	n Torque
Pn205	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 65,535	1 Rev	65,535	After restart	Setup

Note: This parameter is enabled when you use an absolute encoder.

The data will change as shown below when this parameter is set to anything other than the default setting.

- If the motor operates in the reverse direction when the multiturn data is 0, the multiturn data will change to the value set in Pn205.
- If the motor operates in the forward direction when the multiturn data is at the value set in Pn205, the multiturn data will change to 0.

Set Pn205 to one less than the desired multiturn data.

If you change the multiturn limit in Pn205, an A.CCO alarm (Multiturn Limit Disagreement) will be displayed because the setting disagrees with the value in the encoder. Refer to the following section for the procedure to change the multiturn limit settings in the encoder.



Information The multiturn data will always be 0 in the following cases. It is not necessary to reset the absolute encoder in these cases.

· When you use a single-turn absolute encoder

• When the encoder is set to be used as a single-turn absolute encoder (Pn002 =  $n.\Box 2\Box \Box$ ) Absolute encoder-related alarms (A.810 and A.820) will not occur.

6.7.5 Multiturn Limit Disagreement Alarm (A.CC0)

#### 6.7.5 Multiturn Limit Disagreement Alarm (A.CC0)

If you change the multiturn limit in Pn205 (Multiturn Limit), an A.CC0 alarm (Multiturn Limit Disagreement) will be displayed because the setting disagrees with the value in the encoder.

Display	Name	Meaning
A.CC0	Multiturn Limit Disagreement	Different multiturn limits are set in the encoder and SERVO- PACK.

If this alarm is displayed, use the following procedure to change the multiturn limit in the encoder to the same value as the setting of Pn205.

#### **Applicable Tools**

The following table lists the tools that you can use to set the multiturn limit and the applicable tool functions.

Tool	Function	Operating Procedure Reference
Digital Operator	Fn013	Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Setup - Multiturn Limit Setting	Gerating Procedure on page 6-30

This setting can be made with the MEM\_WR (Write Memory) command. Refer to the following manual for information on the MEM\_WR (Write Memory) command.

Ω Σ-7-Series MECHATROLINK-III Communications Standard Servo Profile Command Manual (Manual No.: SIEP S800001 31)

#### **Operating Procedure**

Use the following procedure to adjust the multiturn limit setting.

- 1. Click the 🔎 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Multiturn Limit Setting in the Menu Dialog Box. The Multiturn Limit Setting Dialog Box will be displayed.
- 3. Click the Continue Button.



Click the **Cancel** Button to cancel setting the multiturn limit. The Main Window will return.

6.7.5 Multiturn Limit Disagreement Alarm (A.CC0)

4. Change the setting.



- 5. Click the Writing into the Servopack Button.
- 6. Click the OK Button.

Multiturn Limit Setting				
$\wedge$				
Multiturn limit value was changed. The following procedure is needed to operate with changing the Multiturn limit.				
1. Close this function program.				
<ol><li>"A.CC0.Multiturn Limit Disagreement" is occurred when the power of the Servopack (control) is cycled.</li></ol>				
3. Select "Multiturn Limit Setting function" again.				
<ol> <li>Set the Multiturn limit setting value to the servomotor according to the instruction of the screen.</li> </ol>				
<ol> <li>Cycle power again Multiturn limit change is completed, through these procedures.</li> </ol>				
ОК				

7. Turn the power supply to the SERVOPACK OFF and ON again.

An A.CCO alarm (Multiturn Limit Disagreement) will occur because setting the multiturn limit in the Servomotor is not yet completed even though the setting has been changed in the SERVOPACK.

- 8. Display the Multiturn Limit Setting in the Menu Dialog Box.
- 9. Click the Continue Button.

Multiturn Limit Setting
The position data is cleared when this function is used. Since the Multiturn (multiple rotations) limit is changed, the position data of the machine system is changed and it is very dangerous.
Do you want to continue the process?
Continue

6.7.5 Multiturn Limit Disagreement Alarm (A.CC0)

#### 10. Click the Writing into the Motor Button.

🕐 Multitur	n Limit Setting	<b>×</b>
Set the mult	iturn limit value to the	e servomotor.
Pn205:Multi	turn Limit	
1555	[ Rev ]	Re-Change
(	Writing into the servomo	otor

Click the **Re-change** Button to change the setting.

#### **11.** Click the **OK** Button.

Multiturn Limit Setting
Multiturn Limit Setting has been completed. Cycle (control) power. The operation can be done with the set multiturn limit from the next time when the power is turned on.
It is very dangerous to operate the machine in this state. Be sure to perform the original point re-setup of a machine system after power is turned on again.
ОК

This concludes the procedure to set the multiturn limit.

#### 6.8.1 Connecting an Absolute Linear Encoder

## 6.8 Absolute Linear Encoders

The absolute linear encoder records the current position of the stop position even when the power supply is OFF.

With a system that uses an absolute linear encoder, the host controller can monitor the current position. Therefore, it is not necessary to perform an origin return operation when the power supply to the system is turned ON.

There are three types of linear encoders for Linear Servomotors. The usage of the linear encoder is specified in  $Pn002 = n.\Box X \Box \Box$ .

Refer to the following section for linear encoder models.

Feedback Resolution of Linear Encoder on page 5-44

#### · Parameter Settings When Using an Incremental Linear Encoder

P	Parameter	Meaning	When Enabled	Classification		
Pn002	n.□0□□ (default setting)	Use the encoder as an incremental linear encoder.	After restart	Setup		
	n.0100	Use the encoder as an incremental linear encoder.				

#### · Parameter Settings When Using an Absolute Linear Encoder

P	Parameter	Meaning	When Enabled	Classification		
Pn002	n.□0□□ (default setting)	Use the encoder as an absolute linear encoder.	After restart	Setup		
	n.🗆 1 🗆 🗆	Use the encoder as an incremental linear encoder.				

#### 6.8.1 Connecting an Absolute Linear Encoder

You can get the position data from the absolute linear encoder with MECHATROLINK communications.

Refer to the following section for information on connecting absolute linear encoders. *4.4.3 Wiring the SERVOPACK to the Encoder* on page 4-20

# 6.8.2 Structure of the Position Data of the Absolute Linear Encoder

The position data of the absolute linear encoder is the distance (number of pulses) from the origin of the absolute linear encoder.

The position data is signed 36-bit data.

35										2	0 1	9												0	
±																									
$\subseteq$																									
$\gamma$										$\checkmark$															
Upper 16 bits (with sign)										Lower 20 bits															

When the SERVOPACK sends the position data, it sends the upper 16-bit data (with sign) separately from the lower 20-bit data.

# 6.8.3 Reading the Position Data from the Absolute Linear Encoder

The SENS\_ON (Turn ON Sensor) command is used to read the position data from the absolute linear encoder.

6.9.1 Preparations

## 6.9 Software Reset

You can reset the SERVOPACK internally with the software. A software reset is used when resetting alarms and changing the settings of parameters that normally require turning the power supply to the SERVOPACK OFF and ON again. This can be used to change those parameters without turning the power supply to the SERVOPACK OFF and ON again.



The software reset applies to both axes A and B. If you reset the software, it will be reset for both axes.

Information

- 1. Always confirm that the servo is OFF and that the motor is stopped before you start a software reset.
  - This function resets the SERVOPACK independently of the host controller. The SERVO-PACK carries out the same processing as when the power supply is turned ON and outputs the ALM (Servo Alarm) signal. The status of other output signals may be forcibly changed.
  - 3. When you execute a software reset, the SERVOPACK will not respond for approximately five seconds.

Before you execute a software reset, check the status of the SERVOPACK and Servomotor and make sure that no problems will occur.

#### 6.9.1 Preparations

Always check the following before you perform a software reset.

- The servo must be OFF.
- The motor must be stopped.

#### 6.9.2 Applicable Tools

The following table lists the tools that you can use to perform a software reset and the applicable tool functions.

Tool	Function	Operating Procedure Reference
Digital Operator	Fn030	Ω. Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Setup - Software Reset	€ 6.9.3 Operating Procedure on page 6-35

## 6.9.3 Operating Procedure

There are the following two methods that you can use to perform a software reset.

- Direct connection to the SERVOPACK
- · Connection though a controller

The procedure for each method is given below.

## **Direct Connection to the SERVOPACK**

- 1. Click the 📃 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- 2. Select Software Reset in the Menu Dialog Box. The Software Reset Dialog Box will be displayed.
- 3. Click the Execute Button.

Software Reset
The software reset function resets the Servopack by using software and re-calculates all settings including parameters. Be sure to carefully read the SigmaWin+ Operation Manual before executing this function. Special care must be taken for the following.
The Servopack will stop responding for approximately 5 seconds after the execution begins. Before executing this function, always check the Servopack and motor status to ensure safety.
Execute

Click the Cancel Button to cancel the software reset. The Main Window will return.

4. Click the Execute Button.



#### 5. Click the OK Button to end the software reset operation.

All settings including parameters will have been re-calculated. When you finish this operation, disconnect the SigmaWin+ from the SERVOPACK, and then connect it again.

Software Reset
The software reset function has been completed. All settings including parameters were re-calculated. Always reconnect the SigmaWin+ to the Servopack after execution of this function.
OK

This concludes the procedure to reset the software.

6.9.3 Operating Procedure

#### Connection through a Controller

- 1. Click the 🔎 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Software Reset in the Menu Dialog Box. The Software Reset Dialog Box will be displayed.
- 3. Click the Execute Button.

Software Reset
The software reset function resets the Servopack by using software and re-calculates all settings including parameters. Be sure to carefully read the SigmaWin+ Operation Manual before executing this function. Special care must be taken for the following.
The Servopack will stop responding for approximately 5 seconds after the execution begins. Before executing this function, always check the Servopack and motor status to ensure safety.
Execute

Click the Cancel Button to cancel the software reset. The Main Window will return.

4. Select the Reset MECHATROLINK communication Check Box.



5. Click the Execute Button.



If you perform a software reset without resetting MECHATROLINK communications, a communications error will occur between the controller and SERVOPACK, and communications will no longer be possible.

Always select the **Reset MECHATROLINK communication** Check Box and reset MECHA-TROLINK communications as well.

#### 6. Click the OK Button.

All settings including parameters will have been re-calculated. When you finish this operation, disconnect the SigmaWin+ from the SERVOPACK, and then connect it again.

Software Reset
The software reset function has been completed. All settings including parameters were re-calculated. Always reconnect the SigmaWin+ to the Servopack after execution of this function.
ОК

This concludes the procedure to reset the software.

## 6.10 Initializing the Vibration Detection Level

You can detect machine vibration during operation to automatically adjust the settings of Pn312 or Pn384 (Vibration Detection Level) to detect A.520 alarms (Vibration Alarm) and A.911 warnings (Vibration) more precisely.

This function detects specific vibration components in the Servomotor speed.

	Parameter	Meaning	When Enabled	Classification	
Pn310	n.□□□0 (default setting)	Do not detect vibration.	lana a Rataka		
	n.0001	Output a warning (A.911) if vibration is detected.	Immediately	Setup	
	n.0002	Output an alarm (A.520) if vibration is detected.			

If the vibration exceeds the detection level calculated with the following formula, an alarm or warning occurs according to Pn310 (Vibration Detection Selection).

Rotary Servomotors

Detection level = <u>Vibration detection level (Pn312 [min-1]) × Vibration detection sensitivity (Pn311 [%])</u> 100

Linear Servomotors

Detection level = <u>Vibration detection level (Pn384 [mm/s]) × Vibration detection sensitivity (Pn311 [%])</u>

100

Use this function only if A.520 or A.911 alarms are not output at the correct times when vibration is detected with the default vibration detection level (Pn312 or Pn384).

There will be discrepancies in the detection sensitivity for vibration alarms and warnings depending on the condition of your machine. If there is a discrepancy, use the above formula to adjust Pn311 (Vibration Detection Sensitivity).

	Vibration Detection Sensitivity			Speed Positi	on Torque
Pn311	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	50 to 500	1%	100	Immediately	Tuning

Information 1. Vibration may not be detected because of unsuitable servo gains. Also, not all kinds of vibrations can be detected.

2. Set a suitable moment of inertia ratio (Pn103). An unsuitable setting may result in falsely detecting or not detecting vibration alarms or vibration warnings.

3. To use this function, you must input the actual references that will be used to operate your system.

4. Execute this function under the operating conditions for which you want to set the vibration detection level.

5. Execute this function while the motor is operating at 10% of its maximum speed or faster.

## 6.10.1 Preparations

Always check the following before you initialize the vibration detection level.

- The parameters must not be write prohibited.
- The test without a motor function must be disabled (Pn00C =  $n.\Box\Box\Box$ ).

6.10.2 Applicable Tools

## 6.10.2 Applicable Tools

The following table lists the tools that you can use to initialize the vibration detection level and the applicable tool functions.

Tool	Function	Operating Procedure Reference
Digital Operator	Fn01B	Ω Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Setup - Initialize Vibra- tion Detection Level	6.10.3 Operating Procedure on page 6-38

## 6.10.3 Operating Procedure

Use the following procedure to initialize the vibration detection level.

- 1. Click the 🔎 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Initialize Vibration Detection Level in the Menu Dialog Box. The Initialize Vibration Detection Level Dialog Box will be displayed.
- Select Pn311: Vibration Detection Sensitivity and Pn310: Vibration Detection Selections and then click the Detection Start Button. A setting execution standby mode will be entered.

🗣 Initialize Vibration Detection Level AXIS#00 🛛 🗾			
Setting Condition			
Pn311 : Vibration Detection Sensitivity (50 - 500)			
100 . [%]			
Pn310 : Vibration Detection Selections digit 0 Vibration Detection Selection			
2 : Output an alarm (A.520) if vibration is detected.			
Detection Start			
Setting Result			
Pn312 : Vibration Detection Level			
50 [min-1]			

6.10.3 Operating Procedure

4. Click the Execute Button.

€ Initialize Vibration Detection Level AXIS#00
Setting Condition
Pn311 : Vibration Detection Sensitivity (50 - 500)
100 [%]
Pn310 : Vibration Detection Selections digit 0 Vibration Detection Selection
2 : Output an alarm (A.520) if vibration is detected.
Execute
Setting Result
Pn312 : Vibration Detection Level
50 [min-1]

The newly set vibration detection level will be displayed and the value will be saved in the SERVO-PACK.

9 Initialize Vibration Detection Level AXIS#00			
- Setting Condition			
Pn311 : Vibration Detection Sensitivity (50 - 500)			
100 . [%]			
Pn310 : Vibration Detection Selections digit 0 Vibration Detection Selection			
2 : Output an alarm (A.520) if vibration is detected.			
Setting Result			
Pn312 : Vibration Detection Level			
50 [min-1] <b>5</b> 0 [min-1]			
When vibration exceeds a detection level 50 [min-1], Alarm(A.520) is detected.			

This concludes the procedure to initialize the vibration detection level.

6.10.4 Related Parameters

#### 6.10.4 Related Parameters

The following three items are given in the following table.

- Parameters Related to this Function
  - These are the parameters that are used or referenced when this function is executed.
- Changes during Function Execution
   Not allowed: The parameter cannot be changed using the SigmaWin+ or other tool while this
   function is being executed.
   Allowed: The parameter can be changed using the SigmaWin+ or other tool while this func tion is being executed.
- Automatic Changes after Function Execution Yes: The parameter is automatically set or adjusted after execution of this function. No: The parameter is not automatically set or adjusted after execution of this function.

Parameter	Name	Setting Changes	Automatic Changes
Pn311	Vibration Detection Sensitivity	Allowed	No
Pn312	Vibration Detection Level	Not allowed	Yes
Pn384	Vibration Detection Level	Not allowed	Yes

6.11.1 Automatic Adjustment

## 6.11 Adjusting the Motor Current Detection Signal Offset

The motor current detection signal offset is used to reduce ripple in the torque. You can adjust the motor current detection signal offset either automatically or manually.

## 6.11.1 Automatic Adjustment

Perform this adjustment only if highly accurate adjustment is required to reduce torque ripple. You can specify the axis or axes to automatically adjust. It is normally not necessary to adjust this offset.



Execute the automatic offset adjustment if the torque ripple is too large when compared with other SERVOPACKs.

Information

The offset does not use a parameter, so it will not change even if the parameter settings are initialized.

#### Preparations

Always check the following before you automatically adjust the motor current detection signal offset.

- The parameters must not be write prohibited.
- The servo must be in ready status.
- The servo must be OFF.

#### **Applicable Tools**

The following table lists the tools that you can use to automatically adjust the offset and the applicable tool functions.

Tool	Function	Operating Procedure Reference	
Digital Operator	Fn00E	Ω Σ-7-Series Digital Operator Operating Manual (document No. SIEP S800001 33)	
SigmaWin+	Setup - Adjust Offset - Adjust the Motor Current Detection Signal Offsets	Operating Procedure on page 6-41	

#### **Operating Procedure**

Use the following procedure to automatically adjust the motor current detection signal offset.

- 1. Click the 🔎 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Adjust the Motor Current Detection Signal Offsets in the Menu Dialog Box. The Adjust the Motor Current Detection Signal Offsets Dialog Box will be displayed.

- 6.11.1 Automatic Adjustment
  - 3. Click the Continue Button.



4. Click the Automatic Adjustment Tab in the Adjust the Motor Current Detection Signal Offsets Dialog Box.

Adjust the Motor Current Detection Signal O					
Automatic Adjustment Manual Adjustment					
U-phase Offset -73  V-phase Offset -63					
Adjust					

5. Click the Adjust Button.

The values that result from automatic adjustment will be displayed in the New Boxes.

2 Adjust the Motor Current Detection Signal O					
Automatic Adjustment   Manual Adjustment					
New					
U-phase Offset					
V-phase Offset -63					
Adjust					

This concludes the procedure to automatically adjust the motor current detection signal offset.

## 6.11.2 Manual Adjustment

You can use this function if you automatically adjust the motor current detection signal offset and the torque ripple is still too large. You can specify the axis or axes to manually adjust.

If the offset is incorrectly adjusted with this function, the Servomotor characteristics may be adversely affected.

Observe the following precautions when you manually adjust the offset.
 Operate the Servomotor at a speed of approximately 100 min<sup>-1</sup>.

- Adjust the offset while monitoring the torque reference with the analog monitor until the ripple is minimized.
- Adjust the offsets for the phase-U current and phase-V current of the Servomotor so that they
  are balanced. Alternately adjust both offsets several times.

Information The offset does not use a parameter, so it will not change even if the parameter settings are initialized.

## Preparations

Always check the following before you manually adjust the motor current detection signal offset.

• The parameters must not be write prohibited.

#### Applicable Tools

The following table lists the tools that you can use to manually adjust the offset and the applicable tool functions.

Tool	Function	Operating Procedure Reference
Digital Operator	Fn00F	Ω Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Setup - Adjust Offset - Adjust the Motor Current Detection Signal Offsets	Operating Procedure on page 6-43

#### **Operating Procedure**

Use the following procedure to manually adjust the motor current detection signal offset.

- 1. Operate the motor at approximately 100 min<sup>-1</sup>.
- 2. Click the 🔎 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **3.** Select Adjust the Motor Current Detection Signal Offsets in the Menu Dialog Box. The Adjust the Motor Current Detection Signal Offsets Dialog Box will be displayed.
- 4. Click the Continue Button.



6.11.2 Manual Adjustment

5. Click the Manual Adjustment Tab in the Adjust the Motor Current Detection Signal Offsets Dialog Box.

Adjust the Motor Current Detection Signal O					
Automatic Adjustment Manual	Adjustment				
Motor Current Detection Offset					
Channel U-I	Channel U-phase 💌				
Offset -74	+1 ᠿ↑ -1 Qt↓				

- 6. Set the Channel Box in the Motor Current Detection Offset Area to U-phase.
- **7.** Use the +1 and -1 Buttons to adjust the offset for phase U. Change the offset by about 10 in the direction that reduces the torque ripple. Adjustment range: -512 to +511
- 8. Set the Channel Box in the Motor Current Detection Offset Area to V-phase.
- 9. Use the +1 and -1 Buttons to adjust the offset for phase V. Change the offset by about 10 in the direction that reduces the torque ripple.
- **10.** Repeat steps 4 to 8 until the torque ripple cannot be improved any further regardless of whether you increase or decrease the offsets.
- **11.** Reduce the amount by which you change the offsets each time and repeat steps 4 to 8.

This concludes the procedure to manually adjust the motor current detection signal offset.

6.12.1 FSTP (Forced Stop Input) Signal

## 6.12 Forcing the Motor to Stop

You can force the Servomotor to stop for a signal from the host controller or an external device.

To force the motor to stop, you must allocate the FSTP (Forced Stop Input) signal in Pn516 =  $n.\square\square\squareX$ . You can specify one of the following stopping methods: dynamic brake (DB), coasting to a stop, or decelerating to a stop.

Note: Forcing the motor to stop is not designed to comply with any safety standard. In this respect, it is different from the hard wire base block (HWBB).

Information Panel Operator and Digital Operator Displays

When a forced stop is performed, the panel and the Digital Operator will display FSTP.



• To prevent accidents that may result from contact faults or disconnections, use a normally closed switch for the Forced Stop Input signal.

## 6.12.1 FSTP (Forced Stop Input) Signal

Classifica- tion	Signal	Connector Pin No.	Signal Status	Description
Input	FSTP	Must be allocated.	ON (closed)	Drive is enabled (normal operation).
			OFF (open)	The motor is stopped.

Note: You must allocate the FSTP signal to use it. The parameters that you use depend on the allocation method.

Allocation Method	Parameters to Use
$\Sigma$ -7S-compatible I/O signal allocations	<ul> <li>Pn50A = n.□□□1 (Σ-7S-Compatible I/O Signal Allocations)</li> <li>Pn516 = n.□□□X (FSTP (Forced Stop Input) Signal Allocation)</li> </ul>
Multi-axis I/O signal alloca- tions	<ul> <li>Pn50A = n.□□□2 (Multi-Axis I/O Signal Allocations)</li> <li>Pn597 (FSTP (Forced Stop Input) Signal Allocation)</li> </ul>

Refer to the following section for details.

3 6.1.1 Input Signal Allocations on page 6-3

## 6.12.2 Stopping Method Selection for Forced Stops

Use  $Pn00A = n.\Box\BoxX\Box$  (Stopping Method for Forced Stops) to set the stopping method for forced stops.

Parameter		Description	When Enabled	Classifi- cation
	n. <b>DD</b> 0D	Apply the dynamic brake or coast the motor to a stop (use the stopping method set in $Pn001 = n.\square\square\squareX$ ).		
Pn00A	n.□□1□ (default set- ting)	Decelerate the motor to a stop using the torque set in Pn406 as the maximum torque. Use the setting of Pn001 = $n.\Box\Box\BoxX$ for the status after stopping.		Setup
	n.0020	Decelerate the motor to a stop using the torque set in Pn406 as the maximum torque and then let the motor coast.	After restart	
	n.0030	Decelerate the motor to a stop using the deceleration time set in Pn30A. Use the setting of Pn001 = $n.\square\square\squareX$ for the status after stopping.		
	n.0040	Decelerate the motor to a stop using the deceleration time set in Pn30A and then let the motor coast.		

Note: You cannot decelerate a Servomotor to a stop during torque control. For torque control, the Servomotor will be stopped with the dynamic braking or coast to a stop according to the setting of Pn001 = n.  $\Box \Box \Box X$  (Motor Stopping Method for Servo OFF and Group 1 Alarms).

6.12.2 Stopping Method Selection for Forced Stops

#### Stopping the Servomotor by Setting Emergency Stop Torque (Pn406)

To stop the Servomotor by setting emergency stop torque, set Pn406 (Emergency Stop Torque).

If  $Pn001 = n.\Box\BoxX\Box$  is set to 1 or 2, the Servomotor will be decelerated to a stop using the torque set in Pn406 as the maximum torque.

The default setting is 800%. This setting is large enough to allow you to operate the Servomotor at the maximum torque. However, the maximum emergency stop torque that you can actually use is the maximum torque of the Servomotor.

	Emergency Stop Torque			Speed Positio	n Torque
Pn406	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 800	1%*	800	Immediately	Setup

\* Set a percentage of the motor rated torque.

# Stopping the Servomotor by Setting the Deceleration Time for Servo OFF and Forced Stops (Pn30A)

To specify the Servomotor deceleration time and use it to stop the Servomotor, set Pn30A (Deceleration Time for Servo OFF and Forced Stops).

	Deceleration Time f	or Servo OFF and Fo	Speed Position	١	
Pn30A Setting Range Settin		Setting Unit	Default Setting	When Enabled	Classification
	0 to 10,000	1 ms	0	Immediately	Setup

If you set Pn30A to 0, the Servomotor will be stopped with a zero speed.

The deceleration time that you set in Pn30A is the time to decelerate the motor from the maximum motor speed.



6.12.3 Resetting Method for Forced Stops

## 6.12.3 Resetting Method for Forced Stops

This section describes the reset methods that can be used after stopping operation for an FSTP (Forced Stop Input) signal.

If the FSTP (Forced Stop Input) signal is OFF and the SV\_ON (Servo ON) command is sent, the forced stop state will be maintained even after the FSTP signal is turned ON.

Send the SV\_OFF (Servo OFF) command to place the SERVOPACK in the base block (BB) state and then send the SV\_ON (Servo ON) command.



# Trial Operation and Actual Operation

7

This chapter provides information on the flow and procedures for trial operation and convenient functions to use during trial operation.

7.1	Flow	of Trial Operation7-2
	7.1.1 7.1.2	Flow of Trial Operation for Rotary Servomotors 7-2 Flow of Trial Operation for Linear Servomotors 7-4
7.2	Inspec	tions and Confirmations before Trial Operation 7-6
7.3	Trial O	peration for the Servomotor without a Load 7-7
	7.3.1 7.3.2 7.3.3	Preparations
7.4	Trial Op	peration with MECHATROLINK-III Communications 7-10
7.5	Trial Op	eration with the Servomotor Connected to the Machine7-12
	7.5.1 7.5.2 7.5.3	Precautions7-12Preparations7-12Operating Procedure7-13
7.6	Conve	nient Function to Use during Trial Operation7-14
	7.6.1 7.6.2 7.6.3	Program Jogging
7.7	Opera	tion Using MECHATROLINK-III Commands 7-26

7.1.1 Flow of Trial Operation for Rotary Servomotors

## 7.1 Flow of Trial Operation

## 7.1.1 Flow of Trial Operation for Rotary Servomotors

The procedure for trial operation is given below.

#### • Preparations for Trial Operation

Step	Meaning	Reference
1	Installation Install the Servomotor and SERVOPACK according to the installation conditions. First, operation is checked with no load. Do not connect the Servomotor to the machine.	Chapter 3 SERVOPACK Installation
2	Wiring and Connections Wire and connect the SERVOPACK. First, Servomotor operation is checked without a load. Do not connect the CN1 connector on the SERVOPACK.	Chapter 4 Wiring and Connecting SERVOPACKs
3	Confirmations before Trial Operation	7.2 Inspections and Confirmations before Trial Opera- tion on page 7-6
4	Power ON	-
5	Resetting the Absolute Encoder This step is necessary only for a Servomotor with an Absolute Encoder.	5.16 Resetting the Absolute Encoder on page 5-46

#### 7.1.1 Flow of Trial Operation for Rotary Servomotors

#### Trial Operation



7.1.2 Flow of Trial Operation for Linear Servomotors

## 7.1.2 Flow of Trial Operation for Linear Servomotors

The procedure for trial operation is given below.

#### • Preparations for Trial Operation

Step	Meaning		Reference				
1	Installation Install the Servomotor and SERVOPACK according to the installation conditions. First, operation is checked with no load. Do not connect the Servomotor to the machine.			(Ja)	G Chapter 3 SERVOPACK Installation		
2	<ul> <li>Wiring and Connections</li> <li>Wire and connect the SERVOPACK. First, Servomotor operation is checked without a load. Do not connect the CN1 connector on the SERVOPACK.</li> </ul>			B Chapter 4 Wiring and Connecting SERVOPACKs			
3	Confirm	ations before Trial Ope	ration	7 Tæ	7.2 Inspections and Confirmations ion on page 7-6	before Trial Opera-	
4	Power 0	NC		-			
	Setting	Parameters in the SER	VOPACK				
	Step No. of Parameter to Set Descriptio		n	Remarks	Reference		
	5-1	Pn282	Linear Encoder Scale Pitch		Set this parameter only if you are using a Serial Converter Unit.	page 5-17	
	5-2	-	Writing Parameters to the Linear Servo- motor		Set this parameter only if you are not using a Serial Converter Unit.	page 5-18	
5	5-3	Pn080 = n.□□X□	Motor Phase Sequence Selec- tion		-	page 5-23	
	5-4	Pn080 = n.□□□X	Polarity Sensor Selection		-	page 5-25	
	5-5	_	Polarity Detection		This step is necessary only for a Linear Servomotor with a Polarity Sensor.	page 5-26	
	5-6	Pn50A = n.X□□□ and Pn50B = n.□□□X or Pn590 and Pn591	Overtravel Signal Allocations		-	page 5-29	
	5-7	Pn483, Pn484	Force Control		-	page 6-22	
	Setting	the Origin of the Absolu	ite Linear				
6 Setting the Origin of the Absolute Linear Encoder Note: This step is necessary only for an Absolute Linear Servomotor from Mitutoyo Corpora- tion.				osolute Linear			

#### 7.1.2 Flow of Trial Operation for Linear Servomotors

#### • Trial Operation

Step	Meaning	Reference
1	Trial Operation for the Servomotor without a Load	7.3 Trial Operation for the Servomotor without a Load on page 7-7
2	Trial Operation with MECHATROLINK-III Communications	7.4 Trial Operation with MECHATROLINK-III Communi- cations on page 7-10
3	Trial Operation with the Servomotor Con- nected to the Machine To power CN6A and CN6B To host controller CN1 To host controller	7.5 Trial Operation with the Servomotor Connected to the Machine on page 7-12

## 7.2 Inspections and Confirmations before Trial Operation

To ensure safe and correct trial operation, check the following items before you start trial operation.

- Make sure that the SERVOPACK and Servomotor are installed, wired, and connected correctly.
- Make sure that the correct power supply voltage is supplied to the SERVOPACK.
- Make sure that there are no loose parts in the Servomotor mounting.
- If you are using a Servomotor with an Oil Seal, make sure that the oil seal is not damaged. Also make sure that oil has been applied.
- If you are performing trial operation on a Servomotor that has been stored for a long period of time, make sure that all Servomotor inspection and maintenance procedures have been completed.

Refer to the manual for your Servomotor for Servomotor maintenance and inspection information.

• If you are using a Servomotor with a Holding Brake, make sure that the brake is released in advance. To release the brake, you must apply the specified voltage of 24 VDC to the brake. A circuit example for trial operation is provided below.



## 7.3 Trial Operation for the Servomotor without a Load

You use jogging for trial operation of the Servomotor without a load.

Jogging is used to check the operation of the Servomotor without connecting the SERVOPACK to the host controller. The Servomotor is moved at the preset jogging speed.



• During jogging, the overtravel function is disabled. Consider the range of motion of your machine when you jog the Servomotor.

#### 7.3.1 Preparations

Always check the following before you execute jogging.

- The parameters must not be write prohibited.
- The main circuit power supply must be ON.
- There must be no alarms.
- The servo must be OFF.
- The jogging speed must be set considering the operating range of the machine. The jogging speed is set with the following parameters.

•	Rotary	Servomotors
---	--------	-------------

	Jogging Speed		Speed Position Torque		
Pn304	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 10,000	1 min <sup>-1</sup>	500	Immediately	Setup
	Soft Start Acceleration Time			Speed	
Pn305	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 10,000	1 ms	0	Immediately	Setup
Pn306	Soft Start Deceler	ration Time		Speed	
	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 10,000	1 ms	0	Immediately	Setup

#### • Direct Drive Servomotors

	Jogging Speed		Speed Position Torque			
Pn304	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 10,000	0.1 min <sup>-1</sup>	500	Immediately	Setup	
	Soft Start Acceler	ation Time		Speed		
Pn305	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 10,000	1 ms	0	Immediately	Setup	
	Soft Start Deceler	ration Time		Speed		
Pn306	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 10,000	1 ms	0	Immediately	Setup	

#### • Linear Servomotors

	Jogging Speed		Speed Po	sition Force	
Pn383	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 10,000	1 mm/s	50	Immediately	Setup
	Soft Start Acceler	ration Time		Speed	
Pn305	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 10,000	1 ms	0	Immediately	Setup
	Soft Start Deceler	ration Time		Speed	
Pn306	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 10,000	1 ms	0	Immediately	Setup

7.3.2 Applicable Tools

## 7.3.2 Applicable Tools

The following table lists the tools that you can use to perform jogging and the applicable tool functions.

Tool	Function	Operating Procedure Reference
Digital Operator	Fn002	Ω Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Test Run - Jog	Gerating Procedure on page 7-8

## 7.3.3 Operating Procedure

Use the following procedure to jog the motor.

- 1. Click the 🔎 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select JOG Operation in the Menu Dialog Box. The Jog Operation Dialog Box will be displayed.
- 3. Read the warnings and then click the OK Button.



4. Check the jogging speed and then click the Servo ON Button.

SIDG Operation AXIS#00
JOG Speed Setting
Pn304 : Jogging Speed
500 [min-1] Edit
Operation
Sana ON
Servo OFF
Forward Reverse
+•

The display in the Operation Area will change to Servo ON.

Information To change the speed, click the Edit Button and enter the new speed.

7.3.3 Operating Procedure

5. Click the Forward Button or the Reverse Button.

Jogging will be performed only while you hold down the mouse button.

SJOG Operation AXIS#00	
Pn304 : Jogging Speed	[min-1] Edit
Operation	Servo OFF
Forward	Reverse

6. After you finish jogging, turn the power supply to the SERVOPACK OFF and ON again.

This concludes the jogging procedure.

## 7.4 Trial Operation with MECHATROLINK-III Communications

A trial operation example for MECHATROLINK-III communications is given below.

Refer to the following manual for command details.

Σ-7-Series MECHATROLINK-III Communications Standard Servo Profile Command Manual (Manual No.: SIEP S800001 31)

1. Confirm that the wiring is correct, and then connect the I/O signal connector (CN1 connector).

Refer to the following chapter for details on wiring. *Chapter 4 Wiring and Connecting SERVOPACKs* 

#### 2. Turn ON the power supplies to the SERVOPACK and host controller.

If control power is being supplied correctly, the PWR indicator on the SERVOPACK will light. If main circuit power is being supplied correctly, the CHARGE indicator on the SERVOPACK will light. If communications are established, the L1 or L2 indicators, whichever one corresponds to the CN6A or CN6B connector where the MECHATROLINK-III cable is connected, will light. If the L1 or L2 indicator does not light, recheck the settings of MECHATROLINK-III setting switches (S1, S2, and S3) and then turn the power supply OFF and ON again.

#### 3. Send the CONNECT command from the host controller.

If the SERVOPACK correctly receives the CONNECT command, the CN indicator will light. If the CN indicator does not light, the settings of the CONNECT command are not correct. Correct the settings of the CONNECT command, and then send it from the host controller again.

#### 4. Confirm the product model with the ID\_RD command.

The SERVOPACK will return the product model (example: SGD7W-1R6A20A).

5. Set the following items, which are necessary for trial operation.

Setting	Reference
Electronic Gear	🗊 5.15 Electronic Gear Settings on page 5-42
Motor Direction	5.5 Motor Direction Setting on page 5-16
Overtravel	5.11 Overtravel and Related Settings on page 5-29

#### 6. Save the settings that you made in step 5.

If the settings are saved in the host controller, use the SVPRM\_WR command with the mode set to RAM to save them.

If the settings are saved in the SERVOPACK, use the SVPRM\_WR command with the mode set to non-volatile memory to save them.

7. Send the CONFIG command to enable the settings.

#### 8. Send the SENS\_ON command to obtain the position information (encoder ready).

#### 9. Send the SV\_ON command.

Servomotor operation will be enabled and the SERVOPACK will return 1 for SVON (power supplied to motor) in the status.

#### **10.** Operate the Servomotor at low speed.

Operating Example for a Positioning Command Command: POSING Command settings: Positioning position = 10,000 (If you are using an absolute encoder, add 10,000 to the present position), rapid traverse speed = 400.

#### **11.** While operation is in progress for step 10, confirm the following items.

Confirmation Item	Reference
Confirm that the rotational direction of the Servomotor agrees with the forward or reverse reference. If they do not agree, cor- rect the rotation direction of the Servomo- tor.	
Confirm that no abnormal vibration, noise, or temperature rise occurs. If any abnor- malities are found, implement corrections.	10.5 Troubleshooting Based on the Operation and Condi- tions of the Servomotor on page 10-51

Note: If the load machine is not sufficiently broken in before trial operation, the Servomotor may become overloaded.

7.5.1 Precautions

## 7.5 Trial Operation with the Servomotor Connected to the Machine

This section provides the procedure for trial operation with both the machine and Servomotor.

## 7.5.1 Precautions

## **WARNING**

• Operating mistakes that occur after the Servomotor is connected to the machine may not only damage the machine, but they may also cause accidents resulting in personal injury.



If you disabled the overtravel function for trial operation of the Servomotor without a load, enable the overtravel function (P-OT and N-OT signal) before you preform trial operation with the Servomotor connected to the machine in order to provide protection.

If you will use a brake, observe the following precautions during trial operation.

- Before you check the operation of the brake, implement measures to prevent vibration from being caused by the machine falling due to gravity or an external force.
- First check the Servomotor operation and brake operation with the Servomotor uncoupled from the machine. If no problems are found, connect the Servomotor to the machine and perform trial operation again.

Control the operation of the brake with the /BK (Brake) signal output from the SERVOPACK.

Refer to the following sections for information on wiring and the related parameter settings. *4.4.4 Wiring the SERVOPACK to the Holding Brake* on page 4-29

5.12 Holding Brake on page 5-33



Failures caused by incorrect wiring or incorrect voltage application in the brake circuit may cause the SERVOPACK to fail, damage the SERVOPACK, damage the equipment, or cause an accident resulting in death or injury.

t Observe the precautions and instructions for wiring and trial operation precisely as described in this manual.

#### 7.5.2 Preparations

Always confirm the following before you perform the trial operation procedure for both the machine and Servomotor.

- Make sure that the procedure described in 7.4 Trial Operation with MECHATROLINK-III Communications on page 7-10 has been completed.
- Make sure that the SERVOPACK is connected correctly to both the host controller and the peripheral devices.
  - Overtravel wiring
  - Brake wiring
  - Allocation of the /BK (Brake) signal to a pin on the I/O signal connector (CN1)
  - Emergency stop circuit wiring
  - Host controller wiring
## 7.5.3 Operating Procedure

- **1.** Enable the overtravel signals. (2) 5.11.2 Setting to Enable/Disable Overtravel on page 5-30
- 2. Make the settings for the protective functions, such as the overtravel, and the brake.
   3.11 Overtravel and Related Settings on page 5-29
   5.12 Holding Brake on page 5-33
- **3.** Turn OFF the power supplies to the SERVOPACK. The control power supply and main circuit power supply will turn OFF.
- 4. Couple the Servomotor to the machine.



- 5. Turn ON the power supplies to the machine and host controller and turn ON the control power supply and main circuit power supply to the SERVOPACK.
- 6. Check the protective functions, such overtravel and the brake, to confirm that they operate correctly.

Note: Enable activating an emergency stop so that the Servomotor can be stopped safely should an error occur during the remainder of the procedure.

- 7. Input the /S-ON (Servo ON) signal from the host controller. The servo will turn ON.
- 8. Perform trial operation according to 7.4 Trial Operation with MECHATROLINK-III Communications on page 7-10 and confirm that the same results are obtained as when trial operation was performed on the Servomotor without a load.
- **9.** If necessary, adjust the servo gain to improve the Servomotor response characteristics. The Servomotor and machine may not be broken in completely for the trial operation. Therefore, let the system run for a sufficient amount of time to ensure that it is properly broken in.
- 10. For future maintenance, save the parameter settings with one of the following methods.
  - Use the SigmaWin+ to save the parameters as a file.
  - Use the Parameter Copy Mode of the Digital Operator.
  - · Record the settings manually.

This concludes the procedure for trial operation with both the machine and Servomotor.

## 7.6 Convenient Function to Use during Trial Operation

This section describes some convenient operations that you can use during trial operation. Use them as required.

## 7.6.1 Program Jogging

You can use program jogging to perform continuous operation with a preset operation pattern, travel distance, movement speed, acceleration/deceleration time, waiting time, and number of movements.

You can use this operation when you set up the system in the same way as for normal jogging to move the Servomotor without connecting it to the host controller in order to check Servomotor operation and execute simple positioning operations.

## Preparations

Always check the following before you execute program jogging.

- The parameters must not be write prohibited.
- The main circuit power supply must be ON.
- There must be no alarms.
- The servo must be OFF.
- The range of machine motion and the safe movement speed of your machine must be considered when you set the travel distance and movement speed.
- There must be no overtravel.

## **Additional Information**

- You can use the functions that are applicable to position control, such as the position reference filter.
- The overtravel function is enabled.

## **Program Jogging Operation Pattern**

An example of a program jogging operation pattern is given below. In this example, the Servomotor direction is set to  $Pn000 = n.\Box\Box\Box\Box$  (Use CCW as the forward direction).



Continued on next page.

Continued from previous page.



Information If Pn530 is set to n.  $\Box$   $\Box$   $\Box$ , n.  $\Box$   $\Box$   $\Box$ , n.  $\Box$   $\Box$   $\Box$ , or n.  $\Box$   $\Box$   $\Box$ , you can set Pn536 (Program Jogging Number of Movements) to 0 to perform infinite time operation. You cannot use infinite time operation if Pn530 is set to n.  $\Box$   $\Box$   $\Box$   $\Box$   $\Box$ . If you perform infinite time operation from the Digital Operator, press the **JOG/SVON** Key to turn OFF the servo to end infinite time operation.

## **Related Parameters**

Use the following parameters to set the program jogging operation pattern. Do not change the settings while the program jogging operation is being executed.

Rotary Servomotors

	Program Jogging-R	elated Selections		Speed Posit	ion Torque		
Pn530	Setting Range	Setting Unit	Default Setting	When Enabled	Classification		
	0000 to 0005	-	0000	Immediately	Setup		
	Program Jogging Tr	avel Distance		Speed Position Torque			
Pn531	Setting Range	Setting Unit	Default Setting	When Enabled	Classification		
	1 to 1,073,741,824	1 reference unit	32,768	Immediately	Setup		
	Program Jogging M	lovement Speed		Speed Position Torque			
Pn533	Setting Range	Setting Unit	Default Setting	When Enabled	Classification		
	1 to 10,000	1 min⁻¹	500	Immediately	Setup		
	Program Jogging A	cceleration/Decele	ration Time	Speed Posit	ion Torque		
Pn534	Setting Range	Setting Unit	Default Setting	When Enabled	Classification		
	2 to 10,000	1 ms	100	Immediately	Setup		
	Program Jogging W	aiting Time		Speed Position Torque			
Pn535	Setting Range	Setting Unit	Default Setting	When Enabled	Classification		
	0 to 10,000	1 ms	100	Immediately	Setup		
	Program Jogging N	umber of Movemer	nts	Speed Po	sition Torque		
Pn536	Setting Range	Setting Unit	Default Setting	When Enabled	Classification		
	0 to 1,000	1	1	Immediately	Setup		

#### • Direct Drive Servomotors

	Program Jogging-Re	elated Selections		Speed Po	sition Torque		
Pn530	Setting Range	Setting Unit	Default Setting	When Enabled	Classification		
	0000 to 0005	-	0000	Immediately	Setup		
	Program Jogging Tra	avel Distance		Speed Position Torque			
Pn531	Setting Range	Setting Unit	Default Setting	When Enabled	Classification		
	1 to 1,073,741,824	1 reference unit	32,768	Immediately	Setup		
	Program Jogging M	ovement Speed		Speed Position Torque			
Pn533	Setting Range	Setting Unit	Default Setting	When Enabled	Classification		
	1 to 10,000	0.1 min <sup>-1</sup>	500	Immediately	Setup		
	Program Jogging Acceleration/Deceleration Time Speed Pos				sition Torque		
Pn534	Setting Range	Setting Unit	Default Setting	When Enabled	Classification		
	2 to 10,000	1 ms	100	Immediately	Setup		
	Program Jogging W	aiting Time		Speed Position Torque			
Pn535	Setting Range	Setting Unit	Default Setting	When Enabled	Classification		
	0 to 10,000	1 ms	100	Immediately	Setup		
Pn536	Program Jogging Nu	umber of Movemer	its	Speed Po	sition Torque		
	Setting Range	Setting Unit	Default Setting	When Enabled	Classification		
	0 to 1,000	1	1	Immediately	Setup		

• Linear Servomotors

	Program Jogging-R	elated Selections		Speed Pc	sition Force		
Pn530	Setting Range	Setting Unit	Default Setting	When Enabled	Classification		
	0000 to 0005	-	0000	Immediately	Setup		
	Program Jogging Tr	avel Distance		Speed Position Force			
Pn531	Setting Range	Setting Unit	Default Setting	When Enabled	Classification		
	1 to 1,073,741,824	1 reference unit	32,768	Immediately	Setup		
	Program Jogging M	ovement Speed		Speed Position Force			
Pn585	Setting Range	Setting Unit	Default Setting	When Enabled	Classification		
	1 to 10,000	1 mm/s	50	Immediately	Setup		
	Program Jogging A	cceleration/Deceler	ration Time	Speed Pc	sition Force		
Pn534	Setting Range	Setting Unit	Default Setting	When Enabled	Classification		
	2 to 10,000	1 ms	100	Immediately	Setup		
	Program Jogging W	aiting Time		Speed Position Force			
Pn535	Setting Range	Setting Unit	Default Setting	When Enabled	Classification		
	0 to 10,000	1 ms	100	Immediately	Setup		
Pn536	Program Jogging N	umber of Movemer	nts	Speed Pc	sition Force		
	Setting Range	Setting Unit	Default Setting	When Enabled	Classification		
	0 to 1,000	1	1	Immediately	Setup		

## **Applicable Tools**

The following table lists the tools that you can use to perform program jogging and the applicable tool functions.

Tool	Function	Reference
Digital Operator	Fn004	Ω Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Test Run - Program JOG Operation	G Operating Procedure on page 7-18

## **Operating Procedure**

Use the following procedure for a program jog operation.

- 1. Click the 🔎 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- 2. Select JOG Program in the Menu Dialog Box. The Jog Program Dialog Box will be displayed.
- 3. Read the warnings and then click the OK Button.



**4.** Set the operating conditions, click the **Apply** Button, and then click the **Run** Button. A graph of the operation pattern will be displayed.



7.6.2 Origin Search

5. Click the Servo ON Button and then the Execute Button. The program jogging operation will be executed.

	Servo ON/OFF operation
AUTO V [min-1/div]	$\frown$
•	Servo ON
<sup>700</sup>	Servo OFF
600	
500	
400	
300	- Pun
200	Kuli
100-	
	Stopping
-100-	
-200	
	Progress time
0 010 1002 2020 0004 400	-[sec]
·	The number of forward movements
	Uratimes
FULL [ms/div]	The number of reverse movements
Dunning Information	0/0[times]
Total Time 4880[ms]	
The total amount of movements +9830400[reference units]	
	Punning condition re-petting

• Be aware of the following points if you cancel the program jogging operation while the motor is operating.

**CAUTION** 

- If you cancel operation with the Servo OFF Button, the motor will stop according to setting of the Servo OFF stopping method (Pn001 = n.□□□X).
- If you cancel operation with the **Cancel** Button, the motor will decelerate to a stop and then enter a zero-clamped state.

This concludes the program jogging procedure.

## 7.6.2 Origin Search

The origin search operation positions the motor to the origin within one rotation and the clamps it there.



• Make sure that the load is not coupled when you execute an origin search. The Forward Drive Prohibit (P-OT) signal and Reverse Drive Prohibit (N-OT) signal are disabled during an origin search.

Use an origin search when it is necessary to align the origin within one rotation with the machine origin. The following speeds are used for origin searches.

- Rotary Servomotors: 60 min<sup>-1</sup>
- Direct Drive Servomotors: 6 min<sup>-1</sup>
- Linear Servomotors: 15 mm/s



To align the origin within one rotation with the machine origin

7.6.2 Origin Search

## Preparations

Always check the following before you execute an origin search.

- The parameters must not be write prohibited.
- The main circuit power supply must be ON.
- There must be no alarms.
- The servo must be OFF.

## **Applicable Tools**

The following table lists the tools that you can use to perform an origin search and the applicable tool functions.

Tool	Function	Reference         Ω       Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)         Image: Operating Procedure on page 7-20	
Digital Operator	Fn003	Σ-7-Series Digital Operator Operating Man- ual (Manual No.: SIEP S800001 33)	
SigmaWin+	Setup - Origin Search	Gerating Procedure on page 7-20	

## **Operating Procedure**

Use the following procedure to perform an origin search.

- 1. Click the 🔎 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Search Origin in the Menu Dialog Box. The Origin Search Dialog Box will be displayed.
- 3. Read the warnings and then click the OK Button.



4. Click the Servo ON Button.

🖏 Origin Search AXIS#00
Origin Search Not Executed
Operation Servo OFF
Forward Reverse

#### 5. Click the Forward Button or the Reverse Button.

An origin search will be performed only while you hold down the mouse button. The motor will stop when the origin search has been completed.

🎳 Origin Search AXIS#00
Status Origin Search Not Executed
Operation Servo ON Servo OFF
Forward

This concludes the origin search procedure.

## 7.6.3 Test without a Motor

A test without a motor is used to check the operation of the host controller and peripheral devices by simulating the operation of the Servomotor in the SERVOPACK, i.e., without actually operating a Servomotor. This test allows you to check wiring, debug the system, and verify parameters to shorten the time required for setup work and to prevent damage to the machine that may result from possible malfunctions. The operation of the motor can be checked with this test regardless of whether the motor is actually connected or not.



Use  $PnOOC = n.\square\square\squareX$  to enable or disable the test without a motor.

Parameter		Meaning	When Enabled	Classification
Pn00C	n.□□□0 (default setting)	Disable tests without a motor.	After restart	Setup
	n.□□□1	Enable tests without a motor.		

Information An asterisk is displayed on the status display of the Digital Operator while a test without a motor is being executed.

## Motor Information and Encoder Information

The motor and encoder information is used during tests without a motor. The source of the information depends on the device connection status.

Rotary Servomotor

Motor Connection Status	Information That Is Used	Source of Information	
Connected	Motor information <ul> <li>Rated motor speed</li> <li>Maximum motor speed</li> </ul>	Information in the motor that is connected	
Connected	Encoder information <ul> <li>Encoder resolution</li> <li>Encoder type</li> </ul>	information in the motor that is connected	
Not connected	Motor information • Rated motor speed • Maximum motor speed	<ul> <li>Setting of Pn000 = n.X□□□ (Rotary/Linear Servomotor Startup Selection When Encoder Is Not Connected)</li> <li>Rated motor speed and maximum motor speed The values previously saved in the SERVOPACK will be used for the rated motor speed and maximum motor speed. Use the motor displays (Un020: Rated Motor Speed and Un021: Maximum Motor Speed) to check the values.</li> </ul>	
	Encoder information <ul> <li>Encoder resolution</li> <li>Encoder type</li> </ul>	<ul> <li>Encoder resolution: Setting of Pn00C = n.□X□ (Encoder Resolution for Tests without a Motor)</li> <li>Encoder type: Setting of Pn00C = n.□X□□ (Encoder Type Selection for Tests without a Motor)</li> </ul>	

#### Linear Servomotors

Motor Connection Status	Information That Is Used	Source of Information
	Motor information	Information in the motor that is connected
Connected	Linear encoder informa- tion • Resolution • Encoder pitch • Encoder type	Information in the linear encoder that is connected
	Motor information	Setting of Pn000 = n.X□□□ (Rotary/Linear Servomotor Startup Selection When Encoder Is Not Connected)
Not connected	Linear encoder informa- tion • Resolution • Encoder pitch • Encoder type	<ul> <li>Resolution: 256</li> <li>Encoder pitch: Setting of Pn282 (Linear Encoder Scale Pitch)</li> <li>Encoder type: Setting of Pn00C = n. IXIII (Encoder Type Selection for Tests without a Motor)</li> </ul>

#### Related Parameters

Parameter		Meaning			When Enabled		Classification	
<b>D</b> p000	n.0□□□ (default setting)	When an encoder is not connected, start as SERVOPACK for Rotary Servomotor.			- After restart		Setup	
FILOU	n.1000	When an encoder is not connected, start as SERVOPACK for Linear Servomotor.						
	Linear Encoder S	Scale Pitch		Speed Position			tion	Force
Pn282	Setting Range	Setting Unit	Default Setting	Whe	en Enabled	(	Classification	
	0 to 6,553,600	0.01 µm	0	Aft	ter restart		Setup	
Parameter		Meaning			When Enabled		Clas	sification
	n.□□0□ (default setting)	Use 13 bits as encoder resolution for tests without a motor.						
	n.0010	Use 20 bits as encoder resolution for tests without a motor.						
Pp00C	n.🗆 🗆 2 🗆	Use 22 bits as encoder resolution for tests without a motor.			Aftor roots	rt	Satur	
FILLUC	n.🗆 🗆 3 🗆	Use 24 bits as encoder resolution for tests without a motor.			- Alter restart Setup			Jeiup
	n.□0□□ (default setting)	Use an incremental encoder for tests without a motor.						
	n.0100	Use an absolute encoder for tests without a motor.						

## Motor Position and Speed Responses

For a test without a motor, the following responses are simulated for references from the host controller according to the gain settings for position or speed control.

- Servomotor position
- Motor speed

The load model will be for a rigid system with the moment of inertia ratio that is set in Pn103.

## Restrictions

The following functions cannot be used during the test without a motor.

- Regeneration and dynamic brake operation
- Brake output signal
  - Refer to the following section for information on confirming the brake output signal.
- Items marked with "x" in the following utility function table

SigmaWin+		Digital Operator		Executable?		
Menu Bar Button	SigmaWin+ Function Name	Fn No.	Utility Function Name	Motor Not Connected	Motor Connected	Reference
	Origin Search	Fn003	Origin Search	0	0	page 7-19
	Absolute Encoder Reset	Fn008	Reset Absolute Encoder	×	0	page 5-47
	Analog Monitor Out-	Fn00C	Adjust Analog Monitor Output Offset	0	0	page 9-8
	put Adjustment	Fn00D	Adjust Analog Monitor Output Gain	0	0	page 9-8
	Motor Current Detec-	Fn00E	Autotune Motor Cur- rent Detection Signal Offset	×	0	page 6 41
	ment	Fn00F	Manually Adjust Motor Current Detection Sig- nal Offset	×	0	page 6-41
Setup	Parameter Write Pro- hibition Setting	Fn010	Write Prohibition Set- ting	0	0	page 5-6
·	Multiturn Limit Setting	Fn013	Multiturn Limit Setting after Multiturn Limit Disagreement Alarm	×	0	page 6-30
	Initializing the Vibra- tion Detection Level	Fn01B	Initialize Vibration Detection Level	×	×	page 6-37
	Set Origin	Fn020	Set Absolute Linear Encoder Origin	×	0	page 5-49
	Reset Motor Type Alarm	Fn021	Reset Motor Type Alarm	0	0	-
	Software Reset	Fn030	Software Reset	0	0	page 6-34
	Polarity Detection	Fn080	Polarity Detection	×	×	page 5-26
	Tuning-less Level Setting	Fn200	Tuning-less Level Set- ting	×	×	page 8-16
	Easy FFT	Fn206	Easy FFT	×	×	page 8-95
Parameter	Initialize <sup>*</sup>	Fn005	Initialize Parameters	0	0	page 5-9
	Autotuning without Host Reference	Fn201	Advanced Autotuning without Reference	×	×	page 8-24
	Autotuning with Host Reference	Fn202	Advanced Autotuning with Reference	×	×	page 8-35
Tuning	Custom Tuning	Fn203	One-Parameter Tuning	×	×	page 8-42
	Adjust Anti-reso- nance Control	Fn204	Adjust Anti-resonance Control	×	×	page 8-50
	Vibration Suppres- sion	Fn205	Vibration Suppression	×	×	page 8-55
		Fn011	Display Servomotor Model	0	0	page 9-2
Monitoring	Product Information	Fn012	Display Software Ver- sion	0	0	
		Fn01E	Display SERVOPACK and Servomotor IDs	0	0	page 9-2
Test Oper-	Jogging	Fn002	Jogging	0	0	page 7-7
ation	Program Jogging	Fn004	Program Jogging	0	0	page 7-14

Continued on next page.

Continued from previous page.

SigmaWin+		Digital Operator		Executable?		
Menu Bar Button	SigmaWin+ Function Name	Fn No.	Utility Function Name	Motor Not Connected	Motor Connected	Reference
Alarms	Alarm Display	Fn000	Display Alarm History	0	0	page 10-37
		Fn006	Clear Alarm History	0	0	page 10-38

\* An Initialize Button will be displayed in the Parameter Editing Dialog Box.

## 7.7 Operation Using MECHATROLINK-III Commands

Refer to the following manual for information on MECHATROLINK-III commands.  $\square \Sigma$ -7-Series MECHATROLINK-III Communications Standard Servo Profile Command Manual (Manual No.: SIEP S800001 31)

# Tuning

This chapter provides information on the flow of tuning, details on tuning functions, and related operating procedures.

8.1	Overv	view and Flow of Tuning8-4
	8.1.1 8.1.2	Tuning Functions8-5Diagnostic Tool8-6
8.2	Monit	oring Methods8-7
8.3	Preca	utions to Ensure Safe Tuning8-8
	8.3.1 8.3.2 8.3.3	Overtravel Settings8-8Torque Limit Settings8-8Setting the Position Deviation OverflowAlarm Level8-8
	8.3.4 8.3.5	Vibration Detection Level Setting8-10Setting the Position Deviation OverflowAlarm Level at Servo ONAlarm Level at Servo ON
8.4	Tunin	g-less Function8-12
	8.4.1 8.4.2 8.4.3 8.4.4 8.4.5 8.4.6	Application Restrictions8-12Operating Procedure8-13Troubleshooting Alarms8-14Parameters Disabled by Tuning-less Function8-15Automatically Adjusted Function Setting8-15Related Parameters8-15
8.5	Estim	ating the Moment of Inertia8-16
	8.5.1 8.5.2 8.5.3 8.5.4	Outline8-16Restrictions8-17Applicable Tools8-17Operating Procedure8-18

8.6	Autot	uning without Host Reference8	3-24
	8.6.1 8.6.2 8.6.3 8.6.4 8.6.5	Outline	.8-24 .8-25 .8-26 .8-26
	8.6.6 8.6.7	Automatically Adjusted Function Settings Related Parameters	.8-30 .8-31 .8-34
8.7	Autot	uning with a Host Reference 8	8-35
	8.7.1 8.7.2 8.7.3 8.7.4 8.7.5 8.7.6 8.7.7	OutlineRestrictionsApplicable ToolsOperating ProcedureTroubleshooting Problems in Autotuningwith a Host ReferenceAutomatically Adjusted Function SettingsRelated Parameters	.8-35 .8-36 .8-36 .8-36 .8-40 .8-41 .8-41
8.8	Custo	m Tuning	8-42
	8.8.1 8.8.2 8.8.3 8.8.4 8.8.5 8.8.6 8.8.6 8.8.7	OutlinePreparationsApplicable ToolsOperating ProcedureAutomatically Adjusted Function SettingsTuning Example for Tuning Mode 2 or 3Related Parameters	.8-42 .8-43 .8-43 .8-43 .8-48 .8-48 .8-48 .8-49
8.9	Anti-F	Resonance Control Adjustment 8	8-50
	8.9.1 8.9.2 8.9.3 8.9.4 8.9.5 8.9.6	OutlinePreparationsApplicable ToolsOperating ProcedureRelated ParametersSuppressing Different Vibration Frequencieswith Anti-resonance Control	.8-50 .8-50 .8-51 .8-51 .8-53 .8-53
8.10	Vibrat	ion Suppression	8-55
	8.10.1 8.10.2 8.10.3 8.10.4 8.10.5 8.10.6	OutlinePreparationsApplicable ToolsOperating ProcedureSetting Combined FunctionsRelated Parameters	.8-55 .8-56 .8-56 .8-56 .8-58 .8-58
8.11	Speed	d Ripple Compensation	8-60
	8.11.1 8.11.2 8.11.3	Outline       Setting Up Speed Ripple Compensation         Setting Parameters       Setting Parameters	.8-60 .8-60 .8-64

8.12	Addit	ional Adjustment Functions8-66
	8.12.1 8.12.2 8.12.3 8.12.4 8.12.5 8.12.6 8.12.7	Gain Switching8-66Friction Compensation8-70Current Control Mode Selection8-71Current Gain Level Setting8-72Speed Detection Method Selection8-72Speed Feedback Filter8-72Backlash Compensation8-73
8.13	Manu	al Tuning8-79
	8.13.1 8.13.2	Tuning the Servo Gains8-79Compatible Adjustment Functions8-89
8.14	Diagn	ostic Tools8-93
	8.14.1 8.14.2	Mechanical Analysis

## 8.1 Overview and Flow of Tuning

Tuning is performed to optimize response by adjusting the servo gains in the SERVOPACK.

The servo gains are set using a combination of parameters, such as parameters for the speed loop gain, position loop gain, filters, friction compensation, and moment of inertia ratio. These parameters influence each other, so you must consider the balance between them.

The servo gains are set to stable settings by default. Use the various tuning functions to increase the response even further for the conditions of your machine.

The basic tuning procedure is shown in the following flowchart. Make suitable adjustments considering the conditions and operating requirements of your machine.



8.1.1 Tuning Functions

## 8.1.1 Tuning Functions

Tuning Function	Outline	Applicable Con- trol Methods	Reference
Tuning-less Function	This automatic adjustment function is designed to enable stable operation without servo tuning. This function can be used to obtain a stable response regardless of the type of machine or changes in the load. You can use it with the default settings.	Speed control or position control	page 8-12
Moment of Inertia Estimation	The moment of inertia ratio is calculated by operat- ing the Servomotor a few times. The moment of inertia ratio that is calculated here is used in other tuning functions.	Speed control, position control, or torque control	page 8-16
Autotuning without Host Reference	<ul> <li>The following parameters are automatically adjusted in the internal references in the SERVO- PACK during automatic operation.</li> <li>Gains (e.g., position loop gain and speed loop gain)</li> <li>Filters (torque reference filter and notch filters)</li> <li>Friction compensation</li> <li>Anti-resonance control</li> <li>Vibration suppression</li> </ul>	Speed control or position control	page 8-24
Autotuning with Host Reference	<ul> <li>The following parameters are automatically adjusted with the position reference input from the host controller while the machine is in operation. You can use this function for fine-tuning after you perform autotuning without a host reference.</li> <li>Gains (e.g., position loop gain and speed loop gain)</li> <li>Filters (torque reference filter and notch filters)</li> <li>Friction compensation</li> <li>Anti-resonance control</li> <li>Vibration suppression</li> </ul>	Position control	page 8-35
Custom Tuning	<ul> <li>The following parameters are adjusted with the position reference or speed reference input from the host controller while the machine is in operation.</li> <li>Gains (e.g., position loop gain and speed loop gain)</li> <li>Filters (torque reference filter and notch filters)</li> <li>Friction compensation</li> <li>Anti-resonance control</li> </ul>	Speed control or position control	page 8-42
Anti-resonance Control Adjustment	This function effectively suppresses continuous vibration.	Speed control or position control	page 8-50
Vibration Suppression	This function effectively suppresses residual vibra- tion if it occurs when positioning.	Position control	page 8-55
Speed Ripple Com- pensation	This function reduces the ripple in the motor speed.	Speed control, position control, or torque control	page 8-60
Additional Adjustment Function	This function combines autotuning with custom tuning. You can use it to improve adjustment results.	Depends on the functions that you use.	page 8-66
Manual Tuning	You can manually adjust the servo gains to adjust the response.	Speed control, position control, or torque control	page 8-79

The following table provides an overview of the tuning functions.

8.1.2 Diagnostic Tool

## 8.1.2 Diagnostic Tool

You can use the following tools to measure the frequency characteristics of the machine and set notch filters.

Diagnostic Tool	Outline	Applicable Control Methods	Reference
Mechanical Analysis	The machine is subjected to vibration to detect resonance frequencies. The measurement results are displayed as waveforms or numeric data.	Speed control, position control, or torque control	page 8-93
Easy FFT	The machine is subjected to vibration to detect resonance frequencies. The measurement results are displayed only as numeric data.	Speed control, position control, or torque control	page 8-95

## 8.2 Monitoring Methods

You can use the data tracing function of the SigmaWin+ or the analog monitor signals of the SERVOPACK for monitoring. If you perform custom tuning or manual tuning, always use the above functions to monitor the machine operating status and SERVOPACK signal waveform while you adjust the servo gains.

Check the adjustment results with the following response waveforms.

Position Control

ltom	Unit		
nem	Rotary Servomotor	Linear Servomotor	
Torque reference		%	
Feedback speed	min <sup>-1</sup>	mm/s	
Position reference speed	min <sup>-1</sup> mm/s		
Position deviation	Reference units		

#### • Speed Control

ltom	Unit		
nem	Rotary Servomotor	Linear Servomotor	
Torque reference	%		
Feedback speed	min <sup>-1</sup>	mm/s	
Reference speed	min <sup>-1</sup>	mm/s	

#### Torque Control

ltom	Unit		
nem	Rotary Servomotor	Linear Servomotor	
Torque reference	%		
Feedback speed	min <sup>-1</sup> mm/s		

8.3.1 Overtravel Settings

## **Precautions to Ensure Safe Tuning**

## CAUTION

- Observe the following precautions when you perform tuning.
  - Do not touch the rotating parts of the motor when the servo is ON.
  - · Before starting the Servomotor, make sure that an emergency stop can be performed at any time.
  - Make sure that trial operation has been successfully performed without any problems.
  - · Provide an appropriate stopping device on the machine to ensure safety.

Perform the following settings in a way that is suitable for tuning.

#### 8.3.1 **Overtravel Settings**

Overtravel settings are made to force the Servomotor to stop for a signal input from a limit switch when a moving part of the machine exceeds the safe movement range.

Refer to the following section for details.

5.11 Overtravel and Related Settings on page 5-29

#### 8.3.2 **Torque Limit Settings**

You can limit the torque that is output by the Servomotor based on calculations of the torque required for machine operation. You can use torque limits to reduce the amount of shock applied to the machine when problems occur, such as collisions or interference. If the torque limit is lower than the torgue that is required for operation, overshooting or vibration may occur. Refer to the following section for details.

3 6.6 Selecting Torque Limits on page 6-22

#### Setting the Position Deviation Overflow Alarm Level 8.3.3

The position deviation overflow alarm is a protective function that is enabled when the SERVO-PACK is used in position control.

If the alarm level is set to a suitable value, the SERVOPACK will detect excessive position deviation and will stop the Servomotor if the Servomotor operation does not agree with the reference.

The position deviation is the difference between the position reference value and the actual position.

You can calculate the position deviation from the position loop gain (Pn102) and the motor speed with the following formula.

#### Rotary Servomotors

Motor speed [min<sup>-1</sup>] Encoder resolution<sup>\*1</sup> Pn210 Position deviation [reference units] : 60 Pn102 [0.1/s]/10\*2,\*3 × Pn20E

#### Linear Servomotors

	Motor speed [mm/s]	Resolution	Pn210
Position deviation [reference units]	= Pn102 [0.1/s]/10 <sup>*2, *3</sup>	× Linear encoder pitch $[\mu m]/1,000$	× Pn20E

#### 8.3.3 Setting the Position Deviation Overflow Alarm Level

Position Deviation Overflow Alarm Level (Pn520) [setting unit: reference units]

#### Rotary Servomotors

 $Pn520 > \frac{Maximum motor speed [min<sup>-1</sup>]}{60} \times \frac{Encoder resolution<sup>*1</sup>}{Pn102 [0.1/s]/10^{*2, *3}} \times \frac{Pn210}{Pn20E} \times \frac{(1.2 \text{ to } 2)^{*4}}{Encoder model}$ 

#### · Linear Servomotors

D 500	Maximum motor speed [mm/s]	Resolution	Pn210	(1 0 +0 0)*4
Ph520 >	Pn102 [0.1/s]/10 <sup>*2, *3</sup>	Linear encoder pitch [µm]/1,000	Pn20E	(1.2 (0 2)

\*1. Refer to the following section for details.

5.15 Electronic Gear Settings on page 5-42

- \*2. When model following control (Pn140 = n. 
  DDD1) is enabled, use the setting of Pn141 (Model Following Control Gain) instead of the setting of Pn102 (Position Loop Gain).
- \*3. To check the setting of Pn102 on the Digital Operator, change the parameter display setting to display all parameters (Pn00B = n.□□□1).
- \*4. The underlined coefficient "× (1.2 to 2)" adds a margin to prevent an A.d00 alarm (Position Deviation Overflow) from occurring too frequently.

If you set a value that satisfies the formula, an A.d00 alarm (Position Deviation Overflow) should not occur during normal operation.

If the Servomotor operation does not agree with the reference, position deviation will occur, an error will be detected, and the motor will stop.

The following calculation example uses a Rotary Servomotor with a maximum motor speed of

6,000 and an encoder resolution of 16,777,216 (24 bits). Pn102 is set to 400.  $\frac{Pn210}{Pn20E} = \frac{1}{16}$ 

$$Pn520 = \frac{6,000}{60} \times \frac{16,777,216}{400/10} \times \frac{1}{16} \times 2$$
$$= 2,621,440 \times 2$$

= 5,242,880 (default setting of Pn520)

If the acceleration/deceleration rate required for the position reference exceeds the tracking capacity of the Servomotor, the tracking delay will increase and the position deviation will no longer satisfy the above formulas. If this occurs, lower the acceleration/deceleration rate so that the Servomotor can follow the position reference or increase the position deviation overflow alarm level.

## **Related Parameters**

	Position Deviation Overflow Alarm Level			Position		
Pn520	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	1 to 1,073,741,823	1 reference unit	5,242,880	Immediately	Setup	
	Position Deviation Overflow Warning Level			Position		
Pn51E	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	10 to 100	1%	100	Immediately	Setup	

## **Related Alarms**

Alarm Number	Alarm Name	Alarm Meaning
A.d00	Position Deviation Overflow	This alarm is displayed when the position deviation exceeds the set- ting of Pn520 (Position Deviation Overflow Alarm Level).

8.3.4 Vibration Detection Level Setting

## **Related Warnings**

Warning Number	Warning Name	Meaning
A.900	Position Deviation Overflow	This warning occurs if the position deviation exceeds the specified percentage (Pn520 $\times$ Pn51E/100).

## 8.3.4 Vibration Detection Level Setting

You can set the vibration detection level (Pn312) to more accurately detect A.520 alarms (Vibration Alarm) and A.911 warnings (Vibration) when vibration is detected during machine operation.

Set the initial vibration detection level to an appropriate value. Refer to the following section for details.

37 6.10 Initializing the Vibration Detection Level on page 6-37

# 8.3.5 Setting the Position Deviation Overflow Alarm Level at Servo ON

If the servo is turned ON when there is a large position deviation, the Servomotor will attempt to return to the original position to bring the position deviation to 0, which may create a hazardous situation. To prevent this, you can set a position deviation overflow alarm level at servo ON to restrict operation.

The related parameters and alarms are given in the following tables.

## **Related Parameters**

	Position Deviation Overflow Alarm Level at Servo ON			Position	
Pn526	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	1 to 1,073,741,823	1 reference unit	5,242,880	Immediately	Setup
	Position Deviation Overflow Warning Level at Servo ON			Posit	ion
Pn528	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	10 to 100	1%	100	Immediately	Setup

Rotary Servomotors

	Speed Limit Level at Servo ON			Positi	on
Pn529	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 10,000	1 min <sup>-1</sup>	10,000	Immediately	Setup

Linear Servomotors

	Speed Limit Level at Servo ON			Positio	on
Pn584	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 10,000	1 mm/s	10,000	Immediately	Setup

#### 8.3.5 Setting the Position Deviation Overflow Alarm Level at Servo ON

## **Related Alarms**

Alarm Number	Alarm Name	Alarm Meaning
A.d01	Position Deviation Overflow Alarm at Servo ON	This alarm occurs if the servo is turned ON after the position devia- tion exceeded the setting of Pn526 (Position Deviation Overflow Alarm Level at Servo ON) while the servo was OFF.
A.d02	Position Deviation Overflow Alarm for Speed Limit at Servo ON	If position deviation remains in the deviation counter, the setting of Pn529 or Pn584 (Speed Limit Level at Servo ON) will limit the speed when the servo is turned ON. This alarm occurs if a position reference is input and the setting of Pn520 (Position Deviation Overflow Alarm Level) is exceeded.

Refer to the following section for information on troubleshooting alarms. 10.2.3 Resetting Alarms on page 10-37

## **Related Warnings**

Warning Number	Warning Name	Meaning
A.901	Position Deviation Overflow Warning at Servo ON	This warning occurs if the servo is turned ON while the position deviation exceeds the specified percentage (Pn526 × Pn528/100).

8.4.1 Application Restrictions

## 8.4 **Tuning-less Function**

The tuning-less function performs autotuning to obtain a stable response regardless of the type of machine or changes in the load. Autotuning is started when the servo is turned ON.

## 

- The tuning-less function is disabled during torque control.
- The Servomotor may momentarily emit a sound the first time the servo is turned ON after the Servomotor is connected to the machine. This sound is caused by setting the automatic notch filter. It does not indicate a problem. The sound will not be emitted from the next time the servo is turned ON.
- The Servomotor may vibrate if it exceeds the allowable load moment of inertia. If that occurs, set the tuning-less load level to 2 (Pn170 = n.2□□□) or reduce the Tuning-less Rigidity Level (Pn170 = n.□X□□).
- To ensure safety, make sure that you can perform an emergency stop at any time when you execute the tuning-less function.

## 8.4.1 Application Restrictions

The following application restrictions apply to the tuning-less function.

Function	Executable?	Remarks
Vibration Detection Level Initialization	0	_
Moment of Inertia Estimation	×	Disable the tuning-less function (Pn170 = $n.\Box\Box\Box$ 0) before you execute moment of inertia estimation.
Autotuning without Host Reference	×	Disable the tuning-less function (Pn170 = $n.\Box\Box\Box$ ) before you execute autotuning without a host reference.
Autotuning with Host Reference	×	_
Custom Tuning	×	_
Anti-Resonance Control Adjustment	×	_
Vibration Suppression	×	_
Easy FFT	0	The tuning-less function is disabled while you execute Easy FFT and then it is enabled when Easy FFT has been completed.
Friction Compensation	×	-
Gain Selection	×	_
Mechanical Analysis	0	The tuning-less function is disabled while you execute mechanical analysis and then it is enabled when mechan- ical analysis has been completed.

\* O: Yes ×: No

The tuning-less function is enabled in the default settings. No specific procedure is required. You can use the following parameter to enable or disable the tuning-less function.

Parameter		Meaning	When Enabled	Classification
	n.🗆 🗆 🗆 0	Disable tuning-less function.	After restart	Setup
Pn170	n.□□□1 (default setting)	Enable tuning-less function.		
	n.□□0□ (default setting)	Use for speed control.		
	n.0010	Use for speed control and use host controller for position control.		

When you enable the tuning-less function, you can select the tuning-less type. Normally, set Pn14F to  $n.\square\square2\square$  (Use tuning-less type 3) (default setting). If compatibility with previous models is required, set Pn14F to  $n.\square\square0\square$  (Use tuning-less type 1) or  $n.\square\square1\square$  (Use tuning-less type 2).

Parameter		Meaning	When Enabled	Classification
	n.🗆 🗆 🗆	Use tuning-less type 1.		
Pn14F	n.0010	Use tuning-less type 2. (The noise level is improved more than with tuning-less type 1.)	After restart	Tuning
	n.□□2□ (default setting)	Use tuning-less type 3.		

## **Tuning-less Level Settings**

If vibration or other problems occur, change the tuning-less levels. To change the tuning-less levels, use the SigmaWin+.

### Preparations

Always check the following before you set the tuning-less levels.

- The tuning-less function must be enabled (Pn170 =  $n.\Box\Box\Box$ 1).
- The test without a motor function must be disabled (Pn00C =  $n.\Box\Box\Box$ ).

### ♦ Step

Use the following procedure to set the tuning-less levels.

In addition to the following procedure, you can also set the parameters directly. Refer to *Related Parameters*, below, for the parameters to set.

1. Select *Setup - Response Level Setting* from the menu bar of the Main Window of the SigmaWin+.

The Response Level Setting Dialog Box will be displayed.

8.4.3 Troubleshooting Alarms

#### Click the ▲ or ▼ Button to adjust the response level setting. Increase the response level setting to increase the response. Decrease the response level setting to suppress vibration.

The default response level setting is 4.

Response Level Setting	Description	Remarks
7	Response level: High	
6		You cannot select these levels if tuning-less type 1 or 2 (Pn14F = $n \square \square \square \square$ or $n \square \square \square \square$ ) is used.
5		
4 (default setting)		
3		
2		-
1		
0	Response level: Low	

#### 3. Click the Completed Button.

The adjustment results will be saved in the SERVOPACK.

#### Related Parameters

#### Tuning-less Rigidity Level

If you use tuning-less type 1 or 2 (Pn14F =  $n.\square\square\square\square$  or  $n.\square\square1\square$ ), set the tuning-less level to between 0 and 4 (Pn170 =  $n.\square0\square\square$  to  $n.\square4\square\square$ ). Do not set the tuning-less level to between 5 and 7 (Pn170 =  $n.\square5\square\square$  to  $n.\square7\square\square$ ).

Parameter		Description		When Enabled	Classification
	n.0000	Tuning-less rigidity level 0 (low rig	idity)		
	n.0100	Tuning-less rigidity level 1	2		
	n.🗆2🗆 🗆	Tuning-less rigidity level 2			
	n.🗆3🗆 🗆	Tuning-less rigidity level 3			
Pn170	n.□4□□ (default setting)	Tuning-less rigidity level 4		Immediately	Setup
	n.🗆5🗆 🗆	Tuning-less rigidity level 5			
	n.□6□□	Tuning-less rigidity level 6			
	n.0700	Tuning-less rigidity level 7 (high rig	gidity)		

#### Tuning-less Load Level

Parameter		Description	When Enabled	Classification
	n.0000	Tuning-less load level 0		
Pn170	n.1□□□ (default setting)	Tuning-less load level 1	Immediately	Setup
	n.2000	Tuning-less load level 2		

## 8.4.3 Troubleshooting Alarms

An A.521 alarm (Autotuning Alarm) will occur if a resonant sound occurs or if excessive vibration occurs during position control. If an alarm occurs, implement the following measures.

#### • Resonant Sound

Decrease the setting of Pn170 =  $n.X\square\square\square$  or the setting of Pn170 =  $n.\squareX\square\square$ .

- Excessive Vibration during Position Control
- Increase the setting of  $Pn170 = n.X\square\square\square$  or decrease the setting of  $Pn170 = n.\squareX\square\square$ .

8.4.4 Parameters Disabled by Tuning-less Function

## 8.4.4 Parameters Disabled by Tuning-less Function

When the tuning-less function is enabled ( $Pn170 = n.\Box\Box\Box1$ ) (default setting), the parameters in the following table are disabled.

Item	Item Parameter Name	
	Speed Loop Gain Second Speed Loop Gain	Pn100 Pn104
Gain-Related Parameters	Speed Loop Integral Time Constant Second Speed Loop Integral Time Constant	Pn101 Pn105
	Position Loop Gain Second Position Loop Gain	Pn102 Pn106
	Moment of Inertia Ratio	Pn103
Advanced Control-Related	Friction Compensation Function Selection	Pn408 = n.X□□□
Parameters	Anti-Resonance Control Selection	Pn160= n.□□□X
Gain Selection-Related Parameters	Gain Switching Selection	Pn139= n.□□□X

The tuning-less function is disabled during torque control, Easy FFT, and mechanical analysis for a vertical axis. The gain-related parameters in the above table are enabled for torque control, Easy FFT, and mechanical analysis. Of these, Pn100, Pn103, and Pn104 are enabled for torque control.

## 8.4.5 Automatically Adjusted Function Setting

You can also automatically adjust notch filters.

Normally, set Pn460 to n. D1DD (Adjust automatically) (default setting). Vibration is automatically detected and a notch filter is set.

Set Pn460 to n.  $\Box 0 \Box \Box$  (Do not adjust automatically) only if you do not change the setting of the notch filter before you execute the tuning-less function.

Parameter		Meaning	When Enabled	Classification
D- 400	n.0000	Do not adjust the second stage notch filter automatically during execution of autotuning without a host reference, autotuning with a host reference, and custom tuning.	Immodiately	Tuping
F11400	n.□1□□ (default setting)	Adjust the second stage notch filter automati- cally during execution of autotuning without a host reference, autotuning with a host refer- ence, and custom tuning.	inineulately	Turning

## 8.4.6 Related Parameters

The following parameters are automatically adjusted when you execute the tuning-less function.

Do not manually change the settings of these parameters after you have enabled the tuningless function.

Parameter	Name
Pn401	First Stage First Torque Reference Filter Time Constant
Pn40C	Second Stage Notch Filter Frequency
Pn40D	Second Stage Notch Filter Q Value

8.5.1 Outline

## 8.5 Estimating the Moment of Inertia

This section describes how the moment of inertia is calculated.

The moment of inertia ratio that is calculated here is used in other tuning functions. You can also estimate the moment of inertia during autotuning without a host reference. Refer to the following section for the procedure.

8.6.4 Operating Procedure on page 8-26

## 8.5.1 Outline

The moment of inertia during operation is automatically calculated by the SERVOPACK for round-trip (forward and reverse) operation. A reference from the host controller is not used.

The moment of inertia ratio (i.e., the ratio of the load moment of inertia to the motor moment of inertia) is a basic parameter for adjusting gains. It must be set as accurately as possible.

Although the load moment of inertia can be calculated from the weight and structure of the mechanisms, doing so is very troublesome and calculating it accurately can be very difficult with the complex mechanical structures that are used these days. With moment of inertia estimation, you can get an accurate load moment of inertia simply by operating the motor in the actual system in forward and reverse a few times.

The motor is operated with the following specifications.

- Maximum speed: ±1,000 min<sup>-1</sup> (can be changed)
- Acceleration rate: ±20,000 min<sup>-1</sup>/s (can be changed)
- Travel distance: ±2.5 rotations max. (can be changed)



Note: Execute moment of inertia estimation after jogging to a position that ensures a suitable range of motion.

## 8.5.2 Restrictions

The following restrictions apply to estimating the moment of inertia.

## Systems for which Execution Cannot Be Performed

- · When the machine system can move only in one direction
- When the range of motion is 0.5 rotations or less

## Systems for Which Adjustments Cannot Be Made Accurately

- When a suitable range of motion is not possible
- When the moment of inertia changes within the set operating range
- · When the machine has high dynamic friction
- When the rigidity of the machine is low and vibration occurs when positioning is performed
- When the position integration function is used
- When proportional control is used

Note: If you specify calculating the moment of inertia, an error will occur if V\_PPI in the servo command output signals (SVCMD\_IO) changes to specify the proportional action during moment of inertia estimation.

When mode switching is used

Note: If you specify moment of inertia estimation, mode switching will be disabled and PI control will be used while the moment of inertia is being calculated. Mode switching will be enabled after moment of inertia estimation has been completed.

• When speed feedforward or torque feedforward is input

## Preparations

Always check the following before you execute moment of inertia estimation.

- The main circuit power supply must be ON.
- There must be no overtravel.
- The servo must be OFF.
- The control method must not be set to torque control.
- The gain selection switch must be set to manual gain selection (Pn139 =  $n.\Box\Box\Box$ ).
- The first gains must be selected.
- The test without a motor function must be disabled (Pn00C =  $n.\Box\Box\Box$ ).
- There must be no alarms or warnings.
- The parameters must not be write prohibited.
- The tuning-less function must be disabled (Pn170 =  $n.\Box\Box\Box$ ).

## 8.5.3 Applicable Tools

The following table lists the tools that you can use to estimate the moment of inertia and the applicable tool functions.

Tool	Function	Operating Procedure Reference
SigmaWin+	Tuning - Tuning	🗊 8.5.4 Operating Procedure on page 8-18

## 8.5.4 Operating Procedure

Use the following procedure to estimate the moment of inertia ratio.

## \land WARNING

- Estimating the moment of inertia requires operating the motor and therefore presents hazards. Observe the following precaution.
  - · Confirm safety around moving parts.

This function involves automatic operation with vibration. Make sure that you can perform an emergency stop (to turn OFF the power supply) at any time. There will be movement in both directions within the set range of movement. Check the range of movement and the directions and implement protective controls for safety, such as the overtravel functions.

- Be aware of the following points if you cancel the moment of inertia estimation while the motor is operating.
  - If you cancel operation with the Servo OFF Button, the motor will stop according to setting of the Servo OFF stopping method (Pn001 = n.□□□X).
  - If you cancel operation with the **Cancel** Button, the motor will decelerate to a stop and then enter a zero-clamped state.
- 1. Click the <u>I</u> Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Tuning in the Menu Dialog Box. The Tuning Dialog Box will be displayed. Click the **Cancel** Button to cancel tuning.
- 3. Click the Execute Button.



4. Click the Execute Button.



5. Set the conditions as required.



#### Speed Loop Setting Area

Make the speed loop settings in this area.

If the speed loop response is too bad, it will not be possible to measure the moment of inertia ratio accurately.

The values for the speed loop response that are required for moment of inertia estimation are set for the default settings. It is normally not necessary to change these settings. If the default speed loop gain is too high for the machine (i.e., if vibration occurs), lower the setting. It is not necessary to increase the setting any farther.

#### 2 Identification Start Level Group

This is the setting of the moment of inertia calculation starting level. If the load is large or the machine has low rigidity, the torque limit may be applied, causing moment of inertia estimation to fail.

If that occurs, estimation may be possible if you double the setting of the start level. ③ Edit Buttons

Click the button to display a dialog box to change the settings related to the speed loop or estimation start level.

#### ④ Help Button

Click this button to display guidelines for setting the reference conditions. Make the following settings as required.

- Operate the motor to measure the load moment of inertia of the machine in comparison with the rotor moment of inertia.
- Set the operation mode, reference pattern (maximum acceleration rate, maximum speed, and maximum travel distance), and speed loop-related parameters.
- Correct measurement of the moment of inertia ratio may not be possible depending on the settings. Set suitable settings using the measurement results as reference.

#### **S Reference Selection** Area

Either select the reference pattern for estimation processing from the box, or set the values in the **Detailed Setting** Group. Generally speaking, the larger the maximum acceleration rate is, the more accurate the moment of inertia estimation will be.

Set the maximum acceleration range within the possible range of movement considering the gear ratio, e.g., the pulley diameters or ball screw pitch.

#### 6 Confirm Button

Click this button to display the Reference Confirmation Dialog Box.

Reference confirmation		
Moving distance 2.50	(rotation)	
Driving pattern		
V:Speed	1000.00 [min-1]	
T1:Acceleration Time	50 [ms]	
T2:Constant-speed time	100 [ms]	
Total operation time	400 [ms]	
[OK]		

#### ⑦ Detailed Setting Area

You can change the settings by moving the bars or directly inputting the settings to create the required reference pattern.

8 Next Button

Click this button to display the Reference Transmission Dialog Box.

- O Cancel Button
  - Click this button to return to the Tuning Dialog Box.



Estimating the moment of inertia ratio cannot be performed correctly if the torque limit is activated. Adjust the limits or reduce the acceleration rate in the reference selection so that the torque limit is not activated.

#### 6. Click the Next Button.

The Reference Transmission Dialog Box will be displayed.

7. Click the Start Button.



① Start Button

The reference conditions will be transferred to the SERVOPACK. A progress bar will show the progress of the transfer.

2 Cancel Button

The **Cancel** Button is enabled only while data is being transferred to the SERVOPACK. You cannot use it after the transfer has been completed.

3 Back Button

This button returns you to the Condition Setting Dialog Box. It is disabled while data is being transferred.

④ Next Button

This button is enabled only when the data has been transferred correctly. You cannot use it if an error occurs or if you cancel the transfer before it is completed.

Click the Next Button to display the Operation/Measurement Dialog Box.

S Cancel Button

This button cancels processing and returns you to the Tuning Dialog Box.

8. Click the Next Button.

The Operation/Measurement Dialog Box will be displayed.

9. Click the Servo On Button.



#### 10. Click the Forward Button.

The shaft will rotate in the forward direction and the measurement will start. After the measurement and data transfer have been completed, the **Reverse** Button will be displayed in color.

11. Click the Reverse Button.



The shaft will rotate in the reverse direction and the measurement will start. After the measurement and data transfer have been completed, the **Forward** Button will be displayed in color.



12. Repeat steps 8 to 9 until the Next Button is enabled.

Measurements are performed from 2 to 7 times and then verified. The number of measurements is displayed in upper left corner of the dialog box. A progress bar at the bottom of the dialog box will show the progress of the transfer each time.

13. When the measurements have been completed, click the Servo On Button to turn OFF the servo.

#### 14. Click the Next Button.

The Write Results Dialog Box will be displayed.

Information If you click the **Next** Button before you turn OFF the servo, the following Dialog Box will be displayed. Click the **OK** Button to turn OFF the servo.

Moment of Inertia Identification
1 turns the Servo OFF.
OK Cancel
8.5.4 Operating Procedure

15. Click the Writing Results Button.



### ① Identified Moment of Inertia Ratio Box

The moment of inertia ratio that was found with operation and measurements is displayed here.

<sup>(2)</sup> Writing Results Button

If you click this button, Pn103 (Moment of Inertia Ratio) in the SERVOPACK is set to the value that is displayed for the identified moment of inertia ratio.

### ③ Pn103: Moment of Inertia Ratio Box

The value that is set for the parameter is displayed here.

After you click the **Writing Results** Button, the value that was found with operation and measurements will be displayed as the new setting.

④ Back Button

This button is disabled.

S Cancel Button

This button will return you to the Tuning Dialog Box.

- 16. Confirm that the Identified Moment of Inertia Ratio Box and the Pn103: Moment of Inertia Ratio Box show the same value and then click the Finish Button.
- 17. Click the OK Button.



18. Click the Execute Button.

① Software Reset Common for the Unit	×
The software reset function will be executed. The Servopack will stop responding for approximately 5 seconds after the fuction begins.	
Execute 0%	

If the setting of the moment of inertia ratio (Pn103) was changed, the new value will be saved and the Tuning Dialog Box will be displayed again.

This concludes the procedure to estimate the moment of inertia ratio.

8.6.1 Outline

# 8.6 Autotuning without Host Reference

This section describes autotuning without a host reference.

Important	<ul> <li>Autotuning without a host reference performs adjustments based on the setting of the speed loop gain (Pn100). Therefore, precise adjustments cannot be made if there is vibration when adjustments are started. Make adjustments after lowering the speed loop gain (Pn100) until vibration is eliminated.</li> <li>You cannot execute autotuning without a host reference if the tuning-less function is enabled (Pn170 = n11 (default setting)). Disable the tuning-less function (Pn170 = n0) before you execute autotuning without a host reference.</li> <li>If you change the machine load conditions or drive system after you execute autotuning without a host reference and then you execute autotuning without a host reference with moment of inertia estimation specified, use the following parameter settings. If you execute autotuning without a host reference for any other conditions, the machine may vibrate and may be damaged.</li> <li>Pn140 = n0 (Do not use model following control.)</li> <li>Pn160 = n0 (Do not use anti-resonance control.)</li> <li>Pn408 = n.0000 (Disable friction compensation, first stage notch filter, and second stage notch filter.)</li> <li>Note: If you are using the Digital Operator and the above parameters are not displayed, change</li> </ul>
	the parameter display setting to display all parameters (Pn00B = $n.\Box\Box\Box$ ) and then turn the power supply OFF and ON again.

# 8.6.1 Outline

For autotuning without a host reference, operation is automatically performed by the SERVO-PACK for round-trip (forward and reverse) operation to adjust for machine characteristics during operation. A reference from the host controller is not used.

The following items are adjusted automatically.

- Moment of inertia ratio
- · Gains (e.g., speed loop gain and position loop gain)
- Filters (torque reference filter and notch filters)
- Friction compensation
- Anti-resonance control
- Vibration suppression (only for mode 2 or 3)

Refer to the following section for details on the parameters that are adjusted. **8.6.7** *Related Parameters* on page 8-34

The motor is operated with the following specifications.

Maximum speed	Rated motor speed × $\frac{2}{3}$		
Acceleration Torque	Rated motor torque: Approx. 100% Note: The acceleration torque depends on the setting of the influence of the moment of inertia ratio (Pn103), machine friction, and external disturbance.		
	Rotary Servomotors	You can set the desired travel distance. The default setting is for a value equivalent to 3 motor shaft rotations.	
Travel Distance	Direct Drive Servomotors	You can set the desired travel distance. The default setting is for a value equivalent to 0.3 rotations.	
	Linear Servomotors	You can set the desired travel distance in increments of 1,000 reference units. (The default setting is for 90 mm.)	

8.6.2 Restrictions



Example of Automatic Operation Pattern

a position that ensures a suitable range of motion.

# WARNING

- Autotuning without a host reference requires operating the motor and therefore presents hazards. Observe the following precaution.
  - Confirm safety around moving parts.

This function involves automatic operation with vibration. Make sure that you can perform an emergency stop (to turn OFF the power supply) at any time. There will be movement in both directions within the set range of movement. Check the range of movement and the directions and implement protective controls for safety, such as the overtravel functions.

#### 8.6.2 Restrictions

The following restrictions apply to autotuning without a host reference.

If you cannot use autotuning without a host reference because of these restrictions, use autotuning with a host reference or custom tuning. Refer to the following sections for details. 3.7 Autotuning with a Host Reference on page 8-35

■ 8.8 Custom Tuning on page 8-42

## Systems for Which Execution Cannot Be Performed

- · When the machine system can move only in one direction
- When the range of motion is 0.5 rotations or less

## Systems for Which Adjustments Cannot Be Made Accurately

- When a suitable range of motion is not possible
- · When the moment of inertia changes within the set operating range
- · When the machine has high friction
- When the rigidity of the machine is low and vibration occurs when positioning is performed
- When the position integration function is used
- When proportional control is used

Note: If you specify calculating the moment of inertia, an error will occur if V\_PPI in the servo command output signals (SVCMD\_IO) changes to specify the proportional action during moment of inertia estimation.

When mode switching is used

Note: If you specify moment of inertia estimation, mode switching will be disabled and PI control will be used while the moment of inertia is being calculated. Mode switching will be enabled after moment of inertia estimation has been completed.

- When speed feedforward or torque feedforward is input
- When the positioning completed width (Pn522) is too narrow

8.6.3 Applicable Tools

## Preparations

Always check the following before you execute autotuning without a host reference.

- The main circuit power supply must be ON.
- There must be no overtravel.
- The servo must be OFF.
- The control method must not be set to torque control.
- The gain selection switch must be set to manual gain selection (Pn139 =  $n.\Box\Box\Box$ ).
- The first gains must be selected.
- The test without a motor function must be disabled (Pn00C =  $n.\Box\Box\Box$ ).
- There must be no alarms or warnings.
- The parameters must not be write prohibited.
- The tuning-less function must be disabled (Pn170 = n.□□□0), or the tuning-less function must be enabled (Pn170 = n.□□□1) and moment of inertia estimation must be specified.
- If you execute autotuning without a host reference during speed control, set the mode to 1.
  - Information If you start autotuning without a host reference while the SERVOPACK is in speed control for mode 2 or 3, the SERVOPACK will change to position control automatically to perform autotuning without a host reference. The SERVOPACK will return to speed control after autotuning has been completed.

## 8.6.3 Applicable Tools

The following table lists the tools that you can use to perform autotuning without a host reference and the applicable tool functions.

Tool	Function	Operating Procedure Reference
Digital Operator	Fn201	Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Tuning - Tuning	🕼 8.6.4 Operating Procedure on page 8-26

# 8.6.4 Operating Procedure

Use the following procedure to perform autotuning without a host reference.



- If you are using an MP3000-series Controller for phase control, set the mode selection to 1. If 2 or 3 is selected for the mode, correct phase control may not be possible.
- 1. Confirm that the moment of inertia ratio (Pn103) is set correctly.
- 2. Click the <u>I</u> Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **3.** Select Tuning in the Menu Dialog Box. The Tuning Dialog Box will be displayed.

Click the **Cancel** Button to cancel tuning.

8.6.4 Operating Procedure

4. Click the Execute Button.



5. Select the No Reference Input Option in the Autotuning Area and then click the Autotuning Button.

Tuning AXIS#00		
Set the moment of inertia (mass) ratio before Precautions Precautions		
Moment of inertia (mass) ratio identification		
Pn103 : Moment of Inertia Ratio		
Execute.		
0 %Edit		
Autotuning Reference input from host controller C Position Reference Input		
Advanced adjustment Finish		

**Information** When the following dialog box is displayed, click the **OK** Button and then confirm that the correct moment of inertia ratio is set in Pn103 (Moment of Inertia Ratio).



#### 8.6.4 Operating Procedure

6. Set the conditions in the Switching the load moment of inertia (load mass) identification Box, the Mode selection Box, the Mechanism selection Box, and the Distance Box, and then click the Next Button.

Switching the load moment of intertia (le	oad mass) identific	ation
1:A moment of inertia is not presume	d.	-
Mode selection		
2:For positioning		-
A gain adjustment specialized for pos following automatic adjustments can filter, anti-resonance control, and vibr	itioning will be exe be executed: Mode ation suppression	cuted. In addition, the I following control, notch
Mechanism selection		
2:Ball screw mechanism or linear mo	tor	•
Distance		
The moving range from the current va 786 (-99990 - 99990)	786000	[reference units]
The moving range from the current va 786 (-99990 - 99990) (Setting invalid range : -131 - 131)	786000 3.0	[reference units] [Rotation]
The moving range from the current va 786 × 1000 = (-99990 - 99990) (Setting invalid range : -131 - 131) Tuning parameters	3.0	[reference units] [Rotation]
The moving range from the current va 786 X 1000 = (-99900) - 99900) (Setting invalid range : -131 - 131) Tunino parameters Start tuning using the default setting	lue is specified. 786000 3.0	[reference units] [Rotation]
The moving range from the current ve 786 X 1000 = (-99900 - 99990) (Setting invalid range : -131 - 131) Tuning garameters Start tuning using the default setting	10e is specified. 786000 3.0	[reference units] [Rotation]
The moving range from the current va 786 X 1000 = (-99900) - 99900) (Setting invalid range : -131 - 131) Tuning parameters Start tuning using the default setting	Ive s speched. 786000 3.0 Igs.	[Reference units] [Rotation] t> Cancel
The moving range from the current va 786 X 1000 = (-99900) -99900) (Setting invalid range : -131 - 131) Tuning narameters. Start tuning using the default setting	Ive s speched. 786000 3.0 Igs.	[reference units] [Rotation]

Set the travel distance. Movement range: -99,990,000 to +99,990,000 [reference units] Minimum setting increment for travel distance: 1,000 [reference units] Negative values are for reverse operation and positive values are for forward operation from the current position. Default settings: Rotary Servomotors: Approx. 3 rotations Direct Drive Servomotors: Approx. 0.3 rotations

Linear Servomotors: Approx 90 mm Set the distance to the following values or higher. To ensure tuning precision, we recommend that you use approximately the default distance setting.

Rotary Servomotors: 0.5 rotations Direct Drive Servomotors: 0.05 rotations Linear Servomotors: 5 mm

# • Switching the load moment of inertia (load mass) identification Box

Specify whether to estimate the moment of inertia. 0: A moment of inertia is presumed. (default setting) 1: A moment of inertia is not presumed.

### Mode selection Box

Set the mode.			
Mode Selection	Description		
1: Standard	Standard gain adjustment is per- formed. In addition to gain adjust- ment, notch filters and anti-resonance control are automatically adjusted.		
2: For positioning	Tuning is performed for positioning applications. In addition to gain adjustment, model following control, notch filters, anti-resonance control, and vibration suppression are auto- matically adjusted.		
3: For positioning especially to pre- vent overshooting	Tuning is performed for positioning applications with emphasis on elimi- nating overshooting. In addition to gain adjustment, notch filters, anti- resonance control, and vibration sup- pression are automatically adjusted.		

### Mechanism selection Box

Select the type according to the machine element to drive.

If there is noise or if the gain does not increase, better results may be obtained by changing the rigidity type. Select the type according to the following guidelines.

Mechanism Selection	Description
1: Belt mechanism	Tuning is performed for a mecha- nism with relatively low rigidity, e.g., a belt.
2: Ball screw mech- anism or linear motor	Tuning is performed for a mecha- nism with relatively high rigidity, e.g., a ball screw or Linear Servomotor. Use this setting if there is no other appropriate setting.
3: Rigid model	Tuning is performed for a mecha- nism with high rigidity, e.g., a rigid body system.

#### • Tuning parameters Box

Specify the parameters to use for tuning. If you select the **Start tuning using the default set-tings** Check Box, the tuning parameters will be returned to the default settings before tuning is started.

8.6.4 Operating Procedure

7. Click the Servo ON Button.

Autotuning - Automatic	setting AXIS#00	×
Waiting for execution	Servo ON/OFF ope	rvo OFF
Gain search behaviour evaluation	Mode selection	Start tuning
	Mechanism sel	g ection
Notch filter Anti-res Adj	Distance 786000 3.0	[reference units] [Rotation]
Precautions	< <u>B</u> ack	Finish

8. Click the Start tuning Button.

Autotuning - Automatic	setting AXIS#00	<b>—</b> ×
Waiting for execution	Servo ON/OFF op	ervo ON Servo OFF
Gain search behaviour evaluation	Mode selection 2:For positionir	Start tuning
	Mechanism sel	ection
	2:Ball screw n Distance	echanism or linear motor
Notch filter	786000	[reference units]
OAnti-res Adj Vib Suppress	3.0	[Rotation]
Precautions	< <u>B</u> ack	Finish Cancel

9. Confirm safety around moving parts and click the Yes Button.



The motor will start operating and tuning will be executed.

Vibration that occurs during tuning will be detected automatically and suitable settings will be made for that vibration. When the settings have been completed, the indicators for the functions that were used will light at the lower left of the dialog box.

8.6.5 Troubleshooting Problems in Autotuning without a Host Reference

<b>n</b> /9		
S Autotuning - Automatic	setting AXIS#00	8
Waiting for execution	Servo ON/OFF opera	o ON Servo OFF
Oscillation level measurement		
	Tuning	
Gain search behaviour evaluation	Mode selection	Cancel
()	2.For positioning	
	Mechanism select	ion
	2:Ball screw mech	hanism or linear motor
	Distance	[reference units]
Notch filter	786000	[reference units]
Vib Suppress	3.0	[Rotation]
Precautions	< <u>B</u> ack	Finish Cancel

### 10. When tuning has been completed, click the Finish Button.

The results of tuning will be set in the parameters and you will return to the Tuning Dialog Box.

This concludes the procedure to perform autotuning without a host reference.

# 8.6.5 Troubleshooting Problems in Autotuning without a Host Reference

The following tables give the causes of and corrections for problems that may occur in autotuning without a host reference.

## ◆ Autotuning without a Host Reference Was Not Performed

Possible Cause	Corrective Action
Main circuit power supply is OFF.	Turn ON the main circuit power supply.
An alarm or warning occurred.	Remove the cause of the alarm or warning.
Overtraveling occurred.	Remove the cause of overtraveling.
The second gains were selected with the gain selection.	Disable automatic gain switching.
The setting of the travel distance is too small.	Set the travel distance again in step 6 of the proce- dure.
The settings for the tuning-less function are not correct.	<ul> <li>Disable the tuning-less function (Pn170 = n.□□□0).</li> <li>Enable the tuning-less function (Pn170 = n.□□□1) and specify moment of inertia estimation.</li> </ul>

## When an Error Occurs during Execution of Autotuning without a Host Reference

Error	Possible Cause	Corrective Action
The gain adjustments were not successfully completed.	Machine vibration occurs or the posi- tioning completion signal is not stable when the Servomotor stops.	<ul> <li>Increase the setting of the positioning completed width (Pn522).</li> <li>Change the mode from 2 to 3.</li> <li>If machine vibration occurs, suppress the vibration with the anti-resonance control function and the vibration suppression function.</li> </ul>
An error occurred during calculation of the moment of inertia.	Refer to the following section for troubleshooting information. <i>→</i> When an Error Occurs during Calculation of Moment of Inertia on page 8-31	

Continued on next page.

### 8.6.6 Automatically Adjusted Function Settings

Continued from previous page.

Error	Possible Cause	Corrective Action
Positioning was not completed within approximately 10 sec- onds after position adjustment was com- pleted.	The positioning completed width is too narrow or proportional control is being used.	<ul> <li>Increase the setting of the positioning completed width (Pn522).</li> <li>Set V_PPI to 0 in the servo command output signals (SVCMD_IO).</li> </ul>

### When an Error Occurs during Calculation of Moment of Inertia

Possible Cause	Corrective Action
The SERVOPACK started calculating the moment of inertia but the calculation was not completed.	<ul><li>Increase the setting of the speed loop gain (Pn100).</li><li>Increase the stroke (travel distance).</li></ul>
The moment of inertia fluctuated greatly and did not converge within 10 tries.	Set Pn103 (Moment of Inertia Ratio) from the machine specifications and specify not estimating the moment of inertia.
Low-frequency vibration was detected.	Double the setting of moment of inertia calculation starting level (Pn324).
The torque limit was reached.	<ul> <li>If you are using the torque limit, increase the torque limit.</li> <li>Double the setting of moment of inertia calculation starting level (Pn324).</li> </ul>
The speed control section changed to proportional control during calculation of the moment of inertia, e.g., V_PPI in the servo command output signals (SVCMD_IO) was set to 1.	Use PI control when calculating the moment of inertia.

## Adjustment Results Are Not Satisfactory for Position Control

You may be able to improve the adjustment results by changing the settings of the positioning completed width (Pn522) and the electronic gear ratio (Pn20E/Pn210).

If satisfactory results are still not possible, adjust the overshoot detection level (Pn561). That may improve the adjustment results.

- Pn561 = 100% (default setting)
- This will allow tuning with overshooting that is equivalent to the positioning completed width. • Pn561 = 0%

This will allow tuning to be performed without overshooting within the positioning completed width, but the positioning completed width may be extended.

	Overshoot Detection Level			Speed Posit	ion Torque
Pn561	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 100	1%	100	Immediately	Setup

# 8.6.6 Automatically Adjusted Function Settings

You can specify whether to automatically adjust the following functions during autotuning.

### Automatic Notch Filters

Normally, set Pn460 to n. D1DD (Adjust automatically) (default setting).

Vibration will be detected during autotuning without a host reference and a notch filter will be adjusted.

Set Pn460 to n.  $\Box 0 \Box \Box$  (Do not adjust automatically) only if you do not change the setting of the notch filter before you execute this function.

### 8.6.6 Automatically Adjusted Function Settings

F	Parameter	Function	When Enabled	Classification
Pn460	n.□□□0	Do not adjust the first stage notch filter auto- matically during execution of autotuning with- out a host reference, autotuning with a host reference, and custom tuning.	- Immediately	Tuning
	n.□□□1 (default setting)	Adjust the first stage notch filter automatically during execution of autotuning without a host reference, autotuning with a host reference, and custom tuning.		
	n.0000	Do not adjust the second stage notch filter automatically during execution of autotuning without a host reference, autotuning with a host reference, and custom tuning.		
	n.□1□□ (default setting)	Adjust the second stage notch filter automati- cally during execution of autotuning without a host reference, autotuning with a host refer- ence, and custom tuning.		

## Anti-Resonance Control Adjustment

This function reduces low vibration frequencies, for which the notch filters cannot be used.

Normally, set Pn160 to n. DD1D (Adjust automatically) (default setting).

Vibration will be detected during autotuning without a host reference and anti-resonance control will be automatically adjusted.

F	Parameter	Function	When Enabled	Classification
<b>Pp160</b>	n.□□0□	Do not adjust anti-resonance control automat- ically during execution of autotuning without a host reference, autotuning with a host refer- ence, and custom tuning.	Immodiately	Tupipa
11100	n.□□1□ (default setting)	Adjust anti-resonance control automatically during execution of autotuning without a host reference, autotuning with a host reference, and custom tuning.	ininediately	Turning

## Vibration Suppression

You can use vibration suppression to suppress transitional vibration at a low frequency from 1 Hz to 100 Hz, which is generated mainly when the machine vibrates during positioning.

Normally, set Pn140 to n. D1DD (Adjust automatically) (default setting).

Vibration will be detected during autotuning without a host reference and vibration suppression control will be automatically set.

Set  $Pn140 = n.\Box 0 \Box \Box$  (Do not adjust automatically) only if you do not change the settings for vibration suppression before you execute autotuning without a host reference.

Note: Autotuning without a host reference uses model following control. Therefore, it can be executed only if the mode is set to 2 or 3.

P	arameter	Function	When Enabled	Classification
Pp140	n.0000	Do not adjust vibration suppression automati- cally during execution of autotuning without a host reference, autotuning with a host refer- ence, and custom tuning.	Immodiately	Tupipa
F11140	n.□1□□ (default setting)	Adjust vibration suppression automatically during execution of autotuning without a host reference, autotuning with a host reference, and custom tuning.	ininediately	Turning

### 8.6.6 Automatically Adjusted Function Settings

## ◆ Friction Compensation

Friction compensation compensates for changes in the following conditions.

- Changes in the viscous resistance of the lubricant, such as grease, on the sliding parts of the machine
- Changes in the friction resistance resulting from variations in the machine assembly
- Changes in the friction resistance due to aging

The conditions for applying friction compensation depend on the mode selection.

Mode Selection Settings	Friction Compensation
1: Standard	Based on the setting of Pn408 = n.XDDD (Friction Compensation Function Selection)*
2: For position control	Adjusted with friction compensation.

3: For position control (emphasis on overshooting)

P	arameter	Function	When Enabled	Classification
Pn408	n. 0□□□ (default setting)	Disable friction compensation.	Immediately	Setup
	n. 1000	Enable friction compensation.		

\* Refer to the following section for details.

Required Parameter Settings on page 8-70

## Feedforward

If Pn140 is set to n.0 [10] (Do not use model following control and speed/torque feedforward together (default setting)) and tuning is performed with the mode selection set to 2 or 3, feed-forward (Pn109), the speed feedforward input (VFF), and the torque feedforward input (TFF) will be disabled.

To use the speed feedforward input (VFF), the torque feedforward input (TFF), and model following control from the host controller in the system, set Pn140 to n.1DDD (Use model following control and speed/torque feedforward together).

F	Parameter	Function	When Enabled	Classification
Pp140	n.0□□□ (default setting)	Do not use model following control and speed/torque feedforward together.	Immodiately	Tuning
111140	n.1000	Use model following control and speed/torque feedforward together.	mmediately	runng

Refer to the following manual for information on the torque feedforward input (TFF) and the speed feedforward input (VFF).

Σ-7-Series MECHATROLINK-III Communications Standard Servo Profile Command Manual (Manual No.: SIEP S800001 31)



When model following control is used with the feedforward function, it is used to make optimum feedforward settings in the SERVOPACK. Therefore, model following control is not normally used together with either the speed feedforward input (VFF) or torque feedforward input (TFF) from the host controller. However, model following control can be used with the speed feedforward input (VFF) or torque feedforward input (VFF) if required. An unsuitable feedforward input may result in overshooting.

8.6.7 Related Parameters

# 8.6.7 Related Parameters

The following parameters are automatically adjusted or used as reference when you execute autotuning without a host reference.

Do not change the settings while autotuning without a host reference is being executed.

Parameter	Name	Automatic Changes
Pn100	Speed Loop Gain	Yes
Pn101	Speed Loop Integral Time Constant	Yes
Pn102	Position Loop Gain	Yes
Pn103	Moment of Inertia Ratio	Yes
Pn121	Friction Compensation Gain	Yes
Pn123	Friction Compensation Coefficient	Yes
Pn124	Friction Compensation Frequency Correction	No
Pn125	Friction Compensation Gain Correction	Yes
Pn401	First Stage First Torque Reference Filter Time Constant	Yes
Pn408	Torque-Related Function Selections	Yes
Pn409	First Stage Notch Filter Frequency	Yes
Pn40A	First Stage Notch Filter Q Value	Yes
Pn40C	Second Stage Notch Filter Frequency	Yes
Pn40D	Second Stage Notch Filter Q Value	Yes
Pn140	Model Following Control-Related Selections	Yes
Pn141	Model Following Control Gain	Yes
Pn142	Model Following Control Gain Correction	Yes
Pn143	Model Following Control Bias in the Forward Direction	Yes
Pn144	Model Following Control Bias in the Reverse Direction	Yes
Pn145	Vibration Suppression 1 Frequency A	Yes
Pn146	Vibration Suppression 1 Frequency B	Yes
Pn147	Model Following Control Speed Feedforward Compensation	Yes
Pn160	Anti-Resonance Control-Related Selections	Yes
Pn161	Anti-Resonance Frequency	Yes
Pn163	Anti-Resonance Damping Gain	Yes
Pn531	Program Jogging Travel Distance	No
Pn533	Program Jogging Movement Speed for Rotary Servomotor	No
Pn585	Program Jogging Movement Speed for Linear Servomotor	No
Pn534	Program Jogging Acceleration/Deceleration Time	No
Pn535	Program Jogging Waiting Time	No
Pn536	Program Jogging Number of Movements	No

Yes: The parameter is automatically set.

No: The parameter is not automatically set, but the setting is read during execution.

8.7.1 Outline

# 8.7 Autotuning with a Host Reference

This section describes autotuning with a host reference.



Autotuning with a host reference makes adjustments based on the set speed loop gain (Pn100). Therefore, precise adjustments cannot be made if there is vibration when adjustments are started. Make adjustments after lowering the speed loop gain (Pn100) until vibration is eliminated.

# 8.7.1 Outline

Autotuning with a host reference automatically makes optimum adjustments for operation references from the host controller.

The following items are adjusted automatically.

- Gains (e.g., speed loop gain and position loop gain)
- Filters (torque reference filter and notch filters)
- Friction compensation
- Anti-resonance control
- Vibration suppression

Refer to the following section for details on the parameters that are adjusted. (3) 8.7.7 Related Parameters on page 8-41



### 8.7.2 Restrictions

# 8.7.2 Restrictions

# Systems for Which Adjustments Cannot Be Made Accurately

Adjustments will not be made correctly for autotuning with a host reference in the following cases. Use custom tuning.

- When the travel distance for the reference from the host controller is equal to or lower than the setting of the positioning completed width (Pn522)
- Rotary Servomotors: When the movement speed for the reference from the host controller is equal to or lower than the setting of the rotation detection level (Pn502)
- Linear Servomotors: When the movement speed for the reference from the host controller is equal to or lower than the setting of the zero speed level (Pn581)
- When the time required to stop is 10 ms or less
- When the rigidity of the machine is low and vibration occurs when positioning is performed
- When the position integration function is used
- When proportional control is used
- When mode switching is used
- When the positioning completed width (Pn522) is too narrow

Refer to the following sections for details on custom tuning.

3.8 Custom Tuning on page 8-42

## Preparations

Always check the following before you execute autotuning with a host reference.

- The servo must be in ready status.
- There must be no overtravel.
- The servo must be OFF.
- Position control must be selected if power is supplied to the motor (i.e., when the servo is ON).
- The gain selection switch must be set to manual gain selection (Pn139 =  $n.\Box\Box\Box$ ).
- The first gains must be selected.
- The test without a motor function must be disabled (Pn00C =  $n.\Box\Box\Box$ ).
- There must be no warnings.
- The tuning-less function must be disabled (Pn170 =  $n.\Box\Box\Box$ ).
- The parameters must not be write prohibited.

## 8.7.3 Applicable Tools

The following table lists the tools that you can use to perform autotuning with a host reference and the applicable tool functions.

Tool	Function	Operating Procedure Reference
Digital Operator	Fn202	$\bigcap_{ual} \Sigma-7\text{-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)}$
SigmaWin+	Tuning - Tuning	<i>∎</i> 8.7.4 Operating Procedure on page 8-36

# 8.7.4 Operating Procedure

Use the following procedure to perform autotuning with a host reference.



• If you are using an MP3000-Series Controller for phase control, set the mode selection to 1. If 2 or 3 is selected for the mode, correct phase control may not be possible.

- **1.** Confirm that the moment of inertia ratio (Pn103) is set correctly.
- 2. Click the <u>J</u> Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **3.** Select Tuning in the Menu Dialog Box. The Tuning Dialog Box will be displayed. Click the **Cancel** Button to cancel tuning.
- 4. Click the Execute Button.

Tuning	×
This function executes tuning for the Servopack. Using this function while the motor is running is dangerous. Be sure to carefully read the SigmaWin+ Operation Manual before executing this function. Special care must be taken for the following	g.
<safety precautions=""> <ol> <li>Before executing this function, make sure that the emergency stop (power off) can be activated when needed.</li> <li>The response speed may change considerably during tuning.</li> <li>Before executing this function, make sure that the emergency stop (power off) can be activated when needed.</li> </ol></safety>	
<ol> <li>Confirm the safety of the area adjoining the drive unt.</li> <li>Before executing this function, always confirm that the area within the motor motion range and direction is clear for safe operation. Provide protective devices to ensure safety in the event of overtraveling or other unexpected movement.</li> </ol>	
<ol> <li>Always confirm that there is no position error before running the motor.</li> <li>Be sure to return to the origin and react the position prior to normal operation.</li> <li>Running the motor without resetting the origin can lead to an overrun and is extremely dangerous.</li> </ol>	
4. When the moment of inertia (mass) identification function is used for a vertical axis, check the safety of the system. When the moment of inertia (mass) identification function is used for a vertical axis, confirm that he axis level does not drop when the serve is turned off.	
<turning precautions=""> 5. Set he moment of inertia (mass) ratio first. The moment of inertia (mass) ratio must be set to achieve correct tuning. Be sure to set the ratio. The setting can be performed from the Tuning window.</turning>	
<ol> <li>If vibration is generated, execute custom tuning.</li> <li>Lower the gain until there is no vibration by executing custom tuning.</li> </ol>	
Note: While tuning, you can read the precautions related to the process. Click the Precautions button provided in each tuning window.	
Execute Cancel	

5. Select the **Position reference input** Option in the **Autotuning** Area and then click the **Autotuning** Button.

Tuning AXIS#00	×
Set the moment of inertia (mass) ratio before Precautions	
Moment of inertia (mass) ratio identification	
Pn103 : Moment of Inertia Ratio	
Execute.	
202 % Edit	
Autotuning	
Reference input from host controller	
Position Reference Input	
Advanced adjustment Finish	]

Information

When the following dialog box is displayed, click the **OK** Button and then confirm that the correct moment of inertia ratio is set in Pn103 (Moment of Inertia Ratio).



### 8.7.4 Operating Procedure

6. Set the conditions in the Mode selection Box and the Mechanism selection Box, and then click the Next Button.

If you select the **Start tuning using the default settings** Check Box in the **Tuning parameters** Area, the tuning parameters will be returned to the default settings before tuning is started.

Mode selection Box

	Set conditions.
[	Mode selection
	2:For positioning
	A gain adjustment specialized for positioning will be executed. In addition, the following automatic adjustments can be executed. Model following control, notch filter, anti-resonance control, and vibration suppression.
[	Mechanism selection
	2:Ball screw mechanism or linear motor
	Executes adjustment suitable for relatively high-rigidity mechanism, such as a ball screw or linear motor. Select this type if there is no applicable mechanism.
[	- Tuning parameters
	Start tuning using the default settings.
	Cancel
1	

• Tuning parameters Box Specify the parameters to use for tuning. If you select the Start tuning using the default settings Check Box, the tuning parameters will be returned to the default settings before tuning is started.

Set the mode.		
Mode Selection	Description	
1: Standard	Standard gain adjustment is per- formed. In addition to gain adjust- ment, notch filters and anti- resonance control are automatically adjusted.	
2: For positioning	Tuning is performed for positioning applications. In addition to gain adjustment, model following control, notch filters, anti-resonance control, and vibration suppression are auto- matically adjusted.	
3: For positioning especially to pre- vent overshooting	Tuning is performed for positioning applications with emphasis on elimi- nating overshooting. In addition to gain adjustment, notch filters, anti- resonance control, and vibration sup- pression are automatically adjusted.	

### Mechanism selection Box

Select the type according to the machine element to drive.

If there is noise or if the gain does not increase, better results may be obtained by changing the rigidity type. Select the type according to the following guidelines.

Mechanism Selection	Description	
1: Belt mechanism	Tuning is performed for a mecha- nism with relatively low rigidity, e.g., a belt.	
2: Ball screw mechanism or linear motor	Tuning is performed for a mecha- nism with relatively high rigidity, e.g., a ball screw or Linear Servomotor. Use this setting if there is no other appropriate setting.	
3: Rigid model	Tuning is performed for a mecha- nism with high rigidity, e.g., a rigid body system.	

7. Click the Yes Button.



8.7.4 Operating Procedure

8. Input the correct moment of inertia ratio and click the Next Button.

📲 Autotuning - Moment of Inertia Ratio Setting AXI			
If Moment of Inertia Ratio is not correctly set, vibration may be generated.			
Is Moment of Inertia Ratio correctly set?			
Pn103 : Moment of Inertia Ratio (0 - 20000)			
[%]			
< Back Next > Cancel			

**9.** Turn ON the servo, enter a reference from the host controller, and then click the **Start tuning** Button.

SAutotuning - Automatic s	etting AXIS#00	×
Waiting for execution Oscillation level measurement Gain search behaviour evaluation	Tuning Turn the servo on, input the reference from the host controller, and then click the Start button.	$\mathbf{D}$
runing completed	Mode selection	
Notch filter Anti-res Adj Vib Suppress	2.For positioning Mechanism selection 2.Ball screw mechanism or linear motor	
Precautions	< Back Finish Cancel	

10. Confirm safety around moving parts and click the Yes Button.



The motor will start operating and tuning will be executed.

Vibration that occurs during tuning will be detected automatically and suitable settings will be made for that vibration. When the settings have been completed, the indicators for the functions that were used will light at the lower left of the dialog box.

Autotuning - Automatic se	tting AXIS#00	83
Waiting for execution	-Tuning Executing tuning (Input the reference.)	
Oscillation level measurement	Cancel	
Gain search behaviour evaluation		
Tuning completed		
	Mode selection	
	2:For positioning	
Notch filter	Mechanism selection	
Anti-res Adj	2:Ball screw mechanism or linear motor	
Vib Suppress		
<b>-</b>		_
Precautions	< Back Finish Cancel	

8.7.5 Troubleshooting Problems in Autotuning with a Host Reference

### 11. When tuning has been completed, click the Finish Button.

The results of tuning will be set in the parameters and you will return to the Tuning Dialog Box.

This concludes the procedure to perform autotuning with a host reference.

# 8.7.5 Troubleshooting Problems in Autotuning with a Host Reference

The following tables give the causes of and corrections for problems that may occur in autotuning with a host reference.

## Autotuning with a Host Reference Was Not Performed

Possible Cause	Corrective Action
Main circuit power supply is OFF.	Turn ON the main circuit power supply.
An alarm or warning occurred.	Remove the cause of the alarm or warning.
Overtraveling occurred.	Remove the cause of overtraveling.
The second gains were selected with the gain selection.	Disable automatic gain switching.

## Troubleshooting Errors

Error	Possible Cause	Corrective Action
The gain adjustments were not successfully completed.	Machine vibration occurs or positioning completion is not stable when the Servomotor stops.	<ul> <li>Increase the setting of the positioning completed width (Pn522).</li> <li>Change the mode from 2 to 3.</li> <li>If machine vibration occurs, suppress the vibration with the anti-resonance control function and the vibration suppression function.</li> </ul>
Positioning was not completed within approximately 10 seconds after posi- tion adjustment was completed.	The positioning com- pleted width is too nar- row or proportional control is being used.	<ul> <li>Increase the setting of the positioning completed width (Pn522).</li> <li>Set V_PPI to 0 in the servo command output signals (SVCMD_IO).</li> </ul>

## Adjustment Results Are Not Satisfactory for Position Control

You may be able to improve the adjustment results by changing the settings of the positioning completed width (Pn522) and the electronic gear ratio (Pn20E/Pn210).

If satisfactory results are still not possible, adjust the overshoot detection level (Pn561). That may improve the adjustment results.

- Pn561 = 100% (default setting)
- This will allow tuning with overshooting that is equivalent to the positioning completed width. • Pn561 = 0%

This will allow tuning to be performed without overshooting within the positioning completed width, but the positioning completed width may be extended.

	Overshoot Detection	Speed Positi	on Torque		
Pn561	Setting Range	Setting Unit	Default Setting	When Enabled Classification	
	0 to 100	1%	100	Immediately	Setup

8.7.6 Automatically Adjusted Function Settings

# 8.7.6 Automatically Adjusted Function Settings

These function settings are the same as for autotuning without a host reference. Refer to the following section.

8.6.6 Automatically Adjusted Function Settings on page 8-31

## 8.7.7 Related Parameters

The following parameters are automatically adjusted or used as reference when you execute autotuning with a host reference.

Do not change the settings while autotuning with a host reference is being executed.

Parameter	Name	Automatic Changes
Pn100	Speed Loop Gain	Yes
Pn101	Speed Loop Integral Time Constant	Yes
Pn102	Position Loop Gain	Yes
Pn103	Moment of Inertia Ratio	No
Pn121	Friction Compensation Gain	Yes
Pn123	Friction Compensation Coefficient	Yes
Pn124	Friction Compensation Frequency Correction	No
Pn125	Friction Compensation Gain Correction	Yes
Pn401	First Stage First Torque Reference Filter Time Constant	Yes
Pn408	Torque-Related Function Selections	Yes
Pn409	First Stage Notch Filter Frequency	Yes
Pn40A	First Stage Notch Filter Q Value	Yes
Pn40C	Second Stage Notch Filter Frequency	Yes
Pn40D	Second Stage Notch Filter Q Value	Yes
Pn140	Model Following Control-Related Selections	Yes
Pn141	Model Following Control Gain	Yes
Pn142	Model Following Control Gain Correction	Yes
Pn143	Model Following Control Bias in the Forward Direction	Yes
Pn144	Model Following Control Bias in the Reverse Direction	Yes
Pn145	Vibration Suppression 1 Frequency A	Yes
Pn146	Vibration Suppression 1 Frequency B	Yes
Pn147	Model Following Control Speed Feedforward Compensation	Yes
Pn160	Anti-Resonance Control-Related Selections	Yes
Pn161	Anti-Resonance Frequency	Yes
Pn163	Anti-Resonance Damping Gain	Yes

Yes: The parameter is automatically set.

No: The parameter is not automatically set, but the setting is read during execution.

Tuning

8.8.1 Outline

# 8.8 Custom Tuning

This section describes custom tuning.

## 8.8.1 Outline

You can use custom tuning to manually adjust the servo during operation using a speed or position reference input from the host controller. You can use it to fine-tune adjustments that were made with autotuning.

The following items are adjusted automatically.

- · Gains (e.g., speed loop gain and position loop gain)
- Filters (torque reference filter and notch filters)
- Friction compensation
- Anti-resonance control

Refer to the following section for details on the parameters that are adjusted. **8.8.7** *Related Parameters* on page 8-49

There are two adjustment methods that you can use for custom tuning.

 Tuning Mode 0 (Setting Servo Gains Giving Priority to Stability) or 1 (Setting Servo Gains Giving Priority to Good Response)

These modes allow you to set stable control conditions for multiple servo gains by manipulating only one tuning level. Automatic setting of notch filters and anti-resonance control is provided if vibration is detected. Manual anti-resonance control adjustment is also possible during custom tuning.

 Tuning Mode 2 (Setting Servo Gains Giving Priority to Position Control Applications) or 3 (Setting Servo Gains Giving Priority to Preventing Overshooting in Position Control Applications)

Two tuning levels are manipulated to reduce positioning time even further and set multiple servo gains.

Model following control is used to reduce the positioning time. If vibration is detected, notch filters and anti-resonance control are automatically adjusted, and friction compensation is automatically set. Manual anti-resonance control adjustment and vibration suppression are also possible during custom tuning.

# **A CAUTION**

• Vibration or overshooting may occur during custom tuning. To ensure safety, make sure that you can perform an emergency stop at any time.

## 8.8.2 Preparations

Always check the following before you execute custom tuning.

- The test without a motor function must be disabled (Pn00C =  $n.\Box\Box\Box$ ).
- The tuning-less function must be disabled (Pn170 =  $n.\Box\Box\Box$ 0).
- If speed control is used, tuning mode 0 or 1 must be set.
- The parameters must not be write prohibited.

# 8.8.3 Applicable Tools

The following table lists the tools that you can use to perform custom tuning and the applicable tool functions.

Tool	Function	Operating Procedure Reference
Digital Operator	Fn203	Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Tuning – Tuning	€ 8.8.4 Operating Procedure on page 8-43

# 8.8.4 Operating Procedure

Use the following procedure to perform custom tuning.

## WARNING • Before you execute custom tuning, check the information provided in the SigmaWin+ operating manual. Observe the following precautions. • Make sure that you can perform an emergency stop at any time. When custom tuning is started, several parameters will be overwritten with the recommended settings, which may greatly affect the response before and after execution. Make sure that you can perform an emergency stop at any time. Set the moment of inertia correctly before you execute custom tuning. If the setting greatly differs from the actual moment of inertia, vibration may occur. If you change the feedforward level, the new setting will not be used immediately. It will be used • after positioning is completed. CAUTION • If you are using an MP3000-series Controller for phase control, set the tuning mode to 0 or 1. If 2 or 3 is selected for the tuning mode, correct phase control may not be possible.

- 1. Confirm that the moment of inertia ratio (Pn103) is set correctly.
- 2. Click the *P* Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **3.** Select Tuning in the Menu Dialog Box. The Tuning Dialog Box will be displayed. Click the **Cancel** Button to cancel tuning.

8.8.4 Operating Procedure

4. Click the Execute Button.



5. Click the Advanced adjustment Button.

Tuning AXIS#00
Set the moment of inertia (mass) ratio before Precautions
Moment of inertia (mass) ratio identification
Pn103 : Moment of Inertia Ratio
Execute
100 % Edit
Autotuning
Position Reference Input
C No Reference Input
Advanced adjustment Finish

Information

When the following dialog box is displayed, click the **OK** Button and then confirm that the correct moment of inertia ratio is set in Pn103 (Moment of Inertia Ratio).

Tuning
The moment of inertia (mass) ratio has never been changed from the default setting. Set a correct moment of inertia (mass) ratio in the Moment of Inertia (Mass) Setting window before starting turing. If an incorrect moment of inertia (mass) ratio is set, vibration may be generated during turing. Do you want to continue tuning?
Cancel

6. Click the Custom tuning Button.

Tuning	
Click the button of the function to be executed	
Manually adjust gain and vibration.	
Suppress vibration by decreasing gain when	stopped.

7. Set the Tuning mode Box and Mechanism selection Box, and then click the Next Button.

Custom Tuning - Mode selection AXIS#00	Tuning mode Box	
Tuning mode	Mode Selection	Description
2:Set servo gains for positioning application.     O:Set servo gains with priority given to stability.     Overshoot will rarely occur since priority is given to stability. In addition     to gain adjustments, the notch filter and anti-resonance control (except     for torque (force) control) can be adjusted.     1:Set servo gains with priority given to response.	0: Set servo gains with priority given to stability.	This setting gives priority to stability and preventing overshooting. In addi- tion to gain adjustment, notch filters and anti-resonance control (except during torque control) are automatically adjusted.
Addition to gain adjustments, the notice filter and anti-resonance control     (except for torque (force) control) can be adjusted.      Mechanism selection 2:Ball screw mechanism or linear motor	1: Set servo gains with priority given to response.	Overshooting may occur because pri- ority is given to response. In addition to gain adjustment, notch filters and anti- resonance control (except during torque control) are automatically adjusted.
Executes adjustment suitable for relatively high-rigidity mechanism, such as a ball screw or linear motor. Select this type if there is no applicable	2: Set servo gains for positioning application.	Tuning is performed for positioning applications. In addition to gain adjust- ment, notch filters, anti-resonance control, and vibration suppression are adjusted.
Next > Cancel	3: Set servo gains especially to pre- vent overshooting during positioning application.	Tuning is performed for positioning applications with emphasis on elimi- nating overshooting. In addition to gain adjustment, notch filters, anti-reso- nance control, and vibration suppres- sion are adjusted.

### Mechanism Selection Box

Select the type according to the machine element to drive.

If there is noise or if the gain does not increase, better results may be obtained by changing the rigidity type. Select the type according to the following guidelines.

Mechanism Selection	Description	
1: Belt mechanism	Tuning is performed for a mechanism with relatively low rigidity, e.g., a belt.	
2: Ball screw mechanism or Linear motor	Tuning is performed for a mechanism with relatively high rigidity, e.g., a ball screw or Linear Servomotor. Use this setting if there is no other appropriate setting.	
3: Rigid body system	Tuning is performed for a mechanism with high rigidity, e.g., a rigid body system.	

Information The tuning modes that you can select depend on the SERVOPACK setting.

8. If the moment of inertia ratio is not set correctly, correct the setting and then click the Next Button.



8.8.4 Operating Procedure

9. Turn ON the servo, enter a reference from the host controller, and then click the Start tuning Button.

Tuning Mode 0 or 1

ning mode	0 : Set servo gains with priority given to stability.		Tuning mode	2 : Set servo gains for positioning application.
chanism selection	2 : Ball screw mechanism or linear motor		Mechanism selection	2 : Ball screw mechanism or linear motor
ction compensation	Enable		Friction compensation	Enable
in status	1 gain		Gain status	1 gain
uning level adjustmen etting the tuning level o high can cause pretion or abnormal	Tuning level and start the tuning. Tuning level	Start tuning	FF level adjustment Increase until overshooting occurs.	Tuning level Set the tuning level and start the tuning. Feed forward level (FF)
Finish			FB level adjustmen	t
	Auto-setting Notch filter 1 step inactive 2 step inactive Cancel	Vib Detect	evershooting disappes	Auto-setting Notch filter 1 step inactive 2 step inactive Cancel
	Anti-res Ctrl Adj Anti-res Adj inactiveCencel	Anti-res Ctrl Adj	No Yes	Anti-res Ctrl Adj inactive Cancel
Precautions	< Back To Autotuning Complete	ed. Cancel	Finish	Vib Suppression Frequency 1 inactive Cancel

### **10.** Use the $\blacktriangle$ and $\blacktriangledown$ Buttons to change the tuning level.

Click the **Back** Button during tuning to restore the setting to its original value. The tuning level will return to the value from before when custom tuning was started.

### Tuning Mode 0 or 1

Increase the tuning level until overshooting occurs.

Tuning mode	0 : Set servo gains with priority given to stability.	
Mechanism selection	2 : Ball screw mechanism or linear motor	
Friction compensation	Enable	
Gain status	1 gain	
Tuning level adjustment Setting the tuning level too high can cause vibration or abnormal noise.	Tung level Set the tuning level Tunng level	Back
	Auto-setting Notch filter Vibration not detected 1 step inactive Cancel 2 step Anti-res Ctrl Adj Vibration not detected Anti-res Adj inactive Cancel	Vib Detect

Tuning Mode 2 or 3

Tuning Mode 2 or 3

Increase the feedforward level until overshooting occurs and then increase the feedback level until overshooting is eliminated. Repeat these changes to make the adjustment.

- F

nti-res Ctrl Adi Vib Suppress

Cance

Custom Tuning - Ad	lust AXIS#00	×
Tuning mode	2 : Set servo gains for positioning application.	
Mechanism selection	2 : Ball screw mechanism or linear motor	
Friction compensation	Enable	
Gain status	1 gain	
FF level adjustment	Tuning level Set the tuning level Feed forward level (FF)	Back
overshooting occurs.	Feedback level (FB)	
FB level adjustment		
overshooting disappears.	Auto-setting	1
	Notch filter Vibration not detected	Vib Detect
Response level OK?	2 step inactive Cancel	ΨQ
Yes	Anti-res Ctrl Adj Vibration not detected	
+	Anti-res Adj inactive Cancel	Anti-res Ctrl Adj
Finish	Vib Suppression Frequency 1 inactive Cancel	Vib Suppress
Precautions	< Back To Autotuning Completed.	Cancel

Information

The new feedforward level will not be used until the positioning completed signal is output.

- 11. You can set the functions to suppress vibration (notch filters, automatic anti-resonance setting, anti-resonance control adjustment, and autotuning with a host reference) as required.
  - Refer to the following section for details.
  - Vibration Suppression Functions on page 8-47

8-46

**12.** When tuning has been completed, click the **Completed** Button.

The values that were changed will be saved in the SERVOPACK and you will return to the Tuning Dialog Box.

l uning mode	0 : Set servo gains with priority given to stability.	
Mechanism selection	2 : Ball screw mechanism or linear motor	
Friction compensation	Enable	
Gain status	1 gain	
Tuning level adjustmen Setting the tuning level too high can cause vibration or ebnormal noise.	Uning evel. Set the turning level. Tuning level. Y Y Y Y Y Y Y Y Y Y Y Y Y Y Y Y Y Y Y	Back
	Auto-setting Notch filter Vibration not detected 1 step	Vib Detect
	Anti-res Ctrl Adj Vibration not detected	

This concludes the procedure to set up custom tuning.

## **Vibration Suppression Functions**

### Notch Filters and Automatic Anti-resonance Setting

If the vibration frequency that occurs when you increase the servo gains is at 1,000 Hz or higher, notch filters are effective to suppress vibration. If the vibration is between 100 Hz and 1,000 Hz, anti-resonance control is effective.

### ♦ Automatic Setting

To set vibration suppression automatically, use the parameters to enable notch filters and automatic anti-resonance control setting.

The notch filter frequency (stage 1 or 2) or anti-resonance control frequency that is effective for the vibration that was detected during tuning will be automatically set.



Auto-setting Cancel Buttons

The automatically set notch filter frequencies or the anti-resonance control frequencies may not always suppress vibration. Click the **Cancel** Button to reset the notch filter frequencies or the anti-resonance control frequencies to the values from just before these frequencies were set automatically.

When they are reset, vibration detection will start again.

8.8.5 Automatically Adjusted Function Settings

• Vib Detect Button

While the notch filter or anti-resonance control adjustment automatic setting function is enabled, you can click the **Vib Detect** Button to manually detect vibration. When you click the **Vib Detect** Button, the SERVOPACK will detect vibration at that time, and set the notch filter frequency (stage 1 or 2) or anti-resonance control frequency that is effective for the detected vibration. You can also perform manual vibration detection even when the SERVOPACK does not detect vibration.

• Anti-res Ctrl Adj Button

You can use the **Anti-res Ctrl Adj** Button to execute the anti-resonance control function if fine-tuning is required. Refer to the following section. **8.9** Anti-Resonance Control Adjustment on page 8-50

• Vib Suppress Button

Click the **Vib Suppress** Button to suppress low and transient vibration (oscillation) of approximately 1 Hz to 100 Hz that occurs during positioning. Refer to the following section.

3.10 Vibration Suppression on page 8-55

## Autotuning with a Host Reference

You can perform autotuning with a host reference. Refer to the following section for details. 8.7 Autotuning with a Host Reference on page 8-35

## 8.8.5 Automatically Adjusted Function Settings

You cannot use vibration suppression functions at the same time. Other automatic function settings are the same as for autotuning without a host reference. Refer to the following section.  $\Im$  8.6.6 Automatically Adjusted Function Settings on page 8-31

# 8.8.6 Tuning Example for Tuning Mode 2 or 3

Step	Measurement Display Examples	Operation
1	Position deviation Reference speed Positioning completion signal	The positioning time is measured after the moment of inertia ratio (Pn103) is set correctly. Tuning is completed if the specifications are met. The tuning results are saved in the SERVOPACK.
2		The positioning time will be reduced if the feedforward level is increased. Tuning is completed if the specifications are met. The tuning results are saved in the SERVOPACK. If overshooting occurs before the specifications are met, pro- ceed to step 3.
3		Overshooting will be reduced if the feedback level is increased. If the overshooting is eliminated, proceed to step 4.

8.8.7 Related Parameters

Continued from previous page.

Step	Measurement Display Examples	Operation
4		The graph shows overshooting that occurred when the feed- forward level was increased even more after step 3. In this state, overshooting occurs, but the positioning settling time is shorter. Tuning is completed if the specifications are met. The tuning results are saved in the SERVOPACK. If over- shooting occurs before the specifications are met, repeat steps 3 and 4. If vibration occurs before the overshooting is eliminated, the vibration is suppressed with the notch filters and anti-reso- nance control.
5	-	The tuning results are saved in the SERVOPACK.

# 8.8.7 Related Parameters

The following parameters are automatically adjusted or used as reference when you execute custom tuning.

Parameter	Name	Automatic Changes			
Pn100	Speed Loop Gain	Yes			
Pn101	Speed Loop Integral Time Constant	Yes			
Pn102	Position Loop Gain	Yes			
Pn103	Moment of Inertia Ratio	No			
Pn121	Friction Compensation Gain Yes				
Pn123	Friction Compensation Coefficient	Yes			
Pn124	Friction Compensation Frequency Correction	No			
Pn125	Friction Compensation Gain Correction	Yes			
Pn401	First Stage First Torque Reference Filter Time Constant	Yes			
Pn408	Torque-Related Function Selections	Yes			
Pn409	First Stage Notch Filter Frequency	Yes			
Pn40A	First Stage Notch Filter Q Value	Yes			
Pn40C	Second Stage Notch Filter Frequency	Yes			
Pn40D	Second Stage Notch Filter Q Value	Yes			
Pn140	Model Following Control-Related Selections	Yes			
Pn141	Model Following Control Gain Yes				
Pn142	Model Following Control Gain Correction	Yes			
Pn143	Model Following Control Bias in the Forward Direction	Yes			
Pn144	Model Following Control Bias in the Reverse Direction	Yes			
Pn145	Vibration Suppression 1 Frequency A	No			
Pn146	Vibration Suppression 1 Frequency B	No			
Pn147	Model Following Control Speed Feedforward Compensation	Yes			
Pn160	Anti-Resonance Control-Related Selections	Yes			
Pn161	Anti-Resonance Frequency	Yes			
Pn163	Anti-Resonance Damping Gain	Yes			

Do not change the settings while custom tuning is being executed.

Yes: The parameter is automatically set.

No: The parameter is not automatically set, but the setting is read during execution.

8.9.1 Outline

# 8.9 Anti-Resonance Control Adjustment

This section describes anti-resonance control.

## 8.9.1 Outline

Anti-resonance control increases the effectiveness of vibration suppression after custom tuning.

Anti-resonance control is effective for suppression of continuous vibration frequencies from 100 to 1,000 Hz that occur when the control gain is increased. Vibration can be eliminated by setting vibration frequencies through automatic detection or by manually setting them to adjust the damping gain. Input an operation reference and execute this anti-resonance control adjustment when there is vibration.

Anti-resonance control is automatically set by autotuning without a host reference or autotuning with a host reference. Use anti-resonance control adjustment only if fine-tuning is required or readjustment is required as a result of a failure to detect vibration.

Perform custom tuning if required to increase the response after performing anti-resonance control adjustment. If the control gain is increased, e.g., when custom tuning is performed, vibration may occur again. If that occurs, perform anti-resonance control adjustment again to fine-tune the parameters.

# 

- Related parameters will be set automatically when anti-resonance control adjustment is executed. This may greatly affect the response before and after execution. Make sure that you can perform an emergency stop at any time.
- Before you execute anti-resonance control adjustment, set the correct moment of inertia ratio (Pn103). If the setting greatly differs from the actual moment of inertia ratio, normal control of the machine may not be possible, and vibration may occur.
- Anti-resonance control adjustment detects vibration frequencies between 100 Hz and 1,000 Hz. If the vibration frequency is not within this range, use custom tuning with tuning mode 2 selected to automatically set a notch filter or use vibration suppression.
- Vibration reduction can be made more effective by increasing the anti-resonance damping gain (Pn163), but the vibration may become larger if the damping gain is too high. Increase the damping gain by approximately 0% to 200% in 10% increments while checking the effect on vibration. If vibration reduction is still insufficient at a gain of 200%, cancel the setting, and lower the control gain by using a different method, such as custom tuning.

# 8.9.2 Preparations

Always check the following before you execute anti-resonance control adjustment.

- The tuning-less function must be disabled (Pn170 =  $n.\Box\Box\Box$ ).
- The test without a motor function must be disabled (Pn00C =  $n.\Box\Box\Box$ ).
- The control method must not be set to torque control.
- The parameters must not be write prohibited.

# 8.9.3 Applicable Tools

The following table lists the tools that you can use to perform anti-resonance control adjustment and the applicable tool functions.

Tool	Function	Operating Procedure Reference
Digital Operator	Fn204	Ω Σ-7-Series Digital Operator Operating Man- ual (Manual No.: SIEP S800001 33)
SigmaWin+	Tuning - Tuning	I 8.9.4 Operating Procedure on page 8-51

## 8.9.4 Operating Procedure

To execute anti-resonance control adjustment, an operation reference is input, and the adjustment is executed while vibration is occurring.

The following methods can be used to execute anti-resonance control adjustment.

- To automatically detect the vibration frequency
- To manually set the vibration frequency

Use the following procedure to perform anti-resonance control.



### 8.9.4 Operating Procedure

**1.** Perform steps 1 to 7 of the procedure for custom tuning. Refer to the following section for details.

■ 8.8.4 Operating Procedure on page 8-43

2. Click the Anti-res Ctrl Adj Button.

The rest of the procedure depends on whether you know the vibration frequency.

Tuning mode     0 : Set servo gains with priority given to stability.       Mechanism selecton     2 : Bail screw mechanism or linear motor       Friction compensation     Enable       Gain status     If gain       Tuning level adjustment     If using level       Setting the tuning level     If gain       Setting the tuning level     If gain       Finish     Auto-setting       Finish     Auto-setting       Auto-setting     If gain	Custom Tuning - Ad	Just AXIS#00 🗖 🗐 🗾						
Mechanism selecton 2: Ball screw mechanism or linear motor Friction compensation 2: Ball screw mechanism or linear motor Friction compensation 2: Ball screw mechanism or linear motor Friction compensation 2: Ball screw mechanism or linear motor 1: Start tuning Start tuning Start tuning Finian  Auto-setting Notich fitter 1: step 2: step 2: step Anti-res Ctrl Adj Anti-res	Tuning mode	0 : Set servo gains with priority given to stability.						
Friction compensation     Enable       Gain status     [ gain       Tuning level and start the tuning.     Setting the tuning level       Setting the tuning level     Setting the tuning level       Finish     Auto-setting       Noch fitter     1 step       2 step     BROHZ active       Cancel     Anti-res CtrlAd,       Anti-res CtrlAd,     in active       Anti-res CtrlAd,     in active       Anti-res CtrlAd,     in active	Mechanism selection	2 : Ball screw mechanism or linear motor						
Gain status     1 gain       Turing level add start the tuning.       Turing level add start the tuning.       Stetting the tuning level and start the tuning.       Turing level add start the tuning.       Turing level add start the tuning.       Turing level add start the tuning.       Finish       Auto-setting       Notch fitter       1 step       BioHiz       2 step       BioHiz       Anti-res Ctrl Adj	Friction compensation	Enable						
Tuning level adjustment     Tuning level adjustment       Setting the tuning level     Start tuning Tuning level       Setting the tuning level too high can cause volvation or about the tuning level     Start tuning (1 - 2000)       Finian     Auto-setting Notich filter       Auto-setting Anti-res Ctri Adj Anti-res Ctri Adj Anti-res Ctri Adj Anti-res Ctri Adj Anti-res Ctri Adj Anti-res Ctri Adj	Gain status	gain						
Auto-setting Noch fiter 1 stepinactive 2 step 860Hz active Anti-res Adj Anti-res Adj Stack Precautions Prec	Tuning level adjustment Setting the tuning level too high can acuse vibration or abnormal noise. Finish	Tuning level and start the tuning. Set the tuning level and start the tuning. Tuning level and start the tuning. (1 - 2000)						
Anti-res Ctrl Adj Anti-res Adj		Auto setting Notch fiter 1 stepinactiveCancel 2 stepSGNHzactiveCancel						
Precautions < Back To Autotuning Completed Cancel		Anti-res Ctrl Adj Anti-res Adj inactive Cancel Anti-res Ctrl Adj						
	Precautions	< Back To Autotuning Completed. Cancel						

**3.** If you do not know the vibration frequency, click the **Auto Detect** Button. If you know the vibration frequency, click the **Manual Set** Button.

To Automatically Detect the Vibration Frequency

The frequency will be set.

Citial the Auto Detect Institution to extornatically set the frequency. Set frequency Before	Manual Set
Set frequency Befor	ore adjustment 760 [Hz]
Click the Start adjustment button. << Frequency >>	
Adjust damping gan Inoraasa (Damping Gain).	(1 - 2000) A A A Grant from the value by different from the value by d

To Manually Set the Vibration Frequency

et [Piz]	
	1
Caufion     I a frequency si     defarent from to     adjustment is as	gnificantly e value before t, the current
may be lost. Onc problem is solve increase dampin	te the vibration d, do not g gain.
	A The strength of the str

### 4. Click the Start adjustment Button.

5. Use the ▲ and ▼ Buttons in the Adjustment Area to change the settings. Click the **Reset** Button during tuning to restore the setting to its original value. The tuning level will return to the value from before when custom tuning was started.

To Automatically Detect the Vibration Frequency

Change the setting of the damping gain.

To Manually Set the Vibration Frequency Change the settings of the frequency and damping gain.

W Adjust Anti-resonance Control AX	IS#00			1	/// Adjust Anti-resonance Control AXI	S#00		
Determine frequency Click the Auto Detect button to automatically set the frequency.	Adjustment Frequency Setting Met	Manual Set	Antures Adj: Active		Determine frequency Click the Auto Detect button to automatically set the frequency.	- Adjustment Frequency Setting M Auto Detect	Manual Set	Anti-res Adj Active
Set frequency Click the Start adjustment button.	<< Frequency >>	Before adjustment 760 [Hz]	Reset		Set frequency Click the Start adjustment button.	<< Frequency >>	Before adjustment [iz]	Reset
Finish	«Damping Gain»»		If a frequency significantly different from the value before adjustment is set, the current anti-resonance control effect may be lost. Once the viteration problem is solved, do not increase damping gain.		Finish	«Damping Gain»»		If a frequency significantly different from the value bafore adjustment is set, the current anti-resonance control effect may be lost. Once the vitration problem is solved, do not increase damping gain.
	Precautions		Finish Cancel			Precautions		Finish Cancel

8.9.5 Related Parameters

6. When the adjustment has been completed, click the Finish Button. The values that were changed will be saved in the SERVOPACK and you will return to the Tuning Dialog Box.

Determine frequency	Prequency Setting Me	ethods		Anti res Adj. Active
Click the Auto Detect button to automatically set the frequency.	Auto Detect	Manual Set		
Set frequency		Before adjustment 760	(Hz)	
Click the Start adjustment button.	<< Frequency >>		(HZ)	Reset
Adjust damping gain	ו	(1-2000)		«Caution» If a frequency significantly
Increase (Damping Gain).	erDamping Gainss		Mc1	different from the value before adjustment is set, the current
				may be lost. Once the vibration problem is solved, do not

This concludes the procedure to set up anti-resonance control.

## 8.9.5 Related Parameters

The following parameters are automatically adjusted or used as reference when you execute anti-resonance control adjustment.

Do not change the settings while anti-resonance control adjustment is being executed.

Parameter	Name	Automatic Changes
Pn160	Anti-Resonance Control-Related Selections	Yes
Pn161	Anti-Resonance Frequency	Yes
Pn162	Anti-Resonance Gain Correction	No
Pn163	Anti-Resonance Damping Gain	Yes
Pn164	Anti-Resonance Filter Time Constant 1 Correction	No
Pn165	Anti-Resonance Filter Time Constant 2 Correction	No

Yes: The parameter is automatically set.

No: The parameter is not automatically set, but the setting is read during execution.

## 8.9.6 Suppressing Different Vibration Frequencies with Anti-resonance Control

When you use anti-resonance control and increase the control gain, for some mechanism, vibration can occur at a higher frequency than the frequency for which vibration was suppressed. If this occurs, you can suppress vibration for more than one frequency by adjusting Pn166 (Anti-Resonance Damping Gain 2).

Information

### ation Guidelines for Vibration That Can Be Suppressed

Anti-resonance frequency (Pn161): fa [Hz], Another vibration frequency that occurs when the control gain is increased: fb [Hz]

- Vibration frequencies: 100 Hz to 1,000 Hz
- Range of different vibration frequencies: 1 < (fb/fa)  $\leq$  3 to 4

Tuning

8.9.6 Suppressing Different Vibration Frequencies with Anti-resonance Control

## **Required Parameter Settings**

The following parameter settings are required to use anti-resonance control for more than one vibration frequency.

Parameter		Description			Wher Enable	n ed	Classifi- cation
Pn160	n. <b>□□</b> □0 (default setting)	Do not use anti-resonance control.			After	t	Setup
	n.🗆 🗆 🗆 1	Use anti-resonance co	restart				
	Anti-Resonance Frequency Speec			Speed	Positio	n	Torque
Pn161	Setting Range	Setting Unit	Default Setting	When Ena	abled	Cla	assification
	10 to 20,000	0.1 Hz	1000	Immedia	ately		Tuning
	Anti-Resonance Gain Correction Speed			Speed	Positio	n	Torque
Pn162 Setting Range		Setting Unit	Default Setting	When Enabled		Classification	
	1 to 1,000	1%	100	Immedia	ately		Tuning
	Anti-Resonance Da	amping Gain	Speed	Positio	n	Torque	
Pn163	Setting Range	Setting Unit	Default Setting	When Ena	abled	Cla	assification
	0 to 300	1%	0	Immedia	ately		Tuning
	Anti-Resonance Fil	lter Time Constant 1 C	orrection	Speed	Positio	n	Torque
Pn164	Setting Range	Setting Unit	Default Setting	When Ena	abled	Cla	assification
	-1,000 to 1,000	0.01 ms	0	Immedia	ately		Tuning
	Anti-Resonance Fi	lter Time Constant 2 C	orrection	Speed	Positio	n	Torque
Pn165	Setting Range	Setting Unit	Default Setting	When Ena	abled	Cla	assification
	-1,000 to 1,000	0.01 ms	0	Immedia	ately		Tuning
	Anti-Resonance Da	amping Gain 2		Speed	Positio	n	Torque
Pn166	Setting Range	Setting Unit	Default Setting	When En	abled	Cla	assification
	0 to 1,000	1%	0	Immedia	ately		Tuning

## Adjustment Procedure for Suppressing Different Vibration Frequencies with Anti-resonance Control

Use the following procedure to make adjustments to suppress different vibration frequencies with anti-resonance control.

Step	Operation		
1	Use the gain adjustment and anti-resonance control. Refer to the following section for details. 3.9.4 Operating Procedure on page 8-51		
2	If there is vibration at a higher frequency than the vibration suppressed with anti-resonance control in step 1, adjust Pn166 (Anti-Resonance Damping Gain 2).		
3	<ul> <li>Adjust Pn166 (Anti-Resonance Damping Gain 2) while checking to see if vibration reduction is effective.</li> <li>To adjust Pn166 (Anti-Resonance Damping Gain 2), increase the setting by 10% at a time starting from the value that resulted in Pn163 (Anti-Resonance Damping Gain) from the adjustment in step 1.</li> </ul>		
4	If the vibration disappears, the adjustment is completed. However, if the vibration does not disappear even when you adjust Pn166 (Anti-Resonance Damping Gain 2), reduce the tuning level or feedback level until vibration does not occur.		

8.10.1 Outline

# 8.10 Vibration Suppression

This section describes vibration suppression.

#### Outline 8.10.1

You can use vibration suppression to suppress transient vibration at a low frequency from 1 Hz to 100 Hz, which is generated mainly when the machine vibrates during positioning. This is effective for vibration frequencies for which notch filters and anti-resonance control adjustment are not effective.

Vibration suppression is automatically set by autotuning without a host reference or autotuning with a host reference. Use vibration suppression only if fine-tuning is required or readjustment is required as a result of a failure to detect vibration. To execute vibration suppression, input an operation reference and execute the function when there is vibration.

Perform custom tuning if required to increase the response after performing vibration suppression.

- CAUTION Related parameters will be set automatically when vibration suppression is executed. This may greatly affect the response before and after execution. Make sure that you can perform an emergency stop at any time. • Before you execute vibration suppression, set the correct moment of inertia ratio (Pn103) with autotuning without a host reference or another method. If the setting greatly differs from the actual moment of inertia ratio, normal control of the machine may not be possible, and vibration may occur. • If you execute vibration suppression when you are using an MP3000-Series Controller for
  - phase control, correct phase control may not be possible.



- Vibration suppression detects vibration frequencies between 1 Hz and 100 Hz. • Frequency detection will not be performed if there is no vibration in the position deviation or if the vibration frequency is outside the range of detectable frequencies. If that is a problem, use
- a device such as a displacement meter or vibration sensor to measure the vibration frequency. If an automatically detected vibration frequency is not suppressed, the actual frequency and the detected frequency may be different. Fine-tune the detected frequency if necessary.

## Items That Influence Performance

If continuous vibration occurs while the Servomotor is stopping, vibration suppression cannot be used to suppress the vibration effectively. In this case, use anti-resonance control adjustment or custom tuning.

# **Detection of Vibration Frequencies**

Frequency detection may not be possible if vibration does not appear in the position deviation or the vibration that results from the position deviation is too small. You can adjust the detection sensitivity by changing the setting of the residual vibration detection width (Pn560), which is set as a percentage of the positioning completed width (Pn522). Perform the detection of vibration frequencies again after adjusting the setting of Pn560.

	Residual Vibration D	Detection Width	Posit	ion	
Pn560	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	1 to 3,000	0.1%	400	Immediately	Setup

Note: As a guideline, change the setting 10% at a time. If the setting of this parameter is lowered, the detection sensitivity will be increased. Vibration may not be detected accurately if the setting is too small.

### 8.10.2 Preparations

Information

The vibration frequencies that are automatically detected may vary somewhat with each positioning operation. Perform positioning several times and make adjustments while checking the effect of vibration suppression.

## 8.10.2 Preparations

Always check the following before you execute vibration suppression.

- Position control must be used.
- The tuning-less function must be disabled (Pn170 =  $n.\Box\Box\Box$ 0).
- The test without a motor function must be disabled (Pn00C =  $n.\Box\Box\Box$ ).
- The parameters must not be write prohibited.

## 8.10.3 Applicable Tools

The following table lists the tools that you can use to perform vibration suppression and the applicable tool functions.

Tool	Function	Operating Procedure Reference
Digital Operator	Fn205	Ω Σ-7-Series Digital Operator Operating Man- ual (Manual No.: SIEP S800001 33)
SigmaWin+	Tuning - Tuning	🕼 8.10.4 Operating Procedure on page 8-56

## 8.10.4 Operating Procedure

Use the following procedure to perform vibration suppression.

1. Perform steps 1 to 7 of the procedure for custom tuning. Refer to the following section for details.

8.8.4 Operating Procedure on page 8-43

2. Click the Vib Suppress Button.



8.10.4 Operating Procedure

3. Click the Import Button or click ▲ and ▼ Button to manually adjust the set frequency. When you click the Import Button, the residual vibration frequency in the motor is read as the set frequency. (The frequency can be read only when the residual vibration frequency is between 1.0 and 100.0.)



Frequency detection will not be performed if there is no vibration or if the vibration frequency is outside the range of detectable frequencies. If a vibration frequency is not detected, provide a means of measuring the vibration frequency.

Vibration Suppression AXIS	#00	×
Clearmine the frequency for setting. Click the Import button. Manual setting in also possible. Use the frequency. Click the Set button. The Validation the frequency and the olick the Set button again. Inskyl adjust the frequency and them olick the Set button again.	Adjustment Residual Vibration Frequency Set frequency ( 1.0 - 100.0)	Vb Suppression: inactive
	Precautions	Finish Cancel

### 4. Click the Set Button.



No settings related to vibration suppression are changed during operation. If the Servomotor does not stop within approximately 10 seconds after changing the setting, an update timeout will occur. The setting will be automatically returned to the previous value.

Vibration Suppression AXIS	#00			×
Determine the frequency for setting. Click the Import button. Manual setting is also possible.	Adjustment Residual Vibration Frequency	9.0 [Hz]	Vib Suppression: Active	
Set une requerity. Click the Set button. If the vibration problem could not be solved. finely adjust the frequency and then dick the Set button again. Finish	Set frequency	Set (Hz) (Hz) () () () () () () () () () (	Reset	
	Precautions		Finish Cancel	

If the vibration is not eliminated, use the  $\blacktriangle$  and  $\blacktriangledown$  Buttons for the set frequency to fine-tune the value and click the **Set** Button again.

UVibration Suppression AXIS#00				
Determine the frequency for setting.	Adjustment Residual Vibration Frequency 9.0 [Hz]		Vib Suppression: Active	
Click the Import button. Manual setting is also possible.		Import		
Set the frequency. Click the Set button. If the vibration problem could not be solved, finely adjust the frequency and then click the Set button again.	Set frequency (	(Hz)	Set Reset	
Finish	Precautions		Finish Cancel	

Click the **Reset** Button during adjustment to restore the setting to its original value. The status from before when adjustment was started will be restored.

### 8.10.5 Setting Combined Functions

# 5. When the vibration has been eliminated, click the Finish Button. The updated value will be saved in the SERVOPACK.



Vibration suppression will be enabled in step 5. The motor response, however, will change when the Servomotor comes to a stop with no reference input.

This concludes the procedure to set up vibration suppression.

# 8.10.5 Setting Combined Functions

You can also use the feedforward function when you execute vibration suppression.

In the default settings, feedforward (Pn109), the speed feedforward input (VFF), and the torque feedforward input (TFF) are disabled.

To use the speed feedforward input (VFF), the torque feedforward input (TFF), and model following control from the host controller in the system, set Pn140 to n.1DDD (Use model following control and speed/torque feedforward together).

I	Parameter	Function	When Enabled	Classification
Pn1/0	n.0□□□ (default setting)	Do not use model following control and speed/torque feedforward together.	- Immediately	Tuning
11140	n.1000	Use model following control and speed/ torque feedforward together.		

Refer to the following manual for information on the torque feedforward input (TFF) and the speed feedforward input (VFF).

Σ-7-Series MECHATROLINK-III Communications Standard Servo Profile Command Manual (Manual No.: SIEP S800001 31)



When model following control is used with the feedforward function, it is used to make optimum feedforward settings in the SERVOPACK. Therefore, model following control is not normally used together with either the speed feedforward input (VFF) or torque feedforward input (TFF) from the host controller. However, model following control can be used with the speed feedforward input (VFF) or torque feedforward input (TFF) if required. An unsuitable feedforward input may result in overshooting.
8.10.6 Related Parameters

### 8.10.6 Related Parameters

The following parameters are automatically adjusted or used as reference when you execute vibration suppression.

Do not change the settings while vibration suppression is being executed.

Parameter	Name	Automatic Changes
Pn140	Model Following Control-Related Selections	Yes
Pn141	Model Following Control Gain	Yes
Pn142	Model Following Control Correction	No
Pn143	Model Following Control Bias in the Forward Direction	No
Pn144	Model Following Control Bias in the Reverse Direction	No
Pn145	Vibration Suppression 1 Frequency A	Yes
Pn146	Vibration Suppression 1 Frequency B	Yes
Pn147	Model Following Control Speed Feedforward Compensation	No
Pn14A	Vibration Suppression 2 Frequency	No
Pn14B	Vibration Suppression 2 Correction	No

Yes: The parameter is automatically set.

No: The parameter is not automatically set, but the setting is read during execution.

8.11.1 Outline

## 8.11 Speed Ripple Compensation

This section describes speed ripple compensation.

### 8.11.1 Outline

Speed ripple compensation reduces the amount of ripple in the motor speed due to torque ripple or cogging torque. You can enable speed ripple compensation to achieve smoother operation. To enable it, you must set up ripple compensation on the SigmaWin+.

## 

• Speed ripple compensation requires operating the motor and therefore presents hazards. Observe the following precaution.

Confirm safety around moving parts.

This function involves automatic operation. Make sure that you can perform an emergency stop (to turn OFF the power supply) at any time.



- Execute speed ripple compensation only after adjusting the gains.
- Reset speed ripple compensation after you replace the Servomotor or SERVOPACK.

• Execute speed ripple compensation after jogging to a position that ensures a suitable range of motion.

### 8.11.2 Setting Up Speed Ripple Compensation

### Restrictions

The following restrictions apply to the setup for speed ripple compensation.

Systems for Which Execution Cannot Be Performed

There are no restrictions.

#### Systems for Which Adjustments Cannot Be Made Accurately

Systems for which there is not a suitable range of motion

#### Preparations

Always check the following before you set up speed ripple compensation.

- The main circuit power supply must be ON.
- The servo must be OFF.
- There must be no alarms or warnings.
- The parameters must not be write prohibited.

8.11.2 Setting Up Speed Ripple Compensation

### **Applicable Tools**

The following table lists the tools that you can use to set up speed ripple compensation and the applicable tool functions.

Tool	Function	Reference	
Digital Operator	You cannot set up speed ripple compensation from the Digital Operator.		
SigmaWin+	Solutions – Ripple Compensation	G Operating Procedure on page 8-61	

### **Operating Procedure**

Use the following procedure to set up speed ripple compensation.

- 1. Click the <u>I</u> Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- 2. Select Ripple Compensation in the Menu Dialog Box. The Ripple Compensation Dialog Box will be displayed.
- 3. Click the OK Button.

Ripple Compensation
t is dangerous to operate this function, because the servomotor will rotate. Always be sure to check the user's manual before operating.
1. Perform safety checks around moving parts. While the operation button is being depressed, the servomotor will run at the JOG speed set. Execute after having confirmed that servomotor operation will present no danger.
2. [Forward Run Prohibit (P-OT)]/[Reverse Run Prohibit (N-OT)] is disabled. The Forward Run Prohibit (P-OT)/Reverse Run Prohibit (N-OT) signals are disabled during JOG operation (the servomotor will not stop even if the P-OT/N-OT signals are passed). When operating, care fully verify the action and position of the servomotor/machine.
Clicking the OK button to start the Ripple Compensation.

Information1. Click the Cancel Button to cancel ripple compensation. The Main Window will return.2. If write protection is set, the following dialog box will be displayed.



Click the **OK** Button to cancel write prohibition.

8.11.2 Setting Up Speed Ripple Compensation

4. Click the Edit Button.

0		encaun ·····	74 R R	ifeasurement
A .	v (dw)	pa	M	500 [min-1] Edit Please execute by 100[min-1] or less.
	4			Serve OFF
	2		·	Forward Revenue
	1 · · · · · · · · · · · · · · · · · · ·			+0
-	2		····-1 ····-2	Writing Results
4	3 ·····		····4	Write
- 	0.0 60.0 120.0 180.0 240.0 3	00.0 360.0 420.0 480.0 540.0	→_s ·	•

5. Enter the jogging speed in the Input Value Box and click the OK Button.

Edit AXIS#00	<b>×</b>
Pn304 Jogging Speed	
Input value 500 min 1 ( 0 - 10000 )	
	OK Cancel

6. Click the Servo ON Button.

III Ripple Compensation AXIS#00	
Measure Writing Results Verification Confirm	
	Measurement Ph304 : Jogging Speed
v [ew]	500 [min-1] Edit Please execute by 100/min-1] or less.
5 4 4	Serve OFF
3 2 1	Forward Reverse
0 0 	-Writing Results
2 .3 .4	Wite
	- Confirm
4	Reset

8.11.2 Setting Up Speed Ripple Compensation

#### 7. Click the Forward Button or the Reverse Button.

Measurement operation is started.

The motor will rotate at the preset jogging speed while you hold down the **Forward** or **Reverse** Button and the speed ripple will be measured.

The feedback speed and torque reference graph will be displayed in the Ripple Compensation Dialog Box during jogging.





- 8. After speed ripple measurement has been completed, click the Write Button. The ripple compensation value will be written to the SERVOPACK.
- 9. After writing has been completed, click the OK Button.

Ripple Co	mpensation	×
1	The Ripple Compensation value was written in. Please measure again and verify. If a verification result is good, please click the "Completed" button.	
	ОК	

#### 8.11.3 Setting Parameters

#### 10. Click the Forward Button or the Reverse Button.

Verification operation is started.

The motor will rotate at the preset jogging speed while you hold down the **Forward** or **Reverse** Button.

The waveform with speed ripple compensation applied to it will be displayed.



#### 11. If the verification results are OK, click the Finish Button.

Information To discard the setup results, click the **Reset** Button.

This concludes the setup for speed ripple compensation.

### 8.11.3 Setting Parameters

The function is enabled when you perform the operating procedure on *Operating Procedure* on page 8-61. To cancel speed ripple compensation, use  $Pn423 = n.\square\square\square$  (Disable speed ripple compensation) to disable it.

Parameter		Description	When Enabled	Classifi- cation
Pn423	n.□□□0 (default setting)	Disable speed ripple compensation.	After	Setup
	n.0001	Enable speed ripple compensation.	restart	

If you enable speed ripple compensation, a compensation reference will be applied to reduce ripple even when stopped at a 0 speed reference. In speed control mode, this may result in the motor moving slightly. To prevent this, set  $Pn423 = n.\Box X \Box \Box$  (Speed Ripple Compensation Enable Condition Selection) and Pn427 or Pn49F (Speed Ripple Compensation Enable Speed).

Parameter		Description	When Enabled	Classifi- cation
Pn423	n.□0□□ (default setting)	Speed reference	After	Setup
	n.🗆1🗖 🗖	Motor Speed	restart	

• For Rotary Servomotors

	Speed Ripple Compensation Enable Speed			Speed Positio	n Torque
Pn427	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 10,000	1 min <sup>-1</sup>	0	Immediately	Tuning

8.11.3 Setting Parameters

• For Linear Servomotors



### **Speed Ripple Compensation Warnings**

The speed ripple compensation value is specific to each Servomotor. If you replace the Servomotor while speed ripple compensation is enabled, an A.942 warning (Speed Ripple Compensation Information Disagreement) will occur to warn you.

You can use any of the following methods to clear A.942.

- Reset the speed ripple compensation value on the SigmaWin+.
- Disable speed ripple compensation (Pn423 =  $n.\Box\Box\Box$ ).
- Disable detection of A.942 (Pn423 =  $n.\Box\Box1\Box$ ).

Parameter		Description	When Enabled	Classifi- cation
Pn423	n.□□0□ (default setting)	Detect A.942 alarms.	After	Setup
	n.0010	Do not detect A.942 alarms.	restart	

## 8.12 Additional Adjustment Functions

This section describes the functions that you can use to make adjustments after you perform autotuning without a host reference, autotuning with a host reference, and custom tuning.

Function	Applicable Control Methods	Reference
Gain Switching	Position control, speed control, or torque control*	page 8-66
Friction Compensation	Position control or speed control	page 8-70
Current Gain Level Setting	Position control or speed control	page 8-72
Speed Detection Method Selection	Position control, speed control, or torque control	page 8-72
Backlash Compensation	Position Control	page 8-73

\* Automatic gain switching is enabled only for position control.

### 8.12.1 Gain Switching

Two gain switching functions are available, manual selection and automatic switching. The manual switching function uses an external input signal to select the gains, and the automatic switching function changes the gains automatically.

You can use gain switching to shorten the positioning time by increasing the gains during positioning and suppressing vibration by decreasing the gains while stopping.

Parameter		Function	When Enabled	Classification
Pn139	n.□□□0 (default setting)	Use manual gain switching.	Immediately	Tuning
	n.□□□2	Use automatic gain switching pattern 1.		

Note:  $Pn139 = n.\Box\Box\Box\Box$ 1 is a reserved setting. Do not use this setting.

Refer to the following section for gain switching combinations.

Gain Switching Combinations on page 8-66

Refer to the following sections for information on manual and automatic gain switching. *Manual Gain Switching* on page 8-67 and *Automatic Gain Switching* on page 8-67

### **Gain Switching Combinations**

Selected Gains	Speed Loop Gain	Speed Loop Integral Time Constant	Position Loop Gain	Torque Refer- ence Filter	Model Fol- lowing Con- trol Gain	Model Follow- ing Control Correction	Friction Compensa- tion Gain
Gain Set- tings 1	Speed Loop Gain (Pn100)	Speed Loop Integral Time Constant (Pn101)	Position Loop Gain (Pn102)	First Stage First Torque Reference Fil- ter Time Con- stant (Pn401)	Model Fol- lowing Con- trol Gain* (Pn141)	Model Follow- ing Control Correction* (Pn142)	Friction Compensa- tion Gain (Pn121)
Gain Set- tings 2	Second Speed Loop Gain (Pn104)	Second Speed Loop Integral Time Constant (Pn105)	Second Position Loop Gain (Pn106)	First Stage Second Torque Refer- ence Filter Time Con- stant (Pn412)	Second Model Fol- lowing Con- trol Gain* (Pn148)	Second Model Following Control Gain Correction* (Pn149)	Second Friction Compensa- tion Gain (Pn122)

\* Gain switching for the model following control gain and the model following control gain correction is applicable only to manual gain switching.

To enable gain switching with these parameters, a gain switching input signal must be used and the following conditions must be met. If the conditions are not met, these parameters will not be changed even if the other parameters in the above table are changed.

• There must be no reference.

The motor must be stopped.

### Manual Gain Switching

With manual gain switching, you use G-SEL in the servo command output signals (SVCMD\_IO) to change between gain settings 1 and gain settings 2.

Туре	Command Name	Value	Meaning
Input	G-SEL in the servo command output sig-	0	Changes the gain settings to gain settings 1.
	nals (SVCMD_IO)	1	Changes the gain settings to gain settings 2.

### Automatic Gain Switching

Automatic gain switching is enabled only for position control. The switching conditions are specified by using the following settings.

Parameter		Switching Condition	Selected Gains	Switching Waiting Time	Switching Time
Pn139 n.0002	Condition A satisfied	Gain settings 1 to gain set- tings 2	Gain Switching Waiting Time 1 Pn135	Gain Switching Time 1 Pn131	
	n.□□□2	Condition A not satisfied	Gain settings 2 to gain set- tings 1	Gain Switching Waiting Time 2 Pn136	Gain Switching Time 2 Pn132

Select one of the following settings for switching condition A.

Parameter		Position Control Gain Switching Condition A	For Control Methods Other Than Position Control (No Switching)	When Enabled	Classification
	n.□□0□ (default setting)	/COIN (Positioning Com- pletion) signal ON	Gain settings 1 used.		Tuning
	n.0010	/COIN (Positioning Com- pletion) signal OFF	Gain settings 2 used.	-	
	n.🗆 🗆 2 🗆	/NEAR (Near) signal ON	Gain settings 1 used.		
Pn139	n.🗆 🗆 3 🗆	/NEAR (Near) signal OFF	Gain settings 2 used.	Immediately	
	n.0040	Position reference filter output is 0 and position reference input is OFF.	Gain settings 1 used.		
	n.0050	Position reference input is ON.	Gain settings 2 used.		

Automatic Switching Pattern 1 (Pn139 = n.



#### Relationship between the Waiting Times and Switching Times for Gain Switching

In this example, an ON /COIN (Positioning Completion) signal is set as condition A for automatic gain switching. The position loop gain is changed from the value in Pn102 (Position Loop Gain) to the value in Pn106 (Second Position Loop Gain). When the /COIN signal turns ON, the switching operation begins after the waiting time (Pn135). The switching operation changes the position loop gain linearly from the gain set in Pn102 to the gain set in Pn106 over the switching time (Pn131).





Ation You can use gain switching for either PI control or I-P control (Pn10B =  $n.\Box\Box\Box\Box$  or  $\Box\Box$ 1 $\Box$ ).

### **Related Parameters**

	Speed Loop Gain			Speed Posit	ion	
Pn100	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	10 to 20,000	0.1 Hz	400	Immediately	Tuning	
	Speed Loop Integra	I Time Constant		Speed Posit	ion	
Pn101	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	15 to 51,200	0.01 ms	2,000	Immediately	Tuning	
	Position Loop Gain			Posit	ion	
Pn102	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	10 to 20,000	0.1/s	400	Immediately	Tuning	
	First Stage First Tore	que Reference Filter	Time Constant	Speed Posit	ion Torque	
Pn401	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 65,535	0.01 ms	100	Immediately	Tuning	
	Model Following Control Gain Position					
Pn141	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	10 to 20,000	0.1/s	500	Immediately	Tuning	
	Model Following Co	ntrol Correction	Posit	ion		
Pn142	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	500 to 2,000	0.1%	1,000	Immediately	Tuning	
	Friction Compensat	ion Gain		Speed Posit	ion	
Pn121	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	10 to 1,000	1%	100	Immediately	Tuning	
	Second Speed Loop	o Gain		Speed Position		
Pn104	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	10 to 20,000	0.1 Hz	400	Immediately	Tuning	
	Second Speed Loop	o Integral Time Cons	tant	Speed Posit	ion	
Pn105	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	15 to 51,200	0.01 ms	2,000	Immediately	Tuning	

Continued on next page.

Continued from previous page.

	Second Position Lo	op Gain		Position		
Pn106	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	10 to 20,000	0.1/s	400	Immediately	Tuning	
	First Stage Second	Torque Reference Fil	ter Time Constant	Speed Posit	ion Torque	
Pn412	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 65,535	0.01 ms	100	Immediately	Tuning	
	Second Model Following Control Gain			Position		
Pn148	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	10 to 20,000	0.1/s	500	Immediately	Tuning	
	Second Model Follo	wing Control Gain C	Position			
Pn149	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	500 to 2,000	0.1%	1,000	Immediately	Tuning	
	Second Friction Co	mpensation Gain		Speed Posit	ion	
Pn122	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	10 to 1,000	1%	100	Immediately	Tuning	

### Parameters Related to Automatic Gain Switching

	Gain Switching Time	e 1	Position		
Pn131	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 65,535	1 ms	0	Immediately	Tuning
	Gain Switching Time	e 2		Posit	ion
Pn132	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 65,535	1 ms	0	Immediately	Tuning
	Gain Switching Wait	ting Time 1	Position		
Pn135	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 65,535	1 ms	0	Immediately	Tuning
	Gain Switching Wait	ting Time 2		Posit	ion
Pn136	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 65,535	1 ms	0	Immediately	Tuning

### **Related Monitoring**

• SigmaWin+

You can monitor gain switching with the status monitor or with tracing.

Analog Monitors

Parameter	Analog Monitor	Monitor Name	Output Value	Description
Pn006	n. <b>□□</b> 0B	Active Cain Monitor	1 V	Gain settings 1 are enabled.
Pn007		Active Gain Monitor	2 V	Gain settings 2 are enabled.

8.12.2 Friction Compensation

### 8.12.2 Friction Compensation

Friction compensation is used to compensate for viscous friction fluctuations and regular load fluctuations.

You can automatically adjust friction compensation with autotuning without a host reference, autotuning with a host reference, or custom tuning, or you can manually adjust it with the following procedure.

### **Required Parameter Settings**

The following parameter settings are required to use friction compensation.

Parameter		Fund	ction	When Enabled	Classification
Pn408	n.0□□□ (default setting)	Disable friction comper	nsation.	Immediately	Setup
	n.1000	Enable friction compen	sation.		
	Friction Compen	sation Gain		Speed Posit	ion
Pn121	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	10 to 1,000	1%	100	Immediately	Tuning
	Second Friction Compensation Gain			Speed Posit	ion
Pn122	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	10 to 1,000	1%	100	Immediately	Tuning
	Friction Compen	sation Coefficient	Speed Posit	ion	
Pn123	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 100	1%	0	Immediately	Tuning
	Friction Compen	sation Frequency Corre	ction	Speed Posit	ion
Pn124	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	-10,000 to 10,00	0 0.1 Hz	0	Immediately	Tuning
	Friction Compen	sation Gain Correction		Speed Posit	ion
Pn125	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	1 to 1,000	1%	100	Immediately	Tuning

### **Operating Procedure for Friction Compensation**

Use the following procedure to perform friction compensation.



Before you execute friction compensation, set the moment of inertia ratio (Pn103) as accurately as possible. If the setting greatly differs from the actual moment of inertia, vibration may occur.

Step	Operation
1	Set the following parameters related to friction compensation to their default settings. Friction compensation gain (Pn121): 100 Second friction compensation gain (Pn122): 100 Friction compensation coefficient (Pn123): 0 Friction compensation frequency correction (Pn124): 0 Friction compensation gain correction (Pn125): 100 Note: Always use the default settings for the friction compensation frequency correction (Pn124) and fric- tion compensation gain correction (Pn125).

Continued on next page.

8.12.3 Current Control Mode Selection

Continued from previous page.

Step	Operation				
	Gradually increase the friction compensation coefficient (Pn123) to check the effect of friction com- pensation. Note: Usually, set the friction compensation coefficient (Pn123) to 95% or less. If the effect is insufficient, increase the friction compensation gain (Pn121) by 10% increments until vibration stops.				
2	<ul> <li>Effect of Adjusted Parameters</li> <li>Pn121: Friction Compensation Gain and Pn122: Second Friction Compensation Gain These parameters set the response to external disturbances. The higher the setting is, the better the response will be. If the machine has a resonance frequency, however, vibration may occur if the setting is too high.</li> <li>Pn123: Friction Compensation Coefficient This parameter sets the effect of friction compensation. The higher the setting is, the more effective friction compensation will be. If the setting is too high, however, vibration will occur more easily.</li> </ul>				
3	Effect of Adjustments The following graphs show the response with and without adjustment. Poor response because of friction Low friction Position deviation High friction Before Friction Compensation After Friction Compensation After Friction Compensation				

### 8.12.3 Current Control Mode Selection

Current control mode selection reduces high-frequency noise while the Servomotor is being stopped.

To use current control mode selection, use current control mode 2 (set Pn009 to n.  $\Box \Box 2 \Box$ ).

Parameter		Meaning	When Enabled	Classification
	n. 🗆 🗆 🗆			
Pn009	n. DD1D (default setting)	Use current control mode 1.	After restart	Tuning
	n. 🗆 🗆 2 🗆	Use current control mode 2 (low noise).		



If current control mode 2 is selected, the load ratio may increase while the Servomotor is being stopped.

8.12.4 Current Gain Level Setting

### 8.12.4 Current Gain Level Setting

You can set the current gain level to reduce noise by adjusting the parameter for current control inside the SERVOPACK according to the speed loop gain (Pn100). The noise level can be reduced by decreasing the current gain level (Pn13D) from its default setting of 2,000% (disabled). However, if the setting is decreased, the level of noise will be lowered, but the response characteristic of the SERVOPACK will also be reduced. Adjust the current gain level within the range that maintains the SERVOPACK response characteristic.

	Current Gain Level			Speed Posit	ion
Pn13D	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	100 to 2,000	1%	2,000	Immediately	Tuning

# Important

If the current gain level is changed, the response characteristic of the speed loop will also change. Servo tuning must therefore be performed again.

### 8.12.5 Speed Detection Method Selection

You can use the speed detection method selection to ensure smooth Servomotor speed changes during operation. To ensure smooth motor speed changes during operation, set Pn009 to  $n.\Box 1 \Box \Box$  (Use speed detection 2).

With a Linear Servomotor, you can reduce the noise level of the running motor when the linear encoder scale pitch is large.

Parameter		Meaning	When Enabled	Classification
Pn009	n. □0□□ (default setting)	Use speed detection 1.	After restart	Tuning
	n. 🗆 1 🗆 🗆	Use speed detection 2.		



If the speed detection method is changed, the response characteristic of the speed loop will also change. Servo tuning must therefore be performed again.

### 8.12.6 Speed Feedback Filter

You can set a first order lag filter for the speed feedback in the speed loop. This ensures smooth changes in the feedback speed to reduce vibration. If a large value is set, it will increase the delay and make response slower.

Pn308	Speed Feedback Filter	Time Constant	Speed Position			
	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
111000	0 to 65,535 (0.00 ms to 655.35 ms)	0.01 ms	0 (0.00 ms)	Immediately	Setup	

### 8.12.7 Backlash Compensation

### Outline

If you drive a machine that has backlash, there will be deviation between the travel distance in the position reference that is managed by the host controller and the travel distance of the actual machine. Use backlash compensation to add the backlash compensation value to the position reference and use the result to drive the Servomotor. This will ensure that the travel distance of the actual machine will be the same as the travel distance in the host controller.

Note: 1. Backlash compensation can be used only with a Rotary Servomotor. 2. Backlash compensation can be used only for position control.



### **Related Parameters**

Set the following parameters to use backlash compensation.

#### Backlash Compensation Direction

Set the direction in which to apply backlash compensation.

Parameter		Meaning	When Enabled	Classification
Pn230	n. □□□0 (default setting)	Compensate forward references.	After restart	Setup
	n. 🗆 🗆 🗆 1	Compensate reverse references.		

#### Backlash Compensation Value

Set the amount of backlash compensation to add to the position reference. The amount is set in increments of 0.1 reference unit. However, when the amount is converted to encoder pulses, it is rounded off at the decimal point.

**Example** When Pn231 = 6,553.6 [reference units] and electronic gear ratio (Pn20E/Pn210) = 4/1: 6,553.6 × 4 = 26,214.4 [pulses]

 $\Rightarrow$  The backlash compensation will be 26,214 encoder pulses.

	Backlash Compensatio	n	Position			
Pn231	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
111201	-500,000 to 500,000	0.1 reference units	0	Immediately	Setup	
	1		· · · · · ·		1	
Ì	• The backlash compensation value is restricted by the following formula. Backlash compensation is not performed if this condition is not met.					
Important	$Pn231 \le \frac{Pn210}{Pn20E} \times \frac{Maximum motor speed [min-1]}{60} \times Encoder resolution* \times 0.00025$					
	*Refer to the following section for the encoder resolution.					
	Pn20E = 4, Pn210 = 1 16,777,216 (24 bits) $1/4 \times 6,000/60 \times 16,7'$ ⇒ The backlash comp	, Maximum motor 77,216 × 0.00025 ensation will be lir	speed = 6,000 [n = 104,857.6 [refe mited to 104,857.6	nin <sup>-1</sup> ], and Encoder i erence units] 6 reference units.	resolution =	
	Do not exceed the upp limit on the operation r	per limit of the bac nonitor of the Sigr	klash compensati maWin+.	on value. You can c	heck the upper	

#### Backlash Compensation Time Constant

You can set a time constant for a first order lag filter for the backlash compensation value (Pn231) that is added to the position reference.

If you set Pn233 (Backlash Compensation Time Constant) to 0, the first order lag filter is disabled.

	Backlash Compensatio	n Time Constant		Position		
Pn233	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 65,535	0.01 ms	0	Immediately	Setup	

Note: Changes to the settings are applied when there is no reference pulse input and the Servomotor is stopped. The current operation is not affected if the setting is changed during motor operation.

### **Related Monitoring**

You can monitor the following values on the operation monitor of the SigmaWin+.

Displayed Value	Setting Unit
Current Backlash Compensation Value	0.1 reference units
Backlash Compensation Value Setting Limit	0.1 reference units

### **Compensation Operation**

This section describes the operation that is performed for backlash compensation.

Note: The following figures are for when backlash compensation is applied to references in the forward direction (Pn230 = n.□□□0). The following monitor information is provided in the figures: TPOS (target position in the reference coordinate system), POS (reference position in the reference coordinate system), and APOS (feed-back position in the machine coordinate system). The monitor information includes the feedback position in machine coordinate system (APOS) and other feedback information.

The backlash compensation value is subtracted from the feedback positions in the monitor information, so it is not necessary for the host controller to consider the backlash compensation value.

#### Operation When the Servo Is ON

The backlash compensation value (Pn231) is added in the backlash compensation direction when the servo is ON (i.e., while power is supplied to the motor) and a reference is input in the same direction as the backlash compensation direction (Pn230.0 =  $n.\square\square\squareX$ ).

When there is a reference input in the direction opposite to the backlash compensation direction, the backlash compensation value is not added (i.e., backlash compensation is not performed).

The relationship between APOS and the motor shaft position is as follows:

- If a reference is input in the compensation direction: APOS = Motor shaft position Pn231
- If a reference is input in the direction opposite to the compensation direction: APOS = Motor shaft position

The following figure shows driving the Servomotor in the forward direction from target position TPOS0 to TPOS1 and then to TPOS2, and then returning from TPOS2 to TPOS1 and then to TPOS0.

Backlash compensation is applied when moving from TPOS0 to TPOS1, but not when moving from TPOS2 to TPOS1.



#### Operation When the Servo Is OFF

Backlash compensation is not applied when the servo is OFF (i.e., when power is not supplied to motor). Therefore, the reference position POS is moved by only the backlash compensation value.

The relationship between APOS and the motor shaft position is as follows:

• When servo is OFF: APOS = Servomotor shaft position

The following figure shows what happens when the servo is turned OFF after driving the Servomotor in the forward direction from target position TPOS0 to TPOS1. Backlash compensation is not applied when the servo is OFF. (The SERVOPACK manages the position data so that APOS and POS are the same.)



#### Operation When There Is Overtravel

When there is overtravel (i.e., when driving is prohibited due to an overtravel signal or software limit), the operation is the same as for when the servo is OFF ( $\blacklozenge$  Operation When the Servo Is OFF on page 8-76), i.e., backlash compensation is not applied.

#### Operation When Control Is Changed

Backlash compensation is performed only for position control.

Backlash compensation is not applied when position control is changed to any other control method.

Backlash compensation is applied in the same way as when the servo is ON ( Poperation When the Servo Is ON on page 8-75) if any other control method is changed to position control.

### **Related Monitoring**

You can monitor the following values on the operation monitor of the SigmaWin+.

Displayed Value	Unit	Specification
Input Reference Pulse Speed	min <sup>-1</sup>	Displays the input reference pulse speed before backlash compensation.
Position Deviation	Reference units	Displays the position deviation for the position reference after backlash compensation.
Input Reference Pulse Counter	Reference units	Displays the input reference pulse counter before back- lash compensation.
Feedback Pulse Counter	Encoder pulses	Displays the number of pulses from the actually driven motor encoder.
Feedback Pulse Counter	Reference units	Displays the number of pulses from the actually driven encoder in reference units.

### **MECHATROLINK Monitor Information**

PG count

speed

counter

counter

tion (LPOS)

(upper 32 bits)

Input reference pulse

Input reference pulse

Position deviation

Feedback pulse

Previous value of

latched feedback posi-

000B hex

0017 hex

0018 hex

001C hex

001D hex

0080 hex

Pn824

Pn825

This section describes the information that is set for the MECHATROLINK monitor information (monitor 1, monitor 2, monitor 3, and monitor 4) and the backlash compensation operation.

Monitor Code	Abbreviation	Description	Unit	Remarks
0	POS	Reference position in the reference coordi- nate system (after the position reference filter)	Reference units	_
1	MPOS	Reference position	Reference units	_
2	PERR	Position deviation	Reference units	_
3	APOS	Feedback position in machine coordinate system	Reference units	Feedback position with the backlash com- pensation subtracted
4	LPOS	Feedback latch posi- tion in the machine coordinate system	Reference units	Feedback position with the backlash com- pensation subtracted
5	IPOS	Reference position in the reference coordi- nate system (before the position reference filter)	Reference units	_
6	TPOS	Target position in the reference coordinate system	Reference units	-
E	OMN1	Option monitor 1 (selected with Pn824)	-	-
F	OMN2	Option monitor 2 (selected with Pn825)	_	_
Parameter		Monitor Information	Output Unit	Remarks
	0003 hex	Position deviation (lower 32 bits)	Reference units	-
	0004 hex	Position deviation (upper 32 bits)	Reference units	-
	000A hex	PG count (lower 32 bits)	Reference units	Count value of the actually driven motor

encoder

\_

\_

\_

\_

Feedback position with the backlash com-

pensation subtracted

Reference

units

min<sup>-1</sup>

Reference

units Reference

units

Encoder

pulses

Encoder

pulses

	D
	Ē
F	⊐
'	

#### Related Monitoring Diagrams

The following symbols are used in the related monitoring diagrams.

- [A]: Analog monitor
- [U]: Monitor mode (Un monitor)
- [O]: Output signal
- [T]: Trace data
- [M]: MECHATROLINK monitor information



# 8.13 Manual Tuning

This section describes manual tuning.

### 8.13.1 Tuning the Servo Gains

### Servo Gains



Figure 8.1 Simplified Block Diagram for Position Control

In order to manually tune the servo gains, you must understand the configuration and characteristic of the SERVOPACK and adjust the servo gains individually. In most cases, if you greatly change any one parameter, you must adjust the other parameters again. To check the response characteristic, you must prepare a measuring instrument to monitor the output waveforms from the analog monitor.

The SERVOPACK has three feedback systems (the position loop, speed loop, and current loop), and the response characteristic must be increased more with the inner loops. If this relationship is not maintained, the response characteristic will suffer and vibration will occur more easily.

A sufficient response characteristic is ensured for the current loop. There is never a need for it to be adjusted by the user.

### Outline

You can use manual tuning to set the servo gains in the SERVOPACK to increase the response characteristic of the SERVOPACK. For example, you can reduce the positioning time for position control.

Use manual tuning in the following cases.

- When tuning with autotuning without a host reference or autotuning with a host reference does not achieve the desired results
- When you want to increase the servo gains higher than the gains that resulted from autotuning without a host reference or autotuning with a host reference
- When you want to determine the servo gains and moment of inertia ratio yourself

You start manual tuning either from the default parameter settings or from the gain settings that resulted from autotuning without a host reference or autotuning with a host reference.

### **Applicable Tools**

You can monitor the servo gains with the SigmaWin+ or with the analog monitor.

8.13.1 Tuning the Servo Gains

### Precautions

Vibration may occur while you are tuning the servo gains. We recommend that you enable vibration alarms (Pn310 =  $n.\square\square\square$ ) to detect vibration. Refer to the following section for information on vibration detection.

6.10 Initializing the Vibration Detection Level on page 6-37

Vibration alarms are not detected for all vibration. Also, an emergency stop method is necessary to stop the machine safely when an alarm occurs. You must provide an emergency stop device and activate it immediately whenever vibration occurs.

# Tuning Procedure Example (for Position Control or Speed Control)

Step	Description
1	Adjust the first stage first torque reference filter time constant (Pn401) so that vibration does not occur.
2	Increase the Speed loop gain (Pn100) and reduce the speed loop integral time constant (Pn101) as far as possible within the range that does not cause machine vibration.
3	Repeat steps 1 and 2 and return the settings about 10% to 20% from the values that you set.
4	For position control, increase the position loop gain (Pn102) within the range that does not cause vibration.

Information If you greatly change any one servo gain parameter, you must adjust the other parameters again. Do not increase the setting of just one parameter. As a guideline, adjust the settings of the servo gains by approximately 5% each. As a rule, change the servo parameters in the following order.

- To Increase the Response Speed
- 1. Reduce the torque reference filter time constant.
- 2. Increase the speed loop gain.
- 3. Decrease the speed loop integral time constant.
- 4. Increase the position loop gain.
- To Reduce Response Speed and to Stop Vibration and Overshooting
- 1. Reduce the position loop gain.
- 2. Increase the speed loop integral time constant.
- 3. Decrease the speed loop gain.
- 4. Increase the torque filter time constant.

### Adjusted Servo Gains

You can set the following gains to adjust the response characteristic of the SERVOPACK.

- Pn100: Speed Loop Gain
- Pn101: Speed Loop Integral Time Constant
- Pn102: Position Loop Gain
- Pn401: First Stage First Torque Reference Filter Time Constant

#### Position Loop Gain

The position loop gain determines the response characteristic of the position loop in the SER-VOPACK. If you can increase the setting of the position loop gain, the response characteristic will improve and the positioning time will be shortened. However, you normally cannot increase the position loop gain higher than the inherit vibration frequency of the machine system. Therefore, to increase the setting of the position loop gain, you must increase the rigidity of the machine to increase the inherit vibration frequency of the machine.

	Position Loop Gain			Position	
Pn102	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	10 to 20,000	0.1/s	400	Immediately	Tuning

For machines for which a high position loop gain (Pn102) cannot be set, overflow alarms can Information occur during high-speed operation. If that is the case, you can increase the setting of the following parameter to increase the level for alarm detection.

Use the following condition as a guideline for determining the setting.

 $Pn520 \ge \frac{Maximum feed speed [reference units/s]}{2.0} \times 2.0$ Pn102 ÷ 10 (1/s)

If you use a position reference filter, transient deviation will increase due to the filter time constant. When you make the setting, consider deviation accumulation that may result from the filter.

	Position Deviation	o Overflow Alarm	Position		
Pn520	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
111520	1 to 1,073,741,823	1 reference unit	5,242,880	Immediately	Setup

#### Speed Loop Gain

This parameter determines the response characteristic of the speed loop. If the response characteristic of the speed loop is low, it becomes a delay factor for the position loop located outside of the speed loop. This will result in overshooting and vibration in the speed reference. Therefore, setting the speed loop gain as high as possible within the range that will not cause the machine system to vibrate will produce a stable servo system with a good response characteristic.

	Speed Loop Gain			Speed Positi	on Torque
Pn100	Setting Range	Setting Unit	Default Setting	When Enabled	Classifica- tion
	10 to 20,000	0.1 Hz	400	Immediately	Tuning

Setting of Pn103 =  $\frac{\text{Load moment of inertia at motor shaft }(J_L)}{\text{Servomotor moment of inertia }(L_M)} \times 100(\%)$ 

The default setting of Pn103 (Moment of Inertia Ratio) is 100. Before you tune the servo, calculate the moment of inertia ratio with the above formula and set Pn103 to the calculation result.

	Moment of Inertia Ratio			Speed Positi	on Torque
Pn103	Setting Range	Setting Unit	Default Setting	When Enabled	Classifica- tion
	0 to 20,000	1%	100	Immediately	Tuning

#### Speed Loop Integral Time Constant

To enable response to even small inputs, the speed loop has an integral element. The integral element becomes a delay factor in the servo system. If the time constant is set too high, overshooting will occur, positioning settling time will increase, and the response characteristic will suffer.

	Speed Loop Integral Time Constant		Speed Position		
Pn101	Setting Range	Setting Unit	Default Setting	When Enabled	Classifica- tion
	15 to 51,200	0.01 ms	2,000	Immediately	Tuning

8.13.1 Tuning the Servo Gains

#### ◆ Torque Reference Filter

As shown in the following diagram, the torque reference filter contains a first order lag filter and notch filters arranged in series, and each filter operates independently.

The notch filters can be enabled and disabled with  $Pn408 = n.\Box X \Box X$  and  $Pn416 = n.\Box X X X$ .



\* The second stage second torque reference filter is disabled when Pn40F is set to 5,000 (default setting) and it is enabled when Pn40F is set to a value lower than 5,000.

#### Torque Reference Filter

If you suspect that machine vibration is being caused by the Servo Drive, try adjusting the torque reference filter time constant. This may stop the vibration. The lower the value, the better the control response characteristic will be, but there may be a limit depending on the machine conditions.

	First Stage First Torque Reference Filter Time Constant			Speed Posit	ion Torque
Pn401	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 65,535	0.01 ms	100	Immediately	Tuning
	Second Stage Second Torque Reference Filter Frequency		Speed Posit	ion Torque	
Pn40F	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	100 to 5,000	1 Hz	5000*	Immediately	Tuning
	Second Stage Second Notch Filter Q Value			Speed Posit	ion Torque
Pn410	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	50 to 100	0.01	50	Immediately	Tuning

\* The filter is disabled if you set the parameter to 5,000.

#### Notch Filters

The notch filter can eliminate specific frequency elements generated by the vibration of sources such as resonance of the shaft of a ball screw.

The notch filter puts a notch in the gain curve at the specific vibration frequency (called the notch frequency). The frequency components near the notch frequency can be reduced or removed with a notch filter.

Notch filters are set with three parameters for the notch filter frequency, notch filter Q value, and notch filter depth. This section describes the notch filter Q value and notch filter depth.

#### · Notch filter Q Value

The setting of the notch filter Q value determines the width of the frequencies that are filtered for the notch filter frequency. The width of the notch changes with the notch filter Q value. The larger the notch filter Q value is, the steeper the notch is and the narrower the width of frequencies that are filtered is.

The notch filter frequency characteristics for different notch filter Q values are shown below.



Note: The above notch filter frequency characteristics are based on calculated values and may be different from actual characteristics.

#### • Notch Filter Depth

The setting of the notch filter depth determines the depth of the frequencies that are filtered for the notch filter frequency. The depth of the notch changes with the notch filter depth. The smaller the notch filter depth is, the deeper the notch is, increasing the effect of vibration suppression. However, if the value is too small, vibration can actually increase.

The notch filter is disabled if the notch filter depth, d, is set to 1.0 (i.e., if Pn419 is set to 1,000). The notch filter frequency characteristics for different notch filter depths are shown below.



Note: The above notch filter frequency characteristics are based on calculated values and may be different from actual characteristics.

Parameter		Meaning	When Enabled	Classification
	n.□□□0 (default setting)	Disable first stage notch filter.		
Dn/08	n.0001	Enable first stage notch filter.		
Pn408	n.□0□□ (default setting)	Disable second stage notch filter.		
	n.0100	Enable second stage notch filter.		
	n.□□□0 (default setting)	Disable third stage notch filter.	Immediately	Setup
	n.0001	Enable third stage notch filter.		
Pn416	n.□□0□ (default setting)	Disable fourth stage notch filter.	-	
	n.0010	Enable fourth stage notch filter.		
	n.□0□□ (default setting)	Disable fifth stage notch filter.		
	n.0100	Enable fifth stage notch filter.		

You can enable or disable the notch filter with Pn408.

Set the machine vibration frequencies in the notch filter parameters.

8.13.1 Tuning the Servo Gains

	First Stage Notch Fi	Iter Frequency		Speed Posit	ion Torque
Pn409	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	50 to 5,000	1 Hz	5,000	Immediately	Tuning
	First Stage Notch Fi	lter Q Value		Speed Posit	ion Torque
Pn40A	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	50 to 1,000	0.01	70	Immediately	Tuning
	First Stage Notch Fi	Iter Depth		Speed Posit	ion Torque
Pn40B	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 1,000	0.001	0	Immediately	Tuning
	Second Stage Notc	h Filter Frequency		Speed Posit	ion Torque
Pn40C	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	50 to 5,000	1 Hz	5,000	Immediately	Tuning
	Second Stage Notc	h Filter Q Value		Speed Posit	ion Torque
Pn40D	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	50 to 1,000	0.01	70	Immediately	Tuning
	Second Stage Notc	h Filter Depth		Speed Posit	ion Torque
Pn40E	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 1,000	0.001	0	Immediately	Tuning
	Third Stage Notch F	ilter Frequency		Speed Posit	ion Torque
Pn417	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	50 to 5,000	1 Hz	5,000	Immediately	Tuning
	Third Stage Notch F	ilter Q Value	1	Speed Posit	ion Torque
Pn418	0 III D	<b>O</b>			OL 101 11
Pn418	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
Pn418	50 to 1,000	0.01	70	When Enabled Immediately	Tuning
Pn418	50 to 1,000 Third Stage Notch F	0.01 0.01	70	When Enabled Immediately Speed Posit	Classification       Tuning       ion     Torque
Pn418 Pn419	50 to 1,000 Third Stage Notch F Setting Range	0.01 ilter Depth Setting Unit	Default Setting 70 Default Setting	When Enabled Immediately Speed Posit	Classification Tuning ion Torque Classification
Pn418 Pn419	Setting Range 50 to 1,000 Third Stage Notch F Setting Range 0 to 1,000	Setting Unit       0.01       Filter Depth       Setting Unit       0.001	Default Setting 70 Default Setting 0	When Enabled Immediately Speed Posit When Enabled Immediately	Classification Tuning ion Torque Classification Tuning
Pn418 Pn419	50 to 1,000 Third Stage Notch F Setting Range 0 to 1,000 Fourth Stage Notch	Setting Unit       0.01       Filter Depth       Setting Unit       0.001       Filter Frequency	Default Setting 70 Default Setting 0	When Enabled Immediately Speed Posit When Enabled Immediately Speed Posit	Classification Tuning ion Torque Classification Tuning ion Torque
Pn418 Pn419 Pn41A	Setting Range 50 to 1,000 Third Stage Notch F Setting Range 0 to 1,000 Fourth Stage Notch Setting Range	Setting Unit       0.01       ilter Depth       Setting Unit       0.001       Filter Frequency       Setting Unit	Default Setting 70 Default Setting 0 Default Setting	When Enabled Immediately Speed Posit When Enabled Immediately Speed Posit When Enabled	Classification Tuning ion Torque Classification Tuning ion Torque Classification
Pn418 Pn419 Pn41A	Setting Range 50 to 1,000 Third Stage Notch F Setting Range 0 to 1,000 Fourth Stage Notch Setting Range 50 to 5,000	Setting Unit         0.01         Filter Depth         0.001         Filter Frequency         Setting Unit         1 Hz	Default Setting 70 Default Setting 0 Default Setting 5,000	When Enabled Immediately Speed Posit When Enabled Immediately Speed Posit When Enabled Immediately	Classification Tuning ion Torque Classification Tuning ion Torque Classification Tuning
Pn418 Pn419 Pn41A	Setting Range 50 to 1,000 Third Stage Notch F Setting Range 0 to 1,000 Fourth Stage Notch Setting Range 50 to 5,000 Fourth Stage Notch	Setting Unit       0.01       ilter Depth       Setting Unit       0.001       Filter Frequency       Setting Unit       1 Hz       Filter Q Value	Default Setting 70 Default Setting 0 Default Setting 5,000	When Enabled         Immediately         Speed       Posit         Speed       Posit	Classification Tuning ion Torque Classification Tuning ion Torque Classification Tuning ion Torque
Pn418 Pn419 Pn41A Pn41B	Setting Range 50 to 1,000 Third Stage Notch F Setting Range 0 to 1,000 Fourth Stage Notch Setting Range 50 to 5,000 Fourth Stage Notch Setting Range	Setting Unit0.01ilter DepthSetting Unit0.001Filter FrequencySetting Unit1 HzFilter Q ValueSetting Unit	Default Setting 70 Default Setting 0 Default Setting 5,000 Default Setting	When Enabled         Immediately         Speed       Posit         When Enabled	Classification         Tuning         ion       Torque         Classification         Tuning
Pn418 Pn419 Pn41A Pn41B	Setting Range 50 to 1,000 Third Stage Notch F Setting Range 0 to 1,000 Fourth Stage Notch Setting Range 50 to 5,000 Fourth Stage Notch Setting Range 50 to 1,000	Setting Unit         0.01         ilter Depth         Setting Unit         0.001         Filter Frequency         Setting Unit         1 Hz         Filter Q Value         Setting Unit         0.01	Default Setting 70 Default Setting 0 Default Setting 5,000 Default Setting 70	When Enabled Immediately Speed Posit When Enabled Immediately Speed Posit When Enabled Immediately Speed Posit When Enabled Immediately	Classification Tuning ion Torque Classification Tuning ion Torque Classification Tuning ion Torque Classification Tuning
Pn418 Pn419 Pn41A Pn41B	Setting Range 50 to 1,000 Third Stage Notch F Setting Range 0 to 1,000 Fourth Stage Notch Setting Range 50 to 5,000 Fourth Stage Notch Setting Range 50 to 1,000 Fourth Stage Notch	Setting Unit       0.01       ilter Depth       Setting Unit       0.001       Filter Frequency       Setting Unit       1 Hz       Filter Q Value       Setting Unit       0.01	Default Setting 70 Default Setting 0 Default Setting 5,000 Default Setting 70	When Enabled         Immediately         Speed       Posit         Speed       Posit	Classification Tuning ion Torque Classification Tuning ion Torque Classification Tuning ion Torque Classification Tuning ion Torque
Pn418 Pn419 Pn41A Pn41B Pn41C	Setting Range 50 to 1,000 Third Stage Notch F Setting Range 0 to 1,000 Fourth Stage Notch Setting Range 50 to 5,000 Fourth Stage Notch Setting Range 50 to 1,000 Fourth Stage Notch Setting Range	Setting Unit0.01ilter DepthSetting Unit0.001Filter FrequencySetting Unit1 HzFilter Q ValueSetting Unit0.01Filter DepthSetting Unit0.01	Default Setting 70 Default Setting 0 Default Setting 5,000 Default Setting 70 Default Setting	When Enabled         Immediately         Speed       Posit	Classification         Tuning         ion       Torque
Pn418 Pn419 Pn41A Pn41B Pn41C	Setting Range 50 to 1,000 Third Stage Notch F Setting Range 0 to 1,000 Fourth Stage Notch Setting Range 50 to 5,000 Fourth Stage Notch Setting Range 50 to 1,000 Fourth Stage Notch Setting Range 0 to 1,000	Setting Unit0.01ilter DepthSetting Unit0.001Filter FrequencySetting Unit1 HzFilter Q ValueSetting Unit0.01Filter DepthSetting Unit0.001	Default Setting 70 Default Setting 0 Default Setting 5,000 Default Setting 70 Default Setting 0	When Enabled         Immediately         Speed       Posit	Classification Tuning ion Torque Classification Tuning ion Torque Classification Tuning ion Torque Classification Tuning ion Torque Classification Tuning
Pn418 Pn419 Pn41A Pn41B Pn41C	Setting Range 50 to 1,000 Third Stage Notch F Setting Range 0 to 1,000 Fourth Stage Notch Setting Range 50 to 5,000 Fourth Stage Notch Setting Range 50 to 1,000 Fourth Stage Notch Setting Range 0 to 1,000 Fifth Stage Notch Fi	Setting Unit0.01ilter DepthSetting Unit0.001Filter FrequencySetting Unit1 HzFilter Q ValueSetting Unit0.01Filter DepthSetting Unit0.001Iter Frequency	Default Setting 70 Default Setting 0 Default Setting 5,000 Default Setting 70 Default Setting 0	When Enabled         Immediately         Speed       Posit         Speed       Posit	Classification Tuning ion Torque Classification Tuning ion Torque Classification Tuning ion Torque Classification Tuning ion Torque Classification Tuning ion Torque
Pn418 Pn419 Pn41A Pn41B Pn41C Pn41D	Setting Range 50 to 1,000 Third Stage Notch F Setting Range 0 to 1,000 Fourth Stage Notch Setting Range 50 to 5,000 Fourth Stage Notch Setting Range 50 to 1,000 Fourth Stage Notch Setting Range 0 to 1,000 Fifth Stage Notch Fi Setting Range	Setting Unit0.01ilter DepthSetting Unit0.001Filter FrequencySetting Unit1 HzFilter Q ValueSetting Unit0.01Filter DepthSetting Unit0.001Iter FrequencySetting Unit0.001Setting Unit0.001	Default Setting 70 Default Setting 0 Default Setting 5,000 Default Setting 70 Default Setting 0 Default Setting	When Enabled         Immediately         Speed       Posit	Classification         Tuning         ion       Torque
Pn418 Pn419 Pn41A Pn41B Pn41C Pn41D	Setting Range 50 to 1,000 Third Stage Notch F Setting Range 0 to 1,000 Fourth Stage Notch Setting Range 50 to 5,000 Fourth Stage Notch Setting Range 0 to 1,000 Fourth Stage Notch Setting Range 0 to 1,000 Fifth Stage Notch Fi Setting Range 50 to 5,000	Setting Unit         0.01         ilter Depth         Setting Unit         0.001         Filter Frequency         Setting Unit         1 Hz         Filter Q Value         Setting Unit         0.01         Filter Depth         Setting Unit         0.01         Filter Depth         Setting Unit         0.001         ilter Frequency         Setting Unit         0.001	Default Setting 70 Default Setting 0 Default Setting 5,000 Default Setting 70 Default Setting 0 Default Setting 5,000	When Enabled         Immediately         Speed       Posit	Classification Tuning ion Torque Classification Tuning ion Torque Classification Tuning ion Torque Classification Tuning ion Torque Classification Tuning ion Torque Classification Tuning
Pn418 Pn419 Pn41A Pn41B Pn41C Pn41D	Setting Range 50 to 1,000 Third Stage Notch F Setting Range 0 to 1,000 Fourth Stage Notch Setting Range 50 to 5,000 Fourth Stage Notch Setting Range 50 to 1,000 Fourth Stage Notch Fi Setting Range 0 to 1,000 Fifth Stage Notch Fi Setting Range 50 to 5,000 Fifth Stage Notch Fi	Setting Unit 0.01 ilter Depth Setting Unit 0.001 Filter Frequency Setting Unit 1 Hz Filter Q Value Setting Unit 0.01 Filter Depth Setting Unit 0.001 ilter Frequency Setting Unit 1 Hz ilter Q Value	Default Setting 70 Default Setting 0 Default Setting 5,000 Default Setting 0 Default Setting 0 Default Setting 5,000	When Enabled         Immediately         Speed       Posit	Classification Tuning ion Torque Classification Tuning ion Torque Classification Tuning ion Torque Classification Tuning ion Torque Classification Tuning ion Torque Classification Tuning ion Torque Classification Tuning ion Torque
Pn418 Pn419 Pn41A Pn41B Pn41C Pn41D Pn41E	Setting Range 50 to 1,000 Third Stage Notch F Setting Range 0 to 1,000 Fourth Stage Notch Setting Range 50 to 5,000 Fourth Stage Notch Setting Range 0 to 1,000 Fourth Stage Notch Fi Setting Range 50 to 5,000 Fifth Stage Notch Fi Setting Range 50 to 5,000	Setting Unit0.01ilter DepthSetting Unit0.001Filter FrequencySetting Unit1 HzFilter Q ValueSetting Unit0.01Filter DepthSetting Unit0.001Iter FrequencySetting Unit1 HzIter Q ValueSetting Unit1 HzIter FrequencySetting Unit1 HzIter Q ValueSetting Unit1 HzIter Q ValueSetting Unit	Default Setting 70 Default Setting 0 Default Setting 5,000 Default Setting 0 Default Setting 0 Default Setting 5,000 Default Setting 5,000	When Enabled         Immediately         Speed       Posit	Classification         Tuning         ion       Torque
Pn418 Pn419 Pn41A Pn41B Pn41C Pn41D Pn41E	Setting Range 50 to 1,000 Third Stage Notch F Setting Range 0 to 1,000 Fourth Stage Notch Setting Range 50 to 5,000 Fourth Stage Notch Setting Range 50 to 1,000 Fourth Stage Notch Fi Setting Range 50 to 5,000 Fifth Stage Notch Fi Setting Range 50 to 5,000 Fifth Stage Notch Fi Setting Range 50 to 5,000	Setting Unit0.01ilter DepthSetting Unit0.001Filter FrequencySetting Unit1 HzFilter Q ValueSetting Unit0.01Filter DepthSetting Unit0.001ilter FrequencySetting Unit0.001ilter FrequencySetting Unit1 Hzilter Q ValueSetting Unit0.001Setting Unit0.01	Default Setting 70 Default Setting 0 Default Setting 5,000 Default Setting 0 Default Setting 0 Default Setting 5,000 Default Setting 70	When Enabled         Immediately         Speed       Posit	Classification Tuning ion Torque Classification Tuning ion Torque Classification Tuning ion Torque Classification Tuning ion Torque Classification Tuning ion Torque Classification Tuning ion Torque Classification Tuning ion Torque
Pn418 Pn419 Pn41A Pn41B Pn41C Pn41D Pn41E	Setting Range 50 to 1,000 Third Stage Notch F Setting Range 0 to 1,000 Fourth Stage Notch Setting Range 50 to 5,000 Fourth Stage Notch Setting Range 0 to 1,000 Fourth Stage Notch Fi Setting Range 50 to 5,000 Fifth Stage Notch Fi Setting Range 50 to 5,000 Fifth Stage Notch Fi Setting Range 50 to 1,000 Fifth Stage Notch Fi	Setting Unit         0.01         ilter Depth         Setting Unit         0.001         Filter Frequency         Setting Unit         1 Hz         Filter Q Value         Setting Unit         0.01         Filter Depth         Setting Unit         0.01         Filter Depth         Setting Unit         0.001         Iter Frequency         Setting Unit         1 Hz         Iter Q Value         Setting Unit         0.001         Iter Depth         Setting Unit         0.01         Iter Depth	Default Setting 70 Default Setting 0 Default Setting 5,000 Default Setting 0 Default Setting 5,000 Default Setting 5,000 Default Setting 70	When Enabled         Immediately         Speed       Posit	Classification Tuning Classification Classification Tuning Classification Classification Tuning Classification Tuning Classification Tuning Classification Classification Tuning Classification Classification Tuning Classification Classification Tuning
Pn418 Pn419 Pn41A Pn41B Pn41C Pn41C Pn41E Pn41F	Setting Range 50 to 1,000 Third Stage Notch F Setting Range 0 to 1,000 Fourth Stage Notch Setting Range 50 to 5,000 Fourth Stage Notch Setting Range 0 to 1,000 Fourth Stage Notch Fi Setting Range 50 to 5,000 Fifth Stage Notch Fi Setting Range 50 to 5,000 Fifth Stage Notch Fi Setting Range 50 to 1,000 Fifth Stage Notch Fi Setting Range	Setting Unit0.01ilter DepthSetting Unit0.001Filter FrequencySetting Unit1 HzFilter Q ValueSetting Unit0.01Filter DepthSetting Unit0.001Iter PrequencySetting Unit0.001Iter FrequencySetting Unit1 HzIter Q ValueSetting Unit1 HzIter Q ValueSetting Unit0.01Iter DepthSetting Unit0.01Setting UnitSetting Unit0.01	Default Setting 70 Default Setting 0 Default Setting 5,000 Default Setting 0 Default Setting 0 Default Setting 5,000 Default Setting 70 Default Setting 70 Default Setting 70	When Enabled         Immediately         Speed       Posit         When Enabled	Classification         Tuning         ion       Torque         Classification         Tuning         ion       Torque

**Important** 

• Do not set notch filter frequencies (Pn409, Pn40C, Pn417, Pn41A, and Pn41D) that are close to the speed loop's response frequency. Set a frequency that is at least four times the speed loop gain (Pn100). (However, Pn103 (Moment of Inertia Ratio) must be set correctly. If the setting is not correct, vibration may occur and the machine may be damaged.

 Change the notch filter frequencies (Pn409, Pn40C, Pn417, Pn41A, and Pn41D) only while the Servomotor is stopped. Vibration may occur if a notch filter frequency is changed during operation.

### **Guidelines for Manually Tuning Servo Gains**

When you manually adjust the parameters, make sure that you completely understand the information in the product manual and use the following conditional expressions as guidelines. The appropriate values of the parameter settings are influenced by the machine specifications, so they cannot be determined universally. When you adjust the parameters, actually operate the machine and use the SigmaWin+ or analog monitor to monitor operating conditions. Even if the status is stable while the motor is stopped, an unstable condition may occur when an operation reference is input. Therefore, input operation references and adjust the servo gains as you operate the motor.

Stable gain: Settings that provide a good balance between parameters.

However, if the load moment of inertia is large and the machine system contains elements prone to vibration, you must sometimes use a setting that is somewhat higher to prevent the machine from vibrating.

Critical gain: Settings for which the parameters affect each other

Depending on the machine conditions, overshooting and vibration may occur and operation may not be stable. If the critical gain condition expressions are not met, operation will become more unstable, and there is a risk of abnormal motor shaft vibration and round-trip operation with a large amplitude. Always stay within the critical gain conditions.

If you use the torque reference filter, second torque reference filter, and notch filters together, the interference between the filters and the speed loop gain will be superimposed. Allow leeway in the adjustments.



The following adjusted value guidelines require that the setting of Pn103 (Moment of Inertia Ratio) is correctly set for the actual machine.

#### • When $Pn10B = n.\Box\Box0\Box$ (PI Control)

Guidelines are given below for gain settings 1.

The same guidelines apply to gain settings 2 (Pn104, Pn105, Pn106, and Pn412).

- Speed Loop Gain (Pn100 [Hz]) and Position Loop Gain (Pn102 [/s]) Stable gain: Pn102 [/s]  $\leq 2\pi \times Pn100/4$  [Hz] Critical gain: Pn102 [/s]  $< 2\pi \times Pn100$  [Hz]
- Speed Loop Gain (Pn100 [Hz]) and Speed Loop Integral Time Constant (Pn101 [ms]) Stable gain: Pn101 [ms]  $\geq$  4,000/( $2\pi \times$  Pn100 [Hz]) Critical gain: Pn101 [ms] > 1,000/( $2\pi \times$  Pn100 [Hz])
- Speed Loop Gain (Pn100 [Hz]) and First Stage First Torque Reference Filter Time Constant (Pn401 [ms]) Stable gain: Pn401 [ms] ≤ 1,000/(2π × Pn100 [Hz] × 4)

Critical gain: Pn401 [ms]  $\leq$  1,000/(2 $\pi$  × Pn100 [Hz] × 4)

8.13.1 Tuning the Servo Gains

- Speed Loop Gain (Pn100 [Hz]) and Second Stage Second Torque Reference Filter Frequency (Pn40F [Hz])
   Critical gain: Pn40F [Hz] > 4 × Pn100 [Hz]
   Note: Set the second stage second notch filter Q value (Pn410) to 0.70.
- Speed Loop Gain (Pn100 [Hz]) and First Stage Notch Filter Frequency (Pn409 [Hz]) (or Second Stage Notch Filter Frequency (Pn40C [Hz])) Critical gain: Pn409 [Hz] > 4 × Pn100 [Hz]
- Speed Loop Gain (Pn100 [Hz]) and Speed Feedback Filter Time Constant (Pn308 [ms]) Stable gain: Pn308 [ms]  $\leq$  1,000/(2 $\pi$  × Pn100 [Hz] × 4) Critical gain: Pn308 [ms] < 1,000/(2 $\pi$  × Pn100 [Hz] × 1)

#### • When $Pn10B = n.\Box\Box1\Box$ (I-P Control)

Guidelines are given below for gain settings 1.

The same guidelines apply to gain settings 2 (Pn104, Pn105, Pn106, and Pn412).

For I-P control, the relationships between the speed loop integral time constant, speed loop gain, and position loop gain are different from the relationships for PI control. The relationship between other servo gains is the same as for PI control.

- Speed Loop Gain (Pn100 [Hz]) and Speed Loop Integral Time Constant (Pn101 [ms]) Stable gain: Pn100 [Hz] ≥ 320/Pn101 [ms]
- Position Loop Gain (Pn102 [/s]) and Speed Loop Integral Time Constant (Pn101 [ms]) Stable gain: Pn102 [/s] ≤ 320/Pn101 [ms]

#### Information Selecting the Speed Loop Control Method (PI Control or I-P Control) Usually, I-P control is effective for high-speed positioning and high-speed, high-precision processing applications. With I-P control, you can use a lower position loop gain than for PI control to reduce the positioning time and reduce arc radius reduction. However, if you can use mode switching to change to proportional control to achieve the desired application, then using PI control would be the normal choice.

#### Decimal Points in Parameter Settings

For the SGD7W SERVOPACKs, decimal places are given for the settings of parameters on the Digital Operator, Panel Operator, and in the manual. For example with Pn100 (Speed Loop Gain), Pn100 = 40.0 is used to indicate a setting of 40.0 Hz. In the following adjusted value guidelines, the decimal places are also given.

**Example** • Speed Loop Gain (Pn100 [Hz]) and Speed Loop Integral Time Constant (Pn101 [ms]) Stable gain: Pn101 [ms]  $\geq$  4,000/( $2\pi \times$  Pn100 [Hz]), therefore If Pn100 = 40.0 [Hz], then Pn101 = 4,000/( $2\pi \times$  40.0)  $\approx$  15.92 [ms].

### Model Following Control

You can use model following control to improve response characteristic and shorten positioning time. You can use model following control only with position control.

Normally, the parameters that are used for model following control are automatically set along with the servo gains by executing autotuning or custom tuning. However, you must adjust them manually in the following cases.

- When the tuning results for autotuning or custom tuning are not acceptable
- When you want to increase the response characteristic higher than that achieved by the tuning results for autotuning or custom tuning
- · When you want to determine the servo gains and model following control parameters yourself

8.13.1 Tuning the Servo Gains

The block diagram for model following control is provided below.



#### Manual Tuning Procedure

Use the following tuning procedure for using model following control.

Step	Description
1	Friction compensation must also be used. Set the friction compensation parameters. Refer to the following section for the setting procedure.
	Adjust the servo gains. Refer to the following section for an example procedure. <i>Tuning Procedure Example (for Position Control or Speed Control)</i> on page 8-80
2	Note: 1. Set the moment of inertia ratio (Pn103) as accurately as possible. 2. Refer to the guidelines for manually tuning the servo gains and set a stable gain for the position loop gain (Pn102). a Guidelines for Manually Tuning Servo Gains on page 8-85
3	Increase the model following control gain (Pn141) as much as possible within the range in which overshooting and vibration do not occur.
4	If overshooting occurs or if the response is different for forward and reverse operation, fine-tune model following control with the following settings: model following control bias in the forward direction (Pn143), model following control bias in the reverse direction (Pn144), and model following control speed feedforward compensation (Pn147).

#### Related Parameters

Next we will describe the following parameters that are used for model following control.

- Pn140 (Model Following Control-Related Selections)
- Pn141 (Model Following Control Gain)
- Pn143 (Model Following Control Bias in the Forward Direction)
- Pn144 (Model Following Control Bias in the Reverse Direction)
- Pn147 (Model Following Control Speed Feedforward Compensation)

#### Model Following Control-Related Selections

Set  $Pn140 = n.\square\square\squareX$  to specify whether to use model following control.

If you use model following control with vibration suppression, set Pn140 to  $n.\Box\Box1\Box$  or Pn140 =  $n.\Box\Box2\Box$ . When you also perform vibration suppression, adjust vibration suppression with custom tuning in advance.

Note: If you use vibration suppression (Pn140 = n.  $\Box \Box \Box \Box$  or Pn140 = n.  $\Box \Box \Box \Box$ ), always set Pn140 to n.  $\Box \Box \Box \Box$  (Use model following control).

#### 8.13 Manual Tuning

#### 8.13.1 Tuning the Servo Gains

Parameter		Function	When Enabled	Classification
Pn140	n.□□□0 (default setting)	Do not use model following control.		Tuning
	n.0001	Use model following control.		
	n.□□0□ (default setting)	Do not perform vibration suppression.	Immediately	
	n.0010	Perform vibration suppression for a specific frequency.		
	n.0020	Perform vibration suppression for two specific frequencies.		

#### Model Following Control Gain

The model following control gain determines the response characteristic of the servo system. If you increase the setting of the model following control gain, the response characteristic will improve and the positioning time will be shortened. The response characteristic of the servo system is determined by this parameter, and not by Pn102 (Position Loop Gain).

	Model Following Control Gain			Position	
Pn141	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	10 to 20,000	0.1/s	500	Immediately	Tuning

**Information** For machines for which a high model following control gain cannot be set, the size of the position deviation in model following control will be determined by the setting of the model following control gain. For a machine with low rigidity, in which a high model following control gain cannot be set, position deviation overflow alarms may occur during high-speed operation. If that is the case, you can increase the setting of the following parameter to increase the level for alarm detection.

Use the following conditional expression for reference in determining the setting.

 $Pn 520 \ge \frac{\text{Maximum feed speed [reference units/s]}}{Pn 141/10 [1/s]} \times 2.0$ 

	Position Deviation	Overflow Alarm	Position		
Pn520	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
F11520	1 to 1,073,741,823	1 reference unit	5,242,880	Immediately	Setup

#### Model Following Control Bias in the Forward Direction and Model Following Control Bias in the Reverse Direction

If the response is different for forward and reverse operation, use the following parameters for fine-tuning.

If you decrease the settings, the response characteristic will be lowered but overshooting will be less likely to occur.

Pn143	Model Following Co	ontrol Bias in the Forv	ward Direction	Posit	ion
	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 10,000	0.1%	1,000	Immediately	Tuning
Pn144	Model Following Control Bias in the Reverse Direction Position				
	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 10,000	0.1%	1,000	Immediately	Tuning

#### Model Following Control Speed Feedforward Compensation

If overshooting occurs even after you adjust the model following control gain, model following control bias in the forward direction, and model following control bias in the reverse direction, you may be able to improve performance by setting the following parameter.

If you decrease the settings, the response characteristic will be lowered but overshooting will be less likely to occur.

	Model Following Co	ntrol Speed Feedfor	ward Compensation	Position			
Pn147	Setting Range	Setting Unit	Default Setting	When Enabled	Classification		
	0 to 10,000	0.1%	1,000	Immediately	Tuning		

#### Model Following Control Type Selection

When you enable model following control, you can select the model following control type. Normally, set Pn14F to n. DDD1 (Use model following control type 2) (default setting). If compatibility with previous models is required, set Pn14F to n. DDD0 (Use model following control type 1).

Parameter		Meaning	When Enabled	Classification
Pn14F	n.🗆 🗆 🗆 0	Use model following control type 1.		
	n.□□□1 (default setting)	Use model following control type 2.	After restart	Tuning

### 8.13.2 Compatible Adjustment Functions

The compatible adjustment functions are used together with manual tuning. You can use these functions to improve adjustment results. These functions allow you to use the same functions as for  $\Sigma$ -III-Series SERVOPACKs to adjust  $\Sigma$ -7-Series SERVOPACKs.

### Feedforward

The feedforward function applies feedforward compensation to position control to shorten the positioning time.



Pn109	Feedforward Position				
	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 100	1%	0	Immediately	Tuning
Pn10A	Feedforward Filter Time Constant Position				
	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 6,400	0.01 ms	0	Immediately	Tuning

Note: If you set the feedforward value too high, the machine may vibrate. As a guideline, use a setting of 80% or less.

Tuning

8.13.2 Compatible Adjustment Functions

# Mode Switching (Changing between Proportional and PI Control)

You can use mode switching to automatically change between proportional control and PI control.

Overshooting caused by acceleration and deceleration can be suppressed and the settling time can be reduced by setting the switching condition and switching levels.



#### Related Parameters

Select the switching condition for mode switching with  $Pn10B = n.\Box\Box\BoxX$ .

Parameter		Mode Switching	Parameter That Sets the Level		When	Classification
		Selection	Rotary Servomotor	Linear Servomotor	Enabled	Classification
Pn10B	n.□□□0 (default setting)	Use the internal torque reference as the condition.	Pn1	10C		Setup
	n.0001	Use the speed ref- erence as the con- dition.	Pn10D	Pn181	Immediately	
	n.0002	Use the accelera- tion reference as the condition.	Pn10E	Pn182		
	n.□□□3	Use the position deviation as the condition.	Pn10F			
	n.0004	Do not use mode switching.	_			

#### Parameters That Set the Switching Levels

Rotary Servomotors

	Mode Switching L	evel for Torque Ref	erence	Speed Position		
Pn10C	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 800	1%	200	Immediately	Tuning	
	Mode Switching L	evel for Speed Ref	erence	Speed Position		
Pn10D	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 10,000	1 min <sup>-1</sup>	0	Immediately	Tuning	
	Mode Switching Level for Acceleration			Speed Position		
Pn10E	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 30,000	1 min <sup>-1</sup> /s	0	Immediately	Tuning	
Pn10F	Mode Switching L	evel for Position De	eviation	Position		
	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 10,000	1 reference unit	0	Immediately	Tuning	

• Linear Servomotors

	Mode Switching L	evel for Force Refe	rence	Speed Position		
Pn10C	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 800	1%	200	Immediately	Tuning	
	Mode Switching L	evel for Speed Refe	erence	Speed Position		
Pn181	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 10,000	1 mm/s	0	Immediately	Tuning	
	Mode Switching Level for Acceleration			Speed Position		
Pn182	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 30,000	1 mm/s <sup>2</sup>	0	Immediately	Tuning	
Pn10F	Mode Switching L	evel for Position De	eviation	Position		
	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 10,000	1 reference unit	0	Immediately	Tuning	

#### ■ Using the Torque Reference as the Mode Switching Condition (Default Setting)

When the torque reference equals or exceeds the torque set for the mode switching level for torque reference (Pn10C), the speed loop is changed to P control.

The default setting for the torque reference level is 200%.



#### ■ Using the Speed Reference as the Mode Switching Condition

Rotary Servomotors

When the speed reference equals or exceeds the speed set for the mode switching level for a speed reference (Pn10D), the speed loop is changed to P control.



Linear Servomotors

When the speed reference equals or exceeds the speed set for the mode switching level for a speed reference (Pn181), the speed loop is changed to P control.



8.13.2 Compatible Adjustment Functions

#### Using the Acceleration as the Mode Switching Condition

Rotary Servomotors

When the speed reference equals or exceeds the acceleration rate set for the mode switching level for acceleration (Pn10E), the speed loop is changed to P control.



• Linear Servomotors

When the speed reference equals or exceeds the acceleration rate set for the mode switching level for acceleration (Pn182), the speed loop is changed to P control.



#### Using the Position Deviation as the Mode Switching Condition

When the position deviation equals or exceeds the value set for the mode switching level for position deviation (Pn10F), the speed loop is changed to P control.

This setting is enabled only for position control.



### **Position Integral**

The position integral is the integral function of the position loop. It is used for the electronic cams and electronic shafts when using the SERVOPACK with a Yaskawa MP3000-Series Machine Controller.

	Position Integral Tin	ne Constant	Position			
Pn11F	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 50,000	0.1 ms	0	Immediately	Tuning	

8.14.1 Mechanical Analysis

# 8.14 Diagnostic Tools

### 8.14.1 Mechanical Analysis

### Overview

You can connect the SERVOPACK to a computer to measure the frequency characteristics of the machine. This allows you to measure the frequency characteristics of the machine without using a measuring instrument.



The motor is used to cause machine vibration and then the speed frequency characteristics for the motor torque are measured. The measured frequency characteristics can be used to determine the machine resonance.

You determine the machine resonance for use in servo tuning and as reference for considering changes to the machine. The performance of the servo cannot be completely utilized depending on the rigidity of the machine. You may need to consider making changes to the machine. The information can also be used as reference for servo tuning to help you adjust parameters, such as the servo rigidity and torque filter time constant.

You can also use the information to set parameters, such as the notch filters.



8.14.1 Mechanical Analysis

### **Frequency Characteristics**

The motor is used to cause the machine to vibrate and the frequency characteristics from the torque to the motor speed are measured to determine the machine characteristics. For a normal machine, the resonance frequencies are clear when the frequency characteristics are plotted on graphs with the gain and phase (Bode plots). The Bode plots show the size (gain) of the response of the machine to which the torque is applied, and the phase delay (phase) in the response for each frequency. Also, the machine resonance frequency can be determined from the maximum frequency of the valleys (anti-resonance) and peaks (resonance) of the gain and the phase delay.

For a motor without a load or for a rigid mechanism, the gain and phase change gradually in the Bode plots.



- ① Toolbar
- ② START Button

Click the START Button to start analysis.

3 Measurement and Notch Filter Setting Tab Pages

Measurement Tab Page: Displays detailed information on the results of analysis.

Notch Filter Setting Tab Page: Displays the notch filter frequencies. You can set these values in the parameters.
## 8.14.2 Easy FFT

The machine is made to vibrate and a resonance frequency is detected from the generated vibration to set notch filters according to the detected resonance frequencies. This is used to eliminate high-frequency vibration and noise.

During execution of Easy FFT, a frequency waveform reference is sent from the SERVOPACK to the Servomotor to automatically cause the shaft to rotate multiple times within 1/4th of a rotation, thus causing the machine to vibrate.

Execute Easy FFT after the servo is turned OFF if operation of the SERVOPACK results in high-frequency noise and vibration.

- Never touch the Servomotor or machine during execution of Easy FFT. Doing so may result in injury.



• Use Easy FFT when the servo gain is low, such as in the initial stage of servo tuning. If you execute Easy FFT after you increase the gain, the machine may vibrate depending on the machine characteristics or gain balance.



Easy FFT is built into the SERVOPACK for compatibility with previous products. Normally use autotuning without a host reference for tuning.

## Preparations

Always check the following before you execute Easy FFT.

- The parameters must not be write prohibited.
- The main circuit power supply must be ON.
- The test without a motor function must be disabled (Pn00C =  $n.\Box\Box\Box$ ).
- There must be no alarms.
- The servo must be OFF.
- There must be no overtravel.
- An external reference must not be input.

8.14.2 Easy FFT

## **Operating Procedure**

Use the following procedure for Easy FFT.

- 1. Click the <u>I</u> Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- Select Easy FFT in the Menu Dialog Box. The Easy FFT Dialog Box will be displayed. Click the Cancel Button to cancel Easy FFT. You will return to the main window.
- 3. Click the OK Button.



Another Easy FFT Dialog Box will be displayed.

4. Click the Servo ON Button.

Easy FFT AXIS#00	
Servo ON/OFF operation	
Servo OFF	Servo ON
Measurement start / Stopping operation	
Measurement condition	
Stimulus signal Frequency	Start
Instruction amplitude 15	
Rotation (moving) Forward	, in the second se
Measurement result	
Detected resonance frequency	[Hz]
Optimal notch filter frequency	[Hz]
Notch filter selection	
	Measurement complete

 Select the instruction (reference) amplitude and the rotation direction in the Measurement condition Area, and then click the Start Button. The motor shaft will rotate and measurements will start.

Easy FFT AXIS#00	<b>×</b>
Servo ON/OFF operation	
Servo ON	Servo OFF
Measurement start / Stopping operation	
Measurement condition	
Stimulus signal Frequency	Start
Instruction amplitude 15	
(1 - 800)	
Rotation (moving) Forward	
Measurement result	
Detected resonance frequency	[Hz]
Optimal notch filter frequency	[Hz]
Notch filter selection	
	Measurement complete

When measurements have been completed, the measurement results will be displayed.

6. Check the results in the Measurement result Area and then click the Measurement complete Button.

Easy FFT AXIS#00	
Servo ON/OFF operation	Servo OFF
Measurement start / Stopping operation Measurement condition Stimulus signal Frequency Instruction amplitude 15 • [%] (1 - 800) Rotation (moving) Forward •	
Detected resonance frequency 502	[Hz]
Optimal notch filter frequency 502 Notch filter selection The 1st step	[Hz]
	Measurement complete

8.14.2 Easy FFT

7. Click the **Result Writing** Button if you want to set the measurement results in the parameters.

Easy FFT AXIS#00	×
Notch filter selection	
Pn408:Torque-Related Function Selections digit 0 Notch Filter Selection 1	
0:Disable first stage notch filter.	_
_	
1:Enable first stage notch filter.	_
,	
- Notch filter frequency	
Pn409:First Stage Notch Filter Frequency	
5000 [Hz] <b>5</b> 02 [Hz]	
· · · · · · · · · · · · · · · · · · ·	
Please click a button, when you reflect a measurement result in User Param	ieter.
and the second se	
Result Writing	

This concludes the procedure to set up Easy FFT.

### **Related Parameters**

The following parameters are automatically adjusted or used as reference when you execute Easy FFT.

Do not change the settings of these parameters during execution of Easy FFT.

Parameter	Name	Automatic Changes
Pn408	Torque-Related Function Selections	Yes
Pn409	First Stage Notch Filter Frequency	Yes
Pn40A	First Stage Notch Filter Q Value	No
Pn40C	Second Stage Notch Filter Frequency	Yes
Pn40D	Second Stage Notch Filter Q Value	No
Pn456	Sweep Torque Reference Amplitude	No

Yes: The parameter is automatically set.

No: The parameter is not automatically set, but the setting is read during execution.

# Monitoring

9

This chapter provides information on monitoring SERVO-PACK product information and SERVOPACK status.

9.1	Monit	oring Product Information9-2
	9.1.1 9.1.2	Items That You Can Monitor    9-2      Operating Procedures    9-2
9.2	Monit	oring SERVOPACK Status9-3
	9.2.1 9.2.2 9.2.3	Servo Drive Status
9.3	Monitor	ing Machine Operation Status and Signal Waveforms9-6
	9.3.1 9.3.2 9.3.3	Items That You Can Monitor
9.4	Monit	oring Product Life
	9.4.1 9.4.2 9.4.3	Items That You Can Monitor9-13Operating Procedure9-14Preventative Maintenance9-15
9.5	Alarm	Tracing9-16
	9.5.1 9.5.2	Data for Which Alarm Tracing Is Performed 9-16Applicable Tools

9.1.1 Items That You Can Monitor

## 9.1 Monitoring Product Information

## 9.1.1 Items That You Can Monitor

Monitor Items					
Information on SERVOPACKs	<ul> <li>SERVOPACK model</li> <li>SERVOPACK software version</li> <li>SERVOPACK special specifications</li> <li>SERVOPACK serial number</li> <li>SERVOPACK manufacturing date</li> </ul>				
Information on Servomotors	<ul><li>Servomotor model</li><li>Servomotor serial number</li><li>Servomotor manufacturing date</li></ul>				
Information on Encoders	<ul> <li>Encoder model</li> <li>Rotary encoder resolution and linear encoder pitch resolution</li> <li>Encoder type</li> <li>Encoder software version</li> <li>Encoder serial number</li> <li>Encoder manufacturing date</li> </ul>				

## 9.1.2 Operating Procedures

Use the following procedure to display the product information monitor dialog box.

• Select *Monitor - Read Product Information* from the menu bar of the Main Window of the SigmaWin+.



• With the Digital Operator, you can use Fn011, Fn012, and Fn01E to monitor this information.
 Refer to the following manual for the differences in the monitor items compared with the

SigmaWin+.

Ω Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)

9.2.1 Servo Drive Status

## 9.2 Monitoring SERVOPACK Status

## 9.2.1 Servo Drive Status

Use the following procedure to display the Servo Drive status.

• Start the SigmaWin+. The Servo Drive status will be automatically displayed when you go online with a SERVOPACK.

1	001-9 -R90/	SGD7S A00A		÷		
	A		нв	в	P-OT	The Serve Drive statue is displayed
		POWER	EST	P	N-OT	The Servo Drive status is displayed.
						-

The Servomotor type is displayed.

## 9.2.2 Monitoring Status and Operations

Use the following procedure to display the Motion Monitor and Status Monitor for the SERVO-PACK.

• Select Monitor in the SigmaWin+ Menu Dialog Box.

<b>a</b>		YASK	AWA SigmaWin	+ Ver.7	- 5 ×
	Monitor				▲ 廿 ×
	Operation				- i
	Control I/F	V Item V	Unit	0001-5V2-	
0001-SV2 🜵 🔲		-		Axis A	
-02012 нвв р-от	POS SPO TRO COM	mon Mctor rotating speed	min-1	0	
POWER ESTP N-OT	Stol Com	imon Speed reference	min-1	0	
	POS 590 180 Com	mon Input reference pulse speed	min-1	0	
	POS SPO TRO Com	mon Position error amount	reference ur	0	
	POS SPO 110 Com	mon Accumulated load ratio	96	0	
	POS SPO TRO Com	mon Regenerative load ratio	%	0	
	POS SPO IRO COM	mon Power consumed by DB resi	%	0	
	Com	mon Current Alarm State	-	Normal	
	Status 1/O				
	Status				- <b>1</b>
	Control I/F	V Item V		0001-SV2-	<u>^</u>
				Axis A	
	POS SPO TEO COM	imon Dynamic Brake (DB)	ON(ALL)	ON	
	POS SPO TRO COM	mon Origin not Passed	-	OFF	
	PD5 Com	imon /COIN	-	OFF	E
	SPO Com	imon /V-CMP	-	OFF	
	P05 5P0 180 Com	imon /S-RDY	-	OFF	
	Com	imon /VLT	-	OFF	
	POS SPO TRO Com	mon Brake Interlock (/BK)	ON(ALL)	ON	
· · · · · · · · · · · · · · · · · · ·	POS SPO TRO COM	imon /WARN	-	OFF	· · · · · · · · · · · · · · · · · · ·
	Filter 😑 Hide 🚺	🛠 Standard 🛸 Clear			

### 9.2.2 Monitoring Status and Operations

## **Monitor Items**

The items that you can monitor on the Status Monitor Window and Motion Monitor Window are listed below.

Status Monitor Window

Monitor Items							
<ul> <li>Main Circuit         <ul> <li>Encoder (PGRDY)</li> <li>Motor Power (Request)</li> <li>Motor Power ON</li> <li>Dynamic Brake (DB)</li> <li>Rotation (Movement) Direction</li> <li>Mode Switch</li> <li>Speed Reference (V-Ref Torque Reference (T-Ref Position Reference (PULS)</li> <li>Position Reference Direction</li> <li>Surge Current Limiting Resistor Short Relay</li> <li>Regenerative Error Detection</li> <li>AC Power ON</li> <li>Overcurrent</li> <li>Origin Not Passed</li> </ul> </li> </ul>	Input Signal Status	<ul> <li>/S-ON (Servo ON Input Signal)</li> <li>/P-CON (Proportional Control Input Signal)</li> <li>P-OT (Forward Drive Prohibit Input Signal)</li> <li>N-OT (Reverse Drive Prohibit Input Signal)</li> <li>/P-CL (Forward External Torque Limit Signal)</li> <li>/P-CL (Reverse External Torque Limit Signal)</li> <li>/N-CL (Reverse External Torque Limit Signal)</li> <li>/ALM-RST (Alarm Reset Input Signal)</li> <li>SEN (Absolute Data Request Input Signal)</li> <li>/G-SEL (Gain Selection Input Signal)</li> <li>/P-DET (Polarity Detection Input Signal)</li> <li>/DEC (Origin Return Deceleration Switch Input Signal)</li> <li>/EXT1 (External Latch Input 1 Signal)</li> <li>/EXT2 (External Latch Input 3 Signal)</li> <li>/EXT3 (External Latch Input Signal)</li> </ul>	Output Signal Status	<ul> <li>ALM (Servo Alarm Output Signal)</li> <li>/COIN (Positioning Com- pletion Output Signal)</li> <li>/V-CMP (Speed Coinci- dence Detection Output Signal)</li> <li>/TGON (Rotation Detec- tion Output Signal)</li> <li>/S-RDY (Servo Ready Out- put Signal)</li> <li>/CLT (Torque Limit Detec- tion Output Signal)</li> <li>/VLT (Speed Limit Detec- tion Output Signal)</li> <li>/VLT (Speed Limit Detec- tion Output Signal)</li> <li>/WARN (Warning Output Signal)</li> <li>/NEAR (Near Output Sig- nal)</li> <li>/PM (Preventative Mainte- nance Output Signal)</li> </ul>			

### Motion Monitor Window

Monitor Items						
<ul> <li>Current Alarm State</li> <li>Motor Speed</li> <li>Speed Reference</li> <li>Internal Torque Reference</li> <li>Angle of Rotation 1 (number of encoder pulses from origin within one encoder rotation)</li> <li>Angle of Rotation 2 (angle from origin within one encoder rotation)</li> <li>Input Reference Pulse Speed</li> <li>Deviation Counter (Position Deviation)</li> <li>Cumulative Load</li> <li>Regenerative Load</li> </ul>	<ul> <li>Power Consumption</li> <li>Consumed Power</li> <li>Cumulative Power Consumption</li> <li>DB Resistor Consumption Power</li> <li>Absolute Encoder Multiturn Data</li> <li>Absolute Encoder Position within One Rotation</li> <li>Absolute Encoder (Lower)</li> <li>Absolute Encoder (Upper)</li> <li>Reference Pulse Counter</li> <li>Feedback Pulse Counter</li> <li>Total Operating Time</li> </ul>					

### 9.2.3 I/O Signal Monitor

## 9.2.3 I/O Signal Monitor

Use the following procedure to check I/O signals.

- 1. Click the <u>I</u> Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- 2. Select Wiring Check in the Menu Dialog Box. The Wiring Check Dialog Box will be displayed.
- 3. Click the Monitor Mode Button.

Wiring check AXIS#00			<b></b>
	Model SGD7W-2R8A20A	Monitor Mode	н
CN1-3 -		Forced Output Mode	<mark>Ф</mark> L0
CN1-4 -			H Forced Hi
CN1-5 -	H0 -		Forced Lo
0111.0			
	I		
CN1-7 -	HD   -		- CN1-23,24
CN1-8 -	<b>P</b> [ -		- CN1-25.26
CN1-9 -	B) [-		- CH1923,20
CN1-10 -	H) [ -	-	- CN1-27,28
CN1-11 -	Ð [ -	J-   😶 [	- CN1-29,30
CN1-12 -	B) [ -	· ·	- CN1-31,32
CN1-13 -			
		Hi Hi	ALM0 CN1-19,20
CN1-14 -			ALM1 UN1-21,22
Input sign	al status	Output signa	al status

Information

You can also use the above window to check wiring.

Checking Input Signal Wiring

- Change the signal status at the host controller. If the input signal status on the window changes accordingly, then the wiring is correct.
- Checking Output Signal Wiring Click the **Force Output Mode** Button. This will force the output signal status to change. If the signal status at the host controller changes accordingly, then the wiring is correct. You cannot use the **Force Output Mode** Button while the servo is ON.

9.3.1 Items That You Can Monitor

## 9.3 Monitoring Machine Operation Status and Signal Waveforms

To monitor waveforms, use the SigmaWin+ trace function or a measuring instrument, such as a memory recorder.

## 9.3.1 Items That You Can Monitor

You can use the SigmaWin+ or a measuring instrument to monitor the shaded items in the following block diagram.



### Linear Servomotors



## 9.3.2 Using the SigmaWin+

This section describes how to trace data and I/O with the SigmaWin+.

Refer to the following manual for detailed operating procedures for the SigmaWin+.

C AC Servo Drive Engineering Tool SigmaWin+ Operation Manual (Manual No.: SIET S800001 34)

## **Operating Procedure**

- 1. Click the <u>Servo</u> Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Trace in the Menu Dialog Box. The Trace Dialog Box will be displayed.



Click this button to display the Trace Setting Dialog Box shown below, and set the data to trace and the trace conditions.



## **Trace Objects**

You can trace the following items.

· Data Tracing

Trace Objects		
<ul> <li>Torque Reference</li> <li>Feedback Speed</li> <li>Reference Speed</li> <li>Position Reference Speed</li> <li>Position Error (Deviation)</li> <li>Position Amplifier Error (Deviation)</li> </ul>	<ul> <li>Speed Feedforward</li> <li>Torque Feedforward</li> <li>Effective (Active) Gain</li> <li>Main Circuit DC Voltage</li> <li>Control Mode</li> </ul>	

### • I/O Tracing

	Trace (	Objects	
Input Signals	<ul> <li>/S-ON (Servo ON Input Signal)</li> <li>/P-CON (Proportional Control Input Signal)</li> <li>P-OT (Forward Drive Prohibit Input Signal)</li> <li>N-OT (Reverse Drive Prohibit Input Signal)</li> <li>/ALM-RST (Alarm Reset Input Signal)</li> <li>/P-CL (Forward External Torque/Force Limit Input Signal)</li> <li>/N-CL (Reverse External Torque/Force Limit Input Signal)</li> <li>/G-SEL (Gain Selection Input Signal)</li> <li>/P-DET (Polarity Detection Input Signal)</li> <li>/DEC (Origin Return Deceleration Switch</li> </ul>	Output Signals	<ul> <li>ALM (Servo Alarm Output Signal)</li> <li>/COIN (Positioning Completion Output Signal)</li> <li>/V-CMP (Speed Coincidence Detection Output Signal)</li> <li>/TGON (Rotation Detection Output Sig- nal)</li> <li>/S-RDY (Servo Ready Output Signal)</li> <li>/CLT (Torque Limit Detection Output Sig- nal)</li> <li>/VLT (Speed Limit Detection Output Sig- nal)</li> <li>/WLT (Speed Limit Detection Output Sig- nal)</li> <li>/WARN (Warning Output Signal)</li> <li>/NEAR (Near Output Signal)</li> </ul>
	Input Signal) • /EXT1 (External Latch Input 1 Signal) • /EXT2 (External Latch Input 2 Signal) • /EXT3 (External Latch Input 3 Signal) • FSTP (Forced Stop Input Signal) • SEN (Absolute Data Request Input Signal)	Internal Status	<ul> <li>ACON (Main Circuit ON Signal)</li> <li>PDETCMP (Polarity Detection Completed Signal)</li> <li>DEN (Position Reference Distribution Completed Signal)</li> <li>PSET (Positioning Completion Output Signal)</li> <li>CMDRDY (Command Ready Signal)</li> </ul>

## 9.3.3 Using a Measuring Instrument

Connect a measuring instrument, such as a memory recorder, to the analog monitor connector (CN5) on the SERVOPACK to monitor analog signal waveforms. The measuring instrument is not provided by Yaskawa.

Refer to the following section for details on the connection. (37 4.7.3 Analog Monitor Connector (CN5) on page 4-39

## Setting the Monitor Object

Use Pn006 =  $n.X\square\square\square$  and Pn007 =  $n.X\square\square\square$  (Output Axis Selection) to set the axis to monitor.

Parameter		Description	When Enabled	Classification
Pn006 Pn007	n.0□□□ (default set- ting)	Output axis A data.	Immediately	Setup
	n.1000	Output axis B data.		

Use  $Pn006 = n.\square\squareXX$  and  $Pn007 = n.\square\squareXX$  (Analog Monitor 1 and 2 Signal Selections) to set the items to monitor.

Line Color	Signal	Parameter Setting
White	Analog monitor 1	Pn006 = n.□□XX
Red	Analog monitor 2	Pn007 = n.□□XX
Black (2 lines)	GND	_

Der		Description		
Para	ameter	Monitor Signal	Output Unit	Remarks
	n.□□00 (default setting of Pn007)	Motor Speed	<ul> <li>Rotary Servomotor: 1 V/1,000 min<sup>-1</sup></li> <li>Linear Servomotor: 1 V/1,000 mm/s</li> </ul>	-
	n.□□01	Speed Reference	<ul> <li>Rotary Servomotor:1 V/1,000 min<sup>-1</sup></li> <li>Linear Servomotor:1 V/1,000 mm/s</li> </ul>	_
	n.□□02 (default setting of Pn006)	Torque Reference	1 V/100% rated torque	-
	n.□□03	Position Deviation	0.05 V/Reference unit	0 V for speed or torque control
	n.□□04	Position Amplifier Devi- ation	0.05 V/encoder pulse unit	Position deviation after electronic gear conversion
D=000	n.□□05	Position Command Speed	<ul> <li>Rotary Servomotor:1 V/1,000 min<sup>-1</sup></li> <li>Linear Servomotor:1 V/1,000 mm/s</li> </ul>	-
or Pn007	n.□□06	Reserved parameter (Do not change.)	-	-
All Axes	n.□□07	Reserved parameter (Do not change.)	-	_
	n.□□08	Positioning Completion	Positioning completed: 5 V Positioning not completed: 0 V	Completion is indi- cated by the output voltage.
	n.□□09	Speed Feedforward	<ul> <li>Rotary Servomotor:1 V/1,000 min<sup>-1</sup></li> <li>Linear Servomotor:1 V/1,000 mm/s</li> </ul>	-
	n.□□0A	Torque Feedforward	1 V/100% rated torque	-
	n.□□0B	Active Gain*	1st gain: 1 V 2nd gain: 2 V	The gain that is active is indicated by the output voltage.
	n.□□0C	Completion of Position Reference Distribution	Distribution completed: 5 V Distribution not completed: 0 V	Completion is indi- cated by the output voltage.
	n.□□0D	Reserved parameter (Do not change.)	-	-
	n.🗆🗆10	Main Circuit DC Voltage	1 V/100 V (main circuit DC voltage)	-

\* Refer to the following section for details.

## Changing the Monitor Factor and Offset

You can change the monitor factors and offsets for the output voltages for analog monitor 1 and analog monitor 2. The relationships to the output voltages are as follows:

Analog monitor 1 $= (-1) \times (-1)$	Analog Monitor 1 Signal	Analog Monitor 1	Analog Monitor 1
	Selection (Pn006 = n.□□XX) <sup>×</sup>	Magnification (Pn552) <sup>+</sup>	Offset Voltage (Pn550)
Analog monitor 2 $= (-1) \times (-1) \times (-1)$	Analog Monitor 2 Signal ×	Analog Monitor 2 +	Analog Monitor 2
	Selection (Pn007 = n.□□XX)	Magnification (Pn553)	Offset Voltage (Pn551)

The following parameters are set.

D	Analog Monitor 1 Of	fset Voltage		Speed	osition Torque
	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
7 11 7 0000	-10,000 to 10,000	0.1 V	0	Immediately	Setup
Decc1	Analog Monitor 2 Offset Voltage Speed Position To				osition Torque
	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
7 11 7 0000	-10,000 to 10,000	0.1 V	0	Immediately Setup	
D=550	Analog Monitor 1 Magnification			Speed Po	osition Torque
	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
7 11 7 0000	-10,000 to 10,000	×0.01	100	Immediately	Setup
D=550	Analog Monitor 2 Magnification Speed Position Torc			osition Torque	
All Axes	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	-10,000 to 10,000	×0.01	100	Immediately	Setup

- Example
- Example for Setting the Item to Monitor to the Motor Speed (Pn006 = n.□□00) When Pn552 = 100 (Setting Unit:  $\times 0.01$ )

When Pn552 = 1,000 (Setting Unit: ×0.01)





## Adjusting the Analog Monitor Output

You can manually adjust the offset and gain for the analog monitor outputs for the torque reference monitor and motor speed monitor.

The offset is adjusted to compensate for offset in the zero point caused by output voltage drift or noise in the monitoring system.

The gain is adjusted to match the sensitivity of the measuring system.

The offset and gain are adjusted at the factory. You normally do not need to adjust them.



### ◆ Adjustment Example

An example of adjusting the output of the motor speed monitor is provided below.

Offset Adjustment		Gain Adjustment		
Analog monitor output	voltage t adjustment Motor speed	Analog monitor output voltage       1 [M]     Gain       adjustmen       1000 [min <sup>-1</sup> ]		
Item	Specification	Item	Specification	
Offset Adjustment Range	-2.4 V to 2.4 V	Gain Adjustment Range	100 ±50%	
Adjustment Unit	18.9 mV/LSB	Adjustment Unit	0.4%/LSB	
		<ul> <li>The gain adjustment range is made using a 100% of put value (gain adjustment of 0) as the reference valu with an adjustment range of 50% to 150%.</li> <li>A setting example is given below.</li> <li>Setting the Adjustment Value to -125 100 + (-125 × 0.4) = 50 [%] Therefore, the monitor output voltage goes to 50% of the original value.</li> <li>Setting the Adjustment Value to 125 100 + (125 × 0.4) = 150 [%] Therefore, the monitor output voltage goes to 150% of the original value.</li> </ul>		

Information • The adjustment values do not use parameters, so they will not change even if the parameter settings are initialized.

- Adjust the offset with the measuring instrument connected so that the analog monitor output value goes to zero. The following setting example achieves a zero output.
  - While power is not supplied to the Servomotor, set the monitor signal to the torque reference.
  - In speed control, set the monitor signal to the position deviation.

### Preparations

Always check the following before you adjust the analog monitor output.

• The parameters must not be write prohibited.

### ♦ Applicable Tools

You can use the following tools to adjust analog monitor outputs. The function that is used is given for each tool.

Offset Adjustment

Tool	Function	Operating Procedure Reference	
Digital Operator	Fn00C	Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)	
SigmaWin+	Setup - Analog Monitor Out- put Adjustment		

• Gain Adjustment

Tool	Function	Operating Procedure Reference	
Digital Operator	Fn00D	Ω Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)	
SigmaWin+	Setup - Analog Monitor Out- put Adjustment	Operating Procedure on page 9-12	

### Operating Procedure

Use the following procedure to adjust the analog monitor output.

- 1. Click the <u>I</u> Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Adjust the Analog Monitor Output in the Menu Dialog Box. The Adjust the Analog Monitor Output Dialog Box will be displayed.
- 3. Click the Zero Adjustment or Gain Adjustment Tab.

Search Adjust the Analog Monitor Output AXIS#00
Zero Adjustment Gain Adjustment
Channel CH1
0 offset +1 ᠿ↑
Monitor Signal Torque reference (1 V/100% rated to

**4.** While watching the analog monitor, use the +1 and -1 Buttons to adjust the offset. There are two channels: CH1 and CH2. If necessary, click the down arrow on the **Channel** Box and select the channel.

Search Adjust the Analog Monitor Output AXIS#00
Zero Adjustment Gain Adjustment
Analog Monitor Output Offset
Channel CH1
Monitor Signal Torque reference (1 V/100% rated to

This concludes adjusting the analog monitor output.

# 9.4 Monitoring Product Life

## 9.4.1 Items That You Can Monitor

Monitor Item	Description
SERVOPACK Installation Envi- ronment	<ul> <li>The operating status of the SERVOPACK in terms of the installation environment is displayed. Implement one or more of the following actions if the monitor value exceeds 100%.</li> <li>Lower the surrounding temperature.</li> <li>Decrease the load.</li> </ul>
Servomotor Installation Environ- ment	<ul> <li>The operating status of the SERVOPACK in terms of the installation environment is displayed. Implement one or more of the following actions if the monitor value exceeds 100%.</li> <li>Lower the surrounding temperature.</li> <li>Decrease the load.</li> </ul>
Built-in Fan Service Life Predic- tion	The unused status of the SERVOPACK is treated as the 100% value. The value decreases each time the main circuit power supply is turned ON and each time the servo is turned OFF. Use a monitor value of 0% as a guideline for the replacement period. Refer to the following section for part replacement guidelines.
Capacitor Service Life Predic- tion	The unused status of the SERVOPACK is treated as the 100% value. The value decreases each time the main circuit power supply is turned ON and each time the servo is turned OFF. Use a monitor value of 0% as a guideline for the replacement period. Refer to the following section for part replacement guidelines.
Surge Prevention Circuit Ser- vice Life Prediction	The unused status of the SERVOPACK is treated as the 100% value. The value decreases each time the main circuit power supply is turned ON and each time the servo is turned OFF. Use a monitor value of 0% as a guideline for the replacement period. Refer to the following section for part replacement guidelines.
Dynamic Brake Circuit Service Life Prediction	The unused status of the SERVOPACK is treated as the 100% value. The value decreases each time the main circuit power supply is turned ON and each time the servo is turned OFF. Use a monitor value of 0% as a guideline for the replacement period. Refer to the following section for part replacement guidelines.

9.4.2 Operating Procedure

## 9.4.2 Operating Procedure

Use the following procedure to display the installation environment and service life prediction monitor dialog boxes.

- 1. Click the <u>I</u> Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Life Monitor in the Menu Dialog Box. The Life Monitor Dialog Box will be displayed.

Information With the Digital Operator, you can use Un025 to Un02A to monitor this information.



A value of 100% indicates that the SERVOPACK has not yet been used. The percentage decreases as the SERVOPACK is used and reaches 0% when it is time to replace the SERVOPACK.

## 9.4.3 Preventative Maintenance

You can use the following functions for preventative maintenance.

- Preventative maintenance warnings
- /PM (Preventative Maintenance Output) signal

The SERVOPACK can notify the host controller when it is time to replace any of the main parts.

## **Preventative Maintenance Warning**

An A.9b0 warning (Preventative Maintenance Warning) is detected when any of the following service life prediction values drops to 10% or less: SERVOPACK built-in fan life, capacitor life, inrush current limiting circuit life, and dynamic brake circuit life. You can change the setting of  $PnO0F = n.\Box\Box\BoxX$  to enable or disable these warnings.

Parameter		Description	When Enabled	Classifi- cation
Pn00F	n.□□□0 (default setting)	Do not detect preventative maintenance warnings.	After	Setup
	n.0001	Detect preventative maintenance warnings.	restart	

## /PM (Preventative Maintenance Output) Signal

The /PM (Preventative Maintenance Output) signal is output when any of the following service life prediction values reaches 10% or less: SERVOPACK built-in fan life, capacitor life, inrush current limiting circuit life, and dynamic brake circuit life. The /PM (Preventative Maintenance Output) signal must be allocated.

Even if detection of preventive maintenance warnings is disabled (Pn00F =  $n.\Box\Box\Box$ ), the /PM signal will still be output as long as it is allocated.

Classifi- cation	Signal	Connector Pin No.	Signal Status	Description
Output	/PM	Must be allocated.	ON (closed)	One of the following service life prediction values reached 10% or less: SERVOPACK built-in fan life, capacitor life, inrush current limiting circuit life, and dynamic brake circuit life.
			OFF (open)	All of the following service life prediction values are greater than 10%: SERVOPACK built-in fan life, capacitor life, inrush current limiting circuit life, and dynamic brake circuit life.

Note: You must allocate the /PM signal to use it. The parameters that you use depend on the allocation method.

Allocation Method	Parameters to Use
Σ-7S-Compatible I/O Signal Allocations	<ul> <li>Pn50A = n.□□□1 (Σ-7S-Compatible I/O Signal Allocations)</li> <li>Pn514 = n.□X□□ (/PM (Preventative Maintenance Output) Signal Allocation)</li> </ul>
Multi-axis I/O signal alloca- tions	<ul> <li>Pn50A = n.□□□2 (Multi-Axis I/O Signal Allocations)</li> <li>Pn5BC (/PM (Preventative Maintenance Output) Signal Allocation)</li> </ul>

Refer to the following section for details.

(3 6.1.2 Output Signal Allocations on page 6-6

9.5.1 Data for Which Alarm Tracing Is Performed

#### **Alarm Tracing** 9.5

Alarm tracing records data in the SERVOPACK from before and after an alarm occurs. This data helps you to isolate the cause of the alarm.

You can display the data recorded in the SERVOPACK as a trace waveform on the SigmaWin+.

- Information
  Alarms that occur when the power supply is turned ON are not recorded.
  Alarms that occur during the recording of alarm trace data are not recorded.

  - Alarms that occur while utility functions are being executed are not recorded.

#### Data for Which Alarm Tracing Is Performed 9.5.1

Two types of data are recorded for alarm tracing: numeric data and I/O signal ON/OFF data.

ON/OFF Data
o ON command (/S-ON)
ortional control command (/P-CON)
ard torque command (/P-CL)
erse torque command (/N-CL)
EL1 signal (/G-SEL1)
Ν

#### Applicable Tools 9.5.2

The following table lists the tools that you can use to perform alarm tracing and the applicable tool functions.

Tool	Function Operating Procedure Reference		
Digital Operator	You cannot display alarm tracing data from the Digital Operator.		
SigmaWin+	Alarm - Alarm Tracing	☐ AC Servo Drive Engineering Tool SigmaWin+ Operation Manual (Manual No.: SIET S800001 34)	

# Maintenance

This chapter provides information on the meaning of, causes of, and corrections for alarms and warnings.

(10)

10.1	Inspe	ctions and Part Replacement 10-2
	10.1.1 10.1.2 10.1.3	Inspections10-2Guidelines for Part Replacement10-2Replacing the Battery10-3
10.2	Alarm	Displays
	10.2.1 10.2.2 10.2.3 10.2.4 10.2.5 10.2.6	List of Alarms10-5Troubleshooting Alarms10-10Resetting Alarms10-37Displaying the Alarm History10-37Clearing the Alarm History10-38Resetting Motor Type Alarms10-40
10.3	Warni	ng Displays
	10.3.1 10.3.2	List of Warnings
10.4	Monitori	ng Communications Data during Alarms or Warnings 10-50
10.5	Troublesh	ooting Based on the Operation and Conditions of the Servomotor10-51

10.1.1 Inspections

## **10.1 Inspections and Part Replacement**

This section describes inspections and part replacement for SERVOPACKs.

## 10.1.1 Inspections

Perform the inspections given in the following table at least once every year for the SERVO-PACK. Daily inspections are not required.

Item	Frequency	Inspection	Correction
Exterior	At least once a	Check for dust, dirt, and oil on the surfaces.	Clean with compressed air or a cloth.
Loose Screws	At least once a year	Check for loose terminal block and connector screws and for other loose parts.	Tighten any loose screws or other loose parts.

## 10.1.2 Guidelines for Part Replacement

The following electric or electronic parts are subject to mechanical wear or deterioration over time. Use one of the following methods to check the standard replacement period.

- Use the service life prediction function of the SERVOPACK. Refer to the following section for information on service life predictions.
   *I* 9.4 Monitoring Product Life on page 9-13
- Use the following table.

Part	Standard Replace- ment Period	Remarks
Cooling Fan	4 to 5 years	The standard replacement periods given on the left are for
Electrolytic Capacitor	10 years	<ul> <li>the following operating conditions.</li> <li>Surrounding air temperature: Annual average of 30°C</li> <li>Load factor: 80% max.</li> <li>Operation rate: 20 hours/day max.</li> </ul>
Relays	100,000 power ON operations	Power ON frequency: Once an hour
Battery	3 years without power supplied	Surrounding temperature without power supplied: 20°C

When any standard replacement period is close to expiring, contact your Yaskawa representative. After an examination of the part in question, we will determine whether the part should be replaced.



The parameters of any SERVOPACKs that are sent to Yaskawa for part replacement are reset to the factory settings before they are returned to you. Always keep a record of the parameter settings. And, always confirm that the parameters are properly set before starting operation.

## 10.1.3 Replacing the Battery

If the battery voltage drops to approximately 2.7 V or less, an A.830 alarm (Encoder Battery Alarm) or an A.930 warning (Absolute Encoder Battery Error) will be displayed.

If this alarm or warning is displayed, the battery must be replaced. Refer to the following section for the battery replacement procedure.

## **Battery Alarm/Warning Selection**

Whether to display an alarm or a warning is determined by the setting of  $Pn008 = n.\Box\Box\BoxX$  (Low Battery Voltage Alarm/Warning Selection).

Parameter		Meaning	When Enabled	Classification	
Pn008	n.□□□0 (default setting)	Output alarm (A.830) for low battery voltage.	After restart	Setup	
	n.0001	Output warning (A.930) for low battery voltage.	Ţ		

• Pn008 = n.□□□0

• The ALM (Servo Alarm) signal is output for up to five seconds when the control power supply is turned ON, and then the battery voltage is monitored for four seconds. No alarm will be displayed even if the battery voltage drops below the specified value after these four seconds.

• Pn008 = n.□□□1

The ALM (Servo Alarm) signal is output for up to five seconds when the control power supply is turned ON, and then the battery voltage is monitored continuously.



## **Battery Replacement Procedure**

- When Installing a Battery on the Host Controller
- 1. Turn ON only the control power supply to the SERVOPACK.
- 2. Remove the old battery and mount a new battery.
- **3.** Turn OFF the control power supply to the SERVOPACK to clear the A.830 alarm (Encoder Battery Alarm).
- 4. Turn ON the control power supply to the SERVOPACK again.
- 5. Make sure that the alarm has been cleared and that the SERVOPACK operates normally.

#### 10.1.3 Replacing the Battery

### When Using an Encoder Cable with a Battery Case

1. Turn ON only the control power supply to the SERVOPACK.



2. Open the cover of the Battery Case.



3. Remove the old Battery and mount a new Battery.



4. Close the cover of the Battery Case.



- **5.** Turn OFF the power supply to the SERVOPACK to clear the A.830 alarm (Encoder Battery Alarm).
- 6. Turn ON the power supply to the SERVOPACK.
- 7. Make sure that the alarm has been cleared and that the SERVOPACK operates normally.

## 10.2 Alarm Displays

If an error occurs in the SERVOPACK, an alarm number will be displayed on the panel display.

If there is an alarm, the display will change in the following order.

Example: Alarm A.E60

$$\overset{\text{Status}}{\leftarrow} \text{Indications} \longrightarrow \text{Not lit.} \longrightarrow \textbf{A}, \longrightarrow \text{Not lit.} \longrightarrow \textbf{E} \longrightarrow \text{Not lit.} \longrightarrow \textbf{B} \longrightarrow \text{Not lit.} \longrightarrow \textbf{D} \longrightarrow \text{Not lit.}$$

This section provides a list of the alarms that may occur and the causes of and corrections for those alarms.

## 10.2.1 List of Alarms

The list of alarms gives the alarm name, alarm meaning, alarm stopping method, and alarm reset possibility in order of the alarm numbers.

### Servomotor Stopping Method for Alarms

Refer to the following section for information on the stopping method for alarms. 5.13.2 Servomotor Stopping Method for Alarms on page 5-38

## Alarm Reset Possibility

Yes: You can use an alarm reset to clear the alarm. However, this assumes that the cause of the alarm has been removed.

No: You cannot clear the alarm.

## Alarms for Both Axes

If "All Axes" is given below the alarm number, the alarm applies to both axes. If an alarm occurs for one axis, the same alarm status will occur for the other axis.

## List of Alarms

Alarm Number	Alarm Name	Alarm Meaning	Servo- motor Stop- ping Method	Alarm Reset Possi- ble?
A.020	Parameter Checksum Error	There is an error in the parameter data in the SERVOPACK.	Gr.1	No
A.021 All Axes	Parameter Format Error	There is an error in the parameter data format in the SERVOPACK.	Gr.1	No
A.022 All Axes	System Checksum Error	There is an error in the parameter data in the SERVOPACK.	Gr.1	No
A.024	System Alarm	An internal program error occurred in the SER- VOPACK.	Gr.1	No
A.025	System Alarm	An internal program error occurred in the SER- VOPACK.	Gr.1	No
A.030 All Axes	Main Circuit Detector Error	There is an error in the detection data for the main circuit.	Gr.1	Yes
A.040	Parameter Setting Error	A parameter setting is outside of the setting range.	Gr.1	No

Continued on next page.

Servo-Alarm motor Alarm Reset Alarm Name Alarm Meaning Stop-Number Possiping ble? Method Parameter Combination The combination of some parameters exceeds A.042 Gr.1 No the setting range. Error There is an error in the bank members or bank A.04A Parameter Setting Error 2 Gr 1 No data settings. The capacities of the SERVOPACK and Servomo-A.050 **Combination Error** Gr.1 Yes tor do not match. Unsupported Device A.051 An unsupported device was connected. Gr.1 No Alarm The connected motor is a different type of motor Motor Type Change A.070 Gr 1 No Detected from the previously connected motor. Linear Encoder Pitch Set-The setting of Pn282 (Linear Encoder Scale Pitch) A.080 Gr.1 No has not been changed from the default setting. ting Error The SV\_ON (Servo ON) command was sent from Invalid Servo ON Comthe host controller after a utility function that turns A.0b0 Gr.1 Yes mand Alarm ON the Servomotor was executed. An overcurrent flowed through the power transis-A.100 **Overcurrent Detected** Gr.1 No tor or the heat sink overheated. Motor Overcurrent The current to the motor exceeded the allowable A.101 Gr.1 No Detected current. A.300 Gr.1 **Regeneration Error** There is an error related to regeneration. Yes All Axes A.320 **Regenerative Overload** A regenerative overload occurred. Gr.2 Yes All Axes The AC power supply input setting or DC power A.330 Main Circuit Power Supply supply input setting is not correct. Gr.1 Yes All Axes Wiring Error • The power supply wiring is not correct. A.400 Overvoltage The main circuit DC voltage is too high. Gr.1 Yes All Axes A.410 Undervoltage The main circuit DC voltage is too low. Gr.2 Yes All Axes A.510 Overspeed The motor exceeded the maximum speed. Gr.1 Yes Abnormal oscillation was detected in the motor A.520 Vibration Alarm Gr.1 Yes speed. Vibration was detected during autotuning for the A.521 Gr.1 Autotuning Alarm Yes tuning-less function. Maximum Speed Setting The setting of Pn385 (Maximum Motor Speed) is A.550 Gr.1 Yes Error greater than the maximum motor speed. The Servomotor was operating for several sec-A.710 Instantaneous Overload onds to several tens of seconds under a torque Gr 2 Yes that largely exceeded the rating The Servomotor was operating continuously A.720 Continuous Overload Gr.1 Yes under a torque that exceeded the rating. When the dynamic brake was applied, the rota-A.730 Dynamic Brake Overload tional or linear kinetic energy exceeded the Gr.1 Yes A.731 capacity of the dynamic brake resistor. A.740 Inrush Current Limiting The main circuit power supply was frequently Gr.1 Yes All Axes **Resistor Overload** turned ON and OFF. Internal Temperature Error A.7A1 The surrounding temperature of the control PCB 1 (Control Board Tempera-Gr.2 Yes All Axes is abnormal. ture Error) Internal Temperature Error A.7A2 The surrounding temperature of the power PCB 2 (Power Board Tempera-Gr 2 Yes All Axes is abnormal. ture Error)

Continued on next page.

Continued from previous page.

### Continued from previous page.

Alarm Number	Alarm Name	Alarm Meaning	Servo- motor Stop- ping Method	Alarm Reset Possi- ble?
A.7A3	Internal Temperature Sen- sor Error	An error occurred in the temperature sensor cir- cuit.	Gr.2	No
A.7Ab All Axes	SERVOPACK Built-in Fan Stopped	The fan inside the SERVOPACK stopped.	Gr.1	Yes
A.810	Encoder Backup Alarm	The power supplies to the encoder all failed and the position data was lost.	Gr.1	No
A.820	Encoder Checksum Alarm	There is an error in the checksum results for encoder memory.	Gr.1	No
A.830	Encoder Battery Alarm	The battery voltage was lower than the specified level after the control power supply was turned ON.	Gr.1	Yes
A.840	Encoder Data Alarm	There is an internal data error in the encoder.	Gr.1	No
A.850	Encoder Overspeed	The encoder was operating at high speed when the power was turned ON.	Gr.1	No
A.860	Encoder Overheated	The internal temperature of encoder is too high.	Gr.1	No
A.861	Motor Overheated	The internal temperature of motor is too high.	Gr.1	No
A.890	Encoder Scale Error	A failure occurred in the linear encoder.	Gr.1	No
A.891	Encoder Module Error	An error occurred in the linear encoder.	Gr.1	No
A.b33	Current Detection Error 3	An error occurred in the current detection circuit.	Gr.1	No
A.b6A	MECHATROLINK Commu- nications ASIC Error 1	ASIC error 1 occurred in MECHATROLINK com- munications.	Gr.1	No
A.b6b	MECHATROLINK Commu- nications ASIC Error 2	ASIC error 2 occurred in MECHATROLINK com- munications.	Gr.2	No
A.bF0 All Axes	System Alarm 0	Internal program error 0 occurred in the SERVO- PACK.	Gr.1	No
A.bF1 All Axes	System Alarm 1	Internal program error 1 occurred in the SERVO- PACK.	Gr.1	No
A.bF2 All Axes	System Alarm 2	Internal program error 2 occurred in the SERVO- PACK.	Gr.1	No
A.bF3 All Axes	System Alarm 3	Internal program error 3 occurred in the SERVO- PACK.	Gr.1	No
A.bF4 All Axes	System Alarm 4	Internal program error 4 occurred in the SERVO- PACK.	Gr.1	No
A.bF5 All Axes	System Alarm 5	Internal program error 5 occurred in the SERVO- PACK.	Gr.1	No
A.bF6 All Axes	System Alarm 6	Internal program error 6 occurred in the SERVO- PACK.	Gr.1	No
A.bF7 All Axes	System Alarm 7	Internal program error 7 occurred in the SERVO- PACK.	Gr.1	No
A.bF8 All Axes	System Alarm 8	Internal program error 8 occurred in the SERVO- PACK.	Gr.1	No
A.C10	Servomotor Out of Control	The Servomotor ran out of control.	Gr.1	Yes
A.C20	Phase Detection Error	The detection of the phase is not correct.	Gr.1	No
A.C21	Polarity Sensor Error	An error occurred in the polarity sensor.	Gr.1	No
A.C22	Phase Information Dis- agreement	The phase information does not match.	Gr.1	No
A.C50	Polarity Detection Failure	The polarity detection failed.	Gr.1	No
A.C51	Overtravel Detected during Polarity Detection	The overtravel signal was detected during polarity detection.	Gr.1	Yes
A.C52	Polarity Detection Not Completed	The servo was turned ON before the polarity was detected.	Gr.1	Yes

Maintenance

10

Servo-Alarm motor Alarm Reset Alarm Name Alarm Meaning Stop-Number Possiping ble? Method Out of Range of Motion for The travel distance exceeded the setting of A.C53 Gr.1 No Pn48E (Polarity Detection Range). **Polarity Detection** Polarity Detection Failure A.C54 The polarity detection failed. Gr.1 No 2 Encoder Clear Error or The multiturn data for the absolute encoder was A.C80 Multiturn Limit Setting Gr.1 No not correctly cleared or set. Error **Encoder Communications** Communications between the encoder and SER-A.C90 Gr.1 No Error VOPACK is not possible. **Encoder Communications** An error occurred in calculating the position data Position Data Acceleration A.C91 Gr.1 No of the encoder. Rate Error Encoder Communications An error occurred in the communications timer A.C92 Gr.1 No Timer Error between the encoder and SERVOPACK. A.CA0 Encoder Parameter Error The parameters in the encoder are corrupted. Gr.1 No The contents of communications with the A.Cb0 Encoder Echoback Error Gr.1 No encoder are incorrect. Multiturn Limit Disagree-Different multiturn limits have been set in the A.CC0 Gr.1 No encoder and the SERVOPACK. ment The setting of Pn520 (Position Deviation Overflow Position Deviation Over-A.d00 Alarm Level) was exceeded by the position devia-Gr.1 Yes flow tion while the servo was ON. The servo was turned ON after the position devi-Position Deviation Overation exceeded the setting of Pn526 (Position A.d01 Gr.1 Yes Deviation Overflow Alarm Level at Servo ON) flow Alarm at Servo ON while the servo was OFF. If position deviation remains in the deviation counter, the setting of Pn529 or Pn584 (Speed Position Deviation Over-Limit Level at Servo ON) limits the speed when A.d02 flow Alarm for Speed Limit the servo is turned ON. This alarm occurs if a Gr.2 Yes position reference is input and the setting of at Servo ON Pn520 (Position Deviation Overflow Alarm Level) is exceeded before the limit is cleared. The position feedback data exceeded Position Data Overflow A.d30 Gr.1 No ±1,879,048,192. A synchronization error occurred during MECHA-A.E02 MECHATROLINK Internal TROLINK communications with the SERVO-Yes Gr.1 All Axes Synchronization Error 1 PACK. **MECHATROLINK Trans-**A.E40 The setting of the MECHATROLINK communicamission Cycle Setting Gr.2 Yes All Axes tions transmission cycle is not correct. Error MECHATROLINK Commu-A.E41 The setting of the MECHATROLINK communicanications Data Size Set-Gr 2 Yes All Axes tions data size is not correct. ting Error A.E42 **MECHATROLINK Station** The setting of the MECHATROLINK station Gr.2 No address is not correct. All Axes Address Setting Error MECHATROLINK Syn-A synchronization error occurred during MECHA-A.E50\* Gr.2 Yes chronization Error TROLINK communications. A.E51 **MECHATROLINK Syn-**Synchronization failed during MECHATROLINK Gr.2 Yes All Axes communications. chronization Failed Reception Error in Communications errors occurred continuously A.E60\* MECHATROLINK Commu-Gr 2 Yes during MECHATROLINK communications. nications

Continued from previous page.

### Continued from previous page.

Alarm Number	Alarm Name	Alarm Meaning	Servo- motor Stop- ping Method	Alarm Reset Possi- ble?
A.E61 All Axes	Synchronization Interval Error in MECHATROLINK Transmission Cycle	An error occurred in the transmission cycle during MECHATROLINK communications.	Gr.2	Yes
A.E63 All Axes	MECHATROLINK Syn- chronization Frame Not Received	Synchronization frames were continuously not received during MECHATROLINK communica- tions.	Gr.2	Yes
A.Ed1	Command Execution Tim- eout	A timeout error occurred for a MECHATROLINK command.	Gr.2	Yes
A.F10 All Axes	Power Supply Line Open Phase	The voltage was low for more than one second for phase R, S, or T when the main power supply was ON.	Gr.2	Yes
A.F50	Servomotor Main Circuit Cable Disconnection	The Servomotor did not operate or power was not supplied to the Servomotor even though the SV_ON (Servo ON) command was input when the Servomotor was ready to receive it.	Gr.1	Yes
FL-1*           All Axes           FL-2*           All Axes           FL-3*           All Axes           FL-4*           All Axes           FL-5*           All Axes           FL-6*           All Axes	System Alarm	An internal program error occurred in the SER- VOPACK.	_	No
CPF00 All Axes CPF01 All Axes	Digital Operator Commu- nications Error 1 Digital Operator Commu- nications Error 2	Communications were not possible between the Digital Operator (model: JUSP-OP05A-1-E) and the SERVOPACK (e.g., a CPU error occurred).	_	No

\* These alarms are not stored in the alarm history. They are only displayed on the panel display.

## 10.2.2 Troubleshooting Alarms

The causes of and corrections for the alarms are given in the following table. Contact your Yaskawa representative if you cannot solve a problem with the correction given in the table.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
	The power supply voltage suddenly dropped.	Measure the power supply voltage.	Set the power supply volt- age within the specified range, and initialize the parameter settings.	page 5-9
	The power supply was shut OFF while writing parameter set- tings.	Check the timing of shutting OFF the power supply.	Initialize the parameter settings and then set the parameters again.	
<b>A.020:</b> Parameter	The number of times that parameters were written exceeded the limit.	Check to see if the parameters were fre- quently changed from the host controller.	The SERVOPACK may be faulty. Replace the SER- VOPACK. Reconsider the method for writing the parame- ters.	-
Checksum Error (There is an error in the parameter data in the SER- VOPACK.)	A malfunction was caused by noise from the AC power supply, ground, static elec- tricity, or other source.	Turn the power supply to the SERVOPACK OFF and ON again. If the alarm still occurs, noise may be the cause.	Implement countermea- sures against noise.	page 4-5
	Gas, water drops, or cutting oil entered the SERVOPACK and caused failure of the internal components.	Check the installation conditions.	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-
	A failure occurred in the SERVOPACK.	Turn the power supply to the SERVOPACK OFF and ON again. If the alarm still occurs, the SERVOPACK may have failed.	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-
A.021: Parameter For- mat Error (There is an error in the parameter	The software version of the SERVOPACK that caused the alarm is older than the soft- ware version of the parameters specified to write.	Read the product infor- mation to see if the soft- ware versions are the same. If they are differ- ent, it could be the cause of the alarm.	Write the parameters from another SERVOPACK with the same model and the same software version, and then turn the power OFF and ON again.	page 9-2
SERVOPACK.)	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-
	The power supply voltage suddenly dropped.	Measure the power supply voltage.	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-
A.022: System Check- sum Error (There is an error	The power supply was shut OFF while setting a utility func- tion.	Check the timing of shutting OFF the power supply.	The SERVOPACK may be faulty. Replace the SER- VOPACK.	_
in the parameter data in the SER- VOPACK.)	A failure occurred in the SERVOPACK.	Turn the power supply to the SERVOPACK OFF and ON again. If the alarm still occurs, the SERVOPACK may have failed.	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-

Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
A.024: System Alarm (An internal pro- gram error occurred in the SERVOPACK.)	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-
A.025: System Alarm (An internal pro- gram error occurred in the SERVOPACK.)	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-
A.030: Main Circuit Detector Error	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-
	The SERVOPACK and Servomotor capaci- ties do not match each other.	Check the combination of the SERVOPACK and Servomotor capacities.	Select a proper combina- tion of SERVOPACK and Servomotor capacities.	page 1-8
	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-
A.040:	A parameter setting is outside of the setting range.	Check the setting ranges of the parame- ters that have been changed.	Set the parameters to values within the setting ranges.	-
Parameter Set- ting Error (A parameter set- ting is outside of the setting range.)	The electronic gear ratio is outside of the setting range.	Check the electronic gear ratio. The ratio must be within the fol- lowing range: 0.001 < (Pn20E/Pn210) < 64,000.	Set the electronic gear ratio in the following range: 0.001 < (Pn20E/ Pn210) < 64,000.	page 5-43
	A pin number that does not exist on the SERVOPACK was allocated in Pn590 to Pn5BC. (An alarm will not occur, however, if the signal is disabled.)	For input signals (Pn590 to Pn599), make sure that the allocated pin numbers are between 003 and 014. For output signals (Pn5B0 to Pn5BC), make sure that the allo- cated pin numbers are between 023 and 031.	Allocate pins that actually exist in Pn590 to Pn5BC.	page 6-4, page 6-8

Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
	The speed of program jogging went below the setting range when the electronic gear ratio (Pn20E/ Pn210) or the Servo- motor was changed.	Check to see if the detection conditions <sup>*1</sup> are satisfied.	Decrease the setting of the electronic gear ratio (Pn20E/Pn210).	page 5-43
A.042: Parameter Com- bination Error	The speed of program jogging went below the setting range when Pn533 or Pn585 (Program Jogging Movement Speed) was changed.	Check to see if the detection conditions <sup>*1</sup> are satisfied.	Increase the setting of Pn533 or Pn585.	page 7-14
	The movement speed of advanced autotun- ing went below the setting range when the electronic gear ratio (Pn20E/ Pn210) or the Servomotor was changed.	Check to see if the detection conditions <sup>*2</sup> are satisfied.	Decrease the setting of the electronic gear ratio (Pn20E/Pn210).	page 5-43
A.04A: Parameter Set-	For 4-byte parameter bank members, there are two consecutive members with nothing registered.	-	Change the number of bytes for bank members to an appropriate value.	-
ting Error 2	The total amount of bank data exceeds 64 (Pn900 × Pn901 > 64).	-	Reduce the total amount of bank data to 64 or less.	-
A.050: Combination Error (The capacities of the SERVOPACK and Servomotor do not match.)	The SERVOPACK and Servomotor capaci- ties do not match each other. A failure occurred in the encoder.	Check the capacities to see if they satisfy the following condition: 1/4 ≤ Servomotor capacity SERVOPACK capacity ≤ 4 However, the above for- mula does not apply to the following products. • SGD7W-2R8A SER- VOPACK and SGM7J- A5A Servomotor • SGD7W-2R8A SER- VOPACK and SGM7A-A5A Servomotor Replace the encoder and check to see if the alarm still occurs.	Select a proper combina- tion of the SERVOPACK and Servomotor capaci- ties. Replace the Servomotor or encoder.	page 1-8 -
	A failure occurred in the SERVOPACK.	_	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-

Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
A.051: Unsupported	The motor parameter file was not written to the linear encoder. (This applies only when not using a Serial Converter Unit.)	Check to see if the motor parameter file was written to the lin- ear encoder.	Write the motor parame- ter file to the linear encoder.	page 5-18
	An unsupported Serial Converter Unit or encoder is connected to the SERVOPACK.	Check the product combination specifica-tions.	Change to a correct com- bination of models.	-
A.070: Motor Type Change Detected (The connected	A Rotary Servomotor was removed and a Linear Servomotor was connected.	-	Set the parameters for a Linear Servomotor and reset the motor type alarm. Then, turn the power supply to the SER- VOPACK OFF and ON again.	page 10-40
front type of motor from the previ- ously connected motor.)	A Linear Servomotor was removed and a Rotary Servomotor was connected.	-	Set the parameters for a Rotary Servomotor and reset the motor type alarm. Then, turn the power supply to the SER- VOPACK OFF and ON again.	page 10-40
A.080: Linear Encoder Pitch Setting Error	The setting of Pn282 (Linear Encoder Scale Pitch) has not been changed from the default setting.	Check the setting of Pn282.	Correct the setting of Pn282.	page 5-17
<b>A.0b0:</b> Invalid Servo ON Command Alarm	The SV_ON (Servo ON) command was sent from the host controller after a util- ity function that turns ON the Servomotor was executed.	-	Turn the power supply to the SERVOPACK OFF and ON again. Or, execute a software reset.	page 6-34
	The Main Circuit Cable is not wired correctly or there is faulty contact.	Check the wiring.	Correct the wiring.	
A.100: Overcurrent	There is a short-circuit or ground fault in a Main Circuit Cable.	Check for short-circuits across Servomotor phases U, V, and W, or between the ground and Servomotor phases U, V, and W.	The cable may be short- circuited. Replace the cable.	
(An overcurrent flowed through the power tran- sistor or the heat sink overheated.)	There is a short-circuit or ground fault inside the Servomotor.	Check for short-circuits across Servomotor phases U, V, and W, or between the ground and Servomotor phases U, V, or W.	The Servomotor may be faulty. Replace the Servo- motor.	page 4-19
	There is a short-circuit or ground fault inside the SERVOPACK.	Check for short-circuits across the Servomotor connection terminals U, V, and W on the SER- VOPACK, or between the ground and termi- nals U, V, or W.	The SERVOPACK may be faulty. Replace the SER- VOPACK.	

Continued on next page.

Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
	The regenerative resistor is not wired correctly or there is faulty contact.	Check the wiring.	Correct the wiring.	page 4-16
	The dynamic brake (DB, emergency stop executed from the SERVOPACK) was frequently activated, or a DB overload alarm occurred.	Check the power con- sumed by the DB resis- tor to see how frequently the DB is being used. Or, check the alarm display to see if a DB overload alarm (A.730 or A.731) has occurred.	Change the SERVOPACK model, operating meth- ods, or the mechanisms so that the dynamic brake does not need to be used so frequently.	-
A.100:	The regenerative pro- cessing capacity was exceeded.	Check the regenerative load ratio in the Sig- maWin+ Motion Monitor Tab Page to see how frequently the regenera- tive resistor is being used.	Recheck the operating conditions and load.	*2
Overcurrent Detected (An overcurrent flowed through the power tran- sistor or the heat sink overheated.)	The SERVOPACK regenerative resis- tance is too small.	Check the regenerative load ratio in the Sig- maWin+ Motion Monitor Tab Page to see how frequently the regenera- tive resistor is being used.	Change the regenerative resistance to a value larger than the SERVO- PACK minimum allowable resistance.	*3
	A heavy load was applied while the Ser- vomotor was stopped or running at a low speed.Check to see if the operating conditions exceed Servo Drive specifications.A malfunction was caused by noise.Improve the noise env ronment, e.g. by improving the wiring o installation conditions, and check to see if the alarm still occurs.	Check to see if the operating conditions exceed Servo Drive specifications.	Reduce the load applied to the Servomotor. Or, increase the operating speed.	-
		Improve the noise envi- ronment, e.g. by improving the wiring or installation conditions, and check to see if the alarm still occurs.	Implement countermea- sures against noise, such as correct wiring of the FG. Use an FG wire size equivalent to the SERVO- PACK's main circuit wire size.	-
	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-

Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
	The Main Circuit Cable is not wired correctly or there is faulty contact.	Check the wiring.	Correct the wiring.	page 4-19
	There is a short-circuit or ground fault in a Main Circuit Cable.	Check for short-circuits across cable phases U, V, and W, or between the ground and cable phases U, V, and W.	The cable may be short- circuited. Replace the cable.	
	There is a short-circuit or ground fault inside the Servomotor.	Check for short-circuits across Servomotor phases U, V, and W, or between the ground and Servomotor phases U, V, or W.	The Servomotor may be faulty. Replace the Servo- motor.	
A.101: Motor Overcur- rent Detected (The current to the motor exceeded the	There is a short-circuit or ground fault inside the SERVOPACK.	Check for short-circuits across the Servomotor connection terminals U, V, and W on the SER- VOPACK, or between the ground and termi- nals U, V, or W.	The SERVOPACK may be faulty. Replace the SER- VOPACK.	
allowable cur- rent.)	A heavy load was applied while the Ser- vomotor was stopped or running at a low speed.	Check to see if the operating conditions exceed Servo Drive specifications.	Reduce the load applied to the Servomotor. Or, increase the operating speed.	-
	A malfunction was caused by noise.	Improve the noise envi- ronment, e.g. by improving the wiring or installation conditions, and check to see if the alarm still occurs.	Implement countermea- sures against noise, such as correct wiring of the FG. Use an FG wire size equivalent to the SERVO- PACK's main circuit wire size.	-
	A failure occurred in the SERVOPACK.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
	The jumper between the regenerative resis- tor terminals (B2 and B3) was removed.	Check to see if the jumper is connected between power supply terminals B2 and B3.	Correctly connect a jumper.	
A.300:	The External Regener- ative Resistor is not wired correctly, or was removed or discon- nected.	Check the wiring of the External Regenerative Resistor.	Correct the wiring of the External Regenerative Resistor.	page 4-16
Error	A failure occurred in the SERVOPACK.	_	While the main circuit power supply is OFF, turn the control power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVO- PACK may be faulty. Replace the SERVO- PACK.	-

Continued on next page.

Maintenance

Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
	The power supply voltage exceeded the specified range.	Measure the power supply voltage.	Set the power supply volt- age within the specified range.	-
	The external regener- ative resistance value or regenerative resis- tor capacity is too small, or there has been a continuous regeneration state.	Check the operating conditions or the capacity using the Sig- maJunmaSize+ Capac- ity Selection Software or other means.	Change the regenerative resistance value or capac- ity. Reconsider the operating conditions using the Sig- maJunmaSize+ Capacity Selection Software or other means.	*3
	There was a continu- ous regeneration state because a negative load was continu- ously applied.	Check the load applied to the Servomotor during operation.	Reconsider the system including the servo, machine, and operating conditions.	-
A.320: Regenerative Overload	The setting of Pn600 (Regenerative Resis- tor Capacity) is smaller than the capacity of the Exter- nal Regenerative Resistor.	Check it see if a Regen- erative Resistor is con- nected and check the setting of Pn600.	Correct the setting of Pn600.	page 5-52
	The setting of Pn603 (Regenerative Resis- tance) is smaller than the capacity of the External Regenerative Resistor.	Check to see if a Regenerative Resistor is connected and check the setting of Pn603.	Correct the setting of Pn603.	page 5-52
	The external regener- ative resistance is too high.	Check the regenerative resistance.	Change the regenerative resistance to a correct value or use an External Regenerative Resistor of an appropriate capacity.	*3
	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SER- VOPACK.	_
A.330:	The regenerative resistor was discon- nected when the SERVOPACK power supply voltage was high.	Measure the resistance of the regenerative resistor using a measur- ing instrument.	If you are using the regen- erative resistor built into the SERVOPACK, replace the SERVOPACK. If you are using an Exter- nal Regenerative Resis- tor, replace the External Regenerative Resistor.	-
Main Circuit Power Supply Wiring Error (Detected when the main circuit	DC power was sup- plied when an AC power supply input was specified in the settings.	Check the power sup- ply to see if it is a DC power supply.	Correct the power supply setting to match the actual power supply.	nora 5 12
turned ON.)	AC power was sup- plied when a DC power supply input was specified in the settings.	Check the power sup- ply to see if it is an AC power supply.	Correct the power supply setting to match the actual power supply.	paye 5-15
	A failure occurred in the SERVOPACK.	_	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-
Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
	The power supply voltage exceeded the specified range.	Measure the power supply voltage.	Set the AC/DC power supply voltage within the specified range.	-
	The power supply is not stable or was influenced by a light- ning surge.	Measure the power supply voltage.	Improve the power sup- ply conditions, install a surge absorber, and then turn the power supply OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SER- VOPACK.	-
A.400: Overvoltage (Detected in the	The voltage for AC power supply was too high during accelera- tion or deceleration.	Check the power sup- ply voltage and the speed and torque during operation.	Set the AC power supply voltage within the speci- fied range.	-
main circuit power supply section of the SERVOPACK.)	The external regener- ative resistance is too high for the operating conditions.	Check the operating conditions and the regenerative resistance.	Select a regenerative resistance value that is appropriate for the oper- ating conditions and load.	*3
	The moment of inertia ratio or mass ratio exceeded the allow-able value.	Check to see if the moment of inertia ratio or mass ratio is within the allowable range.	Increase the deceleration time, or reduce the load.	-
	A failure occurred in the SERVOPACK.	_	While the main circuit power supply is OFF, turn the control power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVO- PACK may be faulty. Replace the SERVO- PACK.	-
	The power supply voltage went below the specified range.	Measure the power supply voltage.	Set the power supply volt- age within the specified range.	-
	The power supply voltage dropped during operation.	Measure the power supply voltage.	Increase the power supply capacity.	-
A.410: Undervoltage (Detected in the main circuit power supply section of the SERVOPACK.)	A momentary power interruption occurred.	Measure the power supply voltage.	If you have changed the setting of Pn509 (Momen- tary Power Interruption Hold Time), decrease the setting.	page 6-17
	The SERVOPACK fuse is blown out.	_	Replace the SERVO- PACK and connect a reactor to the DC reactor terminals ( $\ominus$ 1 and $\ominus$ 2) on the SERVOPACK.	-
	A failure occurred in the SERVOPACK.	_	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-

Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
<b>A.510:</b> Overspeed	The order of phases U, V, and W in the motor wiring is not correct.	Check the wiring of the Servomotor.	Make sure that the Servo- motor is correctly wired.	-
	A reference value that exceeded the over- speed detection level was input.	Check the input refer- ence.	Reduce the reference value. Or, adjust the gain.	
exceeded the maximum speed.)	The motor exceeded the maximum speed.	Check the waveform of the motor speed.	Reduce the speed refer- ence input gain and adjust the servo gain. Or, reconsider the operating conditions.	_
	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-
	Abnormal oscillation was detected in the motor speed.	Check for abnormal motor noise, and check the speed and torque waveforms during oper- ation.	Reduce the motor speed. Or, reduce the setting of Pn100 (Speed Loop Gain).	page 8-79
<b>A.520:</b> Vibration Alarm	The setting of Pn103 (Moment of Inertia Ratio) is greater than the actual moment of inertia or was greatly changed.	Check the moment of inertia ratio or mass ratio.	Set Pn103 (Moment of Inertia Ratio) to an appro- priate value.	page 8-16
	The vibration detec- tion level (Pn312 or Pn384) is not suitable.	Check that the vibra- tion detection level (Pn312 or Pn384) is suitable.	Set a suitable vibration detection level (Pn312 or Pn384).	page 6-37
A.521: Autotuning Alarm (Vibration was detected while executing the custom tuning, Easy FFT, or the tuning-less func- tion.)	The Servomotor vibrated considerably while performing the tuning-less function.	Check the waveform of the motor speed.	Reduce the load so that the moment of inertia ratio is within the allowable value. Or increase the load level or reduce the rigidity level in the tuning- less level settings.	page 8-13
	The Servomotor vibrated considerably while performing cus- tom tuning or Easy FFT.	Check the waveform of the motor speed.	Check the operating pro- cedure of corresponding function and implement corrections.	page 8-42, page 8-95
A.550: Maximum Speed Setting Error	The setting of Pn385 (Maximum Motor Speed) is greater than the maximum speed.	Check the setting of Pn385, and the upper limits of the maximum motor speed setting and the encoder output resolution setting.	Set Pn385 to a value that does not exceed the max- imum motor speed.	page 6-20

Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
	The wiring is not cor- rect or there is a faulty contact in the motor or encoder wiring.	Check the wiring.	Make sure that the Servo- motor and encoder are correctly wired.	page 4-19
	Operation was per- formed that exceeded the overload protec- tion characteristics.	Check the motor over- load characteristics and Run command.	Reconsider the load and operating conditions. Or, increase the motor capacity.	-
A.710: Instantaneous Overload A.720:	An excessive load was applied during operation because the Servomotor was not driven due to mechanical problems.	Check the operation reference and motor speed.	Correct the mechanical problem.	-
Continuous Overload	There is an error in the setting of Pn282 (Lin- ear Encoder Scale Pitch).	Check the setting of Pn282.	Correct the setting of Pn282.	page 5-17
	There is an error in the setting of Pn080 = $n.\Box\Box X\Box$ (Motor Phase Sequence Selection).	Check the setting of Pn080 = $n.\Box\Box X\Box$ .	Set Pn080 = n.□□X□ to an appropriate value.	page 5-23
	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SER- VOPACK.	_
A.730 and A.731: Dynamic Brake Overload (An excessive power consump- tion by the dynamic brake was detected.)	The Servomotor was rotated by an external force.	Check the operation status.	Implement measures to ensure that the motor will not be rotated by an external force.	-
	When the Servomo- tor was stopped with the dynamic brake, the rotational or linear kinetic energy exceeded the capac- ity of the dynamic brake resistor.	Check the power con- sumed by the DB resis- tor to see how frequently the DB is being used.	<ul> <li>Reconsider the following:</li> <li>Reduce the Servomotor command speed.</li> <li>Decrease the moment of inertia ratio or mass ratio.</li> <li>Reduce the frequency of stopping with the dynamic brake.</li> </ul>	-
	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-
A.740: Inrush Current Limiting Resistor Overload (The main circuit power supply was frequently turned ON and OFF.)	The allowable fre- quency of the inrush current limiting resis- tor was exceeded when the main circuit power supply was turned ON and OFF.	_	Reduce the frequency of turning the main circuit power supply ON and OFF.	_
	A failure occurred in the SERVOPACK.	_	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-

Continued on next page.

Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
<b>A.7A1:</b> Internal Tempera- ture Error 1 (Control Board Temperature Error)	The surrounding tem- perature is too high.	Check the surrounding temperature using a thermostat. Or, check the operating status with the SERVOPACK installation environment monitor.	Decrease the surround- ing temperature by improving the SERVO- PACK installation condi- tions.	page 3-6
	An overload alarm was reset by turning OFF the power sup- ply too many times.	Check the alarm display to see if there is an overload alarm.	Change the method for resetting the alarm.	-
	There was an exces- sive load or operation was performed that exceeded the regen- erative processing capacity.	Use the accumulated load ratio to check the load during operation, and use the regenera- tive load ratio to check the regenerative pro- cessing capacity.	Reconsider the load and operating conditions.	-
	The SERVOPACK installation orientation is not correct or there is insufficient space around the SERVO- PACK.	Check the SERVOPACK installation conditions.	Install the SERVOPACK according to specifica- tions.	page 3-3, page 3-5
	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-
	The surrounding tem- perature is too high.	Check the surrounding temperature using a thermostat. Or, check the operating status with the SERVOPACK installation environment monitor.	Decrease the surround- ing temperature by improving the SERVO- PACK installation condi- tions.	page 3-6
4 740.	An overload alarm was reset by turning OFF the power sup- ply too many times.	Check the alarm display to see if there is an overload alarm.	Change the method for resetting the alarm.	-
A.7A2: Internal Tempera- ture Error 2 (Power Board Temperature Error)	There was an exces- sive load or operation was performed that exceeded the regen- erative processing capacity.	Use the accumulated load ratio to check the load during operation, and use the regenera- tive load ratio to check the regenerative pro- cessing capacity.	Reconsider the load and operating conditions.	-
	The SERVOPACK installation orientation is not correct or there is insufficient space around the SERVO- PACK.	Check the SERVOPACK installation conditions.	Install the SERVOPACK according to specifica- tions.	page 3-3, page 3-5
	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-
A.7A3: Internal Tempera- ture Sensor Error (An error occurred in the temperature sen- sor circuit.)	A failure occurred in the SERVOPACK.	_	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-

Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
A.7Ab: SERVOPACK Built-in Fan Stopped	The fan inside the SERVOPACK stopped.	Check for foreign matter inside the SERVOPACK.	Remove foreign matter from the SERVOPACK. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SER- VOPACK.	-
	The power to the absolute encoder was turned ON for the first time.	Check to see if the power supply was turned ON for the first time.	Set up the encoder.	
A.810:	The Encoder Cable was disconnected and then connected again.	Check to see if the power supply was turned ON for the first time.	Check the encoder con- nection and set up the encoder.	page 5-46
Encoder Backup Alarm (Detected at the encoder, but only when an abso- lute encoder is used.)	Power is not being supplied both from the control power supply (+5 V) from the SERVOPACK and from the battery power supply.	Check the encoder connector battery and the connector status.	Replace the battery or implement similar mea- sures to supply power to the encoder, and set up the encoder.	
	A failure occurred in the absolute encoder.	-	If the alarm still occurs after setting up the encoder again, replace the Servomotor.	-
	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-
A.820: Encoder Check- sum Alarm (Detected at the encoder.)	A failure occurred in the encoder.	_	<ul> <li>When Using an Absolute Encoder</li> <li>Set up the encoder again.</li> <li>If the alarm still occurs, the Servomotor may be faulty. Replace the Servomotor.</li> <li>When Using a Singleturn Absolute Encoder or Incremental Encoder</li> <li>The Servomotor may be faulty. Replace the Servomotor.</li> <li>The linear encoder may be faulty. Replace the linear encoder.</li> </ul>	page 5-46
	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SER- VOPACK.	_
A.830: Encoder Battery	The battery connec- tion is faulty or a bat- tery is not connected.	Check the battery con- nection.	Correct the battery con- nection.	page 4-20
Alarm (The absolute encoder battery voltage was lower	The battery voltage is lower than the specified value (2.7 V).	Measure the battery voltage.	Replace the battery.	page 10-3
than the speci- fied level.)	A failure occurred in the SERVOPACK.	_	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-

Continued on next page.

Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
	The encoder malfunc- tioned.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the Servomotor or linear encoder may be faulty. Replace the Servo- motor or linear encoder.	-
	An error occurred in reading data from the linear encoder.	-	The linear encoder is not mounted within an appro- priate tolerance. Correct the mounting of the linear encoder.	-
A.840: Encoder Data Alarm (Detected at the encoder.)	Excessive speed occurred in the linear encoder.	-	Control the motor speed within the range specified by the linear encoder manufacturer and then turn ON the control power supply.	-
	The encoder malfunc- tioned due to noise.	_	Correct the wiring around the encoder by separating the Encoder Cable from the Servomotor Main Cir- cuit Cable or by ground- ing the encoder.	-
	The polarity sensor is not wired correctly.	Check the wiring of the polarity sensor.	Correct the wiring of the polarity sensor.	-
	The polarity sensor failed.	_	Replace the polarity sen- sor.	-
A.850: Encoder Over- speed (Detected at the encoder when the control power supply is turned ON.)	Rotary Servomotor: The Servomotor speed was 200 min <sup>-1</sup> or higher when the control power supply was turned ON.	Check the motor speed when the power supply is turned ON.	Reduce the Servomotor speed to a value less than 200 min <sup>-1</sup> , and turn ON the control power supply.	-
	Linear Servomotor: The Servomotor exceeded the speci- fied speed when the control power supply was turned ON.	Check the motor speed when the power supply is turned ON.	Control the motor speed within the range specified by the linear encoder manufacturer and then turn ON the control power supply.	-
	A failure occurred in the encoder.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the Servomotor or linear encoder may be faulty. Replace the Servo- motor or linear encoder.	_
	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-

Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
A.860:	The surrounding air temperature around the Servomotor is too high.	Measure the surround- ing air temperature around the Servomotor.	Reduce the surrounding air temperature of the Servomotor to 40°C or less.	-
heated (Detected when a Rotary Servomo- tor, Absolute Lin-	The Servomotor load is greater than the rated load.	Use the accumulated load ratio to check the load.	Operate the Servo Drive so that the motor load remains within the speci- fied range.	page 9-3
ear Encoder, or Direct Drive Ser- vomotor is con- nected. However, this alarm is not detected for SGMCS Servomotors with	A failure occurred in the encoder.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the Servomotor or absolute linear encoder may be faulty. Replace the Servomotor or absolute linear encoder.	-
(Detected at the encoder.)	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
	The surrounding tem- perature around the Servomotor is too high.	Measure the surround- ing temperature around the Servomotor.	Reduce the surrounding air temperature of the Servomotor to 40° or less.	-
	The motor load is greater than the rated load.	Check the load with the accumulated load ratio on the Motion Monitor Tab Page on the Sig- maWin+.	Operate the Servo Drive so that the motor load remains within the speci- fied range.	page 9-3
A.861: Motor Over- heated	A failure occurred in the Serial Converter Unit.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the Serial Con- verter Unit may be faulty. Replace the Serial Con- verter Unit.	-
	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
A.890: Encoder Scale Error	A failure occurred in the linear encoder.	_	The linear encoder may be faulty. Replace the linear encoder.	_
A.891: Encoder Module Error	A failure occurred in the linear encoder.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the linear encoder may be faulty. Replace the linear encoder.	-
A.b33: Current Detec- tion Error 3	A failure occurred in the current detection circuit.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	_

Continued on next page.

Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
A.b6A: MECHATROLINK Communications ASIC Error 1	There is a fault in the SERVOPACK MECHATROLINK communications sec- tion.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	_
A.b6b: MECHATROLINK Communications ASIC Error 2	A malfunction occurred in the MECHATROLINK communications sec- tion due to noise.	_	<ul> <li>Implement the following countermeasures against noise.</li> <li>Check the MECHA-TROLINK Communications Cable and FG wiring.</li> <li>Attach a ferrite core to the MECHATROLINK Communications Cable.</li> </ul>	-
	There is a fault in the SERVOPACK MECHATROLINK communications sec- tion.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
<b>A.bF0:</b> System Alarm 0	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
A.bF1: System Alarm 1	A failure occurred in the SERVOPACK.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
A.bF2: System Alarm 2	A failure occurred in the SERVOPACK.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
A.bF3: System Alarm 3	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
<b>A.bF4:</b> System Alarm 4	A failure occurred in the SERVOPACK.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	_
A.bF5: System Alarm 5	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-

Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
A.bF6: System Alarm 6	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
A.bF7: System Alarm 7	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
A.bF8: System Alarm 8	A failure occurred in the SERVOPACK.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
	The order of phases U, V, and W in the motor wiring is not correct.	Check the Servomotor wiring.	Make sure that the Servo- motor is correctly wired.	-
A C10:	There is an error in the setting of Pn080 = n.□□X□ (Motor Phase Sequence Selection).	Check the setting of Pn080 = $n.\Box\BoxX\Box$ .	Set Pn080 = n.□□X□ to an appropriate value.	page 5-23
A.C10: Servomotor Out of Control (Detected when the servo is turned ON.)	A failure occurred in the encoder.	_	If the motor wiring is cor- rect and an alarm still occurs after turning the power supply OFF and ON again, the Servomotor or linear encoder may be faulty. Replace the Servo- motor or linear encoder.	-
	A failure occurred in the SERVOPACK.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
	The linear encoder signal level is too low.	Check the voltage of the linear encoder signal.	Fine-tune the mounting of the scale head. Or, replace the linear encoder.	_
A.C20: Phase Detection Error	The count-up direc- tion of the linear encoder does not match the forward direction of the Mov- ing Coil in the motor.	Check the setting of Pn080 = $n.\square\squareX\square$ (Motor Phase Sequence Selection). Check the installation orientation for the linear encoder and Moving Coil.	Change the setting of Pn080 = n. Correctly reinstall the lin- ear encoder or Moving Coil.	page 5-23
	The polarity sensor signal is being affected by noise.	-	Correct the FG wiring. Implement countermea- sures against noise for the polarity sensor wiring.	_

Continued on next page.

Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
<b>A.C21:</b> Polarity Sensor Error	The polarity sensor is protruding from the Magnetic Way of the motor.	Check the polarity sen- sor.	Correctly reinstall the Moving Coil or Magnetic Way of the motor.	-
	The setting of Pn282 (Linear Encoder Scale Pitch) is not correct.	Check the setting of Pn282 (Linear Encoder Scale Pitch).	Check the specifications of the linear encoder and set a correct value.	page 5-17
	The polarity sensor is not wired correctly.	Check the wiring of the polarity sensor.	Correct the wiring of the polarity sensor.	-
	The polarity sensor failed.	-	Replace the polarity sen- sor.	_
A.C22: Phase Informa- tion Disagree- ment	The SERVOPACK phase information is different from the lin- ear encoder phase information.	-	Perform polarity detec- tion.	page 5-28

Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
	The parameter set- tings are not correct.	Check the linear encoder specifications and feedback signal status.	The settings of Pn282 (Linear Encoder Scale Pitch) and Pn080 = n.□□X□ (Motor Phase Sequence Selection) may not match the installa- tion. Set the parameters to correct values.	page 5-17, page 5-23
	There is noise on the scale signal.	Check to make sure that the frame grounds of the Serial Converter Unit and Servomotor are connected to the FG terminal on the SER- VOPACK and that the FG terminal on the SER- VOPACK is connected to the frame ground on the power supply. And, confirm that the shield is properly pro- cessed on the Linear Encoder Cable. Check to see if the detection reference is repeatedly output in one direction.	Implement appropriate countermeasures against noise for the Linear Encoder Cable.	-
A.C50: Polarity Detec- tion Failure	An external force was applied to the Moving Coil of the motor.	_	The polarity cannot be properly detected if the detection reference is 0 and the speed feedback is not 0 because of an external force, such as cable tension, applied to the Moving Coil. Imple- ment measures to reduce the external force so that the speed feedback goes to 0. If the external force cannot be reduced, increase the setting of Pn481 (Polarity Detection Speed Loop Gain).	_
	The linear encoder resolution is too low.	Check the linear encoder scale pitch to see if it is within 100 μm.	If the linear encoder scale pitch is 100 $\mu$ m or higher, the SERVOPACK cannot detect the correct speed feedback. Use a linear encoder scale pitch with higher resolution. (We rec- ommend a pitch of 40 $\mu$ m or less.) Or, increase the setting of Pn485 (Polarity Detection Reference Speed). However, increasing the setting of Pn485 will increase the Servomotor movement range that is required for polarity detection.	_

Maintenance

Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
A.C51: Overtravel Detected during Polarity Detection	The overtravel signal was detected during polarity detection.	Check the overtravel position.	Wire the overtravel sig- nals. Execute polarity detection at a position where an overtravel sig- nal would not be detected.	page 4-34
A.C52: Polarity Detec- tion Not Com- pleted	The servo was turned ON when using an absolute linear encoder, Pn587 was set to n. DDD (Do not detect polarity), and the polarity had not been detected.	_	When using an absolute linear encoder, set Pn587 to n.DDD1 (Detect polar- ity)	-
A.C53: Out of Range of Motion for Polar- ity Detection	The travel distance exceeded the setting of Pn48E (Polarity Detection Range) in the middle of detec- tion.	-	Increase the setting of Pn48E (Polarity Detection Range). Or, increase the setting of Pn481 (Polarity Detection Speed Loop Gain).	-
<b>A.C54:</b> Polarity Detec- tion Failure 2	An external force was applied to the Servo- motor.	_	Increase the setting of Pn495 (Polarity Detection Confirmation Force Refer- ence). Increase the setting of Pn498 (Polarity Detec- tion Allowable Error Range). Increasing the allowable error will also increase the motor tem- perature.	_
A.C80: Encoder Clear Error or Multiturn Limit Setting Error	A failure occurred in the encoder.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the Servomotor or linear encoder may be faulty. Replace the Servo- motor or linear encoder.	-
	A failure occurred in the SERVOPACK.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-

Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
	There is a faulty con- tact in the connector or the connector is not wired correctly for the encoder.	Check the condition of the encoder connector.	Reconnect the encoder connector and check the encoder wiring.	page 4-19
A.C90: Encoder Commu- nications Error	There is a cable dis- connection or short- circuit in the encoder. Or, the cable imped- ance is outside the specified values.	Check the condition of the Encoder Cable.	Use the Encoder Cable within the specified specifications.	-
	One of the following has occurred: corro- sion caused by improper tempera- ture, humidity, or gas, a short-circuit caused by entry of water drops or cutting oil, or faulty contact in con- nector caused by vibration.	Check the operating environment.	Improve the operating environmental, and replace the cable. If the alarm still occurs, replace the SERVOPACK.	page 3-2
	A malfunction was caused by noise.	_	Correct the wiring around the encoder by separating the Encoder Cable from the Servomotor Main Cir- cuit Cable or by ground- ing the encoder.	page 4-5
	A failure occurred in the SERVOPACK.	_	Connect the Servomotor to another SERVOPACK, and turn ON the control power supply. If no alarm occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
	Noise entered on the signal lines because the Encoder Cable is bent or the sheath is damaged.	Check the condition of the Encoder Cable and connectors.	Check the Encoder Cable to see if it is installed correctly.	page 4-8
A.C91: Encoder Commu- nications Posi- tion Data Acceleration Rate	The Encoder Cable is bundled with a high- current line or installed near a high- current line.	Check the installation condition of the Encoder Cable.	Confirm that there is no surge voltage on the Encoder Cable.	_
Error	There is variation in the FG potential because of the influ- ence of machines on the Servomotor side, such as a welder.	Check the installation condition of the Encoder Cable.	Properly ground the machine to separate it from the FG of the encoder.	-

Continued on next page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
	Noise entered on the signal line from the encoder.	_	Implement countermea- sures against noise for the encoder wiring.	page 4-5
	Excessive vibration or shock was applied to the encoder.	Check the operating conditions.	Reduce machine vibra- tion. Correctly install the Ser- vomotor or linear encoder.	-
A.C92: Encoder Commu- nications Timer Error	A failure occurred in the encoder.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the Servomotor or linear encoder may be faulty. Replace the Servo- motor or linear encoder.	_
	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
A.CA0: Encoder Parame- ter Error	A failure occurred in the encoder.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the Servomotor or linear encoder may be faulty. Replace the Servo- motor or linear encoder.	-
	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	_

Continued from previous page.

Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
	The encoder is wired incorrectly or there is faulty contact.	Check the wiring of the encoder.	Make sure that the encoder is correctly wired.	page 4-19
	The specifications of the Encoder Cable are not correct and noise entered on it.	-	Use a shielded twisted- pair wire cable or a screened twisted-pair cable with conductors of at least 0.12 mm <sup>2</sup> .	-
	The Encoder Cable is too long and noise entered on it.	-	<ul> <li>Rotary Servomotors: The Encoder Cable wir- ing distance must be 50 m max.</li> <li>Linear Servomotors: The Encoder Cable wir- ing distance must be 20 m max.</li> </ul>	-
A.Cb0: Encoder Echo- back Error	There is variation in the FG potential because of the influ- ence of machines on the Servomotor side, such as a welder.	Check the condition of the Encoder Cable and connectors.	Properly ground the machine to separate it from the FG of the encoder.	-
	Excessive vibration or shock was applied to the encoder.	Check the operating conditions.	Reduce machine vibra- tion. Correctly install the Ser- vomotor or linear encoder.	-
	A failure occurred in the encoder.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the Servomotor or linear encoder may be faulty. Replace the Servo- motor or linear encoder.	-
	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
	When using a Direct Drive Servomotor, the setting of Pn205 (Mul- titurn Limit) does not agree with the encoder.	Check the setting of Pn205.	Correct the setting of Pn205 (0 to 65,535).	page 6-30
<b>A.CC0:</b> Multiturn Limit Disagreement	The multiturn limit of the encoder is differ- ent from that of the SERVOPACK. Or, the multiturn limit of the SERVOPACK has been changed.	Check the setting of Pn205 in the SERVO- PACK.	Change the setting if the alarm occurs.	page 6-30
	A failure occurred in the SERVOPACK.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-

Continued on next page.

Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
	The Servomotor U, V, and W wiring is not correct.	Check the wiring of the Servomotor's Main Cir- cuit Cables.	Make sure that there are no faulty contacts in the wiring for the Servomotor and encoder.	-
A.d00: Position Devia- tion Overflow (The setting of Pn520 (Position Deviation Over- flow Alarm Level) was exceeded by	The position com- mand speed is too fast.	Reduce the position command speed and try operating the SER- VOPACK.	Reduce the position refer- ence speed or the refer- ence acceleration rate, or reconsider the electronic gear ratio.	page 5-43
	The acceleration of the position reference is too high.	Reduce the reference acceleration and try operating the SERVO- PACK.	Reduce the acceleration of the position reference using a MECHATROLINK command. Or, smooth the position reference accel- eration by selecting the position reference filter (ACCFIL) using a MECHA- TROLINK command.	-
ation while the servo was ON.)	The setting of Pn520 (Position Deviation Overflow Alarm Level) is too low for the operating conditions.	Check Pn520 (Position Deviation Overflow Alarm Level) to see if it is set to an appropriate value.	Optimize the setting of Pn520.	page 8-8
	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
A.d01: Position Devia- tion Overflow Alarm at Servo ON	The servo was turned ON after the position deviation exceeded the setting of Pn526 (Position Deviation Overflow Alarm Level at Servo ON) while the servo was OFF.	Check the position deviation while the servo is OFF.	Optimize the setting of Pn526 (Position Deviation Overflow Alarm Level at Servo ON).	
<b>A.d02:</b> Position Devia- tion Overflow Alarm for Speed Limit at Servo ON	If position deviation remains in the devia- tion counter, the set- ting of Pn529 or Pn584 (Speed Limit Level at Servo ON) limits the speed when the servo is turned ON. This alarm occurs if a position reference is input and the set- ting of Pn520 (Posi- tion Deviation Overflow Alarm Level) is exceeded.	-	Optimize the setting of Pn520 (Position Deviation Overflow Alarm Level). Or, adjust the setting of Pn529 or Pn584 (Speed Limit Level at Servo ON).	page 8-8
A.d30: Position Data Overflow	The position data exceeded ±1,879,048,192.	Check the input refer- ence pulse counter.	Reconsider the operating specifications.	-

Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
A.E02:	The MECHATROLINK transmission cycle fluctuated.	_	Remove the cause of transmission cycle fluctu- ation at the host control- ler.	-
MECHATROLINK Internal Synchro- nization Error 1	A failure occurred in the SERVOPACK.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
A.E40: MECHATROLINK Transmission Cycle Setting Error	The setting of MECHATROLINK transmission cycle is outside of the speci- fied range.	Check the setting of the MECHATROLINK trans- mission cycle.	Set the MECHATROLINK transmission cycle to an appropriate value.	-
A.E41: MECHATROLINK Communications Data Size Setting Error	The number of trans- mission bytes set on DIP switch S3 is not correct.	Check the MECHA- TROLINK communica- tions data size of the host controller.	Reset DIP switch S3 to change the number of transmission bytes to an appropriate value.	page 5-11
A.E42: MECHATROLINK Station Address Setting Error	The station address is outside of the setting range.	Check rotary switches S1 and S2 to see if the station address is between 03 and EF.	Check the setting of the station address of the host controller, and reset rotary switches S1 and S2 to change the address to an appropriate value between 03 and EF.	page 5-11
	Two or more stations on the communica- tions network have the same address.	Check to see if two or more stations on the communications net- work have the same address.	Check the setting of the station address of the host controller, and reset rotary switches S1 and S2 to change the address to an appropriate value between 03 and EF.	
A.F50 <sup>*4</sup> :	The WDT data in the host controller was not updated normally.	Check to see if the WDT data is being updated at the host controller.	Correctly update the WDT data at the host controller.	-
MECHATROLINK Synchronization Error	A failure occurred in the SERVOPACK.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
A.E51: MECHATROLINK Synchronization	The WDT data at the host controller was not updated correctly at the start of syn- chronous communi- cations, so synchronous commu- nications could not be started.	Check to see if the WDT data is being updated in the host controller.	Correctly update the WDT data at the host controller.	_
ralleu	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-

Continued on next page.

Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
	MECHATROLINK wir- ing is not correct.	Check the MECHA- TROLINK wiring.	Correct the MECHA- TROLINK Communica- tions Cable wiring. Correctly connect the ter- minator.	-
A.E60 <sup>*4</sup> : Reception Error in MECHATROLINK Communications	A MECHATROLINK data reception error occurred due to noise.	_	Implement countermea- sures against noise. (Check the MECHA- TROLINK Communica- tions Cable and FG wiring, and implement measures such as attach- ing a ferrite core to the MECHATROLINK Com- munications Cable.)	-
	A failure occurred in the SERVOPACK.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
A.E61: Synchronization	The MECHATROLINK transmission cycle fluctuated.	Check the setting of the MECHATROLINK trans- mission cycle.	Remove the cause of transmission cycle fluctu- ation at the host control- ler.	-
Interval Error in MECHATROLINK Transmission Cycle	A failure occurred in the SERVOPACK.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
	MECHATROLINK wir- ing is not correct.	Check the Servomotor wiring.	Correct the MECHA- TROLINK Communica- tions Cable wiring.	-
A.E63: MECHATROLINK Synchronization Frame Not Received	A MECHATROLINK data reception error occurred due to noise.	-	Implement countermea- sures against noise. (Check the MECHA- TROLINK Communica- tions Cable and FG wiring, and implement measures such as attach- ing a ferrite core to the MECHATROLINK Com- munications Cable.)	-
	A failure occurred in the SERVOPACK.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
A.Ed1:	A timeout error occurred for a	Check the motor status when the command is executed.	Execute the SV_ON or SENS_ON command only when the motor is not operating.	-
Command Exe- cution Timeout MECHATROLINK command.		Check the linear encoder status when the command is exe- cuted.	Execute the SENS_ON command only when a linear encoder is connected.	-

Continue	d from	previous	page
Continue		provious	puge.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
	The three-phase power supply wiring is not correct.	Check the power sup- ply wiring.	Make sure that the power supply is correctly wired.	page 4-10
A.F10: Power Supply	The three-phase power supply is unbalanced.	Measure the voltage for each phase of the three-phase power sup- ply.	Balance the power sup- ply by changing phases.	-
(The voltage was low for more than one second for phase R, S, or T when the main power supply	A single-phase power supply was input with- out specifying a sig- nal-phase AC power supply input (Pn00B = $n.\Box 1 \Box \Box$ ).	Check the power sup- ply and the parameter setting.	Match the parameter set- ting to the power supply.	page 4-10
was ON.)	A failure occurred in the SERVOPACK.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
A.F50: Servomotor Main Circuit Cable Dis-	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-
connection (The Servomotor did not operate or power was not supplied to the Servomotor even though the SV_ON (Servo ON) command was input when the Servomotor was ready to receive it.)	The wiring is not cor- rect or there is a faulty contact in the motor wiring.	Check the wiring.	Make sure that the Servo- motor is correctly wired.	page 4-19
FL-1 <sup>*4</sup> : System Alarm FL-2 <sup>*4</sup> : System Alarm FL-3 <sup>*4</sup> : System Alarm FL-4 <sup>*4</sup> : System Alarm FL-6 <sup>*4</sup> : System Alarm	A failure occurred in the SERVOPACK.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
CPF00: Digital Operator	There is a faulty con- tact between the Digi- tal Operator and the SERVOPACK.	Check the connector contact.	Disconnect the connec- tor and insert it again. Or, replace the cable.	_
Error 1	A malfunction was caused by noise.	_	Keep the Digital Operator or the cable away from sources of noise.	-

Continued on next page.

Continued from previous page. Alarm Number: **Possible Cause** Confirmation Reference Correction Alarm Name Disconnect the Digital Operator and then connect it again. If an alarm A failure occurred in still occurs, the Digital the Digital Operator. Operator may be faulty. CPF01: Replace the Digital Oper-**Digital Operator** ator. Communications Turn the power supply to Error 2 the SERVOPACK OFF and ON again. If an alarm still A failure occurred in the SERVOPACK. occurs, the SERVOPACK may be faulty. Replace the SERVOPACK. \*1. Detection Conditions · Rotary Servomotor If either of the following conditions is detected, an alarm will occur. Encoder resolution Pn20E Pn533 [min<sup>-1</sup>] × \_\_\_\_\_\_ — ≤ · 6 × 10<sup>5</sup> Pn210 Encoder resolution Pn20E Maximum motor speed [min<sup>-1</sup>] × – - ≥ Pn210 Approx. 3.66 × 10<sup>12</sup> Linear Servomotor If either of the following conditions is detected, an alarm will occur. Pn585 [mm/s] Resolution of Serial Converter Unit Pn20F — ×  $\leq$  · Pn210 Linear encoder pitch [µm] 10  $\frac{\text{Resolution of Serial Converter Unit}}{\text{Approx 6.10 x10^{5}}} \geq \frac{\text{Pn20E}}{\text{Pn210}}$ Pn385 [100 mm/s] Linear encoder pitch [µm] \*2. Detection Conditions · Rotary Servomotor If either of the following conditions is detected, an alarm will occur. • Rated motor speed [min<sup>-1</sup>]  $\times$  1/3  $\times$  Encoder resolution  $\leq$ Pn20E 6×10<sup>5</sup> Pn210 Maximum motor speed [min<sup>-1</sup>] × Encoder resolution Pn20E  $\frac{1}{\text{Approx. } 3.66 \times 10^{12}} \ge \frac{1}{\text{Pn210}}$  Linear Servomotor If either of the following conditions is detected, an alarm will occur. Rated motor speed [mm/s]  $\times$  1/3  $\times$  Resolution of Serial Converter Unit  $\leq$  Pn20E Pn210 Linear encoder pitch [µm] 10

[1.1.1]				
 Pn385 [100 mm/s]	~	Resolution of Serial Converter Unit		Pn20E
Linear encoder pitch [µm]	^	Approx. 6.10 ×10 <sup>5</sup>	<	Pn210

\*3. Refer to the following manual for details.

Ω Σ-7-Series Peripheral Device Selection Manual (Manual No.: SIEP S800001 32)

\*4. These alarms are not stored in the alarm history. They are only displayed on the panel display.

## 10.2.3 Resetting Alarms

If there is an ALM (Servo Alarm) signal, use one of the following methods to reset the alarm after eliminating the cause of the alarm.

Ì
Importan

Be sure to eliminate the cause of an alarm before you reset the alarm. If you reset the alarm and continue operation without eliminating the cause of the alarm, it may result in damage to the equipment or fire.

# Resetting Alarms by Sending the ALM\_CLR (Clear Warning or Alarm) Command

Refer to the following manual for details.

Σ-7-Series MECHATROLINK-III Communications Standard Servo Profile Command Manual (Manual No.: SIEP S800001 31)

## **Resetting Alarms Using the Digital Operator**

Press the **ALARM RESET** Key on the Digital Operator. Refer to the following manual for details on resetting alarms.

 $\square$   $\Sigma$ -7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)

## 10.2.4 Displaying the Alarm History

The alarm history displays up to the last ten alarms that have occurred in the SERVOPACK. Alarms are displayed for the selected axis.

Note: The following alarms are not displayed in the alarm history: A.E50 (MECHATROLINK Synchronization Error), A.E60 (Reception Error in MECHATROLINK Communications), and FL-1 to FL-5.

## Preparations

No preparations are required.

## **Applicable Tools**

The following table lists the tools that you can use to display the alarm history and the applicable tool functions.

Tool	Function	Reference
Digital Operator	Fn000	Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Alarm – Display Alarm	Operating Procedure on page 10-38

10.2.5 Clearing the Alarm History

## **Operating Procedure**

Use the following procedure to display the alarm history.

- 1. Click the <u>I</u> Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- 2. Select Display Alarm in the Menu Dialog Box. The Alarm Display Dialog Box will be displayed.
- 3. Click the Alarm History Tab.
  - The following display will appear and you can check the alarms that occurred in the past.



Alarm number: Alarm name Alarms in order of occurrence (Older alarms have higher numbers.)

Information

- 1. If the same alarm occurs consecutively within one hour, it is not saved in the alarm history. If it occurs after an hour or more, it is saved.
- 2. You can clear the alarm history by clicking the **Clear** Button. The alarm history is not cleared when alarms are reset or when the SERVOPACK main circuit power is turned OFF.

This concludes the procedure to display the alarm history.

## 10.2.5 Clearing the Alarm History

You can clear the alarm history that is recorded in the SERVOPACK. You can specify the axis for which to delete the history.

The alarm history is not cleared when alarms are reset or when the SERVOPACK main circuit power is turned OFF. You must perform the following procedure.

#### Preparations

Always check the following before you clear the alarm history.

• The parameters must not be write prohibited.

## **Applicable Tools**

The following table lists the tools that you can use to clear the alarm history and the applicable tool functions.

Tool	Function	Reference
Digital Operator	Fn006	Ω-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Alarm – Display Alarm	Derating Procedure on page 10-39

## **Operating Procedure**

Use the following procedure to reset the alarm history.

- 1. Click the *P* Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Display Alarm in the Menu Dialog Box. The Alarm Display Dialog Box will be displayed.
- 3. Click the Alarm History Tab.
- 4. Click the Clear Button.

The alarm history will be cleared.

			-
No.	Name	Accumulated o.	. ^
01	A.CC0 : Multiturn Limit Disagreement	58:05:29.8	П
02	A.CC0 : Multiturn Limit Disagreement	56:13:55.3	
03	A.C80 : Encoder Clear Error or Multiturn Limit Setting Error	55:52:55.1	
04	A.810 : Encoder Backup Alarm	55:48:10.1	Ξ
05	A.C80 : Encoder Clear Error or Multiturn Limit Setting Error	55:47:08.6	
06	A.830 : Encoder Battery Alarm	55:45:19.1	
07	A.810 : Encoder Backup Alarm	55:45:18.9	
08	A.C90 : Encoder Communications Error	55:44:37.2	
09	A.F10 : Power Supply Line Open Phase	55:34:04.2	-
•	m	+	

This concludes the procedure to reset the alarm history.

10.2.6 Resetting Motor Type Alarms

## 10.2.6 Resetting Motor Type Alarms

The SERVOPACK automatically determines the type of motor that is connected to it. If the type of motor that is connected is changed, an A.070 alarm (Motor Type Change Detected) will occur the next time the SERVOPACK is started. If an A.070 alarm occurs, you must set the parameters to match the new type of motor.

An A.070 alarm is reset by executing the Reset Motor Type Alarm utility function.

- Information 1. This utility function is the only way to reset an A.070 alarm (Motor Type Change Detected). The errors are not reset when you reset alarms or turn OFF the power supply to the SER-VOPACK.
  - 2. If an A.070 alarm occurs, first set the parameters according to the newly connected motor type and then execute the Reset Motor Type Alarm utility function.

### Preparations

Always check the following before you reset a motor type alarm.

• The parameters must not be write prohibited.

## Applicable Tools

The following table lists the tools that you can use to clear the motor type alarm and the applicable tool functions.

Tool	Function	Reference
Digital Operator	Fn021	$\bigcap \Sigma-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)$
SigmaWin+	Alarm – Reset Motor Type Alarm	G Operating Procedure on page 10-40

## **Operating Procedure**

Use the following procedure to reset Motor Type alarm.

- 1. Click the <u>I</u> Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Reset Motor Type Alarm in the Menu Dialog Box. The Reset Motor Type Alarm Dialog Box will be displayed.
- **3.** Click the Clear Button. The alarm will be cleared.

This concludes the procedure to reset Motor Type alarms.

## 10.3 Warning Displays

If a warning occurs in the SERVOPACK, a warning number will be displayed on the panel display. Warnings are displayed to warn you before an alarm occurs.

This section provides a list of warnings and the causes of and corrections for warnings.

## 10.3.1 List of Warnings

The list of warnings gives the warning name and warning meaning in order of the warning numbers.

If "All Axes" is given below the warning number, the warning applies to both axes. If a warning occurs for one axis, the same warning status will occur for the other axis.

Warning Number	Warning Name	Meaning	Resetting
A.900	Position Deviation Overflow	The position deviation exceeded the parameter settings (Pn520 $\times$ Pn51E/100).	Required.
A.901	Position Deviation Overflow Alarm at Servo ON	The position deviation exceeded the parameter settings (Pn526 $\times$ Pn528/100) when the servo was turned ON.	Required.
A.910	Overload	This warning occurs before an overload alarm (A.710 or A.720) occurs. If the warning is ignored and operation is continued, an alarm may occur.	Required.
A.911	Vibration	Abnormal vibration was detected during motor opera- tion. The detection level is the same as A.520. Set whether to output an alarm or a warning by setting Pn310 (Vibration Detection Selection).	Required.
A.912 All Axes	Internal Temperature Warning 1 (Control Board Temperature Error)	The surrounding temperature of the control PCB is abnormal.	Required.
A.913 All Axes	Internal Temperature Warning 2 (Power Board Temperature Error)	The surrounding temperature of the power PCB is abnormal.	Required.
A.920 All Axes	Regenerative Overload	This warning occurs before an A.320 alarm (Regenera- tive Overload) occurs. If the warning is ignored and operation is continued, an alarm may occur.	Required.
A.921	Dynamic Brake Over- load	This warning occurs before an A.731 alarm (Dynamic Brake Overload) occurs. If the warning is ignored and operation is continued, an alarm may occur.	Required.
A.923 All Axes	SERVOPACK Built-in Fan Stopped	The fan inside the SERVOPACK stopped.	Required.
A.930	Absolute Encoder Bat- tery Error	This warning occurs when the voltage of absolute encoder's battery is low.	Required.
A.942	Speed Ripple Com- pensation Information Disagreement	The speed ripple compensation information stored in the encoder does not agree with the speed ripple com- pensation information stored in the SERVOPACK.	Required.
A.94A	Data Setting Warning 1 (Parameter Number Error)	There is an error in the parameter number for a Data Setting Warning 1 (Parameter Number) command.	Automatically reset.*
A.94b	Data Setting Warning 2 (Out of Range)	The command data is out of range.	Automatically reset.*
A.94C	Data Setting Warning 3 (Calculation Error)	A calculation error was detected.	Automatically reset.*
A.94d	Data Setting Warning 4 (Parameter Size)	The data sizes do not match.	Automatically reset.*

Continued on next page.

10-41

10.3.1 List of Warnings

Warning Warning Name Meaning Resetting Number Data Setting Warning 5 A.94E A latch mode error was detected. Required. (Latch Mode Error) **Command Warning 1** A command was sent when the conditions for sending Automatically A.95A (Unsatisfied Coma command were not satisfied. reset.\* mand Conditions) Command Warning 2 Automatically A.95b (Unsupported Com-An unsupported command was sent. reset.\* mand) Command Warning 4 There was command interference, particularly latch Automatically A.95d (Command Interfercommand interference. reset.\* ence) Command Warning 5 The subcommand and main command interfere with Automatically A.95E (Subcommand Not each other. reset.\* Possible) Command Warning 6 Automatically A.95F An undefined command was sent. (Undefined Command) reset.\* MECHATROLINK A communications error occurred during MECHA-A.960 Communications Required. TROLINK communications. Warning This warning occurs before an A.410 alarm (Undervolt-A.971 Undervoltage age) occurs. If the warning is ignored and operation is Required. All Axes continued, an alarm may occur. Command Warning 7 A command that cannot be executed in the current Automatically A.97A reset.\* (Phase Error) phase was sent. Data Clamp Out of The set command data was clamped to the minimum or Automatically A.97b maximum value of the allowable setting range. reset.\* Range A.9A0 Overtravel Overtravel was detected while the servo was ON. Required. A.9b0 Preventative Mainte-One of the consumable parts has reached the end of its Required. All Axes nance Warning service life.

\* If using the commands for the MECHATROLINK-III standard servo profile, the warning will automatically be cleared after the correct command is received. If you use MECHATROLINK-II-compatible profile commands, send an ALM\_CLR (Clear Warning or Alarm) command to clear the warning.

Note: 1. A warning code is not output unless you set Pn001 to n.1 (Output both alarm codes and warning codes).

2. Use Pn008 = n.□X□□ (Warning Detection Selection) to control warning detection. However, the following warnings are not affected by the setting of Pn008 = n.□X□□ and other parameter settings are required in addition to Pn008 = n.□X□□.

0 1		
Warning	Parameters That Must Be Set to Select Warning Detection	Reference
A.911	Pn310 = n. $\Box\Box\BoxX$ (Vibration Detection Selection)	page 6-37
A.923	− (Not affected by the setting of Pn008 = $n.\Box X \Box \Box$ .)	-
A.930	Pn008 = n.	page 10-3
A.942	Pn423 = n. <b>DXD</b> (Speed Ripple Compensation Information Disagreement Warning Detection Selection)	page 8-60
A.94A to A.960 and A.97A to A.97b	Pn800=n.□□X□ (Warning Check Masks)	page 11-3
A.971	$Pn008 = n.\square\square\squareX$ (Low Battery Voltage Alarm/Warning Selection) (Not affected by the setting of $Pn008 = n.\squareX\square\square$ .)	page 6-18
A.9A0	Pn00D = $n.X\square\square\square$ (Overtravel Warning Detection Selection) (Not affected by the setting of Pn008 = $n.\squareX\square\square$ .)	page 5-32
A.9b0	$Pn00F = n.\Box\Box\BoxX$ (Preventative Maintenance Warning Selection)	page 9-15

Continued from previous page.

The causes of and corrections for the warnings are given in the following table. Contact your Yaskawa representative if you cannot solve a problem with the correction given in the table.

Warning Number: Warning Name	Possible Cause	Confirmation	Correction	Reference
	The Servomotor U, V, and W wiring is not correct.	Check the wiring of the Servomotor's Main Cir- cuit Cables.	Make sure that there are no faulty connections in the wiring for the Servomotor and encoder.	-
	A SERVOPACK gain is too low.	Check the SERVO- PACK gains.	Increase the servo gain, e.g., by using autotuning without a host reference.	page 8-24
<b>A.900:</b> Position Deviation Overflow	The acceleration of the position ref- erence is too high.	Reduce the reference acceleration and try operating the SERVO- PACK.	Reduce the acceleration of the position reference using a MECHATROLINK com- mand. Or, smooth the posi- tion reference acceleration by selecting the position reference filter (ACCFIL) using a MECHATROLINK command.	-
	The excessive position deviation alarm level (Pn520 × Pn51E/100) is too low for the operating condi- tions.	Check excessive posi- tion deviation alarm level (Pn520 × Pn51E/ 100) to see if it is set to an appropriate value.	Optimize the settings of Pn520 and Pn51E.	page 8-8
	A failure occurred in the SERVO- PACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	_
A.901: Position Deviation Overflow Alarm at Servo ON	The position devi- ation exceeded the parameter set- tings (Pn526 × Pn528/100) when the servo was turned ON.	_	Optimize the setting of Pn528 (Position Deviation Overflow Warning Level at Servo ON).	_

Continued from previous page.

Warning Number: Warning Name	Possible Cause	Confirmation	Correction	Reference
	The wiring is not correct or there is a faulty contact in the motor or encoder wiring.	Check the wiring.	Make sure that the Servo- motor and encoder are cor- rectly wired.	-
	Operation was performed that exceeded the overload protec- tion characteris- tics.	Check the motor over- load characteristics and Run command.	Reconsider the load and operating conditions. Or, increase the motor capacity.	-
A.910: Overload (warning before an A.710 or A.720 alarm occurs)	An excessive load was applied during operation because the Ser- vomotor was not driven because of mechanical prob- lems.	Check the operation reference and motor speed.	Remove the mechanical problem.	-
	The overload warning level (Pn52B) is not suitable.	Check that the overload warning level (Pn52B) is suitable.	Set a suitable overload warning level (Pn52B).	page 5-40
	A failure occurred in the SERVO- PACK.	-	The SERVOPACK may be faulty. Replace the SERVO- PACK.	-
	Abnormal vibra- tion was detected during motor operation.	Check for abnormal motor noise, and check the speed and torque waveforms during oper- ation.	Reduce the motor speed. Or, reduce the servo gain with custom tuning.	page 8-42
A.911: Vibration	The setting of Pn103 (Moment of Inertia Ratio) is greater than the actual moment of inertia or was greatly changed.	Check the moment of inertia ratio or mass ratio.	Set Pn103 (Moment of Iner- tia Ratio) to an appropriate value.	page 8-16
	The vibration detection level (Pn312 or Pn384) is not suitable.	Check that the vibration detection level (Pn312 or Pn384) is suitable.	Set a suitable vibration detection level (Pn312 or Pn384).	page 6-37

Continued from previous page.

Warning Number: Warning Name	Possible Cause	Confirmation	Correction	Reference
	The surrounding temperature is too high.	Check the surrounding temperature using a thermostat. Or, check the operating status with the SERVOPACK installation environ- ment monitor.	Decrease the surrounding temperature by improving the SERVOPACK installa- tion conditions.	page 3-6
	An overload alarm was reset by turn- ing OFF the power supply too many times.	Check the alarm display to see if there is an overload alarm.	Change the method for resetting the alarm.	-
A.912: Internal Tempera- ture Warning 1 (Control Board Tem- perature Error)	There was an excessive load or operation was performed that exceeded the regenerative pro- cessing capacity.	Use the accumulated load ratio to check the load during operation, and use the regenera- tive load ratio to check the regenerative pro- cessing capacity.	Reconsider the load and operating conditions.	-
	The SERVOPACK installation orien- tation is not cor- rect or there is insufficient space around the SER- VOPACK.	Check the SERVO- PACK installation con- ditions.	Install the SERVOPACK according to specifications.	page 3-3, page 3-5
	A failure occurred in the SERVO- PACK.	_	The SERVOPACK may be faulty. Replace the SERVO- PACK.	-
	The surrounding temperature is too high.	Check the surrounding temperature using a thermostat. Or, check the operating status with the SERVOPACK installation environ- ment monitor.	Decrease the surrounding temperature by improving the SERVOPACK installa- tion conditions.	page 3-6
	An overload alarm was reset by turn- ing OFF the power supply too many times.	Check the alarm display to see if there is an overload alarm.	Change the method for resetting the alarm.	-
A.913: Internal Tempera- ture Warning 2 (Power Board Tem- perature Error)	There was an excessive load or operation was performed that exceeded the regenerative pro- cessing capacity.	Use the accumulated load ratio to check the load during operation, and use the regenera- tive load ratio to check the regenerative pro- cessing capacity.	Reconsider the load and operating conditions.	-
	The SERVOPACK installation orien- tation is not cor- rect or there is insufficient space around the SER- VOPACK.	Check the SERVO- PACK installation con- ditions.	Install the SERVOPACK according to specifications.	page 3-3, page 3-5
	A failure occurred in the SERVO- PACK.	-	The SERVOPACK may be faulty. Replace the SERVO- PACK.	-

Continued on next page.

Continued from previous page.

Warning Number: Warning Name	Possible Cause	Confirmation	Correction	Reference
	The power supply voltage exceeded the specified range.	Measure the power supply voltage.	Set the power supply volt- age within the specified range.	-
<b>A.920:</b> Regenerative Over- load (warning before an A.320 alarm occurs)	There is insuffi- cient external regenerative resis- tance, regenera- tive resistor capacity, or SER- VOPACK capac- ity, or there has been a continuous regeneration state.	Check the operating conditions or the capacity using the Sig- maJunmaSize+ Capac- ity Selection Software or another means.	Change the regenerative resistance value, regenera- tive resistance capacity, or SERVOPACK capacity. Reconsider the operating conditions using the Sigma- JunmaSize+ Capacity Selection Software or other means.	-
	There was a con- tinuous regenera- tion state because a negative load was continuously applied.	Check the load applied to the Servomotor during operation.	Reconsider the system including the servo, machine, and operating conditions.	-
	The Servomotor was rotated by an external force.	Check the operation status.	Implement measures to ensure that the motor will not be rotated by an exter- nal force.	-
A.921: Dynamic Brake Overload (warning before an A.731 alarm occurs)	When the Servo- motor was stopped with the dynamic brake, the rotational or linear kinetic energy exceeded the capacity of the dynamic brake resistor.	Check the power con- sumed by the DB resis- tor to see how frequently the DB is being used.	<ul> <li>Reconsider the following:</li> <li>Reduce the Servomotor command speed.</li> <li>Decrease the moment of inertia or mass.</li> <li>Reduce the frequency of stopping with the dynamic brake.</li> </ul>	-
	A failure occurred in the SERVO- PACK.	-	The SERVOPACK may be faulty. Replace the SERVO- PACK.	-
A.923: SERVOPACK Built- in Fan Stopped	The fan inside the SERVOPACK stopped.	Check for foreign mat- ter inside the SERVO- PACK.	Remove foreign matter from the SERVOPACK. If an alarm still occurs, the SER- VOPACK may be faulty. Replace the SERVOPACK.	-
A.930: Absolute Encoder Battery Error (The	The battery con- nection is faulty or a battery is not connected.	Check the battery con- nection.	Correct the battery connec- tion.	page 4-20
absolute encoder battery voltage was lower than the spec- ified level.) (Detected only when an abso-	The battery volt- age is lower than the specified value (2.7 V).	Measure the battery voltage.	Replace the battery.	page 10-3
only when an abso- lute encoder is con- nected.)	A failure occurred in the SERVO- PACK.	_	The SERVOPACK may be faulty. Replace the SERVO- PACK.	-

Continued from previous page.

Warning Number: Warning Name	Possible Cause	Confirmation	Correction	Reference
	The speed ripple	_	Reset the speed ripple compensation value on the SigmaWin+.	page 8-60
A.942: Speed Ripple Com- pensation Informa- tion Disagreement	information stored in the encoder does not agree with the speed ripple compensa-	_	Set Pn423 to n. D 1 (Do not detect A.942 alarms). However, changing the set- ting may increase the speed ripple.	Reference         page 8-60         page 8-60         page 8-60         page 10-         page 10-
	tion information stored in the SER- VOPACK.	-	Set Pn423 to n. DD0 (Disable speed ripple com- pensation). However, changing the setting may increase the speed ripple.	
A.94A: Data Setting Warn- ing 1 (Parameter Number Error)	An invalid param- eter number was used.	Check the command that caused the warn-ing.	Use the correct parameter number.	page 10- 50
A.94b: Data Setting Warn- ing 2 (Out of Range)	The set com- mand data was clamped to the minimum or maxi- mum value of the setting range.	Check the command that caused the warn-ing.	Set the parameter within the setting range.	page 10- 50
A.94C: Data Setting Warn- ing 3 (Calculation Error)	The calculation result of the set- ting is not correct.	Check the command that caused the warn-ing.	Set the parameter within the setting range.	page 10- 50
A.94d: Data Setting Warn- ing 4 (Parameter Size)	The parameter size set in the command is not correct.	Check the command that caused the warn-ing.	Set the correct parameter size.	page 10- 50
A.94E: Data Setting Warn- ing 5 (Latch Mode Error)	A latch mode error was detected.	Check the command that caused the warn-ing.	Change the setting of Pn850 or the LT_MOD data for the LTMOD_ON com- mand sent by the host con- troller to an appropriate value. (The applies when using the MECHATROLINK-II-com- patible profile.)	page 10- 50
A.95A: Command Warning 1 (Unsatisfied Com- mand Conditions)	The command conditions are not satisfied.	Check the command that caused the warn- ing.	Send the command after the command conditions are satisfied.	page 10- 50
A.95b: Command Warning 2 (Unsupported Command)	An unsupported command was received.	Check the command that caused the warn-ing.	Do not send unsupported commands.	page 10- 50
A.95d: Command Warning 4 (Command Inter- ference)	The command sending condi- tions for latch- related com- mands was not satisfied.	Check the command that caused the warn-ing.	Send the command after the command conditions are satisfied.	page 10- 50
A.95E: Command Warning 5 (Subcommand Not Possible)	The command sending condi- tions for subcom- mands was not satisfied.	Check the command that caused the warn-ing.	Send the command after the conditions are satisfied.	page 10- 50

Maintenance

10

Continued from previous page.

Warning Number: Warning Name	Possible Cause	Confirmation	Correction	Reference
A.95F: Command Warning 6 (Undefined Com- mand)	An undefined command was sent.	Check the command that caused the warn-ing.	Do not send undefined commands.	page 10- 50
	The MECHA- TROLINK Com- munications Cable is not wired cor- rectly.	Check the wiring condi- tions.	Correct the MECHA- TROLINK communications cable wiring.	page 4-38
A.960: MECHATROLINK Communications Warning	A MECHA- TROLINK data reception error occurred due to noise.	Confirm the installation conditions.	<ul> <li>Implement the following countermeasures against noise.</li> <li>Check the MECHA-TROLINK Communications Cable and FG wiring and implement countermeasures to prevent noise from entering.</li> <li>Attach a ferrite core to the MECHATROLINK Communications Cable.</li> </ul>	_
	A failure occurred in the SERVO- PACK.	-	The SERVOPACK may be faulty. Replace the SERVO- PACK.	_
	For a 200-V SER- VOPACK, the AC power supply volt- age dropped below 140 V.	Measure the power supply voltage.	Set the power supply volt- age within the specified range.	-
	The power supply voltage dropped during operation.	Measure the power supply voltage.	Increase the power supply capacity.	-
A.971: Undervoltage	A momentary power interrup- tion occurred.	Measure the power supply voltage.	If you have changed the setting of Pn509 (Momen- tary Power Interruption Hold Time), decrease the setting.	page 6-17
	The SERVOPACK fuse is blown out.	-	Replace the SERVOPACK and connect a reactor.	page 4-18
	A failure occurred in the SERVO- PACK.	_	The SERVOPACK may be faulty. Replace the SERVO- PACK.	-
<b>A.97A:</b> Command Warning 7 (Phase Error)	A command that cannot be exe- cuted in the cur- rent phase was sent.	_	Send the command after the command conditions are satisfied.	-
<b>A.97b:</b> Data Clamp Out of Range	The set com- mand data was clamped to the minimum or maxi- mum value of the setting range.	-	Set the command data within the setting ranges.	-

Continued from previous page.

Warning Number: Warning Name	Possible Cause	Confirmation	Correction	Reference
A.9A0: Overtravel (Over- travel status was detected.)	Overtravel was detected while the servo was ON.	Check the status of the overtravel signals on the input signal monitor.	<ul> <li>Even if an overtravel signal is not shown by the input signal monitor, momentary overtravel may have been detected. Take the following precautions.</li> <li>Do not specify move- ments that would cause overtravel from the host controller.</li> <li>Check the wiring of the overtravel signals.</li> <li>Implement countermea- sures against noise.</li> </ul>	page 5-32
A.9b0: Preventative Mainte- nance Warning	One of the con- sumable parts has reached the end of its service life.	_	Replace the part. Contact your Yaskawa representa- tive for replacement.	page 9-15

## **10.4** Monitoring Communications Data during Alarms or Warnings

You can monitor the command data that is received when an alarm or warning occurs, such as a data setting warning  $(A.94\Box)$  or a command warning  $(A.95\Box)$  by using the following parameters. The following is an example of the data when an alarm or warning has occurred in the normal state.

Command Data during Alarms and Warnings: Pn890 to Pn8A6 Response Data during Alarms and Warnings: Pn8A8 to Pn8BE

Command Byte	Command Data Storage Whe	n an Alarm or Warning Occurs
Sequence	CMD	RSP
0	Pn890 = n.□□□□□□XX	Pn8A8 = n.DDDDDDXX
1	Pn890 = n.□□□□XX□□	Pn8A8 = n.DDDDXXDD
2	Pn890 = n.□□XX□□□□	Pn8A8 = n.DDXXDDDD
3	Pn890 = n.XX <b>DDDDDD</b>	Pn8A8 = n.XX <b>DDDDD</b>
4 to 7	Pn892	Pn8AA
8 to 11	Pn894	Pn8AC
12 to 15	Pn896	Pn8AE
16 to 19	Pn898	Pn8B0
20 to 23	Pn89A	Pn8B2
24 to 27	Pn89C	Pn8B4
28 to 31	Pn89E	Pn8B6
32 to 35	Pn8A0	Pn8B8
36 to 39	Pn8A2	Pn8BA
40 to 43	Pn8A4	Pn8BC
44 to 47	Pn8A6	Pn8BE

Note: 1. Data is stored in little endian byte order and displayed in the hexadecimal.

2. Refer to the following manual for command details.

Ω Σ-7-Series MECHATROLINK-III Communications Standard Servo Profile Command Manual (Manual No.: SIEP S800001 31)

## **10.5** Troubleshooting Based on the Operation and Conditions of the Servomotor

This section provides troubleshooting based on the operation and conditions of the Servomotor, including causes and corrections.

Turn OFF the Servo System before troubleshooting the items shown in bold lines in the table.

Problem	Possible Cause	Confirmation	Correction	Reference
Servomotor Does Not Start	The control power supply is not turned ON.	Measure the voltage between control power supply terminals.	Correct the wiring so that the control power supply is turned ON.	-
	The main circuit power sup- ply is not turned ON.	Measure the voltage across the main circuit power input terminals.	Correct the wiring so that the main circuit power supply is turned ON.	-
	The I/O signal connector (CN1) pins are not wired cor- rectly or are disconnected.	Check the wiring condi- tion of the I/O signal con- nector (CN1) pins.	Correct the wiring of the I/O signal connector (CN1) pins.	page 4-31, page 9-5
	The wiring for the Servomo- tor Main Circuit Cables or Encoder Cable is discon- nected.	Check the wiring condi- tions.	Wire the cable cor- rectly.	-
	There is an overload on the Servomotor.	Operate the Servomotor with no load and check the load status.	Reduce the load or replace the Servomo- tor with a Servomotor with a larger capacity.	-
	The type of encoder that is being used does not agree with the setting of $Pn002 = n.\Box X \Box \Box$ (Encoder Usage).	Check the type of the encoder that is being used and the setting of $Pn002 = n.\Box X \Box \Box$ .	Set Pn002 = $n.\Box X \Box \Box$ according to the type of the encoder that is being used.	page 6-27
	There is a mistake in the input signal allocations (Pn50A, Pn50B, Pn511, Pn516, or Pn590 to Pn599).	Check the input signal allocations (Pn50A, Pn50B, Pn511, Pn516, and Pn590 to Pn599).	Correctly allocate the input signals (Pn50A, Pn50B, Pn511, Pn516, and Pn590 to Pn599).	page 6-3, page 9-5
	The SV_ON command was not sent.	Check the commands sent from the host con- troller.	Send the SV_ON com- mand from the host controller.	-
	The SENS_ON (Turn ON Sensor) command was not sent.	Check the commands sent from the host con- troller.	Send the commands to the SERVOPACK in the correct sequence.	-
	The P-OT (Forward Drive Prohibit) or N-OT (Reverse Drive Prohibit) signal is still OFF.	Check the P-OT and N- OT signals.	Turn ON the P-OT and N-OT signals.	page 9-5
	The FSTP (Forced Stop Input) signal is still OFF.	Check the FSTP signal.	<ul> <li>Turn ON the FSTP signal.</li> <li>If you will not use the function to force the motor to stop, set Pn516 = n.□□□X (FSTP (Forced Stop Input) Signal Allocation) to disable the signal.</li> </ul>	page 9-5
	A failure occurred in the SER- VOPACK.	-	Replace the SERVO- PACK.	-

Continued on next page.

10

Maintenance

		Continued from previous page.				
Problem	Possible Cause	Confirmation	Correction	Reference		
Servomotor Does Not Start		Check the setting of Pn080 =n.□□□X (Polar- ity Sensor Selection).	Correct the parameter setting.	page 5-25		
	The polarity detection was not executed.	Check the inputs to the SV_ON (Servo ON) com- mand.	<ul> <li>If you are using an incremental linear encoder, send the SV_ON command from the host controller.</li> <li>If you are using an absolute linear encoder, execute polarity detection.</li> </ul>	page 5-26		
Servomotor Moves Instanta- neously, and Then Stops	There is a mistake in the Ser- vomotor wiring.	Check the wiring.	Wire the Servomotor correctly.	-		
	There is a mistake in the wir- ing of the encoder or Serial Converter Unit.	Check the wiring.	Wire the Serial Con- verter Unit correctly.	-		
	There is a mistake in the lin- ear encoder wiring.	Check the wiring.	Wire the cable cor- rectly.	_		
	The setting of Pn282 (Linear Encoder Scale Pitch) is not correct.	Check the setting of Pn282.	Correct the setting of Pn282.	page 5-17		
	The count-up direction of the linear encoder does not match the forward direction of the Moving Coil in the motor.	Check the directions.	Change the setting of Pn080 = $n.\Box\Box X\Box$ (Motor Phase Sequence Selection). Place the linear encoder and motor in the same direction.	page 5-23		
	Polarity detection was not performed correctly.	Check to see if electrical angle 2 (electrical angle from polarity origin) at any position is between ±10°.	Correct the settings for the polarity detection- related parameters.	-		
Servomotor Speed Is Unstable	There is a faulty connection in the Servomotor wiring.	The connector connec- tions for the power line (U, V, and W phases) and the encoder or Serial Converter Unit may be unstable. Check the wir- ing.	Tighten any loose ter- minals or connectors and correct the wiring.	-		
Servomotor Moves with- out a Refer- ence Input	A failure occurred in the SER- VOPACK.	-	Replace the SERVO- PACK.	-		
	The count-up direction of the linear encoder does not match the forward direction of the Moving Coil in the motor.	Check the directions.	Change the setting of Pn080 = n.□□X□ (Motor Phase Sequence Selection). Match the linear encoder direction and Servomotor direction.	page 5-23		
	Polarity detection was not performed correctly.	Check to see if electrical angle 2 (electrical angle from polarity origin) at any position is between ±10°.	Correct the settings for the polarity detection- related parameters.	-		
	Continued from pre	vious page.				
--	--	-------------				
Confirmation	Correction	Reference				
eck the setting of 001 = n.□□□X.	Set Pn001 = n.□□□X correctly.	_				
eck the moment of rtia, motor speed, and namic brake frequency use. If the moment of rtia, motor speed, or namic brake frequency use is excessive, the namic brake resis-	Replace the SERVO- PACK. To prevent dis- connection, reduce the load.	-				

Dynamic Brake Does Not Operate	The setting of Pn001 = n.□□□X (Motor Stopping Method for Servo OFF and Group 1 Alarms) is not suit- able.	Check the setting of Pn001 = $n.\Box\Box\BoxX$ .	Set Pn001 = n.□□□X correctly.	-
	The dynamic brake resistor is disconnected.	Check the moment of inertia, motor speed, and dynamic brake frequency of use. If the moment of inertia, motor speed, or dynamic brake frequency of use is excessive, the dynamic brake resis- tance may be discon- nected.	Replace the SERVO- PACK. To prevent dis- connection, reduce the load.	-
	There was a failure in the dynamic brake drive circuit.	_	There is a defective component in the dynamic brake circuit. Replace the SERVO- PACK.	-
	The Servomotor vibrated considerably while perform- ing the tuning-less function with the default settings.	Check the waveform of the motor speed.	Reduce the load so that the moment of inertia ratio or mass ratio is within the allow- able value, or increase the load level or reduce the rigidity level in the tuning-less level set- tings.	page 8-12
	The machine mounting is not secure.	Check to see if there are any loose mounting screws.	Tighten the mounting screws.	-
	The machine mounting is not	Check to see if there is misalignment in the coupling.	Align the coupling.	-
		Check to see if the coupling is balanced.	Balance the coupling.	-
	The bearings are defective.	Check for noise and vibration around the bearings.	Replace the Servomo- tor.	-
Abnormal Noise from Servomotor	There is a vibration source at the driven machine.	Check for any foreign matter, damage, or defor- mation in the machine's moving parts.	Consult with the machine manufacturer.	-
	Noise interference occurred because of incorrect I/O signal cable specifications.	Check the I/O signal cables to see if they sat- isfy specifications. Use shielded twisted-pair cables or screened twisted-pair cables with conductors of at least 0.12 mm <sup>2</sup> (stranded wire).	Use cables that satisfy the specifications.	-
	Noise interference occurred because an I/O signal cable is too long.	Check the lengths of the I/O signal cables.	The I/O signal cables must be no longer than 3 m.	-
	Noise interference occurred because of incorrect Encoder Cable specifications.	Check the Encoder Cable to see if it satisfies speci- fications. Use shielded twisted-pair cables or screened twisted-pair cables with conductors of at least 0.12 mm <sup>2</sup> (stranded wire).	Use cables that satisfy the specifications.	-

Problem

Possible Cause

Continued from provid

Continued on next page.

Problem	Possible Cause	Confirmation	Correction	Reference
	Noise interference occurred because the Encoder Cable is too long.	Check the length of the Encoder Cable.	<ul> <li>Rotary Servomotors: The Encoder Cable length must be 50 m max.</li> <li>Linear Servomotors: Make sure that the Serial Converter Unit cable is no longer than 20 m and that the Linear Encoder Cable and the Sensor Cable are no longer than 15 m each.</li> </ul>	-
	Noise interference occurred because the Encoder Cable is damaged.	Check the Encoder Cable to see if it is pinched or the sheath is damaged.	Replace the Encoder Cable and correct the cable installation envi- ronment.	_
Abnormal Noise from Servomotor	The Encoder Cable was sub- jected to excessive noise interference.	Check to see if the Encoder Cable is bundled with a high-current line or installed near a high-cur- rent line.	Correct the cable lay- out so that no surge is applied by high-current lines.	-
	There is variation in the FG potential because of the influence of machines on the Servomotor side, such as a welder.	Check to see if the machines are correctly grounded.	Properly ground the machines to separate them from the FG of the encoder.	-
	There is a SERVOPACK pulse counting error due to noise.	Check to see if there is noise interference on the signal line from the encoder.	Implement counter- measures against noise for the encoder wiring.	-
	The encoder was subjected to excessive vibration or shock.	Check to see if vibration from the machine occurred. Check the Ser- vomotor installation (mounting surface preci- sion, securing state, and alignment). Check the linear encoder installation (mounting sur- face precision and secur- ing method).	Reduce machine vibra- tion. Improve the mounting state of the Servomotor or linear encoder.	-
	A failure occurred in the encoder.	-	Replace the Servomo- tor.	_
	A failure occurred in the Serial Converter Unit.	-	Replace the Serial Con- verter Unit.	-
	A failure occurred in the linear encoder.	-	Replace the linear encoder.	-

Droblars	Descible Cause	Confirmation		Deference
Problem	Possible Cause	Confirmation	Correction	Reference
Servomotor Vibrates at Frequency of Approx. 200 to 400 Hz.	The servo gains are not bal- anced.	Check to see if the servo gains have been cor- rectly tuned.	Perform autotuning without a host reference.	page 8-24
	The setting of Pn100 (Speed Loop Gain) is too high.	Check the setting of Pn100. The default setting is Kv = 40.0 Hz.	Set Pn100 to an appro- priate value.	-
	The setting of Pn102 (Posi- tion Loop Gain) is too high.	Check the setting of Pn102. The default setting is Kp = 40.0/s.	Set Pn102 to an appro- priate value.	-
	The setting of Pn101 (Speed Loop Integral Time Con- stant) is not appropriate.	Check the setting of Pn101. The default setting is Ti = 20.0 ms.	Set Pn101 to an appro- priate value.	-
	The setting of Pn103 (Moment of Inertia Ratio or Mass Ratio) is not appropri- ate.	Check the setting of Pn103.	Set Pn103 to an appropriate value.	-
	The servo gains are not bal- anced.	Check to see if the servo gains have been cor- rectly tuned.	Perform autotuning without a host reference.	page 8-24
	The setting of Pn100 (Speed Loop Gain) is too high.	Check the setting of Pn100. The default setting is Kv = 40.0 Hz.	Set Pn100 to an appro- priate value.	-
Large Motor Speed Overshoot on Starting and Stop- ping	The setting of Pn102 (Posi- tion Loop Gain) is too high.	Check the setting of Pn102. The default setting is Kp = 40.0/s.	Set Pn102 to an appro- priate value.	-
	The setting of Pn101 (Speed Loop Integral Time Con- stant) is not appropriate.	Check the setting of Pn101. The default setting is Ti = 20.0 ms.	Set Pn101 to an appro- priate value.	-
	The setting of Pn103 (Moment of Inertia Ratio or Mass Ratio) is not appropri- ate.	Check the setting of Pn103.	Set Pn103 to an appro- priate value.	-
	The torque reference is saturated.	Check the waveform of the torque reference.	Use the mode switch.	-
	The force limits (Pn483 and Pn484) are set to the default values.	The default values of the force limits and Pn483 = 30% and Pn484 = 30%.	Set Pn483 and Pn484 to appropriate values.	page 6-22

Continued from previous page.

_	Continued from previou					
Problem	Possible Cause	Confirmation	Correction	Reference		
Absolute Encoder Position Deviation Error (The position that was	Noise interference occurred because of incorrect Encoder Cable specifications.	Check the Encoder Cable to see if it satisfies speci- fications. Use shielded twisted-pair cables or screened twisted-pair cables with conductors of at least 0.12 mm <sup>2</sup> (stranded wire).	Use cables that satisfy the specifications.	-		
	Noise interference occurred because the Encoder Cable is too long.	Check the length of the Encoder Cable.	<ul> <li>Rotary Servomotors: The Encoder Cable length must be 50 m max.</li> <li>Linear Servomotors: Make sure that the Serial Converter Unit cable is no longer than 20 m and that the Linear Encoder Cable and the Sensor Cable are no longer than 15 m each.</li> </ul>	-		
	Noise interference occurred because the Encoder Cable is damaged.	Check the Encoder Cable to see if it is pinched or the sheath is damaged.	Replace the Encoder Cable and correct the cable installation envi- ronment.	-		
saved in the host con- troller when the power was turned	Replace the Encoder Cable and correct the cable instal- lation environment.	Check to see if the Encoder Cable is bundled with a high-current line or installed near a high-cur- rent line.	Correct the cable lay- out so that no surge is applied by high-current lines.	-		
OFF is dif- ferent from the posi- tion when the power	There is variation in the FG potential because of the influence of machines on the Servomotor side, such as a welder.	Check to see if the machines are correctly grounded.	Properly ground the machines to separate them from the FG of the encoder.	-		
was next turned ON.)	There is a SERVOPACK pulse counting error due to noise.	Check to see if there is noise interference on the I/O signal line from the encoder or Serial Con- verter Unit.	Implement counter- measures against noise for the encoder or Serial Converter Unit wiring.	-		
	The encoder was subjected to excessive vibration or shock.	Check to see if vibration from the machine occurred. Check the Servomotor installation (mounting sur- face precision, securing state, and alignment). Check the linear encoder installation (mounting sur- face precision and secur- ing method).	Reduce machine vibra- tion. Improve the mounting state of the Servomotor or linear encoder.	-		
	A failure occurred in the encoder.	-	Replace the Servomo- tor or linear encoder.	-		
	A failure occurred in the SER- VOPACK.	-	Replace the SERVO- PACK.	-		

	Continued from previo						
Problem	Possible Cause	Confirmation	Correction	Reference			
Absolute Encoder Position		Check the error detec- tion section of the host controller.	Correct the error detec- tion section of the host controller.	-			
Deviation Error (The position that was		Check to see if the host controller is executing data parity checks.	Perform parity checks for the multiturn data or absolute encoder posi- tion data.	-			
saved in the host con- troller when the power was turned OFF is dif- ferent from the posi- tion when the power was next turned ON.)	Host Controller Multiturn Data or Absolute Encoder Position Data Reading Error	Check for noise interfer- ence in the cable between the SERVO- PACK and the host con- troller.	Implement counter- measures against noise and then perform parity checks again for the multiturn data or abso- lute encoder position data.	-			
		Check the external power supply (+24 V) voltage for the input signals.	Correct the external power supply (+24 V) voltage for the input signals.	-			
	The P-OT/N-OT (Forward Drive Prohibit or Reverse Drive Prohibit) signal was input.	Check the operating con- dition of the overtravel limit switches.	Make sure that the overtravel limit switches operate correctly.	-			
		Check the wiring of the overtravel limit switches.	Correct the wiring of the overtravel limit switches.	page 5-29			
		Check the settings of the overtravel input signal allocations (Pn50A/Pn50B or Pn590/Pn591).	Set the parameters to correct values.	page 5-29			
		Check for fluctuation in the external power supply (+24 V) voltage for the input signals.	Eliminate fluctuation from the external power supply (+24 V) voltage for the input signals.	-			
Overtravel	The P-OT/N-OT (Forward Drive Prohibit or Reverse Drive Prohibit) signal mal- functioned.	Check to see if the opera- tion of the overtravel limit switches is unstable.	Stabilize the operating condition of the over- travel limit switches.	-			
Occurred		Check the wiring of the overtravel limit switches (e.g., check for cable damage and loose screws).	Correct the wiring of the overtravel limit switches.	-			
	There is a mistake in the allo- cation of the P-OT or N-OT (Forward Drive Prohibit or	Check to see if the P-OT signal is allocated in Pn50A = $n.X\Box\Box\Box$ .	If another signal is allo- cated in Pn50A =n.X□□□, allocate the P-OT signal instead.	nage 5-29			
	Reverse Drive Prohibit) sig- nal in Pn50A = n.X□□□ or Pn50B = n.□□□X.	Check to see if the N-OT signal is allocated in Pn50B = $n.\Box\Box\BoxX$ .	If another signal is allo- cated in Pn50B =n.□□□X, allocate the N-OT signal instead.	page 0 20			
	The selection of the Servo- motor stopping method is	Check the servo OFF stopping method set in $Pn001 = n.\Box\BoxX$ or $Pn001 = n.\Box\BoxX\Box$ .	Select a Servomotor stopping method other than coasting to a stop.	page 5-30			
	not correct.	Check the torque control stopping method set in Pn001 = $n.\Box\BoxX$ or Pn001 = $n.\Box\BoxX\Box$ .	Select a Servomotor stopping method other than coasting to a stop.				

Problem	Possible Cause	Confirmation	Correction	Reference
Improper Stop Posi-	The limit switch position and dog length are not appropriate.	_	Install the limit switch at the appropriate position.	-
Overtravel (OT) Signal	The overtravel limit switch position is too close for the coasting distance.	_	Install the overtravel limit switch at the appropriate position.	-
Position Deviation (without Alarm)	Noise interference occurred because of incorrect Encoder Cable specifications.	Check the Encoder Cable to see if it satisfies speci- fications. Use shielded twisted-pair cables or screened twisted-pair cables with conductors of at least 0.12 mm <sup>2</sup> (stranded wire).	Use cables that satisfy the specifications.	-
	Noise interference occurred because the Encoder Cable is too long.	Check the length of the Encoder Cable.	<ul> <li>Rotary Servomotors: The Encoder Cable length must be 50 m max.</li> <li>Linear Servomotors: Make sure that the Serial Converter Unit cable is no longer than 20 m and that the Linear Encoder Cable and the Sensor Cable are no longer than 15 m each.</li> </ul>	-
	Noise interference occurred because the Encoder Cable is damaged.	Check the Encoder Cable to see if it is pinched or the sheath is damaged.	Replace the Encoder Cable and correct the cable installation envi- ronment.	-
	The Encoder Cable was sub- jected to excessive noise interference.	Check to see if the Encoder Cable is bundled with a high-current line or installed near a high-cur- rent line.	Correct the cable lay- out so that no surge is applied by high-current lines.	-
	There is variation in the FG potential because of the influence of machines on the Servomotor side, such as a welder.	Check to see if the machines are correctly grounded.	Properly ground the machines to separate them from the FG of the encoder.	-
	There is a SERVOPACK pulse counting error due to noise.	Check to see if there is noise interference on the I/O signal line from the encoder or Serial Con- verter Unit.	Implement counter- measures against noise for the encoder wiring or Serial Converter Unit wiring.	-
	The encoder was subjected to excessive vibration or shock.	Check to see if vibration from the machine occurred. Check the Servomotor installation (mounting sur- face precision, securing state, and alignment). Check the linear encoder installation (mounting sur- face precision and secur- ing method).	Reduce machine vibra- tion. Improve the mounting state of the Servomotor or linear encoder.	-
	The coupling between the machine and Servomotor is not suitable.	Check to see if position offset occurs at the cou- pling between machine and Servomotor	Correctly secure the coupling between the machine and Servomotor.	-

Continued from previous page.

Problem	Possible Cause	Confirmation	Correction	Reference
Position Deviation (without Alarm)	Noise interference occurred because of incorrect I/O signal cable specifications.	Check the I/O signal cables to see if they sat- isfy specifications. Use shielded twisted-pair cables or screened twisted-pair cables with conductors of at least 0.12 mm <sup>2</sup> (stranded wire).	Use cables that satisfy the specifications.	-
	Noise interference occurred because an I/O signal cable is too long.	Check the lengths of the I/O signal cables.	The I/O signal cables must be no longer than 3 m.	-
	An encoder fault occurred. (The pulse count does not change.)	_	Replace the Servomo- tor or linear encoder.	-
	A failure occurred in the SER- VOPACK.	-	Replace the SERVO- PACK.	-
	The surrounding air tempera- ture is too high.	Measure the surrounding air temperature around the Servomotor.	Reduce the surround- ing air temperature to 40°C or less.	-
	The surface of the Servomo- tor is dirty.	Visually check the surface for dirt.	Clean dirt, dust, and oil from the surface.	-
Servomotor Overheated	There is an overload on the Servomotor.	Check the load status with a monitor.	If the Servomotor is overloaded, reduce the load or replace the Servo Drive with a SERVOPACK and Ser- vomotor with larger capacities.	-
	Polarity detection was not performed correctly.	Check to see if electrical angle 2 (electrical angle from polarity origin) at any position is between $\pm 10^{\circ}$ .	Correct the settings for the polarity detection- related parameters.	-

Continued from previous page.

# **Parameter Lists**

This chapter provides information on the parameters.

(11)

11.1	List o	f Servo Parameters 11-2
	11.1.1 11.1.2	Interpreting the Parameter Lists11-2List of Servo Parameters11-3
11.2	List of	MECHATROLINK-III Common Parameters 11-53
	11.2.1 11.2.2	Interpreting the Parameter Lists
		Parameters11-53
11.3	Paran	neter Recording Table

11.1.1 Interpreting the Parameter Lists

## **11.1 List of Servo Parameters**

## 11.1.1 Interpreting the Parameter Lists



### 11.1.2 List of Servo Parameters

The following table lists the parameters.

- Note: Do not change the following parameters from their default settings.
  Reserved parameters
  Parameters not given in this manual
  Parameters that are not valid for the Servomotor that you are using, as given in the parameter table

Parameter No.	Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence	
	2	Basic Fund tions 0	ction Selec-	0000 to 10B1	-	0000	All	After restart	Setup	_	
	Rotation Direction Selection										
			Movemen	lovement Direction Selection						ence	
				Use CCW as the f	orward dir	ection.					
		n.🗆🗆 X	0	Use the direction ward direction.	in which th	ne linear er	coder counts	up as the fo	r-	- 10	
				Use CW as the fo	rward dire	ction. (Rev	erse Rotation	Mode)	page :	0-10	
Pn000			1	Use the direction forward direction.	in which th (Reverse I	ne linear er Movement	ncoder counts Mode)	down as the	Э		
		n.🗆 🗆 🛛	Reserved	parameter (Do no	ot change.	)					
		n.¤X¤¤	Reserved	parameter (Do no	ot change.	)					
			Rotary/Lir nected	near Servomotor	Startup Se	election W	hen Encoder	Is Not Con-	Refere	ence	
		n.XDDD	0	When an encoder Rotary Servomoto	is not cor or.	inected, st	art as SERVC	PACK for	— page !	5-15	
			1	When an encoder ear Servomotor.	is not cor	inected, st	art as SERVC	PACK for Lir	1-		
	2	Application Selections	1 Function	0000 to 1142	-	0000	All	After restart	Setup	-	
			Motor Sto	pping Method for	r Servo Of	FF and Gro	oup 1 Alarms		Refere	ence	
			0	Stop the motor by applying the dynamic brake.							
		n.□□□X	1	Stop the motor by the applying dynamic brake and then release the dynamic brake.					page 5	5-37	
				-							
			2	Coast the motor t	o a stop w	ithout the	dynamic brak	e.			
			2 Overtrave	Coast the motor to I Stopping Metho	o a stop w d	ithout the	dynamic brak	е.	Refere	ence	
			2 Overtrave 0	Coast the motor t I Stopping Metho Apply the dynamic stopping method	o a stop w d brake or set in Pn0	coast the	dynamic brak motor to a sto JDX).	e. op (use the	Refere	ence	
			2 Overtrave 0 1	Coast the motor to I Stopping Metho Apply the dynamic stopping method Decelerate the mo- the maximum torc	o a stop w d c brake or set in Pn00 otor to a st jue and the	coast the 01 = $n.\Box\Box$ op using the servo-lo	dynamic brak motor to a sto IDX). he torque set ock the motor.	e. op (use the in Pn406 as	Refere	ence	
Pn001		n.00X0	2 Overtrave 0 1 2	Coast the motor to I Stopping Metho Apply the dynamic stopping method Decelerate the mo- the maximum torc Decelerate the mo- the maximum torc	d c brake or set in Pn00 otor to a st jue and the otor to a st jue and the	ithout the coast the $01 = n.\square\square$ op using the op using the op using the op using the op using the	dynamic brak motor to a sto IIX). he torque set ock the motor. he torque set notor coast.	e. op (use the in Pn406 as in Pn406 as	Refere	ence	
Pn001		n.00X0	2 Overtrave 0 1 2 3	Coast the motor to I Stopping Method Apply the dynamic stopping method Decelerate the mo- the maximum torc Decelerate the mo- the maximum torc Decelerate the mo- Pn30A and then s	d c brake or set in Pn00 otor to a st jue and the otor to a st jue and the otor to a st jue and the otor to a st ervo-lock	coast the 01 = n. op using the op using the op using the op using the op using the the motor.	dynamic brak motor to a sto IDX). he torque set ock the motor. he torque set notor coast. he deceleratic	e. op (use the in Pn406 as in Pn406 as in time set in	Page 8	ence 5-30	
Pn001		n.00X0	2 Overtrave 0 1 2 3 4	Coast the motor to I Stopping Metho Apply the dynamic stopping method Decelerate the mo- the maximum torc Decelerate the mo- Pn30A and then s Decelerate the mo- Pn30A and then k	d c brake or set in Pn00 otor to a st jue and the otor to a st jue and the otor to a st ervo-lock otor to a st ervo-lock	coast the 01 = n. op using the op using the op using the op using the the motor. op using the op using the	dynamic brak motor to a sto IDX). he torque set notor coast. he deceleration	e. op (use the in Pn406 as in Pn406 as on time set in on time set in	page 5	ance	
Pn001		n.□□X□	2     Overtrave     0     1     2     3     4	Coast the motor to I Stopping Method Apply the dynamic stopping method Decelerate the mo the maximum torc Decelerate the mo Decelerate the mo Decelerate the mo Decelerate the mo Decelerate the mo Decelerate the mo Pn30A and then le	d c brake or set in Pn00 otor to a st jue and the otor to a st jue and the otor to a st ervo-lock is otor to a st et the moto AC/DC In	coast the D1 = n. op using the op using the op using the op using the the motor. op using the pr coast.	dynamic brak motor to a sto IDX). he torque set notor coast. he deceleration he deceleration	e. op (use the in Pn406 as in Pn406 as on time set in on time set in	page 5	5-30 ence	
Pn001		n.□□X□	2Overtrave01234Main Circo0	Coast the motor to I Stopping Method Apply the dynamic stopping method Decelerate the mo- the maximum torce Decelerate the mo- Pn30A and then se Decelerate the mo- Pn30A and the sec Decelerate the mo- Decelerate the mo- Dn30A and the sec Dn30A and the sec Dn30A an	d c brake or set in Pn00 otor to a st jue and the otor to a st jue and the otor to a st ervo-lock otor to a st et the moto AC/DC In s the main do not use	coast the i coast the i op using the op using the op using the op using the the motor. op using the the motor. op using the put Select circuit powers and compared to op using the compared	dynamic brak motor to a sto JIX). he torque set notor coast. he deceleration he deceleration he deceleration ver supply using porverter).	e. op (use the in Pn406 as in Pn406 as on time set in on time set in on time set in	page 5	5-30 2000	
Pn001		n.□X□ All Axes	2Overtrave01234Main Circ01	Coast the motor to I Stopping Method Apply the dynamic stopping method Decelerate the motor the maximum torce Decelerate the motor Pn30A and then so Decelerate the motor Pn30A and then so Decelerate the motor Pn30A and then so Decelerate the motor Input AC power as and L3 terminals ( Input DC power as and $\ominus$ 2 terminals converter or the so	d c brake or set in Pn00 botor to a st jue and the botor to a st jue and the botor to a st ervo-lock botor to a st ervo-lock botor to a st et the motor AC/DC In s the main do not use s the main s or the B1 hared com	ithout the coast the p $01 = n.\square \square$ op using the op using the op using the op using the the motor. op using the the motor. op using the correction of the or coast. <b>put Select</b> circuit pow e shared correction of the circuit pow l and $\bigcirc 2$ verter).	dynamic brak motor to a sto IDX). he torque set notor coast. he deceleration he deceleration ver supply usin ponverter). wer supply usin terminals (use	e. op (use the in Pn406 as in Pn406 as in Pn406 as in time set in on time set in ng the L1, L2 ng the B1/ e an external	Page 8	5-30 5-13	

11

								Con	tinued from	n previou	s page.	
Parameter No.	Size	N	Name		Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence	
	2	Application Selections	r Function 2		0000 to 4213	-	0011	-	After restart	Setup	-	
			MECHAT Option	ROL	DLINK Command Position and Speed Control			ed Control	Applicable Motors	Refere	ence	
			0	Res	erved setting (	Do not us	e.)					
		n.🗆 🗆 🗆 X	1	Use	TLIM as the t	orque limit			A 11	*1		
			2	Reserved setting (Do not use.)					All	.1	1	
			3	Reserved setting (Do not use.)								
			Torque C	Control Option					Applicable Motors	Refere	ence	
Pn002		n.🗆🗆 X 🗆	0	Res	erved setting (	Do not us	e.)					
			1	Use the speed limit for torque control (VLIM) as the speed limit.				All	*1	*1		
	Ī		Encoder	Usa	ge				Applicable Motors	Refere	ence	
		n.¤X¤¤	0	Use tion	e the encoder a s.	according	to encode	r specifica-	All			
			1	Use	the encoder a	as an incre	mental en	coder.		page	6-27	
			2	Use enc	e the encoder a oder.	as a single	-turn abso	lute	Rotary			
		n.XDDD	Reserved	pa	rameter (Do no	ot change	)					

Continued from previous page.

Parameter No.	Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence		
	2	Application Selections	Function 6	0000 to 105F	-	0002	All	Immedi- ately	Setup	page 9-8		
						I.		l				
	Ī		Analog Mo	nitor 1 Signal S	election							
				Motor speed (1	V/1,000 m	nin <sup>-1</sup> )						
			00	Motor speed (1	V/1,000 m	nm/s)						
			01	Speed reference	e (1 V/1,00	00 min <sup>-1</sup> )						
			01	Speed reference	e (1 V/1,00	)0 mm/s)						
			02	Torque reference	ce (1 V/100	% rated to	rque)					
			02	Force reference	e (1 V/100%	6 rated for	ce)					
			03	Position deviat	on (0.05 V/	reference	unit)					
				Position amplif	er deviatior	n (after eleo	ctronic gear) (	0.05 V/enco	der pulse	unit)		
			04	Position amplif pulse unit)	er deviatior	n (after eleo	ctronic gear) (	0.05 V/linea	r encoder			
			05	Position referer	nce speed (	1 V/1,000	min <sup>-1</sup> )					
			05	Position referer	nce speed (	1 V/1,000	mm/s)					
			06	Reserved settir	ng (Do not i	use.)						
Pn006 All Axes		n.□□XX	07	Reserved settir	ng (Do not i	use.)						
			08	Positioning cor pleted: 0 V)	npletion (po	ositioning c	completed: 5	V, positioninę	g not com	-		
		-	00	Speed feedforward (1 V/1,000 min <sup>-1</sup> )								
			03	Speed feedforward (1 V/1,000 mm/s)								
			0.0	Torque feedforward (1 V/100% rated torque)								
			UA	Force feedforward (1 V/100% rated force)								
			0B	Active gain (1s	gain: 1 V,	2nd gain: 2	2 V)					
			OC	Completion of pleted: 0 V)	position ref	erence dis	tribution (com	pleted: 5 V,	not com-			
			0D	Reserved settir	ng (Do not ι	use.)						
			0E	Reserved settir	ng (Do not u	use.)						
			0F	Reserved settir	ng (Do not u	use.)						
			10	Main circuit DC	voltage							
			11 to 5F	Reserved settir	igs (Do not	use.)						
		n.¤X¤¤	Reserved	oarameter (Do r	ot change	.)						
			Output Axis Selection									
		n.XDDD	0	Output axis A data.								
			1	Output axis B	lata.							
	-											

Continued on next page.

			Continued from previous page.										
Parameter No.	Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence			
	2	Application Selections	n Function 7	0000 to 105F	_	0000	All	Immedi- ately	Setup	page 9-8			
			Analog Mor	itor 2 Signal Se	election								
			00	Motor speed (1	V/1,000 m	nin <sup>-1</sup> )							
					v/1,000 II	$\frac{11173}{20}$							
			01	Speed reference	) (1 )//1,00	0  mm(a)							
				Speed reference	= (1 V/1,00	0/ rotod to							
			02			/ rated for							
			03		$\frac{(1 \sqrt{100})}{(1 \sqrt{100})}$	reference							
			00	Position amplifie	r deviation		ctronic dear) (	0.05.V/encc	dar nulsa	unit)			
			04	Position amplifie	er deviation	n (after elec	ctronic gear) (	0.05 V/linea	r encoder				
				Position referen	re sneed (	1 V/1 000	min <sup>-1</sup> )						
			05	Position referen	ce speed (	speed (1 V/1,000 mm/s)							
			06	Reserved setting	a (Do not i	use.)							
		n.□□XX	07	Reserved setting	a (Do not i	use.)							
Pn007 All Axes			08	Positioning com pleted: 0 V)	pletion (po	ositioning c	completed: 5	V, positionin	g not com	-			
				Speed feedforward (1 V/1,000 min <sup>-1</sup> )									
			09	Speed feedforward (1 V/1,000 mm/s)									
				Torque feedforward (1 V/100% rated torque)									
			0A	Force feedforwa	ard (1 V/10	0% rated	force)						
			0B	Active gain (1st	gain: 1 V,	2nd gain: 2	2 V)						
			0C	Completion of p pleted: 0 V)	osition ref	erence dis <sup>.</sup>	tribution (com	pleted: 5 V,	not com-				
			0D	Reserved setting	g (Do not i	use.)							
			0E	Reserved setting	g (Do not i	use.)							
			0F	Reserved setting	g (Do not i	use.)							
			10	Main circuit DC	voltage								
			11 to 5F	Reserved setting	gs (Do not	use.)							
		n.¤X¤¤	Reserved p	arameter (Do no	ot change	.)							
			Output Axis	Selection									
		n.XDDD	0	Output axis A d	ata.								
			1	Output axis B d	ata.								

Continued from previous page.

Parameter No.       Name       Setting Range       Default Unit       Applicable Motors       When Enabled fication       Classification         2       Application Function Selections 8       0000 to 7121       -       4000       Rotary       After restart       Setup         n.□□□X       0       Output alarm (A.830) for low battery voltage.	Refer- ence - nce 0-2 nce
2       Application Function Selections 8       0000 to 7121       -       4000       Rotary       After restart       Setup         n.□□□X       Low Battery Voltage Alarm/Warning Selection       Refere page 1       Refere page 1       Page 1         0       Output alarm (A.830) for low battery voltage.       page 1       Page 1         1       Output warning (A.930) for low battery voltage.       Page 1         0       Do not detect undervoltage       Refere         0       Do not detect undervoltage.       Page 1         1       Detect undervoltage warning and limit torque at host controller.       Page 6         2       Detect undervoltage warning and limit torque with Pn424 and Pn425 (i.e., only in SERVOPACK).       Page 6	nce 0-2 nce
Image: Non-Doc	nce
Low Battery Voltage Alarm/Warning Selection       Reference         0       Output alarm (A.830) for low battery voltage.       page 1         1       Output warning (A.930) for low battery voltage.       page 1         1       Output warning (A.930) for low battery voltage.       page 1         0       Do not detect undervoltage       Reference         0       Do not detect undervoltage.       Photos         1       Detect undervoltage warning and limit torque at host controller.       page 1         2       Detect undervoltage warning and limit torque with Pn424 and Pn425 (i.e., only in SERVOPACK).       page 1	nce
n.□□□X       0       Output alarm (A.830) for low battery voltage.       page 1         1       Output warning (A.930) for low battery voltage.       page 1         n.□□X□       Function Selection for Undervoltage       Reference         0       Do not detect undervoltage.       page 1         1       Detect undervoltage warning and limit torque at host controller.       page 6         2       Detect undervoltage warning and limit torque with Pn424 and Pn425 (i.e., only in SERVOPACK).       page 6	0-2 nce
Image: Non-Domain Non-Do	nce
Function Selection for Undervoltage       Reference         0       Do not detect undervoltage.       Physical Processor         1       Detect undervoltage warning and limit torque at host controller.       Physical Processor         2       Detect undervoltage warning and limit torque with Ph424 and Ph425 (i.e., only in SERVOPACK).       Physical Processor	nce
Pn008       0       Do not detect undervoltage.       page 6         1       Detect undervoltage warning and limit torque at host controller.       page 6         2       Detect undervoltage warning and limit torque with Pn424 and Pn425 (i.e., only in SERVOPACK).       page 6	
Pn008       n.□□X□       1       Detect undervoltage warning and limit torque at host controller.       page 6         2       Detect undervoltage warning and limit torque with Pn424 and Pn425 (i.e., only in SERVOPACK).       page 6	
2         Detect undervoltage warning and limit torque with Pn424 and Pn425 (i.e., only in SERVOPACK).	-18
Warning Detection Selection Refere	nce
n. IXIII 0 Detect warnings. page	10-
1Do not detect warnings except for A.971.41	
n.XDDD Reserved parameter (Do not change.)	
2Application Function Selections 90000 to 0121-0010AllAfter restartTuning	_
n. DDDX Reserved parameter (Do not change.)	
Current Control Mode Selection	
n. D X D Use current control mode 1. page 8	-71
2 Use current control mode 2.	
	ICE
Speed Detection Method Selection Refere	100
Speed Detection Method Selection         Refere           n.□X□□         0         Use speed detection 1.         Detection 1.         Detection 1.	70
N.IIXIII     Speed Detection Method Selection     Reference       0     Use speed detection 1.     page 8       1     Use speed detection 2.     Page 8	-72
Speed Detection Method Selection     Reference       0     Use speed detection 1.     page 8       1     Use speed detection 2.     page 8	-72

Continued on next page.

		Continued from previous page.											
Parameter No.	Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence			
	2	Application Selections	n Function A	0000 to 0044	-	0001	All	After restart	Setup	_			
			Motor Sto	oping Method fo	r Group 2	Alarms			Refer	ence			
			0	Apply the dynami stopping method	c brake or set in Pn(	01 = n. <b>□[</b>	motor to a st ⊐⊡X).	op (use the					
			1 [ 1	Decelerate the mo he maximum toro status after stopp	otor to a s que. Use t ing.	top using t ne setting (	the torque set of Pn001 = n.	t in Pn406 as DDDX for th	s ne				
		n.DDDX	2 [	Decelerate the me	otor to a s que and th	top using t nen let the	the torque set motor coast.	t in Pn406 as	bage	5-37			
			3 F	Decelerate the mo Pn30A. Use the s stopping.	otor to a s etting of F	top using t 2n001 = n.	the decelerati	on time set i e status afte	n r				
			4 [	Decelerate the mo Pn30A and then I	otor to a s et the mo	top using t tor coast.	the decelerati	on time set i	n				
Pn00A			Stopping I	Method for Force	ed Stops				Befer	ence			
11100/1				Apply the dynami	c brake or	coast the	motor to a st	op (use the	110101				
			0 5	topping method	set in Pn0	001 = n. <b>□</b> [	⊐□X).						
			1 [	Decelerate the me he maximum tore status after stopp	otor to a s que. Use t ing.	top using t he setting (	the torque set of Pn001 = n.	t in Pn406 as DDDX for th	s ne				
		n.🗆 🗆 X 🗆	2 [	Decelerate the me	otor to a s que and th	top using t nen let the	the torque set motor coast.	t in Pn406 as	page	6-45			
			3 F	Decelerate the mo Pn30A. Use the s stopping.	otor to a s etting of F	top using t n001 = n.	the decelerati □□□X for th	on time set i e status afte	n r				
			4 [	Decelerate the mo Pn30A and then I	otor to a s et the mo	top using t tor coast.	the decelerati	on time set i	n				
	n.□X□□ Reserved parameter (Do not change.)												
	n.XDDD Reserved parameter (Do not change.)												
	2	Application Selections	n Function B	0000 to 1121	-	0000	All	After restart	Setup	-			
						ł		•		•			
			Operator Pa	arameter Displav	Selection	ר ו			Refere	nce			
		n.DDDX	<b>0</b> Di	splay only setup	paramete	rs.							
			1 Di	splay all paramet	ters.				page (	5-3			
			Motor Stop	ping Method for	Group 2	Alarms			Refere	nce			
			0 S	top the motor by	setting th	e speed re	eference to 0.						
Pn00B		n.🗆 🗆 X 🗆	1 A st	pply the dynamic opping method s	brake or set in Pn0	coast the i	motor to a sto I□X).	op (use the	page 5	5-38			
			2 S	et the stopping n	nethod wit	:h Pn00A =	= n.□□□X.						
			Power Inpu	t Selection for T	hree-phas	e SERVO	PACK		Refere	nce			
		n.🗆X🗆 🗆	0 U:	se a three-phase	power su	pply input.							
		All Axes	1 U:	se a three-phase ipply input.	power su	pply input	as a single-pl	nase power	page 5	-13			
		n.X000	Reserved p	arameter (Do no	t change.								

Continued from previous page.

Continued from previous page.

Parameter	Size	N	ame		Setting Bange	Setting Unit	Default Setting	Applicable	When	Classi-	Refer-		
	2	Application Selections	n Function C	n	0000 to 0131	-	0000	-	After restart	Setup	page 7-21		
								L	I				
			Functio	n Sele	ection for Test	without a	Motor			Applical Motor	ble s		
		n.□□□X	0	Disa	able tests with	out a moto	or.			All			
			1	Ena	ble tests witho	out a moto	r.						
			Encode	r Res	olution for Tes	ts without	a Motor			Applicable Motors			
Pn00C			0	Use	e 13 bits.								
111000		11.00/0	1	Use	e 20 bits.					Rotar	v		
			2	Use	22 bits.					-	, ,		
			3	Use	e 24 bits.								
			Encoder Type Selection for Tests without a Motor								ble s		
			0 Use an incremental encoder.							All			
			1	Use	e an absolute e								
		n.XDDD	Reserve	ed par	ameter (Do no	ot change.	)						
	2	Application Selections	n Function D	n	0000 to 1001	-	0000	All	After restart	Setup	page 5-32		
F													
		n.DDDX	Reserve	ed par	ameter (Do no	ot change.	.)						
Pn00D		n.🗆🗆 X 🗆	IDXD Reserved parameter (Do not change.)										
		n.□X□□ Reserved parameter (Do not change.)											
			Overtravel Warning Detection Selection										
		n.XDDD	0	Do	not detect ove	rtravel wa	rnings.						
			1	Det	ect overtravel	warnings.							
	2	Application Selections	n Function	n	0000 to	-	0000	All	After	Setup	_		
		OCICCIONS	1		2011				lostart				
			Provent	ativo	Maintenance	Narning S	election			Reference			
		n.DDDX	0		ot detect preve	entative ma	aintenance	warnings.		Tererene			
Pn00F			1	Dete	ct preventative	maintena	nce warnir	igs.		page 9-	15		
All Axes						1	1						
			Reserve	ed par	ameter (Do no	ot change.	.)						
		n.¤X¤¤	. DXDD Reserved parameter (Do not change.)										
		n.XDDD	Reserve	ed par	rameter (Do no	ot change.	)						
						1		1		1			
Pn021	2	Reserved p not change	paramete e.)	r (Do	-	-	0000	All	-	-	_		

Continued on next page.

	Continued from previous page.										
Parameter No.	Size	Ν	lame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence	
	2	Application Selections	n Function 80	0000 to 1111	_	0000	Linear	After restart	Setup	-	
			Polarity Sens	or Selection					Refere	nce	
	n	.000X	0 Use	polarity senso	r.				page 5	5-25	
			1 Do	not use polarity	sensor.						
Pn080			Motor Phase	Sequence Sele	ection				Reference		
	n	.00X0	0 Set	a phase-A lead	l as a pha	se sequen	ce of U, V, an	d W.	page 5	5-23	
			1 Set	a phase-B lead	l as a pha	se sequen	ce of U, V, an	d W.	page 3-20		
	n	.0X00	Reserved par	ameter (Do no	t change.)						
	n	ХППП	Reserved par	ameter (Do no	t change )						
					t onlange.)						
Pp100	0	Speedlo	on Coin	10 to 20 000	0147	400	All	Immedi-	Tuning	page	
FILLO	2	Speed Loo		10 10 20,000	0.1112	400	All	ately	Turning	8-79	
Pn101	2	Speed Loo Time Cons	op Integral stant	15 to 51,200	0.01 ms	2000	All	Immedi- ately	Tuning	page 8-79	
Pn102	2	Position L	oop Gain	10 to 20,000	0.1/s	400	All	Immedi- ately	Tuning	page 8-79	
Pn103	2	Moment o	f Inertia Ratio	0 to 20,000	1%	100	All	Immedi- ately	Tuning	page 8-79	
Pn104	2	Second S Gain	peed Loop	10 to 20,000	0.1 Hz	400	All	Immedi- ately	Tuning	page 8-66	
Pn105	2	Second S Integral Ti	peed Loop me Constant	15 to 51,200	0.01 ms	2000	All	Immedi- ately	Tuning	page 8-66	
Pn106	2	Second Pe Gain	osition Loop	10 to 20,000	0.1/s	400	All	Immedi- ately	Tuning	page 8-66	
Pn109	2	Feedforwa	ard	0 to 100	1%	0	All	Immedi- ately	Tuning	page 8-89	
Pn10A	2	Feedforwa Constant	ard Filter Time	0 to 6,400	0.01 ms	0	All	Immedi- ately	Tuning	page 8-89	

Continued from previous page.

Parameter No.	Size	N	ame		Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence	
	2	Gain Applie	cation Seleo	C-	0000 to 5334	-	0000	All	-	Setup	_	
			Mode Sw	itchi	ing Selection				When Enable	d Refere	ence	
			0	Use (leve	the internal to al setting: Pn1	orque refer 0C).	ence as th	e condition				
			1	Use ting:	the speed ref : Pn10D).	erence as	the condit	ion (level set-				
		n.000X		Use ting:	the speed ref : Pn181).	erence as	the condit	ion (level set-				
			2	Use setti	the accelerati ing: Pn10E).	on referen	ce as the	condition (leve	ately	- page 8	3-90	
Pn10B				Use sett	the accelerati ing: Pn182).	on referen	ce as the	condition (leve	el			
			3	Use ting	the position c : Pn10F).	leviation a	s the cond	lition (level set	-			
			4	Do r	not use mode	switching.						
			Speed Lo	op (	Control Metho	d			When Enabled	d Refere	Reference	
		n.🗆🗆 X 🗆	0 PI con 1 I-P con 2 to 3 Reserved		ontrol		After	0000	2 70			
			2 to 3 Reserved paral		erved settings	(Do not u	se.)		restart	page	5-79	
		n.¤X¤¤	□ Reserved parar		ameter (Do no	ot change.	.)					
		n.XDDD	Reserved	par	ameter (Do no	ot change.	)					
							1					
Pn10C	2	Mode Swit for Torque	ching Level Reference	I	0 to 800	1%	200	All	Immedi- ately	Tuning	page 8-90	
Pn10D	2	Mode Swit for Speed	ching Level Reference	I	0 to 10,000	1 min <sup>-1</sup>	0	Rotary	Immedi- ately	Tuning	page 8-90	
Pn10E	2	Mode Swit for Acceler	ching Level ration	I	0 to 30,000	1 min <sup>-1</sup> /s	0	Rotary	Immedi- ately	Tuning	page 8-90	
Pn10F	2	Mode Swit for Position	ching Level Deviation	I	0 to 10,000	1 refer- ence unit	0	All	Immedi- ately	Tuning	page 8-90	
Pn11F	2	Position In Constant	tegral Time		0 to 50,000	0.1 ms	0	All	Immedi- ately	Tuning	page 8-92	
Pn121	2	Friction Cc Gain	ompensation	n	10 to 1,000	1%	100	All	Immedi- ately	Tuning	page 8-66, page 8-70	
Pn122	2	Second Fri pensation	iction Com- Gain	-	10 to 1,000	1%	100	All	Immedi- ately	Tuning	page 8-66, page 8-70	
Pn123	2	Friction Co Coefficient	ompensation	n	0 to 100	1%	0	All	Immedi- ately	Tuning	page 8-70	
Pn124	2	Friction Co Frequency	mpensation Correction	n	-10,000 to 10,000	0.1 Hz	0	All	Immedi- ately	Tuning	page 8-70	
Pn125	2	Friction Co Gain Corre	mpensation ection	n	1 to 1,000	1%	100	All	Immedi- ately	Tuning	page 8-70	
Pn131	2	Gain Switc	hing Time <sup>-</sup>	1	0 to 65,535	1 ms	0	All	Immedi- ately	Tuning	page 8-66	
Pn132	2	Gain Switc	ching Time 2	2	0 to 65,535	1 ms	0	All	Immedi- ately	Tuning	page 8-66	
Pn135	2	Gain Switc Time 1	hing Waitin	tion Com- ain 10 pensation 10 pensation -1 pensation 1 pensation 1 ng Time 1 0 t ng Time 2 0 t ng Waiting 0 t		1 ms	0	All	Immedi- ately	Tuning	page 8-66	
Pn136	2	Gain Switc Time 2	hing Waitin	g	0 to 65,535	1 ms	0	All	Immedi- ately	Tuning	page 8-66	

Continued on next page.

							Cor	ntinued from	n previou	s page.		
Parameter No.	Size	N	lame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence		
	2	Automatic	Gain Switch-	0000 to	-	0000	All	Immedi- ately	Tuning	page 8-66		
				0002				utory		0.00		
			Gain Switch	ning Selection								
			0 TI	se manual gain s ne gain is switch als (SVCMD_IO).	switching. ed manua	lly with G-	SEL in the se	rvo comman	d output s	ig-		
		n.🗆🗆 🗆 X	1 R	eserved setting (	Do not us	e.)						
			2 U 3 5 5	se automatic gai ne gain is switch witching conditic econd gain to the	in switchir ed automa n A is sati e first gain	ng pattern atically fron sfied. The when swit	1. n the first gair gain is switch ching conditi	n to the seco ned automatio on A is not s	nd gain w cally from atisfied.	hen the		
Pn139			Gain Switch	ning Condition A	4							
			0 /0	COIN (Positioning	g Complet	ion Output	) signal turns	ON.				
			1 /0	COIN (Positioning	g Complet	ion Output	) signal turns	OFF.				
		n.🗆🗆 X 🗆	2 //	IEAR (Near Outp	out) signal	turns ON.						
			3 /٢	IEAR (Near Outp	out) signal	turns OFF.						
			4 P	osition reference	filter outp	out is 0 and	l position refe	rence input i	s OFF.			
			5 P	osition reference	input is C	N.						
		n.¤X¤¤	Reserved p	arameter (Do no	ot change	.)						
		n.XDDD	Reserved p	arameter (Do no	ot change	.)						
Pn13D	2	Current Ga	ain Level	100 to 2,000	Immedi- ately	Tuning	page 8-72					
	2	Model Foll trol-Relate	owing Con- d Selections	0000 to 1121	-	0100	All	Immedi- atelv	Tuning	-		
								,				
			Model Follo	wing Control Se	election				Referer	ice		
		n.DDDX	0 Do	Do not use model following control.								
			1 Use	1 Use model following control.								
			Vibration Suppression Selection Refere									
			<b>0</b> Do									
			1 Per	form vibration su	uppressior	n for a spe	cific frequenc	у.	page 8-	79		
			2 Per	form vibration su	uppressior	n for two sp	pecific freque	ncies.				
Pn140			Vibration S	uppression Adiu	stment S	election			Referer	ice		
		n.OXOO	0 tio	o not adjust vibron of autotuning	ation supp without a	pression au host refere tuning.	tomatically du ence, autotun	uring execu- ing with a				
			1 A	djust vibration su utotuning withou rence, and custo	uppressior t a host re m tuning.	automatic ference, a	cally during ex utotuning with	kecution of n a host ref-	page 8-	.31		
						16				_		
			Speed Feed	a not upo model		edforward	(TFF) Selecti	ion	Referer	ice		
		n.XDDD	0	ard together.	lollowing	control and	u speed/torqt	ne leegiol-		0.1		
			1 U	se model followi	ng control	and speed	d/torque feed	forward	page 8-	31		
Pn141	2	Model Foll trol Gain	owing Con-	10 to 20,000	0.1/s	500	All	Immedi- ately	Tuning	page 8-79		
Pn142	2	Model Foll trol Gain C	owing Con- Correction	500 to 2,000	0.1%	1000	All	Immedi- ately	Tuning	page 8-66		
Pn143	2	Model Foll trol Bias in Direction	owing Con- the Forward	0 to 10,000	0.1%	1000	All	Immedi- ately	Tuning	page 8-79		

Continued from previous page
------------------------------

								i pi o no a	e page.
Parameter No.	Size	Name	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
Pn144	2	Model Following Con- trol Bias in the Reverse Direction	0 to 10,000	0.1%	1000	All	Immedi- ately	Tuning	page 8-79
Pn145	2	Vibration Suppression 1 Frequency A	10 to 2,500	0.1 Hz	500	All	Immedi- ately	Tuning	page 8-55
Pn146	2	Vibration Suppression 1 Frequency B	10 to 2,500	0.1 Hz	700	All	Immedi- ately	Tuning	page 8-55
Pn147	2	Model Following Con- trol Speed Feedforward Compensation	0 to 10,000	0.1%	1000	All	Immedi- ately	Tuning	page 8-79
Pn148	2	Second Model Follow- ing Control Gain	10 to 20,000	0.1/s	500	All	Immedi- ately	Tuning	page 8-66
Pn149	2	Second Model Follow- ing Control Gain Correc- tion	500 to 2,000	0.1%	1000	All	Immedi- ately	Tuning	page 8-66
Pn14A	2	Vibration Suppression 2 Frequency	10 to 2,000	0.1 Hz	800	All	Immedi- ately	Tuning	page 8-55
Pn14B	2	Vibration Suppression 2 Correction	10 to 1,000	1%	100	All	Immedi- ately	Tuning	page 8-55
	2	Control-Related Selec- tions	0000 to 0021	_	0021	All	After restart	Tuning	_

			Model Fo	Model Following Control Type Selection									
		n.🗆🗆 🗆 X	0	Use	e model followir	ng control	type 1.			0000	2 90		
			1	Use	e model followir	ng control	type 2.			page of	5-09		
			Tuning-le	ess T	vpe Selection					Refere	ence		
Pn14F			0	Use	e tuning-less ty	pe 1.							
		n.□□X□	1	Use	e tuning-less ty	pe 2.				page 8	3-13		
			2	Use	e tuning-less ty	ре 3.							
		n.¤X¤¤	Reserved	d par	rameter (Do no	ot change.	)						
	n.XDDD Reserved parameter (Do not change.)												
	2	Anti-Resor trol-Related	nance Con- d Selections		0000 to 0011	-	0010	All	Immedi- ately	Tuning	-		
			Anti-Res	onar	nce Control Se	lection				Refere	ence		
		n.🗆🗆 🗆 X	0	Do	not use anti-re	sonance c	ontrol.			nage 8	3-50		
			1	Use	e anti-resonanc	e control.				pago			
			Anti-Res	onar	nce Control Ad	justment	Selection			Refere	ence		
Pn160		n.00X0	0	Do tion refe	Do not adjust anti-resonance control automatically during execu- tion of autotuning without a host reference, autotuning with a host reference, and custom tuning.								
			1	Adjust anti-resonance control automatically during execution of autotuning without a host reference, autotuning with a host reference, and custom tuning.							5-31		
		n.¤X¤¤	Reserved	d par	rameter (Do no	ot change.	)						
		n.XDDD	Reserved	d par	rameter (Do no	ot change.	)						
Pn161	2	Anti-Resor quency	nance Fre-		10 to 20,000	0.1 Hz	1000	All	Immedi- ately	Tuning	page 8-50		
Pn162	2	Anti-Resor Correction	nance Gair	۱	1 to 1,000	1%	100	All	Immedi- ately	Tuning	page 8-50		
Pn163	2	Anti-Resor ing Gain	nance Dam	-חר	0 to 300	1%	0	All	Immedi- ately	Tuning	page 8-50		

11

							Con	itinued from	n previou	s page.
Parameter No.	Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
Pn164	2	Anti-Resor Time Cons rection	ance Filter tant 1 Cor-	-1,000 to 1,000	0.01 ms	0	All	Immedi- ately	Tuning	page 8-50
Pn165	2	Anti-Resor Time Cons rection	ance Filter tant 2 Cor-	-1,000 to 1,000	0.01 ms	0	All	Immedi- ately	Tuning	page 8-50
Pn166	2	Anti-Resor ing Gain 2	nance Damp-	0 to 1,000	1%	0	All	Immedi- ately	Tuning	page 8-50
	2	Tuning-less Related Se	s Function- lections	0000 to 2711	-	1401	All	-	Setup	page 8-12
	Ī	n.000X	Tuning-less	Selection	- f				Whe Enab	en led
			1 En	able tuning-les	s function.				Afte resta	er art
			Speed Cont	rol Method					Whe Enab	en led
Pn170		n.UUXU	0 Us	e for speed cor	ntrol.	sa host co	ntroller for po	sition contro	Afte	er art
	Ī		Rigidity Leve	el					When Enabled	
		n.¤X¤¤	0 to 7 Se	t the rigidity lev	el.				Imme	edi- ly
		n.XOOO	Tuning-less	Load Level					Whe Enab	en led
			0 to 2 Se	t the load level	for the tun	ing-less fu	nction.		Imme atel	edi- ly
Pn181	2	Mode Swit for Speed	ching Level Reference	0 to 10,000	1 mm/s	0	Linear	Immedi- ately	Tuning	page 8-90
Pn182	2	Mode Swit for Acceler	ching Level ation	0 to 30,000	1 mm/s <sup>2</sup>	0	Linear	Immedi- ately	Tuning	page 8-90
Pn205	2	Multiturn L	imit	0 to 65,535	1 rev	65535	Rotary	After restart	Setup	page 6-28
	2	Position Control tion Select	ontrol Func- ions	0000 to 2210	-	0010	All	After restart	Setup	_
	I	n.DDDX	Reserved pa	arameter (Do no	ot change.	)				
		n.00X0	Reserved pa	arameter (Do no	ot change.	)				
		n.¤X¤¤	Reserved pa	arameter (Do no	ot change.	)				
Pn207			/COIN (Posi	tioning Comple	tion Outp	ut) Signal	Output Timin	g	Refe enc	er- ce
			0 Sa Wi	Itput when the a me or less than dth).	absolute v the setting	alue of the g of Pn522	position devi 2 (Positioning	ation is the Completed		
		n.X000	1 Ou an	Itput when the a less than the se d the reference	absolute v etting of Pi after the p	alue of the 1522 (Posi position ref	position erro tioning Comp erence filter is	r is the same leted Width) s 0.	e page 6	6-13
			2 Ou an	Itput when the a less than the se d the reference	absolute v etting of Pr input is 0.	alue of the 1522 (Posi	position erro tioning Comp	r is the same leted Width)	)	
Pn20E	4	Electronic (Numerato	Gear Ratio r)	1 to 1,073,741.824	1	16	All	After restart	Setup	page 5-42
Pn210	4	Electronic (Denomina	, Gear Ratio tor)	1 to 1,073,741,824	1	1	All	After restart	Setup	page 5-42

Continued from previous page.

Parameter No.	Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
	2	Position Co sion Functi	ontrol Expan- on Selections	0000 to 0001	-	0000	All	After restart	Setup	page 8-73
Pn230		n.000X	Backlash Co 0 Co 1 Co	mpensation Di mpensate forw mpensate reve	rection ard referer rse referen	nces.				
1 11230		n.00X0	Reserved pa	rameter (Do no	ot change.	.)				
		n.¤X¤¤	Reserved pa	rameter (Do no	ot change.	)				
		n.XOOO	Reserved pa	rameter (Do no	ot change.	)				
Pn231	4	Backlash (	Compensation	-500,000 to 500,000	0.1 ref- erence units	0	All	Immedi- ately	Setup	page 8-73
Pn233	2	Backlash ( tion Time (	Compensa- Constant	0 to 65,535	0.01 ms	0	All	Immedi- ately	Setup	page 8-73
Pn282	4	Linear Enc Pitch	oder Scale	0 to 6,553,600	0.01 μm	0	Linear	After restart	Setup	page 5-17
Pn304	2	Jogging Sp	beed	0 to 10,000	Rotary: 1 min <sup>-1</sup> Direct Drive: 0.1 min <sup>-1</sup>	500	Rotary	Immedi- ately	Setup	page 7-7
Pn305	2	Soft Start / Time	Acceleration	0 to 10,000	1 ms	0	All	Immedi- ately	Setup	*1
Pn306	2	Soft Start I Time	Deceleration	0 to 10,000	1 ms	0	All	Immedi- ately	Setup	*1
Pn308	2	Speed Fee Time Cons	dback Filter tant	0 to 65,535	0.01 ms	0	All	Immedi- ately	Setup	page 8-79
Pn30A	2	Deceleration Servo OFF Stops	on Time for and Forced	0 to 10,000	1 ms	0	All	Immedi- ately	Setup	page 5-31
Pn30C	2	Speed Fee Average M Time	dforward ovement	0 to 5,100	0.1 ms	0	All	Immedi- ately	Setup	page 8-89
	2	Vibration D Selections	etection	0000 to 0002	-	0000	All	Immedi- ately	Setup	page 6-37
			Vibration Det	ection Selection	n					
			0 Do	not detect vibr	ation.					
			1 Ou	tput a warning	(A.911) if v	vibration is	detected.			
Pn310			<b>2</b> Ou	tput an alarm (/	4.520) if vi	bration is o	detected.			
		n.DDXD	Reserved pa	rameter (Do no	ot change.	)				
		n.OXOO	Reserved pa	rameter (Do no	ot change.	)				
		n.XOOO	Reserved pa	rameter (Do no	ot change.	.)				
Pn311	2	Vibration D	etection Sen-	50 to 500	1%	100	All	Immedi-	Tuning	page
Pn312	2	Vibration D Level	etection	0 to 5,000	1 min <sup>-1</sup>	50	Rotary	Immedi- ately	Tuning	page 6-37
Pn316	2	Maximum	Motor Speed	0 to 65,535	1 min <sup>-1</sup>	10000	Rotary	After restart	Setup	page 6-20
Pn324	2	Moment of culation St	Inertia Cal- arting Level	0 to 20,000	1%	300	All	Immedi- ately	Setup	page 8-31
Pn383	2	Jogging Sp	beed	0 to 10,000	1 mm/s	50	Linear	Immedi- ately	Setup	page 7-7

11

								Con	tinued from	n previou	s page.
Parameter No.	Size	Na	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence	
Pn384	2	Vibration D Level	etection		0 to 5,000	1 mm/s	10	Linear	Immedi- ately	Tuning	page 6-37
Pn385	2	Maximum N	Motor Spe	əd	1 to 100	100 mm/s	50	Linear	After restart	Setup	page 6-20
Pn401	2	First Stage Reference Constant	First Torqu Filter Time	he	0 to 65,535	0.01 ms	100	All	Immedi- ately	Tuning	page 8-82
Pn402	2	Forward To	orque Limit		0 to 800	1%*2	800	Rotary	Immedi- ately	Setup	page 6-22
Pn403	2	Reverse To	rque Limit		0 to 800	1% <sup>*2</sup>	800	Rotary	Immedi- ately	Setup	page 6-22
Pn404	2	Forward Ex Limit	ternal Torc	lne	0 to 800	1% <sup>*2</sup>	100	All	Immedi- ately	Setup	page 6-23
Pn405	2	Reverse Ex Limit	ternal Toro	lne	0 to 800	1% <sup>*2</sup>	100	All	Immedi- ately	Setup	page 6-23
Pn406	2	Emergency	Stop Torc	que	0 to 800	1% <sup>*2</sup>	800	All	Immedi- ately	Setup	page 5-30
Pn407	2	Speed Limi Torque Cor	it during htrol		0 to 10,000	1 min <sup>-1</sup>	10000	Rotary	Immedi- ately	Setup	page 6-15
	2	Torque-Rel tion Selecti	ated Func- ons	-	0000 to 1111	All	_	Setup	-		
	_										
			Notch Fil	ter S	Selection 1				When Enabled	Refere	ence
		n.🗆 🗆 🗆 X	0	Disa	able first stage	notch filte	er.		Immedi	- nage 8	3-82
			1	Ena	able first stage	notch filte	r.		ately	page c	
			Speed Li	mit \$	Selection				When Enabled	Refere	ence
				Use	e the smaller of	the maxim	е				
			0	Use	the smaller of	the maxim	е				
Pn408				sett Use	ting of Pn480 a e the smaller of	the spear the overs	After restart	page 6	8-15		
			1 -	spe	ed and the set	ting of Pn	407 as the	speed limit.			
				spe	ed and the set	ting of Pn					
			Notch Fil	ter S	Selection 2				When Enabled	Refere	ence
		n.¤X¤¤	0	Disa	able second st	age notch	filter.		Immedi	- page 8	3-82
			1	Ena	able second sta	age notch	filter.		ately	13	
			Friction C	Com	pensation Fun	ction Sele	ection		When Enabled	Refere	ence
		n.XDDD	0	Disa	able friction co	mpensatic	n.		Immedi	- page 8	3-70
			1	Ena	able friction cor	npensatio	n.		atery		
Pn409	2	First Stage Frequency	Notch Filt	er	50 to 5,000	1 Hz	5000	All	Immedi- ately	Tuning	page 8-82
Pn40A	2	First Stage Q Value	Notch Filt	er	50 to 1,000	0.01	70	All	Immedi- ately	Tuning	page 8-82
Pn40B	2	First Stage Depth	Notch Filt	er	0 to 1,000	0.001	0	All	Immedi- ately	Tuning	page 8-82
Pn40C	2	Second State ter Frequer	age Notch	Fil-	50 to 5,000	1 Hz	5000	All	Immedi- ately	Tuning	page 8-82
Pn40D	2	Second State ter Q Value	age Notch	Fil-	50 to 1,000	0.01	70	All	Immedi- ately	Tuning	page 8-82
Pn40E	2	Second Sta ter Depth	age Notch	Fil-	0 to 1,000	0.001	0	All	Immedi- ately	Tuning	page 8-82
Pn40F	2	Second Sta Torque Ref Frequency	age Secon erence Filt	d er	100 to 5,000	1 Hz	5000	All	Immedi- ately	Tuning	page 8-82

Continued	from	previous	page.
0011111000	110111	proviouo	pugo.

Parameter No.	Size	N	lame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence	
Pn410	2	Second St Notch Filte	age Second er Q Value	50 to 100	0.01	50	All	Immedi- ately	Tuning	page 8-82	
Pn412	2	First Stage Torque Re Time Cons	e Second ference Filter stant	0 to 65,535	0.01 ms	100	All	Immedi- ately	Tuning	page 8-66	
	2	Torque-Re tion Select	lated Func- tions 2	0000 to 1111	-	0000	All	Immedi- ately	Setup	page 8-84	
			1								
			Notch Filter	Selection 3							
		n.DDDX	0 Di	sable third stage	e notch filt	er.					
				lable third stage		÷.					
Dp/16			Notch Filter	Selection 4							
F11410		n.UUXU		sable fourth stag	ge notch fi	ter.					
			Notch Filter	Selection 5							
		n.¤X¤¤	0 Di 1 Er	Disable fifth stage notch filter. Enable fifth stage notch filter.							
		n.XDDD	Reserved p	arameter (Do no	ot change.	)					
			p		g	1					
Pn417	2	Third Stag Frequency	e Notch Filter	50 to 5,000	1 Hz	5000	All	Immedi- ately	Tuning	page 8-84	
Pn418	2	Third Stag Q Value	e Notch Filter	50 to 1,000	0.01	70	All	Immedi- ately	Tuning	page 8-84	
Pn419	2	Third Stag Depth	e Notch Filter	0 to 1,000	0.001	0	All	Immedi- ately	Tuning	page 8-84	
Pn41A	2	Fourth Sta ter Freque	ge Notch Fil- ncy	50 to 5,000	1 Hz	5000	All	Immedi- ately	Tuning	page 8-84	
Pn41B	2	Fourth Sta ter Q Value	ige Notch Fil- e	50 to 1,000	0.01	70	All	Immedi- ately	Tuning	page 8-84	
Pn41C	2	Fourth Sta ter Depth	ge Notch Fil-	0 to 1,000	0.001	0	All	Immedi- ately	Tuning	page 8-84	
Pn41D	2	Fifth Stage Frequency	e Notch Filter	50 to 5,000	1 Hz	5000	All	Immedi- ately	Tuning	page 8-84	
Pn41E	2	Fifth Stage Q Value	e Notch Filter	50 to 1,000	0.01	70	All	Immedi- ately	Tuning	page 8-84	
Pn41F	2	Fifth Stage Depth	Notch Filter	0 to 1,000	0.001	0	All	Immedi- ately	Tuning	page 8-83	
	2	Speed Rip sation Sele	ple Compen- ections	0000 to 1111	-	0000	Rotary	_	Setup	page 8-60	
			Speed Ripp	le Compensatio	on Functio	n Selectio	'n		Whe Enab	en Iled	
		n.DDDX	<b>0</b> Di	sable speed rip	ole compe	nsation.			Imme	edi-	
			1 Er	nable speed ripp	le comper	nsation.			ate	ly	
Pn423			Speed Ripp tion Selection	le Compensatio	on Informa	tion Disag	preement War	rning Detec-	Whe Enab	en led	
11120			<b>0</b> D	etect A.942 alar	ms.				Afte	∋r	
			1 De	o not detect A.9	42 alarms				resta	art	
			Speed Ripple Compensation Enable Condition Selection Enable					n led			
			0 Sr	Speed reference					Afte	)r art	
			1 M	Motor speed restart							
		n.XDDD	Reserved p	arameter (Do no	ot change.	)					
			LU Reserved parameter (Do not change.)								

11

							Con	tinued from	n previou	s page.				
Parameter No.	Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence				
Pn424	2	Torque Lim cuit Voltage	iit at Main Ci e Drop	r- 0 to 100	1% <sup>*2</sup>	50	All	Immedi- ately	Setup	page 6-18				
Pn425	2	Release Tir Limit at Ma Voltage Dro	me for Torqu ain Circuit op	e 0 to 1,000	1 ms	100	All	Immedi- ately	Setup	page 6-18				
Pn426	2	Torque Fee Average M Time	edforward ovement	0 to 5,100	0.1 ms	0	All	Immedi- ately	Setup	page 8-89				
Pn427	2	Speed Ripp sation Enal	ple Compen ble Speed	- 0 to 10,000	1 min <sup>-1</sup>	0	Rotary Ser- vomotor	Immedi- ately	Tuning	page 8-60				
Pn456	2	Sweep Tore ence Ampli	que Refer- itude	1 to 800	1%	15	All	Immedi- ately	Tuning	page 8-95				
	2	Notch Filte Selections	r Adjustmen 1	t 0000 to 0101	_	0101	All	Immedi- ately	Tuning	page 8-12, page 8-24, page 8-42				
			Notch Filte	r Adjustment Se	lection 1									
		n.000X	0 t	Do not adjust the uning without a h uning.	first stage ost referer	notch filter nce, autotu	r automatically ning with a ho	y during exectors reference	cution of a , and cust	uto- tom				
Pn460			1 <sup>A</sup>	djust the first sta vithout a host refe	ige notch f erence, au	filter autom totuning w	natically during ith a host refe	g execution o rence, and c	of autotun ustom tur	ing ning.				
	1	n.00X0	Reserved p	parameter (Do no	ot change.	)								
			Notch Filte	r Adjustment Se	lection 2									
	1	n.0X00	0 a	To not adjust the second stage notch filter automatically during execution of autotuning without a host reference, autotuning with a host reference, and custom tuning.										
			A 1 ir t	djust the second ng without a host uning.	stage not reference	ch filter au , autotunin	tomatically du g with a host	uring execution reference, a	on of auto nd custon	tun- า				
	١	n.X000	Reserved p	parameter (Do no	ot change.	)								
Pn480	2	Speed Lim Force Cont	it during trol	0 to 10,000	1 mm/s	10000	Linear	Immedi- ately	Setup	page 6-15				
Pn481	2	Polarity De Speed Loo	tection p Gain	10 to 20,000	0.1 Hz	400	Linear	Immedi- ately	Tuning	-				
Pn482	2	Polarity De Speed Loo Time Cons	tection p Integral tant	15 to 51,200	0.01 ms	3000	Linear	Immedi- ately	Tuning	_				
Pn483	2	Forward Fo	orce Limit	0 to 800	1% <sup>*2</sup>	30	Linear	Immedi- ately	Setup	page 6-22				
Pn484	2	Reverse Fo	orce Limit	0 to 800	1%*2	30	Linear	Immedi- ately	Setup	page 6-22				
Pn485	2	Polarity De ence Spee	tection Refe d	r- 0 to 100	1 mm/s	20	Linear	Immedi- ately	Tuning	-				
Pn486	2	Polarity De ence Accel Deceleration	tection Refe leration/ on Time	r- 0 to 100	1 ms	25	Linear	Immedi- ately	Tuning	-				
Pn487	2	Polarity De stant Spee	tection Con d Time	0 to 300	1 ms	0	Linear	Immedi- ately	Tuning	_				
Pn488	2	Polarity De ence Waitir	tection Refe ng Time	r- 50 to 500	1 ms	100	Linear	Immedi- ately	Tuning	_				
Pn48E	2	Polarity De Range	tection	1 to 65,535	1 mm	10	Linear	Immedi- ately	Tuning	-				
Pn490	2	Polarity De Level	tection Load	0 to 20,000	1%	100	Linear	Immedi- ately	Tuning	-				
Pn495	2	Polarity De firmation Fo	tection Con- orce Refer-	0 to 200	1%	100	Linear	Immedi- ately	Tuning	-				

Continued from previous page.

Parameter	d)		Setting	Sotting	Default	Applicable	When	Classia	Refer-
No	Siz(	Name	Bange	Unit	Setting	Motors	Fnabled	fication	ence
	•,		riango	Office	ootting	Mictore	Enabled	noution	01100
Pn498	2	Polarity Detection Allow- able Error Range	0 to 30	1 deg	10	Linear	Immedi- ately	Tuning	-
Pn49F	2	Speed Ripple Compen- sation Enable Speed	0 to 10,000	1 mm/s	0	Linear	Immedi- ately	Tuning	page 8-60
Pn502	2	Rotation Detection Level	1 to 10,000	1 min <sup>-1</sup>	20	Rotary	Immedi- ately	Setup	page 6-10
Pn503	2	Speed Coincidence Detection Signal Output Width	0 to 100	1 min <sup>-1</sup>	10	Rotary	Immedi- ately	Setup	page 6-11
Pn506	2	Brake Reference-Servo OFF Delay Time	0 to 50	10 ms	0	All	Immedi- ately	Setup	page 5-33
Pn507	2	Brake Reference Out- put Speed Level	0 to 10,000	1 min <sup>-1</sup>	100	Rotary	Immedi- ately	Setup	page 5-33
Pn508	2	Servo OFF-Brake Com- mand Waiting Time	10 to 100	10 ms	50	All	Immedi- ately	Setup	page 5-33
Pn509 All Axes	2	Momentary Power Inter- ruption Hold Time	20 to 50,000	1 ms	20	All	Immedi- ately	Setup	page 6-17

Continued on next page.

Parameter No.	Size	N	ame		Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence			
	2	Input Signa 1	al Select	tions	0000 to FFF2	-	0881	All	After restart	Setup	-			
			I/O Sig	nal All	ocation Mode					Refere	ence			
			0	Res	erved setting (	Do not us	e.)							
		11.000X	1	Use	e Σ-7S-compat	ible I/O się	gnal alloca	tions (Pn50A	to Pn517).	page	6-3			
			2	Use	e multi-axis I/O	signal allo	ocations (P	n590 to Pn5E	3C).					
		n.DDXD	Reserv	ved par	rameter (Do no	ot change.	.)							
		n.¤X¤¤	Reserv	ved par	ameter (Do no	ot change.	)							
			P-OT (	Forwa	rd Drive Prohit	oit) Signal	Allocation	I		Refere	ence			
			0	Axis A: Enable forward drive when CN1-3 input signal is ON (closed). Axis B: Enable forward drive when CN1-9 input signal is ON (closed).										
			1	<ul> <li>Axis B: Enable forward drive when CN1-6 input signal is ON (closed).</li> <li>Axis B: Enable forward drive when CN1-10 input signal is ON (closed).</li> <li>Closed).</li> </ul>										
			2	Axis A: Axis B: (closec	Enable forwar Enable forwar ).	d drive wh d drive wh	nen CN1-5 nen CN1-1	input signal is 1 input signal	s ON (closed is ON	).				
Pn50A			3	Axis A: Axis B: (closec	Enable forwar Enable forwar ).	d drive wh d drive wh	nen CN1-6 nen CN1-1	input signal is 2 input signal	s ON (closed is ON	).				
11100/1			4	<ul> <li>Axis A: Enable forward drive when CN1-7 input signal is ON (closed).</li> <li>Axis B: Enable forward drive when CN1-13 input signal is ON (closed).</li> </ul>						).				
			5	Axis A: Axis B: (closec	Enable forwar Enable forwar ).	d drive wh d drive wh	ien CN1-8 ien CN1-1	input signal is 4 input signal	s ON (closed is ON	).				
			6	Reserv	ed setting (Do	not use.)				page 5	5-29			
			7	Set the	signal to alwa	ys prohibi	t forward c	lrive.						
			8	Set the	signal to alwa	ys enable	forward dr	ive.						
			9	Axis A: Axis B:	Enable forwar Enable forwar	d drive wh d drive wh	ien CN1-3 ien CN1-9	input signal is input signal is	s OFF (open) s OFF (open)					
			A	Axis A: Axis B:	Enable forward Enable forward	d drive wh d drive wh	ien CN1-4 ien CN1-1	input signal is D input signal	s OFF (open) is OFF (open	).				
			в	Axis A: Axis B:	Enable forware Enable forware	d drive wh d drive wh	ien CN1-5 ien CN1-1	input signal is 1 input signal	s OFF (open) is OFF (open	).				
			С	Axis A: Axis B:	Enable forwar	d drive wh d drive wh	ien CN1-6 ien CN1-12	input signal is 2 input signal	s OFF (open) is OFF (open	open). (open).				
	D Axis A: Enable forward drive when CN1-7 input signal is OFF (open). Axis B: Enable forward drive when CN1-13 input signal is OFF (open)					).								
			E	Axis A: Axis B:	Enable forwar Enable forwar	d drive wh d drive wh	ien CN1-8 ien CN1-14	input signal is 4 input signal	s OFF (open) is OFF (open	).				
			F	Reserv	ed setting (Do	not use.)								

Continued from previous page.

Continued from previous page.

Parameter No.	Size	N	ame		Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence					
	2	Input Signa 2	al Selectior	าร	0000 to FFFF	_	8881	All	After restart	Setup	-					
			N-OT (Be	vers	e Drive Prohit	oit) Signal	Allocation	1		Refere	ence					
				Axis	A: Enable rev	erse drive	when CN <sup>-</sup>	I-3 input sign	al is ON							
			0	(clo: Axis (clo:	sed). B: Enable rev sed).	erse drive	when CN	1-9 input sign	al is ON							
			1	Axis (clos Axis (clos	A: Enable rev sed). B: Enable rev sed).	erse drive erse drive	when CN <sup>-</sup> when CN <sup>-</sup>	I-4 input sign I-10 input sig	al is ON nal is ON							
			2	Axis (clo: Axis (clo:	A: Enable rev sed). B: Enable rev sed).	erse drive erse drive	when CN <sup>-</sup> when CN <sup>-</sup>	I-5 input sign I-11 input sig	al is ON nal is ON							
			3	Axis (clos Axis (clos												
			4	Axis (clo: Axis (clo:	A: Enable rev sed). B: Enable rev sed).	erse drive erse drive	when CN <sup>-</sup> when CN <sup>-</sup>	I-7 input sign I-13 input sig	al is ON nal is ON							
			5	Axis A: Enable reverse drive when CN1-8 input signal is ON (closed). Axis B: Enable reverse drive when CN1-14 input signal is ON (closed).												
			6	Res	erved setting (	Do not us	e.)									
Pn50B		n.🗆 🗆 🗆 X	7	Set	the signal to a	lways pro	hibit revers	e drive.		page {	5-29					
			8	Set	the signal to a	lways ena	ble reverse	e drive.		1						
			9	Axis (ope Axis (ope	A: Enable rev en). B: Enable rev en).	erse drive erse drive	when CN <sup>-</sup>	1-3 input sign 1-9 input sign	al is OFF al is OFF							
			А	Axis (ope Axis (ope	A: Enable rev en). B: Enable rev en).	erse drive erse drive	when CN <sup>-</sup> when CN <sup>-</sup>	I-4 input sign I-10 input sig	al is OFF nal is OFF							
				Axis	A: Enable rev	erse drive	when CN	I-5 input sign	al is OFF							
			В	(ope Axis (ope	en). B: Enable rev en).	erse drive	when CN	1-11 input sig	nal is OFF							
			с	Axis (ope Axis (ope	A: Enable rev en). B: Enable rev en).	erse drive erse drive	when CN <sup>-</sup>	I-6 input sign I-12 input sig	al is OFF nal is OFF	F						
				Axis	A: Enable rev	erse drive	when CN	I-7 input sign	al is OFF							
			D	(ope Axis (ope	en). 5 B: Enable rev en).	erse drive	when CN	1-13 input sig	nal is OFF							
			E	Axis (ope Axis (ope	A: Enable rev en). B: Enable rev en).	erse drive erse drive	when CN <sup>-</sup> when CN <sup>-</sup>	I-8 input sign I-14 input sig	al is OFF nal is OFF							
			F	Res	erved setting (	Do not us	e.)									
	n.DDXD Reserved pa				ameter (Do no	ot change	)									
	Continued							ontinued c	n next pa	aqe.						

Continued on next page.

								Con	tinued from	n previou	s page.
Parameter No.	Size	Na	ame		Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
	i			ruord	External To	raus Limi	t Innut) Si		ed from pr	evious pa	age.
			/P-0L (FC	rwaru	External to		t input) Się		n 	Refere	ence
			0	Axis A Axis E	: Active whe 3: Active whe	en CN1-3 en CN1-9	input signa input signa	al is ON (close al is ON (close	d). d).		
			1	Axis A Axis E	: Active whe 3: Active whe	en CN1-4 en CN1-10	input signa ) input sigr	l is ON (close nal is ON (clos	d). ed).		
			2	Axis A Axis E	: Active whe B: Active whe	en CN1-5 en CN1-11	input signa input sigr	ll is ON (close nal is ON (clos	d). ed).		
			3	Axis A Axis E							
			4	Axis A Axis E							
			5	Axis A Axis E							
			6	Reser	ved setting (	Do not us	e.)				
		n.🗆X🗆	7	The si	page 6-23						
Pn50B			8	The si	page 6-23						
			9	Axis A Axis E							
			А	Axis A: Active when CN1-4 input signal is OFF (open). Axis B: Active when CN1-10 input signal is OFF (open).							
			В	Axis A Axis E	: Active whe 3: Active whe	en CN1-5 en CN1-11	input signa input sigr	I is OFF (oper nal is OFF (ope	ו). en).		
			С	Axis A Axis E	: Active whe 3: Active whe	en CN1-6 en CN1-12	input signa ? input sigr	I is OFF (oper nal is OFF (ope	ו). en).		
			D	Axis A: Active when CN1-7 input signal is OFF (open). Axis B: Active when CN1-13 input signal is OFF (open).							
			E Axis A: Active when CN1-8 input signal is OFF (open). Axis B: Active when CN1-14 input signal is OFF (open).							_	
			F	Reser	ved setting (	Do not us	e.)				
	Ī		/N-CL (Re	verse External Torque Limit Input) Signal Allocation							ence
		n.XDDD	0 to F	The al Torque	locations are e Limit Input	e the same ) signal all	e as the /P ocations.	-CL (Forward	External	page 6	6-23

Continued from previous page.

_					_					i proviou	o pugo.	
Parameter No.	Size	N	ame		Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence	
	2	Output Sig tions 1	nal Selec-		0000 to 6666	-	0000	All	After restart	Setup	-	
			/COIN (P	ositi	oning Comple	tion Outp	ut) Signal	Allocation		Refere	ence	
			0	Disa	abled (the abov	ve signal c	output is no	ot used).				
			1	Axis min Axis	s A: Output the al. s B: Output the	e signal fro e signal fro	m the CN <sup>-</sup> m the CN <sup>-</sup>	1-23 or CN1-2 1-25 or CN1-2	24 output ter 26 output ter	-		
		11.000X		min Axis	al. A: Output the	e signal fro	m the CN <sup>-</sup>	I-27 or CN1-2	28 output ter	page 6	6-13	
			2	Axis	ai. s B: Output the al.	e signal fro	m the CN <sup>.</sup>	1-29 or CN1-3	30 output ter	-		
Pn50E			3 to 6	Res	erved setting (	Do not us	e.)					
			/V-CMP (	(Spe	ed Coincidend	ce Detecti	on Output	) Signal Alloc	ation	Refere	ence	
		n.□□X□	0 to 6	The tion	allocations are ) signal allocat	e the same ions.	e as the /C	OIN (Position	ing Comple-	page 6	6-11	
			/TGON (F	Rota	tion Detection	Output) S	Signal Allo	cation		Reference		
		n.¤X¤¤	0 to 6	O to 6       The allocations are the same as the /COIN (Positioning Completion) signal allocations.								
			/S-BDY (	/S-RDY (Servo Ready) Signal Allocation								
		n.X000	0 to 6         The allocations are the same as the /COIN (Positioning Completion) signal allocations.							page 6	6-11	
	tion) signal allocations.									Į		
	2	Output Sig tions 2	nal Selec-		0000 to 6666	-	0100	All	After restart	Setup	-	
			/CLT (Tor	que	Limit Detectio	on Output)	Signal All	ocation		Refere	ence	
			0	Disa	abled (the abov	ve signal o	output is no	ot used).				
			1	Axis min Axis min	s A: Output the al. s B: Output the al.	e signal fro e signal fro	m the CN <sup>-</sup>	1-23 or CN1-2 1-25 or CN1-2	24 output ter 26 output ter	-		
				Axis	A: Output the	e signal fro	m the CN	I-27 or CN1-2	28 output ter	- page 6	5-26	
			2	min Axis min	al. s B: Output the al.	e signal fro	om the CN <sup>-</sup>	1-29 or CN1-3	30 output ter	-		
Pn50F			3 to 6	Res	erved setting (	Do not us	e.)					
			/VLT (Spe	eed	Limit Detection	n) Signal <i>I</i>	Allocation			Refere	ence	
	n.□IX□     The allocations are the same as the /CLT (Torque Limit Detection Output) signal allocations.							page 6	6-15			
			/BK (Bral	ke O	utput) Signal A	Allocation				Refere	ence	
		n. $\Box$ X $\Box$ D to 6 The allocations are the same as the /CLT (Torque Limit Detection Output) signal allocations.							page {	5-33		
			/WARN (	Warr	ning Output) S	ignal Allo	cation			Refere	ence	
		n.XDDD	0 to 6	The Out	allocations are put) signal allo	e the same cations.	e as the /C	LT (Torque Li	mit Detectior	page	6-9	

Continued on next page.

			Continued from p						n previou	s page.	
Parameter No.	Size	N	ame		Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
	2	Output Sig tions 3	nal Selec-		0000 to 0666	-	0000	All	After restart	Setup	-
			/NEAR (N	lear	Output) Signa	I Allocatic	n			Refere	ence
			0	Disa	abled (the abov	/e signal c	utput is no	ot used).			
		n.□□□X	1	1 Axis A: Output the signal from the CN1-23 or CN1-24 output ter- minal. Axis B: Output the signal from the CN1-25 or CN1-26 output ter- minal.							
Pn510			2	Axis min Axis min	s A: Output the al. s B: Output the al.	e signal fro e signal fro	m the CN <sup>-</sup> m the CN <sup>-</sup>	1-27 or CN1-2 1-29 or CN1-3	28 output ter 30 output ter		5-14
			3 to 6	Res	served setting (	Do not us	e.)				
		n.DDXD	Reserved	d pai	rameter (Do no	ot change.	.)				
		n.¤X¤¤	Reserved	l pai	rameter (Do no	ot change.	)				
		n.XDDD	Reserved	d parameter (Do not change.)							

Continued from previous page.

Parameter No.	Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence		
	2	Input Signa 5	al Selections	0000 to FFFF	-	5432	All	After restart	Setup	page 6-3		
						I			1			
			/DEC (Origin	n Return Decele	eration Sw	itch Input)	Signal Alloc	ation				
			0 Ax Ax	kis A: Active whe	en CN1-3 en CN1-9	input signa input signa	al is ON (close al is ON (close	ed). ed).				
			1 Ax Ax	kis A: Active whe	en CN1-4 en CN1-10	input signa ) input sigr	al is ON (close nal is ON (clos	d). sed).				
			2 Ax Ax	kis A: Active whe	en CN1-5 en CN1-11	input signa input sigr	al is ON (close nal is ON (clos	d). sed).				
			3 Ax Ax	kis A: Active whe	en CN1-6 en CN1-12	input signa 2 input sigr	al is ON (close nal is ON (clos	d). sed).				
			4 Ax Ax	kis A: Active whe	en CN1-7 en CN1-13	input signa 3 input sigr	al is ON (close nal is ON (clos	d). sed).				
			5 Ax Ax	kis A: Active whe	en CN1-8 en CN1-14	input signa I input sigr	al is ON (close nal is ON (clos	d). sed).				
			6 Re	eserved setting (	Do not us	e.)						
		n.🗆 🗆 🗆 X	7 Tr	ne signal is alwa	ys active.							
			8 Th	ne signal is alway	ys inactive	•						
			9 A> A>	Axis A: Active when CN1-3 input signal is OFF (open). Axis B: Active when CN1-9 input signal is OFF (open).								
			A Ax	kis A: Active whe kis B: Active whe	en CN1-4 en CN1-1(	input signa ) input sigr	al is OFF (oper nal is OFF (op	า). en).				
			B Ax Ax	kis A: Active whe kis B: Active whe	en CN1-5 en CN1-11	input signa input sigr	al is OFF (oper nal is OFF (op	n). en).				
			C Ax Ax									
Pn511			D Ax Ax	D Axis A: Active when CN1-7 input signal is OFF (open). Axis B: Active when CN1-13 input signal is OFF (open).								
			EAxis A: Active when CN1-8 input signal is OFF (open). Axis B: Active when CN1-14 input signal is OFF (open).	n). en).								
			F Re	eserved setting (	Do not us	e.)						
			/EXT1 (Exte	rnal Latch Inpu	t 1) Signal	Allocation	า					
			0 to 2 Th	ne signal is alwa	ys inactive	•						
			3 Ax	kis A: Active whe	en CN1-6 en CN1-12	input signa ? input sigr	al is ON (close nal is ON (clos	d). sed).				
			4 Ax Ax	kis A: Active whe	en CN1-7 en CN1-13	input signa 3 input sigr	al is ON (close nal is ON (clos	d). sed).				
			5 Ax	kis A: Active whe	en CN1-8 en CN1-14	input signa Linput sigr	al is ON (close nal is ON (clos	d). sed).				
			6 to B Th	ne signal is alwa	ys inactive							
			C Ax	kis A: Active whe kis B: Active whe	en CN1-6 en CN1-12	input signa 2 input sigr	al is OFF (oper nal is OFF (ope	n). en).				
	D Axis A: Active when CN1-7 input signal is OFF (open). Axis B: Active when CN1-13 input signal is OFF (open).							ר). en).				
			E Axis A: Active when CN1-8 input signal is OFF (open). Axis B: Active when CN1-14 input signal is OFF (open).									
			F Th	ne signal is alwa	ys inactive							
			/EXT2 (Exte	rnal Latch Inpu	t 2) Signal	Allocation	า					
		n.¤X¤¤	0 to F Th	ie allocations ar	e the same	e as the /E	XT1 (External	Latch Input	1) signal a	allo-		
			/FXT3 (Exte	(External Lateh Input 2) Signal Allocation								
		n.XDDD	0 to F	F     The allocations are the same as the /EXT1 (External Latch Input 1) signal allocations.								

Continued on next page.

							Con	tinued from	n previou	s page.			
Parameter No.	Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence			
Pn512	2 Output S Settings		inal Inverse	0000 to 1111	-	0000	All	After restart	Setup	page 6-6			
	n.□□□X       Output Inversion for CN1-23, CN1-24, CN1-25, and CN1-26 Terminals (Axis A: CN1-23 and CN1-24, Axis B: CN1-25 and C         0       The signal is not inverted.         1       The signal is inverted.         0       The signal is inverted.         1       The signal is inverted.         0       The signal is inverted.         0       The signal is not inverted.         0       The signal is not inverted.         0       The signal is not inverted.         1       The signal is inverted.         1       Reserved parameter (Do not change.)         n.XDDD       Reserved parameter (Do not change.)								d CN1-26	5) 			
	2	Output Sig tions 4	inal Selec-	0000 to 0666	_	0000	All	After restart	Setup	-			
	[	n.DDDX	Reserved pa	arameter (Do no	ot change.	)							
	]	n.□□X□ Reserved parameter (Do not change.)											
	ĺ	n.0X00	/PM (Preventative Maintenance Output) Signal Allocation										
			0 Dis	sabled (the abo	ve signal c	utput is no	ot used).						
Pn514			1 Ax mi Ax mi	Axis A: Output the signal from the CN1-23 or CN1-24 output ter- minal. Axis B: Output the signal from the CN1-25 or CN1-26 output ter- minal.									
			2 Ax mi Ax mi	is A: Output the nal. is B: Output the nal.	e signal fro e signal fro	m the CN <sup>-</sup>	1-27 or CN1-2 1-29 or CN1-3	28 output ter 30 output ter		page 9-15			
			3 to 6 Re	served setting	(Do not us	e.)							
		n.XDDD	Reserved pa	arameter (Do no	ot change	)							

Continued from previous page.

Parameter No.	Size	I	Name	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence				
	2	Input Sigr 7	nal Selections	0000 to FFFF	-	8888	All	After restart	Setup	-				
					ł									
			FSTP (Force	STP (Forced Stop Input) Signal Allocation										
			0 A:	kis A: Enable dri kis B: Enable dri	ve when ( ve when (	CN1-3 inpu CN1-9 inpu	it signal is ON it signal is ON	l (closed). l (closed).						
			1 A:	kis A: Enable dri kis B: Enable dri	ve when ( ve when (	CN1-4 inpu CN1-10 inp	it signal is ON out signal is O	l (closed). N (closed).						
			2 A:	kis A: Enable dri kis B: Enable dri	ve when ( ve when (	CN1-5 inpu CN1-11 inp	it signal is ON out signal is O	l (closed). N (closed).						
			3 A:	kis A: Enable dri kis B: Enable dri	ve when ( ve when (	CN1-6 inpu CN1-12 inp	it signal is ON out signal is O	l (closed). N (closed).						
			4 A:	kis A: Enable dri kis B: Enable dri	ve when ( ve when (	CN1-7 inpu CN1-13 inp	it signal is ON out signal is O	l (closed). N (closed).						
			5 A:	kis A: Enable dri kis B: Enable dri	ve when ( ve when (	CN1-8 inpu CN1-14 inp	it signal is ON out signal is O	l (closed). N (closed).						
			6 R	eserved setting	(Do not us	se.)								
	r	n.000X	7 Se st	et the signal to a op).	always pro	hibit drive	(always force	the motor to		1				
Pn516		8		et the signal to a otor to stop).	— page c	- page 6-45								
			9 A:	kis A: Enable dri kis B: Enable dri	ve when ( ve when (	CN1-3 inpu CN1-9 inpu	it signal is OF it signal is OF	F (open). F (open).						
			A A:	kis A: Enable dri kis B: Enable dri	ve when ( ve when (	CN1-4 inpu CN1-10 inp	it signal is OF out signal is O	F (open). FF (open).						
			B A:	kis A: Enable dri kis B: Enable dri										
			C A:	kis A: Enable dri kis B: Enable dri	ve when ( ve when (	CN1-6 inpu CN1-12 inp	it signal is OF out signal is O	F (open). FF (open).		_				
			D A:	kis A: Enable dri kis B: Enable dri	ve when ( ve when (	CN1-7 inpu CN1-13 inp	it signal is OF out signal is O	F (open). FF (open).						
			E A:	kis A: Enable dri kis B: Enable dri	ve when ( ve when (	CN1-8 inpu CN1-14 inp	it signal is OF out signal is O	F (open). FF (open).						
			F R	Reserved setting (Do not use.)										
	r	n.00X0	Reserved pa	rameter (Do not	t change.)									
	r	n.OXOO	Reserved pa	rameter (Do not	t change.)									
	r	n.XOOO	Reserved pa	rameter (Do not										
				1			1		1	1				
Pn51E	2	Position L flow Warr	ing Level	10 to 100	1%	100	All	Immedi- ately	Setup	page 10-41				
Pn520	4	Position [ flow Alarn	Deviation Over- n Level	1 to 1,073,741,823	1 refer- ence unit	524288 0	All	Immedi- ately	Setup	page 8-8, page 10-5				
Pn522	4	Positionin Width	g Completed	0 to 1,073,741,824	1 refer- ence unit	7	All	Immedi- ately	Setup	page 6-13				
Pn524	4	Near Sigr	al Width	1 to 1,073,741,824	1 refer- ence unit	107374 1824	All	Immedi- ately	Setup	page 6-14				
Pn526	4	Position I flow Alarn Servo ON	Deviation Over- n Level at	1 to 1,073,741,823	1 refer- ence unit	524288 0	All	Immedi- ately	Setup	page 8-8				
Pn528	2	Position E flow Warr Servo ON	Deviation Over- ning Level at	10 to 100	1%	100	All	Immedi- ately	Setup	page 8-8				
Pn529	2	Speed Lir Servo ON	nit Level at	0 to 10,000	1 min <sup>-1</sup>	10000	Rotary	Immedi- ately	Setup	page 8-8				
Pn52B	2	Overload	Warning Level	1 to 100	1%	20	All	Immedi- ately	Setup	page 5-40				

Parameter Lists

							Con	tinued from	n previou:	s page.		
Parameter No.	Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence		
Pn52C	2	Base Curre at Motor O Detection	ent Derating verload	10 to 100	1%	100	All	After restart	Setup	page 5-40		
Pn52D	2	Reserved p	parameter (Do e.)	-	-	50	All	-	_	_		
2 Pr Re		Program Je Related Se	ogging- elections	0000 to 0005	-	0000	All	Immedi- ately	Setup	page 7-14		
			Program Jog	ging Operation	n Pattern							
			0 (Wa mo	aiting time in Pr vements in Pn8	1535 → Fo 536	prward by t	travel distance	e in Pn531) >	Number	of		
Pn530			1 (Wa mo	Waiting time in Pn535 $\rightarrow$ Reverse by travel distance in Pn531) $\times$ Number of movements in Pn536								
			2 (Wa mo (Wa mo	(Waiting time in Pn535 → Forward by travel distance in Pn531) × Number of movements in Pn536 (Waiting time in Pn535 → Reverse by travel distance in Pn531) × Number of movements in Pn536								
	n.□□□X		3 (Wa mo (Wa mo	(Waiting time in Pn535 $\rightarrow$ Reverse by travel distance in Pn531) × Number of movements in Pn536 (Waiting time in Pn535 $\rightarrow$ Forward by travel distance in Pn531) × Number of movements in Pn536								
			4 in F Ph	(Waiting time in Pn535 $\rightarrow$ Forward by travel distance in Pn531 $\rightarrow$ Waiting time in Pn535 $\rightarrow$ Reserve by travel distance in Pn531) × Number of movements in Pn536								
			5 in F Ph	(Waiting time in Pn535 $\rightarrow$ Reverse by travel distance in Pn531 $\rightarrow$ Waiting time in Pn535 $\rightarrow$ Forward by travel distance in Pn531) $\times$ Number of movements in Pn536								
	n.□□X□ Reserved parameter (Do not change.)											
	n.xuuu   Reserved parameter (Do not change.)											
Pn531	4	Program Jo Distance	ogging Travel	1 to 1,073,741,824	1 refer- ence unit	32768	All	Immedi- ately	Setup	page 7-14		
Pn533	2	Program Jogging Move- ment Speed		1 to 10,000	Rotary: 1 min <sup>-1</sup> Direct Drive: 0.1 min <sup>-1</sup>	500	Rotary	Immedi- ately	Setup	page 7-14		
Pn534	2	Program Je eration/De Time	ogging Accel- celeration	2 to 10,000	1 ms	100	All	Immedi- ately	Setup	page 7-14		
Pn535	2	Program Joing Time	ogging Wait-	0 to 10,000	1 ms	100	All	Immedi- ately	Setup	page 7-14		
Pn536	2	Program Je ber of Mov	ogging Num- rements	0 to 1,000	Times	1	All	Immedi- ately	Setup	page 7-14		
Pn550 All Axes	2	Analog Mo Voltage	nitor 1 Offset	-10,000 to 10,000	0.1 V	0	All	Immedi- ately	Setup	page 9-6		
Pn551 All Axes	2	Analog Mo Voltage	nitor 2 Offset	-10,000 to 10,000	0.1 V	0	All	Immedi- ately	Setup	page 9-6		
Pn552 All Axes	2	Analog Mo nification	nitor 1 Mag-	-10,000 to 10,000	× 0.01	100	All	Immedi- ately	Setup	page 9-6		
Pn553 All Axes	2	Analog Mo nification	nitor 2 Mag-	-10,000 to 10,000	× 0.01	100	All	Immedi- ately	Setup	page 9-6		
Pn55A All Axes	2	Power Cor Monitor Ur	nsumption nit Time	1 to 1,440	1 min	1	All	Immedi- ately	Setup	_		
Pn560	2	Residual V Detection	ibration Width	1 to 3,000	0.1%	400	All	Immedi- ately	Setup	page 8-55		

0

								0011			o pago.	
Parameter No.	Size	N	ame		Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence	
Pn561	2	Overshoot Level	Detection		0 to 100	1%	100	All	Immedi- ately	Setup	page 8-24, page 8-35	
Pn581	2	Zero Spee	d Level		1 to 10,000	1 mm/s	20	Linear	Immedi- ately	Setup	page 6-10	
Pn582	2	Speed Coi Detection S Width	ncidence Signal Out	put	0 to 100	1 mm/s	10	Linear	Immedi- ately	Setup	page 6-11	
Pn583	2	Brake Refe put Speed	erence Ou Level	t-	0 to 10,000	1 mm/s	10	Linear	Immedi- ately	Setup	page 5-33	
Pn584	2	Speed Lim Servo ON	it Level at		0 to 10,000	1 mm/s	10000	Linear	Immedi- ately	Setup	page 8-8	
Pn585	2	Program Jogging Move- ment Speed		1 to 10,000	1 mm/s	50	Linear	Immedi- ately	Setup	page 7-14		
Pn586	2	Motor Running Cooling Ratio		0 to 100	1%/ Max. speed	0	Linear	Immedi- ately	Setup	-		
	2	Polarity De Execution Absolute L	etection Selection inear Enco	for oder	0000 to 0001	-	0000	Linear	Immedi- ately	Setup	-	
			Polarity	Doto	ation Solaction	for Abso	luto Linoa	r Epoodor		Poforon		
				Oranity Detection Selection for Absolute Linear Encoder     Do not detect polarity							ice	
Pn587			1	Detect polarity.							-26	
		n.00X0	Reserve	d parameter (Do not change.)								
	n.□X□□ Reserved parameter (Do not change.)											
	n.XDDD Reserved parameter (Do not change.)											
	P-OT (Forward Drive Prohibit) Signal Alloca- tion			0000 to 3019	_	Axis A: 1003, Axis B: 1009	All	After restart	Setup	page 5-29, page 6-3		
	_											
			Allocate	d Pin	Number							
			003	Allo	cate the signal	to CN1-3						
			004	Allo	cate the signal	to CN1-4	•					
			005	Allo	cate the signal	to CN1-5	•					
			005	Allo	cate the signal cate the signal	to CN1-5						
			005 006 007	Allo Allo Allo	cate the signal cate the signal cate the signal	to CN1-5 to CN1-6 to CN1-7						
		n.□XXX	005 006 007 008	Allo Allo Allo Allo	cate the signal cate the signal cate the signal cate the signal	to CN1-5 to CN1-6 to CN1-7 to CN1-8						
Pn590		n.□XXX	005 006 007 008 009	Allo Allo Allo Allo Allo	cate the signal cate the signal cate the signal cate the signal cate the signal	to CN1-5 to CN1-6 to CN1-7 to CN1-8 to CN1-9						
Pn590		n.⊡XXX	005 006 007 008 009 010	Allo Allo Allo Allo Allo Allo	cate the signal cate the signal cate the signal cate the signal cate the signal cate the signal	to CN1-5 to CN1-6 to CN1-7 to CN1-8 to CN1-9 to CN1-1	0.					
Pn590		n.□XXX	005 006 007 008 009 010 011	Allo Allo Allo Allo Allo Allo	cate the signal cate the signal cate the signal cate the signal cate the signal cate the signal cate the signal	to CN1-5 to CN1-6 to CN1-7 to CN1-8 to CN1-9 to CN1-1 to CN1-1	0. 1.					
Pn590		n.□XXX	005 006 007 008 009 010 011 012 013	Allo Allo Allo Allo Allo Allo Allo	cate the signal cate the signal	to CN1-5 to CN1-6 to CN1-7 to CN1-8 to CN1-9 to CN1-1 to CN1-1 to CN1-1	0. 1. 2.					
Pn590		n.⊡XXX	005 006 007 008 009 010 011 012 013 014	Allo Allo Allo Allo Allo Allo Allo Allo	cate the signal cate the signal	to CN1-5 to CN1-6 to CN1-7 to CN1-8 to CN1-9 to CN1-1 to CN1-1 to CN1-1 to CN1-1 to CN1-1	0. 1. 2. 3. 4.					
Pn590		n.□XXX	005 006 007 008 009 010 011 012 013 014	Allo Allo Allo Allo Allo Allo Allo Allo	cate the signal cate the signal	to CN1-5 to CN1-6 to CN1-7 to CN1-8 to CN1-9 to CN1-1 to CN1-1 to CN1-1 to CN1-1						
Pn590		n.⊡XXX	005 006 007 008 009 010 011 012 013 014 Polarity 0	Allo Allo Allo Allo Allo Allo Allo Allo	cate the signal cate the signal	to CN1-5 to CN1-6 to CN1-7 to CN1-8 to CN1-9 to CN1-1 to CN1-1 to CN1-1 to CN1-1	0. 1. 2. 3. 4.	1 drive				
Pn590			005 006 007 008 009 010 011 012 013 014 Polarity 0 1	Allo Allo Allo Allo Allo Allo Allo Allo	cate the signal cate the signal	to CN1-5 to CN1-6 to CN1-7 to CN1-8 to CN1-9 to CN1-1 to CN1-1 to CN1-1 to CN1-1 to CN1-1 to CN1-1	0. 1. 2. 3. 4. ble forward	d drive.				
Pn590	_	n.□XXX	005 006 007 008 009 010 011 012 013 014 Polarity 0 1 2	Allo Allo Allo Allo Allo Allo Allo Allo	cate the signal cate the signal	to CN1-5 to CN1-6 to CN1-7 to CN1-8 to CN1-9 to CN1-1 to CN1-1 to CN1-1 to CN1-1 to CN1-1 to CN1-1 kways ena signal is C	0. 1. 2. 3. 4. ble forward DN (closed	d drive.				
Pn590	_	n.□XXX	005 006 007 008 009 010 011 012 013 014 Polarity 0 1 2 3	Allo Allo Allo Allo Allo Allo Allo Allo	cate the signal cate the signal	to CN1-5 to CN1-6 to CN1-7 to CN1-8 to CN1-9 to CN1-1 to CN1-1 to CN1-1 to CN1-1 to CN1-1 lways ena signal is C	0. 1. 2. 3. 4. ble forward DN (closed DFF (open) nibit forward	d drive. ). rd drive.				

11
								Con	itinued from	1 previou	s page.				
Parameter No.	Size	N	ame Setting Setting Default Applicable When Clas Range Unit Setting Motors Enabled ficat												
	2	N-OT (Rev Prohibit) Si tion	erse Drive ignal Alloca	1-	0000 to 3019	-	Axis A: 1004, Axis B: 1010	All	After restart	Setup	page 5-29, page 6-3				
			Allocated	Pin	Number										
			003	Allc	cate the signa	I to CN1-3									
			004	Allc	cate the signa	l to CN1-4	•								
			005	Allc	cate the signa	I to CN1-5									
			006	Allc	cate the signa	I to CN1-6	i.								
			007	Allo	cate the signa	I to CN1-7									
		n.□XXX	008	Allo	cate the signa	I to CN1-8									
Pn591			009	Allo	cate the signa	I to CN1-9	0.								
			010	Allo	cate the signa	I to CN1-1	0.								
			012	Allo	cate the signa		1. 0								
			012	Allo	cate the signa		2.								
			013		cate the signa		3. 4								
				Alle	cate the signa		7.								
		Polarity Selection													
			0	0       Set the signal to always enable reverse drive.         1       Active when input signal is ON (closed).											
	n.xuuu				ive when input	signal is (	DIN (CIOSED	).							
			2	ACL	the signal to c	signal is C	DFF (open)	o drivo							
			5	Set	the signal to a	uways pro		e unve.							
	2 /DEC (Origin Return 2 Deceleration Switch Input) Signal Allocat				0000 to 3019	_	Axis A: 1005, Axis B: 1011	All	After restart	Setup	_				
			Allocated	Pin	Number										
			003	Allo	cate the signa	I to CN1-3									
			004	Allo	cate the signa	I to CN1-4	· <u>·</u>								
			005	Allo	cate the signa	I to CN1-5									
			006	Allo	cate the signa	I to CN1-6	j.								
			007	Allc	cate the signa	l to CN1-7									
		n.□XXX	008	Allc	cate the signa	l to CN1-8	i.								
Pn592			009	Allc	cate the signa	l to CN1-9									
			010	Allc	cate the signa	l to CN1-1	0.								
			011	Allc	cate the signa	l to CN1-1	1.								
			012	Allc	cate the signa	I to CN1-1	2.								
			013	Allc	cate the signa	I to CN1-1	3.								
			014	Allc	cate the signa	I to CN1-1	4.								
			Polarity S	ele	ction										
			0	The	signal is alwa	ys inactive									
		n.XDDD	1	Act	ive when input	signal is (	ON (closed	).							
			2	Act	ive when input	signal is (	OFF (open)								
			3	The signal is always active.											

Continued from previous page

Parameter No.	Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence		
	2	/EXT1 (Ext Input 1) Sig tion	ernal Latch gnal Alloca-	0000 to 2019	-	Axis A: 1006, Axis B: 1012	All	After restart	Setup	_		
			Allocated Pi	n Number								
			000 to 005	The signal is al	ways inac	tive.						
			006	Allocate the sig	gnal to CN	1-6.						
			007	Allocate the sig	gnal to CN	1-7.						
D		n.□XXX	008	Allocate the sig	gnal to CN	1-8.						
Pn593			009 to 011	The signal is always inactive.								
			012	Allocate the sig	gnal to CN	1-12.						
			013	Allocate the sig	gnal to CN	1-13.						
			014	Allocate the sig	gnal to CN	1-14.						
			Polarity Sele	ection								
	n.XDDD			The signal is al	ways inac	tive.						
			1	Active when input signal is ON (closed).								
			2	Active when in	put signal	is OFF (op	en).					
	2	/EXT2 (Ext Input 2) Sig tion	ernal Latch gnal Alloca-	0000 to 2019	_	Axis A: 1007, Axis B: 1013	All	After restart	Setup	_		
		-		+	•		•		•			
			Allocated Pi	n Number								
			000 to 005	The signal is al	ways inac	tive.						
			006	Allocate the sig	gnal to CN	1-6.						
			007	Allocate the sig	gnal to CN	1-7.						
		n.□XXX	008	Allocate the sig	gnal to CN	1-8.						
Pn594			009 to 011	The signal is al	ways inac	tive.						
			012	Allocate the sig	gnal to CN	1-12.						
			013	Allocate the sig	gnal to CN	1-13.						
			014	Allocate the sig	gnal to CN	1-14.						
			Polarity Sele	ection								
			0	The signal is al	ways inac	tive.						
			1	Active when in	put signal	is ON (clo	sed).					
			2	Active when in	put signal	is OFF (op	en).					
	!											

Continued on next page.

								Con	linued from	i previou	s page.
Parameter No.	Size	N	ame		Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
	2	/EXT3 (Ext Input 3) Sig tion	ernal Latch gnal Alloca-	l -	0000 to 2019	_	Axis A: 1008, Axis B: 1014	All	After restart	Setup	_
			Allocated	Pin	Number						
			000 to 00	)5	The signal is al	ways inac	tive.				
			006		Allocate the sig	gnal to CN	1-6.				
			007		Allocate the sig	gnal to CN	1-7.				
Pn595		n.□XXX	800		Allocate the sig	gnal to CN	1-8.				
1 11000			009 to 01	1	The signal is al	ways inac	tive.				
			012		Allocate the sig	gnal to CN	1-12.				
			013		Allocate the sig	gnal to CN	1-13.				
			014	-	Allocate the sig	griai to Civ	1-14.				
			Polarity S	sele	ction						
		n.XDDD	0		The signal is al	ways inac	tive.				
			1		Active when in	put signal	is ON (clo	sed).			
					Active when in	put signal	is OFF (op	en).			
	2	FSTP (Ford	ed Stop		0000 to	_	0000	All	After	Setup	page
		Input) Sign	al Allocatio	n	3019				restart		6-45
			Allocated	Pin	Number						
			003	Allc	cate the signa	to CN1-3	8.				
			004	Allc	cate the signa	to CN1-4					
			005	Allc	cate the signa	to CN1-5	<b>.</b>				
			006	Allo	cate the signa	to CN1-6	ð.				
			007	Allc	cate the signa	to CN1-7	<u>.</u>				
		n.□XXX	800	Allo	cate the signa	to CN1-8	3.				
			009	Allo	cate the signa		0.				
Pn597			010	Allo	cate the signa		U. 1				
			010	Allo	cate the signa		1. 0				
			012	Allo	cate the signa		2.				
			013	Allo	cate the signa		3. 1				
			014	AllC	cate the signa		4.				
			Polarity S	sele	ction						
			0	Set sto	the signal to a c).	lways ena	ble drive (a	always disable	e forcing the	motor to	
		n.XDDD	1	Ena	ble drive wher	the input	signal is C	N (closed).			
			2	Ena	ble drive wher	the input	signal is C	OFF (open).			
			3	Set the signal to always prohibit drive (always force the motor to stop).							
											_

Continued from previous page.

Continued from previous page.

Parameter No.	Size	N	ame		Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence		
	2	/P-CL (Fornal Torque Signal Alloc	ward Exter Limit Inpu cation	r- t)	0000 to 3019	-	0000	All	After restart	Setup	page 6-3, page 6-23		
			Allocated	d Pin	Number								
			003	Allo	cate the signa	I to CN1-3	8.						
			004	Allo	cate the signa	l to CN1-4							
			005	Allo	cate the signa	I to CN1-5	j.						
			006	Allo	cate the signa	I to CN1-6	ö.						
			007	Allo	cate the signa	I to CN1-7							
		n.□XXX	008	Allo	cate the signa	I to CN1-8	8.						
Pn598			009	Allo	cate the signa	I to CN1-9	).						
			010	Allo	cate the signa	I to CN1-1	0.						
			011	Allo	cate the signa	I to CN1-1	1.						
			012	Allo	cate the signa	I to CN1-1	2.						
			013	Allo	cate the signal		3.						
			014	Allo	cate the signa		4.						
			Polarity \$	Seleo	ction								
			0	The	signal is alway	ys inactive							
		n.XDDD	1	Act	ive when input	signal is (	DN (closed	).					
			2	Act	ive when input	signal is C	DFF (open)						
			3	The	signal is alway	ys active.							
		/N-CL (Rev	verse Exte	r-	0000 to				Aftor		page		
	2	nal Torque Signal Allo	Limit Inpu	t)	3019	-	0000	All	restart	Setup	page		
		eigna. /e	oution								6-23		
	_												
			Allocated	2 Allocate the signal to CN1-3									
			003	Allo	cate the signa	I to CN1-3	8.						
			004	Allo	cate the signa	I to CN1-4							
			005	Allo	cate the signa	I to CN1-5							
			006	Allo	cate the signa	I to CN1-6	).						
			007	Allo	cate the signa	I to CN1-/							
		n.⊔XXX	800	Allo	cate the signal		5. N						
Pn599			009	Allo	cate the signal		0						
			010	Allo	cate the signa		1						
			011	Allo	cate the signa		1. 2						
			012		cate the signal		2. 3						
			010	Allo	cate the signal		4						
	-												
			Polarity S	Selec	ction	in the sector							
				1 ne	signai is alway	ys mactive	NI (alaast	)					
			2	ACT	ive when input	signal is C		).					
			2	The	signal is alway	vs activa	on (open)	•					
	-				- orginar io arwa	,0 00000.							

Continued on next page.

								Con	tinued from	n previou:	s page.		
Parameter No.	Size	N	ame		Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence		
	2	/COIN (Pos Completion nal Allocati	sitioning n Output) Sig- on		0000 to 2039	-	0000	All	After restart	Setup	page 6-3, page 6-13		
			Allocated	d Pin	Number								
			023	Allo	cate the signa	I to CN1-2	3.						
			025	Allo	Allocate the signal to CN1-25.								
Pn5B0		n.uxxx	027	Allo	cate the signa	I to CN1-2							
			029	Allo	cate the signa	l to CN1-2	9.						
			031	Allo	cate the signa	I to CN1-3	1.						
			Polarity S	Polarity Selection									
			0	Disa	abled (the abov	ve signal c	utput is no	ot used).					
		n.XDDD	1	Out	put the above	signal.							
			2	Inve	ert the above s	ignal and	output it.						
		-											
	2	/V-CMP (S dence Dete Signal Allo	peed Coin ection Outp cation	ci- out)	0000 to 2039	_	0000	All	After restart	Setup	page 6-3, page 6-11		
			Allocated	Allocated Pin Number									
			023 Allocate the signal to CN1-23.										
			025	Allo	cate the signa	l to CN1-2	5.						
Pn5B1		n.□XXX	027	Allo	cate the signal	I to CN1-2							
			029	Allocate the signal to CN1-29.									
			031	031 Allocate the signal to CN1-31.									
			Polarity Selection										
			0 Disabled (the above signal output is not used).										
		n.XDDD	1	Output the above signal									
			2	Inve	ert the above s	ignal and	output it.						
						0	•						
	2	/TGON (Ro tion Outpu cation	otation Det t) Signal A	ec- llo-	0000 to 2039	_	0000	All	After restart	Setup	page 6-3, page 6-10		
			Allocated	d Pin	Number								
			023	Allo	cate the signa	l to CN1-2	3.						
		n EIXXX	025	Allo	cate the signa	l to CN1-2	5.						
Pn5B2		11. ЦАЛА	027	Allo	cate the signa	l to CN1-2							
			029	Allo	cate the signa	I to CN1-2	9.						
			031	Allo	cate the signa	to CN1-3	51.						
			Polarity S	Seleo	ction								
			0	Disa	abled (the abov	ve signal c	utput is no	ot used).					
			1	Out	put the above	signal.							
			2	Inve	ert the above s	ignal and	output it.						

Continued from previous page.

Parameter No.	Size	N	lame		Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence		
	2	/S-RDY (S Signal Allo	ervo Read cation	ly)	0000 to 2039	-	0000	All	After restart	Setup	page 6-3, page 6-11		
			Allocate	d Pin	Number								
			023	Allo	cate the signa	I to CN1-2	3.						
			025	Allo	cate the signa	l to CN1-2	5.						
Pn5B3		11.	027	Allo	cate the signa	l to CN1-2	7.						
			029	Allo	cate the signa	l to CN1-2	9.						
			031	Allo	cate the signa	l to CN1-3	1.						
			Polarity	Seleo	ction								
			0	Disa	abled (the abo	ve signal c	utput is no	ot used).					
		n.XUUU	1	Out	put the above	signal.							
			2	Inve	ert the above s	ignal and (	output it.						
	2	/CLT (Torq Detection Allocation	ue Limit Output) Sig	gnal	0000 to 2039	-	0000	All	After restart	Setup	page 6-3, page 6-26		
			Allocate	d Pin	Number								
		n.⊡XXX	023 Allocate the signal to CN1-23.										
			025 Allocate the signal to CN1-25.										
Pn5B4			027	Allo	cate the signa	l to CN1-2	7.						
THODI			029	Allo	cate the signa	l to CN1-2	9.						
			031	Allo	cate the signa	I to CN1-3	1.						
			Polarity	Selec	ction								
			0	Dis	abled (the abo	ve signal o	utput is no	ot used).					
		n.XDDD	Disabled (the above signal output is not used).										
			2	Inve	ert the above s	ional and o	output it.						
						. <u>g</u>							
	2	/VLT (Spee Detection) tion	ed Limit Signal Allo	oca-	0000 to 2039	-	0000	All	After restart	Setup	page 6-3, page 6-15		
			Allocate	d Pin	Number								
			023	Allo	cate the signa	l to CN1-2	3.						
		n EXXX	025	Allo	cate the signa	I to CN1-2	5.						
Pn5B5			027	Allo	cate the signa	I to CN1-2	7.						
			029	Allo	cate the signa	I to CN1-2	9.						
			031	Allo	cate the signa	l to CN1-3	1.						
			Polarity	Seleo	ction								
			0	Disa	abled (the abo	ve signal c	utput is no	ot used).					
			1	Out	put the above	signal.							
			2 Invert the above signal and output it.										

Continued on next page.

								Cor	tinued from	n previou	s page.	
Parameter No.	Size	N	ame		Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence	
	2	/BK (Brake nal Allocati	Output) S on	ig-	0000 to 2039	_	Axis A: 1023, Axis B: 1025	All	After restart	Setup	page 5-33, page 6-3	
			Allocator	Din	Numbor							
			Anocated				2					
			025		cate the signa		.0.					
D 5D0		n.□XXX	023		cate the signa		.0.					
Ph5B6			027		cate the signa		20					
			023		cate the signa		.5.					
			001	Alic	cate the signa						_	
			Polarity S	Sele	ction							
		n.XDDD	0	Dis	abled (the abo	ve signal c	output is no	ot used).				
			1	Out	put the above	signal.						
			2	Inve	ert the above s	ignal and	output it.					
	2	/WARN (W put) Signal	arning Out Allocation	-	0000 to 2039	-	0000	All	After restart	Setup	page 6-3, page 6-9	
			Allocated	l Pin	Number							
			023	Allo	cate the signa	I to CN1-2	23.					
		n.□XXX	025	Allo	cate the signa	l to CN1-2	25.					
Pn5B7			027	Allo	cate the signa	I to CN1-2	27.					
			029	Allocate the signal to CN1-29.								
			031	031 Allocate the signal to CN1-31.								
			Polarity S	Sele	ction							
			0	Dis	abled (the abo	ve signal c	outout is no	ot used)				
		n.XDDD	1	U Disabled (the above signal output is not used).     Output the above signal								
			2	Inve	ert the above s	ional and	outout it					
			_			ignal and	output in					
	2	/NEAR (Ne Signal Allo	ar Output) cation		0000 to 2039	_	0000	All	After restart	Setup	page 6-3, page	
											0-14	
			Allocated	l Pin	Number							
			023	Allc	cate the signa	I to CN1-2	23.					
		n.□XXX	025	Allc	cate the signa	I to CN1-2	25.					
Pn5B8			027	Allc	cate the signa	I to CN1-2	27.					
			029	Allc	cate the signa	I to CN1-2	29.					
			031	Allc	cate the signa	I to CN1-3	31.					
			Polarity S	Sele	ction							
		VDDD	0	Dis	abled (the abo	ve signal c	output is no	ot used).				
			1	Out	put the above	signal.						
			2	Inve	ert the above s	ignal and	output it.					
			aI									

Continued from previous page.

						1				. p	0 00.90.
Parameter	ze	N	lame		Setting	Setting	Default	Applicable	When	Classi-	Refer-
No.	Si		lamo		Range	Unit	Setting	Motors	Enabled	fication	ence
	2	/PM (Preve tenance O Allocation	entative Ma utput) Sigr	in- al	0000 to 2039	-	0000	All	After restart	Setup	page 9-15
			Allocated	l Pin	Number						
			023	Allo	cate the signal	l to CN1-2	3.				
			025	Allo	cate the signal	I to CN1-2	5.				
Pp5BC			027	Allo	cate the signal	l to CN1-2	7.				
FIISBO			029	Allo	cate the signal	l to CN1-2	9.				
			031	Allo	ocate the signal	l to CN1-3	1.				
			Polarity S	Sele	ction						
			0	Dis	abled (the abov	ve signal o	utput is no	ot used).			
	n.XDDD		1	Out	tput the above	signal.					
			2 Inve		Invert the above signal and output it.						
Pn600 All Axes	2	Regenerat Capacity*3	egenerative Resistor		Depends on model.*3	10 W	0	All	Immedi- ately	Setup	page 5-52
Pn601	2	Dynamic E tor Allowat Consumpt	amic Brake Resis- Allowable Energy sumption		0 to 65,535	10 J	0	All	After restart	Setup	*5
Pn603 All Axes	2	Regenerat tance	enerative Resis-		0 to 65,535	10 m $\Omega$	0	All	Immedi- ately	Setup	page 5-52
Pn604	2	Dynamic E tance	Dynamic Brake Resis- tance		0 to 65,535	10 m $\Omega$	0	All	After restart	Setup	*5
									Continue	ed on nex	t page.

								Con	itinued from	n previou	s page.	
Parameter No.	Size	N	ame		Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence	
	2	Communic trols	ations Co	n-	0000 to 1FF3	-	1040	All	Immedi- ately	Setup	-	
					I		L	l.				
			MECHA	TROI	INK Commun	ications C	heck Mas	k for Debugg	ina			
			0	Do n	ot mask.							
			1	Ignor	e MECHATROI	_INK comr	nunication	s errors (A.E6	60).		_	
			2	Ignor	e WDT errors (	A.E50).		,	,		_	
			3	Ignor error:	e both MECHA s (A.E50).	TROLINK	communic	ations errors	(A.E60) and	WDT	_	
			Warning	Che	ck Masks						T	
			0	Do n	ot mask.							
			1	Ignor	e data setting	warnings (	A.94 <b>□</b> ).				_	
			2	Ignor	e command wa	arnings (A	.95□).				-	
			3	Ignor	e both A.94	and A.95	J warnings				_	
			4	Ignor	e communicati	ons warni	ngs (A.96 <b>E</b>	]).			_	
D=200			5	lgnor	e both A.94	and A.96	J warnings					
PN800			6	lgnor	e both A.95	and A.96 <b>E</b>	J warnings					
		n.🗆🗆 X 🗆	7	lgnor	e A.94 <b>□</b> , A.95	□, and A.	96 <b>□</b> warni	ngs.			_	
			8	lgnor	e data setting	warnings (	A.97A and	A.97b).			_	
			9	lgnor	e A.94 <b>□</b> , A.97	A, and A.9	97b warnin	gs.			_	
			A	Ignor	e A.95□, A.97	A, and A.S	97b warnin	gs.			_	
			В	Ignor	nore A.94□, A.95□, A.97A, and A.97b warnings.							
			С	lgnor	e A.96□, A.97	A, and A.9	97b warnin	gs.			_	
			D	Ignore A.94 $\Box$ , A.96 $\Box$ , A.97A, and A.97b warnings.								
			E	Ignore A.94□, A.95□, A.96□, A.97A, and A.97b warnings.								
			F	ignor	e A.94⊔, A.95	Ц, А.96Ц	, A.97A, a	10 A.970 War	nings.		_	
		n.¤X¤¤	Reserved parameter (Do not change.)									
		n.XDDD Automatic Warning Clear Selection for Debugging <sup>*6</sup>										
		M3*6	0	0 Retain warnings for debugging.								
			1	Auto	matically clear	warnings (	MECHATE	OLINK-III spe	ecification).		_	
	2	Application Selections Limits)	n Function 6 (Softwa	are	0000 to 0103	-	0003	All	Immedi- ately	Setup	page 6-21	
			Softwar	o Lim	it Soloction							
			0	Enab	le both forward	and reve	rse softwa	re limits			-	
		n.DDDX	1	Disat	ble forward soft	ware limit					_	
			2	Disat	ole reverse soft	ware limit.	-				_	
Pn801			3	Disat	le both forwar	d and reve	erse softwa	re limits.			_	
		n.DDXD	Reserve	d pa	rameter (Do no	ot change.	)				I	
			Software	e l im	it Check for R	eferences					T I	
		n. 🗆 X 🗆 🗆	0		ot perform soft	ware limit	checks for	references.			-	
			1	Perfo	rm software lin	nit checks	for referer	ices.			_	
											-	
	n.XDDD Reserved parameter (Do not change.)											
Pn803	2 Origin Range 0 to 250 1 refer- ence unit						10	All	Immedi- ately	Setup	*1	
Pn804	4	Forward S	oftware Li	mit	-1,073,741,823 to	1 refer- ence	107374 1823	All	Immedi- atelv	Setup	page 6-21	
					1,073,741,823	unit			,,			

Continued north previous page.	Continued	from	previous	page.
--------------------------------	-----------	------	----------	-------

							001		i previou	s page.
Parameter No.	Size	Name		Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
Pn806	4	Reverse Software	Limit	-1,073,741,823 to 1,073,741,823	1 refer- ence unit	-10737 41823	All	Immedi- ately	Setup	page 6-21
Pn808	4	Absolute Encoder Offset	Origin	-1,073,741,823 to 1,073,741,823	1 refer- ence unit	0	All	Immedi- ately <sup>*7</sup>	Setup	page 5-49
Pn80A	2	First Stage Linear eration Constant	Accel-	1 to 65,535	10,000 refer- ence units/s <sup>2</sup>	100	All	Immedi- ately <sup>*8</sup>	Setup	*1
Pn80B	2	Second Stage Lin Acceleration Cons	ear stant	1 to 65,535	10,000 refer- ence units/s <sup>2</sup>	100	All	Immedi- ately <sup>*8</sup>	Setup	*1
Pn80C	2	Acceleration Cons Switching Speed	stant	0 to 65,535	100 ref- erence units/s	0	All	Immedi- ately <sup>*8</sup>	Setup	*1
Pn80D	2	First Stage Linear Deceleration Cons	stant	1 to 65,535	10,000 refer- ence units/s <sup>2</sup>	100	All	Immedi- ately <sup>*8</sup>	Setup	*1
Pn80E	2	Second Stage Lin Deceleration Cons	ear stant	1 to 65,535	10,000 refer- ence units/s <sup>2</sup>	100	All	Immedi- ately <sup>*8</sup>	Setup	*1
Pn80F	2	Deceleration Cons Switching Speed	stant	0 to 65,535	100 ref- erence units/s	0	All	Immedi- ately <sup>*8</sup>	Setup	*1
Pn810	2	Exponential Accel tion/Deceleration	era- Bias	0 to 65,535	100 ref- erence units/s	0	All	Immedi- ately <sup>*9</sup>	Setup	*1
Pn811	2	Exponential Accel tion/Deceleration Constant	era- Time	0 to 5,100	0.1 ms	0	All	Immedi- ately <sup>*9</sup>	Setup	*1
Pn812	2	Movement Averag Time	е	0 to 5,100	0.1 ms	0	All	Immedi- ately *9	Setup	*1
Pn814	4	External Positionir Final Travel Distan	ig ce	-1,073,741,823 to 1,073,741,823	1 refer- ence unit	100	All	Immedi- ately	Setup	*1
	2	Origin Return Moc tings	le Set-	0000 to 0001	-	0000	All	Immedi- ately	Setup	*10
		Origin	Returr	Direction						1
		n.000X 0	Retu	rn in forward di	rection.					-
Pn816		1	Retu	rn in reverse di	rection.					-
M2 *11		n.DDXD Reser	ved pa	rameter (Do no	ot change.	)				I
		n. 🗆 X 🗆 🛛 🛛 Reser	ved pa	rameter (Do no	ot change.	)				
			ved na	rameter (Do no	t change	)				
			reu pa		r onange.	1				
Pn817 *12	2	Origin Approach S 1	speed	0 to 65,535	100 ref- erence units/s	50	All	Immedi- ately <sup>*8</sup>	Setup	*1
Pn818 *13	2	Origin Approach S 2	speed	0 to 65,535	100 ref- erence units/s	5	All	Immedi- ately <sup>*8</sup>	Setup	*1
Pn819	4	Final Travel Distan Origin Return	ce for	-1,073,741,823 to 1,073,741,823	1 refer- ence unit	100	All	Immedi- ately	Setup	*1
								<u> </u>		

11

Parameter No.         S         Name Bange Input Signal Monitor         Setting Range CCCC         Setting Unit Setting CCCC         Setting Motors         Motors Enabled Bases (mmcd- rately)         When Enabled Setting Motors         When Enabled Enable (mmcd- rately)         Setup Fiscion Setup         99           2         Ipput Signal Monitor Setup         0000 to CCCC         -         0000         All         Immed- rately)         Setup         99           Pn81E         Immed- Monitor CN1-2 input terminal.         -         0000         All         Immed- rately)         Setup         90           Monitor CN1-3 input terminal.         -         Monitor CN1-4 input terminal.         - <th></th> <th colspan="10">Continued from previous page.</th>		Continued from previous page.										
2         Input Signal Monitor         0000 to CCCC         -         0000         All         Immediately         Setup         10           Pn81E         0         Do not map.         -         0         Do not map.         -	Parameter No.	Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence	
Pn81E         Old Signal Mapping         Old Signal Mapping           Image: Second State		2	Input Sign	al Monitor	0000 to	_	0000	All	Immedi-	Setup	*10	
Pn81E <ul> <li>IOID Signal Mapping</li> <li>Monitor CN1-1 input terminal.</li> <li>Monitor CN1-2 input terminal.</li> <li>Monitor CN1-3 input terminal.</li> <li>Monitor CN1-3 input terminal.</li> <li>Monitor CN1-3 input terminal.</li> <li>Monitor CN1-1 input terminal.</li> <li>Monitor CN1-13 input terminal.</li> <li>Monitor CN1-14 input terminal.</li> <li>Monitor CN1-15 input terminal.</li> <li>Monitor CN1-16 input terminal.</li> <li>Monitor CN1-16 input terminal.</li> <li>Monitor CN1-16 input terminal.</li> <li>Monitor CN1-16 input terminal.</li> <li>Commond Data Mapping</li> <li>to C The mappings are the same as the IO12 signal mappings.</li> <li>IO15 Signal Mapping</li> <li>to C The mappings are the same as the IO12 signal mappings.</li> </ul> NLDID       Option Field Allocation       IO15 Signal Mapping         NLDID       Option Field Allocation.       IEld Signal Mapping         NLDID       Obto C The mappings are the same as the IO12 signal mappings.         NLDID       Option Field Allocation.         NLDID       Obto Disable option field allocation.         I Enable allocation. <td></td> <td></td> <td>Selections</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>atery</td> <td>•</td> <td></td>			Selections						atery	•		
Pn81E         0         Do rot map. 1         Monitor CN1-1 input terminal. 2         Monitor CN1-2 input terminal. 3         Monitor CN1-2 input terminal. 4           Monitor CN1-3 input terminal. 4         Monitor CN1-3 input terminal. 6         Monitor CN1-12 input terminal. 7         Monitor CN1-12 input terminal. 8           Monitor CN1-12 input terminal. 6         Monitor CN1-13 input terminal. 7         Monitor CN1-13 input terminal. 8         Monitor CN1-14 input terminal. 9           Monitor CN1-12 input terminal. 8         Monitor CN1-15 input terminal. 8         Monitor CN1-16 input terminal. 9           Monitor CN1-14 input terminal. 7         Monitor CN1-16 input terminal. 8         Monitor CN1-16 input terminal. 9           MDDD         O14 Signal Mapping 0 to C         The mappings are the same as the IO12 signal mappings. 7           NDDD         IO15 Signal Mapping 0 to C         The mappings are the same as the IO12 signal mappings. 7           NDDD         IO15 Signal Mapping 0 to C         O1111         -         0010         All         After restart         *10           MDDD         IO15 Signal Mapping 0 to C         Disable option field allocation. 1         -         0010         All         After restart         *10           MDDT         Disable option field allocation. 1         -         Disable option field allocation. 1         -         10         All         Immedi- atoly </td <td></td> <td>-</td>											-	
Pn81E         0         Do Not Trap. 1         Monitor CN1-1 input terminal. 2         Monitor CN1-2 input terminal. 3         Monitor CN1-3 input terminal. 4         Monitor CN1-3 input terminal. 5         Monitor CN1-14 input terminal. 6         Monitor CN1-14 input terminal. 6         Monitor CN1-14 input terminal. 7         Monitor CN1-14 input terminal. 8         Monitor CN1-14 input terminal. 9         Mon				IO12 Signal	Mapping							
Pn81E         Image: second secon				U Don	itor CN1-1 inpu	t terminal					_	
Pn81E         Image: Second Secon				2 Mon	itor CN1-2 inpu	t terminal.					_	
Pn81E <ul> <li>Monitor CN1-4 input terminal.</li> <li>Monitor CN1-5 input terminal.</li> <li>Monitor CN1-10 input terminal.</li> <li>Monitor CN1-11 input terminal.</li> <li>Monitor CN1-12 input terminal.</li> <li>Monitor CN1-13 input terminal.</li> <li>Monitor CN1-13 input terminal.</li> <li>Monitor CN1-13 input terminal.</li> <li>Monitor CN1-15 input terminal.</li> <li>Monitor CN1-16 input terminal.</li></ul>				3 Mon	itor CN1-3 inpu	t terminal.					_	
Pn81E         S         Monitor CN1-6 input terminal.           M2*11         A         Monitor CN1-11 input terminal.           M2*11         A         Monitor CN1-12 input terminal.           M2*11         A         Monitor CN1-12 input terminal.           M2*11         A         Monitor CN1-13 input terminal.           B         Monitor CN1-13 input terminal.         A           M Monitor CN1-13 input terminal.         B         Monitor CN1-16 input terminal.           B         Monitor CN1-16 input terminal.         B           N.IDDX         IO13 Signal Mapping 0 to C         The mappings are the same as the IO12 signal mappings.           N.IDD         IO15 Signal Mapping 0 to C         The mappings are the same as the IO12 signal mappings.         *10           M2*11         Option Field Allocation 1 Enable option field allocation.         1         Pister         *10           Pn81F         Option Field Allocation.         1         Enable option field allocation.         *10           Pn81F         Reserved parameter (Do not change.)         N.IDD         Reserved parameter (Do not change.)         All         Immedi- ately         Setup         *1           Pn820         4         Forward Latching Area         2,147,483,648 to 2,147,483,648         1 refer- on All         All				4 Mon	itor CN1-4 inpu	t terminal.					_	
Pn81E <ul> <li>MOITOR CN1-11 input terminal.</li> <li>Monitor CN1-12 input terminal.</li> <li>Monitor CN1-12 input terminal.</li> <li>Monitor CN1-13 input terminal.</li> <li>Monitor CN1-16 input terminal.</li> <li>Monitor CN1-15 input terminal.</li> <li>Monitor CN1-16 input terminal.</li> <li>Monitor CN1-16 input terminal.</li> <li>C Monitor CN1-16 input terminal.</li> <li>C The mappings are the same as the IO12 signal mappings.</li> <li>I C T he mappings are the same as the IO12 signal mappings.</li> <li>I C T he mappings are the same as the IO12 signal mappings.</li> <li>I Enable option field allocation.</li> <li>I Enable option field allocation.</li> <li>I Enable option field allocation.</li> <li>I Enable allocation.<td></td><td></td><td></td><td>5 Mon</td><td>itor CN1-5 inpu</td><td>t terminal.</td><td></td><td></td><td></td><td></td><td>-</td></li></ul>				5 Mon	itor CN1-5 inpu	t terminal.					-	
Pn81E       7       Monitor CN1-11 input terminal.         8       Monitor CN1-12 input terminal.       9         9       Monitor CN1-13 input terminal.       1         A       Monitor CN1-16 input terminal.       1         B       Monitor CN1-16 input terminal.       1013 Signal Mapping         n.□DXD       1013 Signal Mapping       1014 Signal Mapping         n.□DXD       1014 Signal Mapping       1014 Signal Mapping         n.□XDD       1015 Signal Mapping       1010 C         0 to C       The mappings are the same as the IO12 signal mappings.       1015 Signal Mapping         n.XDDD       1015 Signal Mapping       1111       -       0010       All       After restart       Setup       *10         Pn81F       2       Command Data Alloca-       0000 to 1111       -       0010       All       After restart       Setup       *10         Pn81F       0       Disable option field allocation.       1       Enable option field allocation.       1       Enable option.       1       Enable option.         n.□DXD       0       Disable allocation.       1       Enable allocation.       1       1       Enable allocation.       1       1       Enable allocation.       1       1       2,147,4			n.🗆🗆 🗆 X	6 Mon	itor CN1-6 inpu	t terminal.					_	
IM2*1       8       Monitor CN1-12 input terminal.         9       Monitor CN1-13 input terminal.         A       Monitor CN1-16 input terminal.         B       Monitor CN1-16 input terminal.         C       Monitor CN1-16 input terminal.         0       to C         The mappings are the same as the IO12 signal mappings.         n.       IO13 Signal Mapping         0       to C         0       to C         The mappings are the same as the IO12 signal mappings.         n.       IO15 Signal Mapping         0       to C         The mappings are the same as the IO12 signal mappings.         n.       IO15 Signal Mapping         0       to C         0       to C         The mappings are the same as the IO12 signal mappings.         n.       IO15 Signal Mapping         0       to C         The mappings are the same as the IO12 signal mappings.         n.       IO15 Signal Mapping         0       to C         The mappings are the same as the IO12 signal mappings.         n.       IO16 All cation         n.       III11         -       0010         All Enable option field allocation.	Pn81E			7 Mon	itor CN1-11 inp	ut termina	l.				_	
M2*11       9       Monitor CN1-13 input terminal.         A       Monitor CN1-14 input terminal.         B       Monitor CN1-15 input terminal.         C       Monitor CN1-16 input terminal.         n.□DXD       IO13 Signal Mapping 0 to C       The mappings are the same as the IO12 signal mappings.         n.□DXD       IO14 Signal Mapping 0 to C       The mappings are the same as the IO12 signal mappings.         n.NDDD       IO15 Signal Mapping 0 to C       The mappings are the same as the IO12 signal mappings.         n.NDDD       IO15 Signal Mapping 0 to C       Oto C       The mappings are the same as the IO12 signal mappings.         n.NDDD       IO15 Signal Mapping 0 to C       Oto C       The mappings are the same as the IO12 signal mappings.         M2*10       Option Field Allocation nDDX       Option Field Allocation.       1111       -       0010       All       After restart       Setup       *10         Pn81F       Position Control Command TFF/TLIM Allocation.       -       0       Disable allocation.       -       10       All       Mmedi- ately       *10         Pn81F       Position Control Command TFF/TLIM Allocation       -       0       Disable allocation.       -       10       Disable allocation.         nDIXD       Reserved parameter (Do not change.)       -<	THOTE			8 Mon	itor CN1-12 inp	ut termina	l.					
Pn81F <ul> <li>A forward Latching Area</li> <li>2,147,483,648</li> <li>1 refer- 0</li> <li>4 Forward Latching Area</li> </ul> <ul> <li>A forward Latching Area</li> <li>2,147,483,648</li> <li>1 refer- 0</li> <li>A forward Latching Area</li> </ul> <ul> <li>2,147,483,648</li> <li>1 refer- 0</li> <li>0 All</li> <li>1 mmedi- ately</li> <li>1 mmedi- 2,147,483,648</li> <li>1 refer- 0</li> <li>0 All</li> <li>1 mmedi- ately</li> <li>1 mmedi- 2,147,483,648</li> <li>1 refer- 0</li> <li>1 mmedi- 1 for 3 of 4 forward Latching Area</li> <li>2,147,483,648</li> <li>1 refer- 0</li> <li>0 All</li> <li>1 mmedi- ately</li> <li>2,147,483,648</li> <li>1 refer- 0</li> <li>1 mmedi- ately</li> <li>1 mmedi- 3,163,647</li> <li>1 for 3,163,647</li> <li>1 mmedi- ately</li> <li>1 mmedi- 3,163,647</li> <li>1 mmedi- 3,163,647</li> <li>1,143,648</li> <li>1 mmedi- 3,163,647</li> <li>1 mmedi- 3,147,483,648</li> <li>1 mmedi- 3,163,647</li> <li1 mmedi-<="" td=""><td>M2 *11</td><td></td><td></td><td>9 Mon</td><td>itor CN1-13 inp</td><td>ut termina</td><td>l.</td><td></td><td></td><td></td><td>_</td></li1></ul>	M2 *11			9 Mon	itor CN1-13 inp	ut termina	l.				_	
B       Monitor CN1-15 input terminal.         C       Monitor CN1-16 input terminal.         n.□X□       IO13 Signal Mapping 0 to C       The mappings are the same as the IO12 signal mappings.         n.□X□□       IO14 Signal Mapping 0 to C       The mappings are the same as the IO12 signal mappings.         n.□X□□       IO15 Signal Mapping 0 to C       The mappings are the same as the IO12 signal mappings.         n.□□□       IO15 Signal Mapping 0 to C       The mappings are the same as the IO12 signal mappings.         Pn81F       Q       Command Data Alloca- tions       0000 to 1111       -       0010       All       After restart       Setup       *10         Pn81F       M2<*11       Position Control Command TFF/TLIM Allocation 1       Enable option field allocation.       - <td></td> <td></td> <td></td> <td>A Mon</td> <td>itor CN1-14 inp</td> <td>ut termina</td> <td>l.</td> <td></td> <td></td> <td></td> <td>_</td>				A Mon	itor CN1-14 inp	ut termina	l.				_	
C       Monitor CN1-16 input terminal.         n.□CX□       IO13 Signal Mapping 0 to C       The mappings are the same as the IO12 signal mappings.         n.□X□□       IO14 Signal Mapping 0 to C       The mappings are the same as the IO12 signal mappings.         n.□X□□       IO15 Signal Mapping 0 to C       The mappings are the same as the IO12 signal mappings.         n.X□□□       IO15 Signal Mapping 0 to C       The mappings are the same as the IO12 signal mappings.         n.X□□□       IO15 Signal Mapping 0 to C       The mappings are the same as the IO12 signal mappings.         n.□□□       Oto C       The mappings are the same as the IO12 signal mappings.         n.□□□       Oto C       The mappings are the same as the IO12 signal mappings.         n.□□□       Oto C       The mappings are the same as the IO12 signal mappings.         n.□□□       Oto C       The mappings are the same as the IO12 signal mappings.         n.□□       Oto C       The mapping on the same as the IO12 signal mappings.         n.□□       Option Field Allocation 1       Enable option field allocation.         n.□       DICI       Option Field Allocation.       Immediae         n.□       DICI       Reserved parameter (Do not change.)       Immediae         n.□       Reserved parameter (Do not change.)       All       Immediately       Setup       <				B Mon	itor CN1-15 inp	ut termina	l.				_	
n.□□X□       IO13 Signal Mapping 0 to C       The mappings are the same as the IO12 signal mappings.         n.□X□□       IO14 Signal Mapping 0 to C       The mappings are the same as the IO12 signal mappings.         n.X□□□       IO15 Signal Mapping 0 to C       The mappings are the same as the IO12 signal mappings.         n.X□□□       IO15 Signal Mapping 0 to C       The mappings are the same as the IO12 signal mappings.         n.X□□□       IO15 Signal Mapping 0 to C       The mappings are the same as the IO12 signal mappings.         2       Command Data Alloca- tions       0000 to 1111       -       0010       All       After restart       Setup       *10         Pn81F       0       Disable option field allocation. 1       Enable option field allocation. 1       -       0010       All       After restart       Setup       *10         M2*11       -       Option Field Allocation 1       -       0010       All       Immedi- restart       Setup       *10         M2*11       -       0       Disable allocation. 1       -				C Mon	itor CN1-16 inp	ut termina	l.				_	
Pn81F       0 <td></td> <td></td> <td></td> <td>IO13 Signal</td> <td>Mapping</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>Ī</td>				IO13 Signal	Mapping						Ī	
N.IXIII       IO14 Signal Mapping 0 to C       The mappings are the same as the IO12 signal mappings.         N.XIIIII       IO15 Signal Mapping 0 to C       The mappings are the same as the IO12 signal mappings.         N.XIIIII       Ot C       The mappings are the same as the IO12 signal mappings.         IO15 Signal Mapping n.XIIIII       Ot C       The mappings are the same as the IO12 signal mappings.         IO10       All       After restart       Setup       *10         IO10       All       After restart       Setup       *10         IO10       All       After restart       Setup       *10         IO10       Disable option field allocation.       1       Enable option field allocation.         IO10       N       Position Control Command TFF/TLIM Allocation       1       Enable allocation.         IO10       Disable allocation.       1       Enable allocation.       1       Enable allocation.         IO20       Reserved parameter (Do not change.)       IO10       Immediately       Setup       *1         Pn820       4       Forward Latching Area       2147,483,644 2,147,483,644       1 refer- ence 0       0       All       Immediately       Setup       *1         Pn822       4       Reverse Latching Area       2147,493,644       <				0 to C The	mappings are tl	ne same a	s the IO12	signal mapp	ings.		-	
N.EXED       Iotrogram mappings         0 to C       The mappings are the same as the IO12 signal mappings.         n.XEDD       IO15 Signal Mapping         0 to C       The mappings are the same as the IO12 signal mappings.         n.XEDD       IO15 Signal Mapping         0 to C       The mappings are the same as the IO12 signal mappings.         2       Command Data Alloca-       0000 to         1111       -       0010       All       After restart       Setup       *10         Pn81F       Option Field Allocation       -       010       All       After restart       Setup       *10         Pn81F       Option Field Allocation       -       0       Disable option field allocation.       -				IO14 Signal	Manning						T	
Option       Field Allocation       0010       All       After restart       Setup       *10         Pn81F       0       0       Disable option field allocation.       0       0       Disable option field allocation.       1       1       Enable option field allocation.       *10         Pn81F       0       0       Disable option field allocation.       1       Enable option field allocation.       *10         N.DDD**********************************			n.🗆X🗆 🗆	0 to C The	mapping are t	he same a	s the IO12	signal mapp	inas.			
N.XIIII       IO15 Signal Mapping 0 to C       The mappings are the same as the IO12 signal mappings.         2       Command Data Alloca- tions       0000 to 1111       -       0010       All       After restart       Setup       *10         Pn81F       0       Disable option field Allocation. 1       Enable option field allocation. 1       -       0010       All       After restart       Setup       *10         Pn81F       0       Disable option field allocation. 1       Enable option field allocation. 1       - <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td>5-</td> <td></td> <td>-</td>									5-		-	
O to C       The mappings are the same as the IO12 signal mappings.         2       Command Data Alloca- tions       0000 to 1111       -       0010       All       After restart       Setup       *10         Pn81F         M2*11       Option Field Allocation         n.□□IX       Option Field Allocation.         1       Enable option field allocation.         1       Enable option field allocation.         n.□DX□       Position Control Command TFF/TLIM Allocation         n.□X□       Reserved parameter (Do not change.)         n.□X□       Reserved parameter (Do not change.)         n.X□□□       Reserved parameter (Do not change.)         n.820       A       Forward Latching Area       -2,147,483,648       1 reference       0       All       Immediately       Setup       *1         Pn822       4       Reverse Latching Area       -2,147,483,648       1 reference       0       All       Immediately       Setup <th colspan<="" td=""><td></td><td></td><td>n.X000</td><td>IO15 Signal</td><td>Mapping</td><td></td><td></td><td></td><td></td><td></td><td></td></th>	<td></td> <td></td> <td>n.X000</td> <td>IO15 Signal</td> <td>Mapping</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>			n.X000	IO15 Signal	Mapping						
2       Command Data Alloca- tions       0000 to 1111       -       0010       All       After restart       Setup       *10         Pn81F       n.□□□X       0       Disable option field allocation. 1       Enable option field allocation. 1       Enable option field allocation. 1       F		_		0 to C The	ne mappings are the same as the IO12 signal mappings.							
2       Command Data Alloca- tions       0000 to 1111       -       0010       All       After restart       Setup       *10         Pn81F       0       Disable option field Allocation.       0       Disable option field allocation.       -				<b>D</b>					A 61	1		
Pn81F       Option Field Allocation 0       Disable option field allocation.         1       Enable allocation.         1       <		2	tions	Data Alloca-	0000 to 1111	-	0010	All	After restart	Setup	*10	
Pn81F       Option Field Allocation         Image: Non-Field Allocation       0       Disable option field allocation.         Image: Non-Field Allocation       1       Enable option field allocation.         Image: Non-Field Allocation       1       Enable option field allocation.         Image: Non-Field Allocation       1       Enable option field allocation.         Image: Non-Field Allocation       0       Disable option field allocation.         Image: Non-Field Allocation       0       Disable allocation.         Image: Non-Field Allocation       1       Enable allocation.         Image: Non-Field Allocation.       Non-Field Allocation.       Non-Field Alloc						I					I	
Pn81F       0       Disable option field allocation.         M2*11       1       Enable option field allocation.         M2*11       0       Disable allocation.         M2*11       0       Disable allocation.         M2*11       0       Disable allocation.         N.DDXD       0       Disable allocation.         1       Enable allocation.         1       Enable allocation.         1       Enable allocation.         N.DDXD       Reserved parameter (Do not change.)         N.XDDD       Reserved parameter (Do not change.)         N.XDDD       Reserved parameter (Do not change.)         Pn820       4       Forward Latching Area       -2,147,483,648       1 refer- ence unit       0       All       Immedi- ately       Setup       *1         Pn822       4       Reverse Latching Area       -2,147,483,648       1 refer- ence       0       All       Immedi- ately       Setup       *1		1		Option Field	Allocation						T	
Pn81F       Position Control Command TFF/TLIM Allocation         M2*11       Position Control Command TFF/TLIM Allocation         M2*11       Position Control Command TFF/TLIM Allocation         Image: Second control control command control command tree control command control command control command tree control command control command tree control command control control command control contende control contendecontrol control contr			n.🗆 🗆 🗆 X	0 Disa	ble option field	allocation.					-	
Prior       Position Control Command TFF/TLIM Allocation         M2*11       Position Control Command TFF/TLIM Allocation         Image: Non-Image: Image: Image				1 Enat	ble option field a	allocation.					_	
M2*11       Image: Position Control Contenditicon Control Control Contendity Control Control C	PNOIF	ī		Besition Cor	tral Command		1 Allocatio	<b>n</b>			-	
Image: Intervention of the product	M2 *11						Allocatio	11				
n.□X□□       Reserved parameter (Do not change.)         n.□X□□       Reserved parameter (Do not change.)         n.X□□□       Reserved parameter (Do not change.)         Pn820       4       Forward Latching Area       -2,147,483,648 to 2,147,483,647       1 refer- ence unit       0       All       Immedi- ately       Setup       *1         Pn822       4       Reverse Latching Area       -2,147,483,648 to 2,147,483,647       1 refer- ence unit       0       All       Immedi- ately       Setup       *1				1 Enat	ole allocation.						_	
n.DXDD       Reserved parameter (Do not change.)         n.XDDD       Reserved parameter (Do not change.)         Pn820       4       Forward Latching Area       -2,147,483,648       1 reference on the second control of the second contex and control of the second control of the se		- 1									_	
n.X□□□       Reserved parameter (Do not change.)         Pn820       4       Forward Latching Area       -2,147,483,648 to 2,147,483,647       1 refer- ence unit       0       All       Immedi- ately       Setup       *1         Pn822       4       Reverse Latching Area       -2,147,483,648 to 2,147,483,647       1 refer- ence unit       0       All       Immedi- ately       Setup       *1			n.¤X¤¤	Reserved pa	rameter (Do no	ot change.	)					
Pn820       4       Forward Latching Area       -2,147,483,648 to 2,147,483,647       1 refer- ence unit       0       All       Immedi- ately       Setup       *1         Pn822       4       Reverse Latching Area       -2,147,483,648 2,147,483,647       1 refer- ence unit       0       All       Immedi- ately       Setup       *1			n.XDDD	Reserved parameter (Do not change.)								
Pn820       4       Forward Latching Area       -2,147,483,648 to 2,147,483,647       1 refer- ence unit       0       All       Immedi- ately       Setup       *1         Pn822       4       Reverse Latching Area       -2,147,483,648 to 2,147,483,647       1 refer- ence to 2,147,483,647       0       All       Immedi- ately       Setup       *1		-									_	
Pn820       4       Forward Latching Area       to 2,147,483,647       ence unit       0       All       Intribut- ately       Setup       *1         Pn822       4       Reverse Latching Area       -2,147,483,648       1 refer- ence 0       0       All       Immedi- ately       Setup       *1					-2,147,483,648	1 refer-			Immodi			
Pn822     4     Reverse Latching Area     -2,147,483,648     1 refer- ence     0     All     Immedi- ately     Setup     *1	Pn820	4	Forward La	atching Area	to 2 147 483 647	ence	0	All	ately	Setup	*1	
Pn822 4 Reverse Latching Area to ence 0 All Immediately Setup *1		-2.147,483,648 1 refer-										
	Pn822	4	Reverse La	atching Area	to	ence	0	All	ately	Setup	*1	

Continued from previous page.

							001		in previou	s page.		
Parameter No.	Size		Name	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence		
	2	Option M tion	Ionitor 1 Selec-	0000 to FFFF	-	0000	-	Immedi- ately	Setup	*1		
						r.		I.				
		Setting			Monitor			Ap	plicable M	otors		
	Н	igh-Speed	d Monitor Regior	n								
	0	000 hex	Motor speed [1	000000 hex/o	verspeed	detection s	speed]		All			
	0	001 hex	Speed reference	e [1000000 he	ex/overspe	ed detecti	on speed]		All			
	0	002 hex	Torque [100000	00 hex/maximu	ım torque]				All			
	0	003 hex	Position deviati	on (lower 32 b	its) [refere	nce units]			All			
	0	004 hex	Position deviati	on (upper 32 b	oits) [refere	ence units]			All			
	0	00A hex	Encoder count	(lower 32 bits)	[reference	e units]			All			
	0	00B hex	Encoder count	(upper 32 bits)	) [reference	e units]			All			
	L	ow-Speed	I Monitor Regior	ו								
	0	010 hex	Un000: Motor s	speed [min <sup>-1</sup> ]					All			
	0	011 hex	Un001: Speed	Reference [mir	<sup>-1</sup> ]				All			
	0	012 hex	Un002: Torque	Reference [%]					All			
	0	013 hex	Un003: Rotatio Number of enc displayed in de	nal Angle 1 [er oder pulses fro cimal	ncoder pul om origin v	ses] vithin one (	encoder rotati	ion	All			
			Un003: Rotatio Linear encoder	nal Angle 1 [lin pulses from th	layed in decir	mal						
Dp904	0	014 hex	Un004: Rotatio Electrical angle	nal Angle 2 [de from polarity c	eg] prigin				All			
F11024			Un004: Electric Electrical angle	al Angle 2 [deg from polarity o	g] origin				7.01			
M3 <sup>10</sup>	0	015 hex	Un005: Input S	ignal Monitor					All			
	0	016 hex	Un006: Output	Signal Monitor					All			
	0	017 hex	Un007: Input R	eference Spee	d [min <sup>-1</sup> ]				All			
	0	018 hex	Un008: Position	n Deviation [ref	erence un	its]			All			
	0	019 hex	Un009: Accum	ulated Load Ra	atio [%]				All			
	0	01A hex	Un00A: Regene	erative Load Ra	atio [%]				All			
	0	01B hex	Un00B: Dynam	ic Brake Resis	tor Power	Consump	tion [%]		All			
	0	01C hex	Un00C: Input F	Reference Pulse	e Counter	[reference	units]		All			
	0	01D hex	Un00D: Feedba	ack Pulse Cour	nter [enco	der pulses	]		All			
	0	023 hex	Initial multiturn	data [Rev]					Rotary			
	0	024 hex	Initial increment	tal data [pulses	6]				Rotary			
	0	025 hex	Initial absolute	position data (I	ower 32 b	its) [pulses	6]		Linear			
	0	026 hex	Initial absolute	position data (i	upper 32 k	oits) [pulse	s]		Linear			
	0	040 hex	Un025: SERVC	PACK Installat	ion Enviro	nment Mo	nitor		All			
	0	041 hex	Un026: Servor	notor Installatio	n Environ	ment Moni	tor		All			
	0	042 hex	Un027: Built-in	Fan Remaining	g Life Rati	0			All			
	0	043 hex	Un028: Capaci	tor Remaining	Life Ratio			All				
	0	044 hex	Un029: Surge I	Prevention Circ	uit Remai	ning Life R	atio		All			
	0	045 hex	Un02A: Dynam	ic Brake Circui	it Remainir	ng Life Rat	io		All			
	0	046 hex	Un032: Instant	aneous Power					All			
	0	047 hex	Un033: Power	Consumption					All			
	0	048 hex	Un034: Cumula	ative Power Co	nsumption	<u></u> ו			All			

								Con	itinu	ed fron	n previous	s page.
Parameter	ize	N	lame		Setting	Setting	Default	Applicable	V	/hen	Classi-	Refer-
No.	ت. ا				Range	Unit	Setting	Motors	En	abled	fication	ence
		Setting				Monitor				Applic	cable Moto	ors
		Communica	ations Mo	odule	Only					1		
D - 00 4		0080 hex	Previou: pulses]	s value	e of latched fee	dback po	sition (LPC	S1) [encoder			All	
Pn824		0081 hex	Previou: pulses]	s value	e of latched fee	dback po	sition (LPC	S2) [encoder			All	
M3 *6		0084 hex	Continu	ous La	atch Status (EX	(STATUS)					All	
		All Areas	1							1		
		Other values	Reserve	ed sett	ings (Do not us	se.)					All	
	2	Option Mo tion	onitor 2 S	elec-	0000 to FFFF	-	0000	All	lm a	medi- ately	Setup	*1
		- H				r.			1		1 1	
Pn825		0000 hex to	)						0 1			_
		0084 hex	The se	ettings	are the same	as those t	or the Opti	ion Monitor I	Sele	ction.		_
		<u>-</u>				10,000						
Pn827	2	Linear Dec Constant	celeration 1 for Stop	pniq	1 to 65,535	reter- ence	100	All	Im at	medi- elv <sup>*8</sup>	Setup	*1
			•	1 0		units/s <sup>2</sup>						
Pn829	2	SVOFF Wa SVOFF at to Stop)	aiting Tim Decelera	e (for tion	0 to 65,535	10 ms	0	All	lm at	medi- ely <sup>*8</sup>	Setup	*1
	2	Option Fie	ld Alloca	tions	0000 to	_	1813	All	ļ	After	Setup	*10
	_	1			1E1E				re	estart	ootap	
												-
	ACCFIL Allocation (Option)											
			0	Alloca	ate bits 0 and 1		IL.					-
			1	Alloca	ate bits 1 and 2		IL.					_
			3	Alloca	ate bits 3 and 4	4 to ACCE	IL.					-
			4	Alloca	ate bits 4 and 8	5 to ACCF	IL.					-
			5	Alloca	ate bits 5 and 6	5 to ACCF	IL.					_
			6	Alloca	ate bits 6 and 3	7 to ACCF	IL.					_
			7	Alloca	ate bits 7 and 8	3 to ACCF	IL.					_
			8	Alloca	ate bits 8 and 9	9 to ACCF	IL.					_
			9	Alloca	ate bits 9 and	10 to ACC	FIL.					_
Pn82A			A	Alloca	ate bits 10 and	11 to AC						-
M2 *11			Б С	Alloca	ate bits 11 and	12 to AC						-
			D	Alloca	ate bits 13 and	14 to AC	CEIL.					-
			E	Alloca	ate bits 14 and	15 to AC	CFIL.					_
			ACCEII	Alloc	ation Enable/[	Disable Se						
		n.DDXD	0	Disab	le ACCFIL allo	cation.						
			1	Enab	le ACCFIL allo	cation.						-
												_
			G_SEL	Alloca	ation (Option)							
			0 to E	The s	ettings are the	same as	for the AC	CFIL allocatio	ns.			_
			0.05	A 11 -	then Fridd (S	lask la O						
			G_SEL	Dicol	ation Enable/D	isable Sel	ection					
			1	Fnab	le G SEL alloc	ation						-
				Lindo								-

Continued from previous page.

Parameter No.	Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
	2	Option Fiel	d Allocations	0000 to 1F1F	-	1D1C	All	After restart	Setup	*10
		р. ПППХ	V_PPI Alloca 0 Alloc 1 Alloc 2 Alloc 3 Alloc 4 Alloc 5 Alloc 6 Alloc 7 Alloc	tion (Option) ate bit 0 to V_F ate bit 1 to V_F ate bit 2 to V_F ate bit 3 to V_F ate bit 4 to V_F ate bit 5 to V_F ate bit 5 to V_F ate bit 6 to V_F	PPI. PPI. PPI. PPI. PPI. PPI. PPI. PPI.					
Pn82B M2 *11			8     Alloc       9     Alloc       9     Alloc       B     Alloc       C     Alloc       D     Alloc       E     Alloc       F     Alloc	ate bit 7 to v_r ate bit 8 to V_F ate bit 9 to V_F ate bit 10 to V_ ate bit 11 to V_ ate bit 12 to V_ ate bit 13 to V_ ate bit 14 to V_ ate bit 15 to V_	PPI. PPI. PPI. PPI. PPI. PPI. PPI. PPI.					
		n.OOXO	V_PPI Alloca0Disate1Enable	tion Enable/Di ble V_PPI alloca le V_PPI alloca	sable Sele ation. tion.	ection				_
		n.¤X¤¤	P_PI_CLR AI0 to FThe s	ocation (Optic	on) same as	for the V_F	PI allocations	5.		
		n.X000	P_PI_CLR AI0Disate1Enable	location Enabl ble P_PI_CLR a le P_PI_CLR a	e/Disable Illocation.	Selection				
	2	Option Fiel 3	d Allocations	0000 to 1F1F	_	1F1E	All	After restart	Setup	*10
		n.DDDX	P_CL Allocat 0 to F The s	>L Allocation (Option)         > F         The settings are the same as for the V_PPI allocations.						
Pn82C		n.OOXO	P_CL Allocat0Disat1Enab	ion Enable/Dis ble P_CL alloca le P_CL alloca	able Sele ition. tion.	ction				_
		n.¤X¤¤	N_CL Allocat0 to FThe s	ion (Option) settings are the	same as	for the V_F	PPI allocations	3.		
		n.XDDD	N_CL Allocat0Disat1Enab	ion Enable/Dis ble N_CL alloca le N_CL alloca	sable Sele ation. tion.	ction				_

Continued on next page.

								Con	tinued fron	n previou	s page.
Parameter No.	Size	N	lame		Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
	2	Option Fie 4	ld Alloca	tions	0000 to 1F1C	-	0000	All	After restart	Setup	*10
	- [		BANK_	SEL1	Allocation (Op	tion)					
			0	Alloca	ate bits 0 to 3	to BANK_	SEL1.				
			1	Alloca	ate bits 1 to 4	to BANK_	SEL1.				
			2	Alloc	ate bits 2 to 5	to BANK_	SEL1.				
			3	Alloca	ate bits 3 to 6	to BANK_	SEL1.				
			4	Alloca	ate bits 4 to 7	to BANK_	SEL1.				
		n.DDDX	5	Alloca	ate bits 5 to 8	to BANK_	SEL1.				_
			6	Alloc	ate bits 6 to 9	to BANK_	SEL1.				_
			7	Alloca	ate bits 7 to 10	) to BANK	_SEL1.				_
			8	Alloca	ate bits 8 to 11	to BANK	_SEL1.				
Pn82D			9	Alloca	ate bits 9 to 12	to BANK	_SEL1.				_
*11				Alloca	ate bits 10 to 1	3 to BAN	COFL1				_
M2 **			В	Allocate bits 11 to 14 to BANK_SEL1.							
			U	Alloca		5 LU BAIN	SELT.				
	Ī		BANK_	SEL1	Allocation Ena	able/Disab	le Selectio	on			
		n.DDXD	0	Disab	le BANK_SEL	1 allocatio	n.				_
			1	Enab	le BANK_SEL1	allocatior	۱.				
	LT_DISABLE Allocation (Option)										
			0 to F	F The settings are the same as for the V_PPI allocations.							
											_
			LT_DIS	ABLE	Allocation Ena	able/Disat	le Selection	on			
		n.XDDD	0	Disat	ble LT_DISABLI	E allocatio	n.				
	_		1	Enab	Ie LI_DISABLE	allocatior	1.				

Continued from previous page.

Parameter No.	Size	N	lame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
	2	Option Fie 5	eld Allocations	0000 to 1D1F	-	0000	All	After restart	Setup	*10
		n.DDDX	Reserved pa	rameter (Do no	ot change.	)				
		n.DDXD	Reserved pa	rameter (Do no	ot change.	)				
			OUT_SIGNA	L Allocation (O	ption)					
			0 Alloc	ate bits 0 to 2 t	to OUT_SI	GNAL.				_
			1 Alloc	ate bits 1 to 3 t		GNAL.				_
			2 Alloc	ate bits 2 to 5 t		GNAL.				_
			4 Alloc	ate bits 4 to 6 t	to OUT_SI	GNAL.				_
Pn82E			5 Alloc	ate bits 5 to 7 t	to OUT_SI	GNAL.				
M2 *11		n.¤X¤¤	6 Alloc	ate bits 6 to 8 t	to OUT_SI	GNAL.				_
			7 Alloc	ate bits 7 to 9 t	to OUT_SI	GNAL.				_
			8 Alloc	ate bits 8 to 10	) to OUT_S	SIGNAL.				
			9 Alloc	ate bits 9 to 11	to OUT_S	SIGNAL.				_
			A Alloc	ate bits 10 to 1	2 to OUT_	SIGNAL.				_
			B Alloc	ate bits 11 to 1	3 to OUT_	SIGNAL.				
				ate bits 12 to 1	4 to OUT_	SIGNAL.				_
			DAIIOC		5 10 001	SIGNAL.				_
			OUT_SIGNA	L Allocation Er	nable/Disa	ble Select	ion			
	n.XDDD 0 Disable OUT_SIGNAL allocation.									
			<b>1</b> Enab	le OUT_SIGNA	L allocatio	n.				
		_			1		1		1	
	2	Motion Se	ettings	0000 to 0001	-	0000	All	After restart	Setup	*1
				austice (Decale	unting One	ataut Cal				-
				Pn80A to Pn80		1Stant Sele	ettings of Pro	334 to Pn84	) are	
		n.🗆🗆 🗆 X	0 ignor	rnooA to Fnoo red.)		527. (THE S	ettings of Frid	554 LU F1104	Jare	
Pn833			1 Use	Pn834 to Pn84	0. (The se	ttings of P	n80A to Pn80	F and Pn82	7 are	_
			Ignoi	ed.)						_
		n.🗆🗆 X 🗆	Reserved pa	rameter (Do no	ot change.	)				
		n.¤X¤¤	Reserved pa	rameter (Do no	ot change.	)				1
		n XOOO	Reserved pa	rameter (Do no	ot change	)				
			neserved pa		onange.	/				
					10.000					
Pn834	4	First Stage	e Linear Accel-	1 to	refer-	100	ΔШ	Immedi-	Setup	*1
1 11004	-	eration Co	onstant 2	20,971,520	ence units/s <sup>2</sup>	100	711	ately *8	Octup	
					10,000					
Pn836	4	Second St	tage Linear	1 to	refer-	100	All	Immedi-	Setup	*1
		Accolutati		20,011,020	units/s <sup>2</sup>			atery		
Dp929	л	Accelerati	on Constant	0 to	1 refer-	0	Δ11	Immedi-	Sotup	*1
r11030	4	Switching	Speed 2	2,097,152,000	unit/s	U	All	ately *8	Setup	-1
		Eirot Oto	Lipoor	1 +0	10,000			Immodi		
Pn83A	4	Decelerati	e Linear on Constant 2	20,971,520	ence	100	All	ately *8	Setup	*1
			Deceleration Constant 2		units/s <sup>2</sup>		,			

Continued on next page.

								Con	tinued from	n previou	s page.
Parameter No.	Size	N	ame		Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
Pn83C	4	Second St Deceleratio	age Line on Cons	ear tant 2	1 to 20,971,520	10,000 refer- ence units/s <sup>2</sup>	100	All	Immedi- ately <sup>*8</sup>	Setup	*1
Pn83E	4	Deceleration Switching	on Cons Speed 2	tant	0 to 2,097,152,000	1 refer- ence unit/s	0	All	Immedi- ately <sup>*8</sup>	Setup	*1
Pn840	4	Linear Dec Constant 2	eleratior for Sto	ו pping	1 to 20,971,520	10,000 refer- ence units/s <sup>2</sup>	100	All	Immedi- ately <sup>*8</sup>	Setup	*1
Pn842 *12	4	Second Or Approach	rigin Speed 1		0 to 20,971,520	100 ref- erence units/s	0	All	Immedi- ately <sup>*8</sup>	Setup	*1
Pn844 *13	4	Second Or Approach	rigin Speed 2		0 to 20,971,520	100 ref- erence units/s	0	All	Immedi- ately <sup>*8</sup>	Setup	*1
Pn846	2	POSING C Scurve Ac Deceleration	ommano celeratio on Rate	d n/	0 to 50	1%	0	All	Immedi- ately <sup>*8</sup>	Setup	_
Pn850	2	Number of Sequences	Latch		0 to 8	-	0	All	Immedi- ately	Setup	*1
Pn851	2	Continuous Latch Sequence Count			0 to 255	-	0	All	Immedi- ately	Setup	*1
	2	Latch Seq Settings	uence 1	to 4	0000 to 3333	-	0000	All	Immedi- ately	Setup	*1
			Latch	tch Sequence 1 Signal Selection							
			0	Phase C							
		n.ПППХ	1	FXT1	signal						
			2	EXT2	' signal						_
			3	EXT3	signal						_
	- 1				- 3 -						-
Pn852			Latch	Seque	nce 2 Signal S	election					
		n.□□X□	0 to 3	3 The settings are the same as those for the Latch Sequence 1 Signal Selection.							
	Latch Sequence 3 Signal Selection								T		
		n.¤X¤¤	0 to 3	The stion.	settings are the	same as	those for t	he Latch Seq	uence 1 Sigr	nal Selec-	_
			Latch Sequence 4 Signal Selection								T I
		n.XDDD		The settings are the same as those for the Latch Sequence 1 Signal Selec-							-
			0 to 3	tion.		23					_

Continued from previous page.

Parameter No.	Size	N	ame		Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence	
	2	Latch Seq Settings	uence 5 1	to 8	0000 to 3333	-	0000	All	Immedi- ately	Setup	*1	
		1									<u> </u>	
			Latch S	Sequer	nce 5 Signal S	election						
			0	Phase	эC						-	
		n.🗆🗆 🗆 X	1	EXT1	signal						-	
			2	EXT2	signal						_	
			3	EXT3	signal						_	
B 050			Latch S	Sequer	nce 6 Signal S	election					<b>I</b>	
Pn853		n.□□X□	0 to 3	The s tion.	ettings are the	same as	those for t	he Latch Seq	uence 5 Sigr	nal Selec-	_	
			Latch S	Sequer	nce 7 Signal S	election					1	
		n.¤X¤¤	0 to 3	The s tion.	ettings are the	same as	those for t	he Latch Seq	uence 5 Sigr	nal Selec-	_	
			Latch S	Sequer	nce 8 Signal S	election						
		n.XDDD	0 to 3	The s tion.	ettings are the	same as	those for t	he Latch Seq	uence 5 Sigr	nal Selec-	-	
	2	SVCMD_IC Monitor Al	D Input Si locations	ignal 1	0000 to 1717	-	0000	All	Immedi- ately	Setup	*1	
			Input Signal Monitor Allocation for CN1-3 (SVCMD_IO)									
			0 Allocate bit 24 (IO_STS1) to CN1-3 input signal monitor.								_	
			1	Alloca	ate bit 25 (IO_8	STS2) to C	N1-3 inpu	t signal monit	or.		_	
			2	Alloca	ate Dit 26 (IO_3	STS3) to C		t signal monit	or.		-	
			3	Alloca	ate bit 28 (IO $_{\circ}$	STS5) to C	N1-3 inpu	t signal monit	or.		-	
			5	Alloca	ate bit 29 (10_6	STS6) to C	N1-3 inpu	t signal monit	or.		_	
Pn860			6	Alloca	ate bit 30 (10 §	STS7) to C	N1-3 inpu	t signal monit	or.		_	
*6			7	Alloca	ate bit 31 (IO_S	STS8) to C	N1-3 inpu	t signal monit	or.		_	
<u>M3</u> 10			CN1-3	Input :	Signal Monito	r Enable/D	Disable Se	lection				
		n.🗆🗆 X 🗆	0	Disab	le allocation fo	or CN1-3 in	nput signal	l monitor.			-	
			1	Enabl	e allocation fo	r CN1-3 in	iput signal	monitor.			_	
			Input S	ignal N	Monitor Alloca	tion for C	N1-4 (SVC	CMD_IO)				
		n.UXUU	0 to 7 The settings are the same as the CN1-3 allocations.								_	
			CN1-4 Input Signal Monitor Enable/Disable Selection									
		n.XDDD	0	0 Disable allocation for CN1-4 input signal monitor.							_	
			1	1 Enable allocation for CN1-4 input signal monitor.							_	

Continued on next page.

							Con	tinued from	n previou	s page.			
Parameter No.	Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence			
	2	SVCMD_IC Monitor All	) Input Signal locations 2	0000 to 1717	_	0000	All	Immedi- ately	Setup	*1			
			Input Signal	Monitor Alloca	tion for C	N1-5 (SVC	CMD_IO)			[			
			0 to 7 The	settings are the	e same as	the CN1-3	allocations.			_			
			CN1-5 Input	Signal Monito	r Enable/[	Disable Se	lection						
Pn861		n.🗆 🗆 X 🗆	0 Disa	ble allocation fo	or CN1-5 i	nput signal	monitor.			-			
*/			1 Enat	le allocation fo	r CN1-5 ir	iput signal	monitor.			_			
<u>M3</u> *			Input Signal	Monitor Alloog	tion for C					-			
		n.¤X¤¤	0 to 7 The	settings are the		the CN1-3	allocations						
										-			
			CN1-6 Input	Signal Monito	r Enable/E	Disable Se	lection						
		n.XDDD	0 Disa	ble allocation to	or CN1-6 II	nput signal	monitor.			-			
			I Enac	ble allocation to	r GNT-6 Ir	iput signai	monitor.			_			
			) Innut Cianal	0000 to				Immodi					
	2	Monitor All	locations 3	1717	-	0000	All	ately	Setup	*1			
		1											
			Input Signal	Monitor Alloca	tion for C	N1-7 (SVC	MD_IO)			ī			
		n.UUUX	0 to 7 The	settings are the	e same as	the CN1-3	allocations.			-			
			CNI1-7 Input	Signal Monito	r Enable/[	)isable Se	lection			-			
Pn862		n.ППХП	0 Disa	ble allocation fo	or CN1-7 i	nout signal	monitor						
			1 Enat	ble allocation fo	r CN1-7 ir	iput signal	monitor.			-			
M3 *6			Input Signal Monitor Allocation for CN1-8 (SVCMD_IO)										
		n.¤X¤¤		Monitor Alloca	tion for C	N1-8 (SVC	MD_IO)						
				settings are the	same as		anocations.			_			
			CN1-8 Input Signal Monitor Enable/Disable Selection										
		n.XDDD	0 Disa	ble allocation fo	or CN1-8 i	nput signal	monitor.			_			
			1 Enat	ble allocation to	r CN1-8 ir	iput signal	monitor.			-			
				0000 1	1				1				
	2	Monitor All	locations 4	1717	-	0000	All	ately	Setup	*1			
		4		1		I			1				
			Input Signal Monitor Allocation for CN1-9 (SVCMD_IO)										
		n.🗆 🗆 🗆 X	0 to 7 The	settings are the	same as	the CN1-3	allocations.			-			
			CNI1 0 Input	Signal Monito	r Enabla/F	)icable Se	laction			-			
Pn863			0 Disa				monitor						
			1 Enat	ble allocation fo	r CN1-9 ir	iput signal	monitor.			_			
M3 *6						1				-			
		n.¤X¤¤	Input Signal Monitor Allocation for CN1-10 (SVCMD_IO)										
			0 to 7 The settings are the same as the CN1-3 allocations.							_			
			CN1-10 Input Signal Monitor Enable/Disable Selection										
		n.XDDD	0         Disable allocation for CN1-10 input signal monitor.							_			
			1 Enat	ble allocation fo	r CN1-10	input signa	al monitor.			_			

Continued from previous page.

Parameter No.	Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
	2	SVCMD_IC Monitor All	) Input Signa ocations 5	0000 to 1717	-	0000	All	Immedi- ately	Setup	*1
			Input Signa	I Monitor Alloca	ation for C	N1-11 (SV	CMD_IO)			
			0 to 7 The	settings are the	e same as	the CN1-3	allocations.			_
			CN1-11 Inp	ut Signal Monit	or Enable	Disable S	election			
Pn864		n.🗆🗆 X 🗆	0 Dis	able allocation fo	or CN1-11	input sign	al monitor.			_
MO *6			1 Ena	ble allocation fo	r CN1-11	input signa	al monitor.			_
1013			Input Signa	I Monitor Alloca	ation for C	N1-12 (SV	CMD_IO)			
		n.¤X¤¤	0 to 7 The	settings are the	e same as	the CN1-3	allocations.			_
			CN1-12 Inc	ut Signal Monit	or Enable	/Disable S	election			
		n.XDDD	0 Dis	able allocation fo	or CN1-12	input sign	al monitor.			-
			1 Ena	ble allocation fo	r CN1-12	input signa	al monitor.			_
										_
	2	SVCMD_IC Monitor All	) Input Signa ocations 6	0000 to 1717	-	0000	All	Immedi- ately	Setup	*1
			1							_
		n.🗆 🗆 🗆 X	Input Signa	I Monitor Alloca	ation for C	N1-13 (SV	CMD_IO)			
			0 to 7 The	settings are the	e same as	the CN1-3	allocations.			_
			CN1-13 Inp	ut Signal Monit	or Enable/	'Disable S	election			
Pn865		n.🗆🗆 X 🗆	0 Dis	able allocation fo	or CN1-13	input sign	al monitor.			
M2 *6			1 Ena	ble allocation fo	r CN1-13	input signa	al monitor.			_
IVIS			Input Signa	I Monitor Alloca	ation for C	N1-14 (SV	CMD_IO)			
	0 to 7 The settings are the same as the CN1-3 allocations.									_
			CN1-14 Inc	nut Signal Monitor Enable/Disable Selection						
		n.XDDD	0 Dis	able allocation fo	or CN1-14	input sign	al monitor.			-
			1 Ena	ble allocation fo	r CN1-14	input signa	al monitor.			_
			- I							-

Continued on next page.

							Con	itinued from	1 previous	s page.		
Parameter No.	Size	N	lame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence		
	2	SVCMD_IC nal Monito	Output Sig- or Allocations	0000 to 1717	_	0000	All	Immedi- ately	Setup	*1		
										·		
			Output Signa	al Monitor Allo	cation for	CN1-23 ar	nd CN1-24 (S	SVCMD IO)		E		
			0 Alloc	ate bit 24 (IO S	STS1) to C	N1-23/CN	1-24 output s	signal monito	or.	-		
			1 Alloc	ate bit 25 (IO_S	STS2) to C	N1-23/CN	1-24 output s	signal monito	or.	-		
			2 Alloc	ate bit 26 (IO_S	STS3) to C	N1-23/CN	1-24 output s	signal monito	or.	-		
		n.🗆 🗆 🗆 X	3 Alloc	ate bit 27 (IO_S	STS4) to C	N1-23/CN	1-24 output	signal monito	or.	_		
			4 Alloc	ate bit 28 (IO_S	STS5) to C	N1-23/CN	1-24 output	signal monito	or.	_		
Pn868			5 Alloc	ate bit 29 (IO_S	STS6) to C	N1-23/CN	1-24 output	signal monito	or.	-		
1 11000			6 Alloc	ate bit 30 (IO_S	STS7) to C	N1-23/CN	1-24 output s	signal monito	or.	-		
M3 *6			7 Alloc	ate bit 31 (IU_8	5158) to C	-NT-23/CN	1-24 output s	signal monito	or.	_		
			CN1-23/CN1	-24 Output Sig	gnal Moni <sup>.</sup>	tor Enable,	/Disable Sele	ection				
		n.🗆🗆 X 🗆	0 Disal	ole allocation fo	or CN1-23,	/CN1-24 o	utput signal n	nonitor.		_		
			1 Enab	le allocation fo	r CN1-23/	CN1-24 ot	utput signal m	nonitor.		_		
			Output Signa	al Monitor Allo	cation for	CN1-25 ar	nd CN1-26 (S	SVCMD_IO)		Ī.		
		n.UXUU	0 to 7 The	settings are the	same as	the CN1-2	3/CN1-24 allo	ocations.		-		
			CN1-25/CN1	-26 Output Sid	nal Moni	tor Enable	/Disable Sele	action		ī		
		n.XDDD	0 Disa	ble allocation fo	or CN1-25	CN1-26 o	utput signal n	nonitor.				
			1 Enak	le allocation fo	r CN1-25/	CN1-26 ou	utput signal m	nonitor.		-		
			1 Enable allocation for CN1-25/CN1-26 output signal monitor.									
	2	SVCMD_IC nal Monito 2	Output Sig- or Allocations	0000 to 1717	-	0000	All	Immedi- ately	Setup	*1		
		n.DDDX	Output Signa	al Monitor Alloo	cation for	CN1-27 ar	nd CN1-28 (S 3/CN1-24 all	SVCMD_IO)				
					_							
Pn869			CN1-27/CN1	ection								
		n.UUXU	0 Disat		_							
M3 *6					I GINT-277	GN1-20 U	itput signal n			_		
		n.¤X¤¤	Output Signa	al Monitor Allo	cation for	CN1-29 ar	nd CN1-30 (S	SVCMD_IO)				
			0 to 7 The s	settings are the	same as t	he CN1-23	3/CN1-24 allo	ocations.		_		
			CN1-29/CN1	-30 Output Sig	gnal Moni <sup>.</sup>	tor Enable	/Disable Sele	ection				
		n.XDDD	0 Disab	le allocation fo	r CN1-29/	CN1-30 ol	utput signal m	nonitor.		_		
			1 Enab	le allocation for	CN1-29/0	CN1-30 ou	tput signal m	onitor.		_		
	2	SVCMD_IC nal Monito 3	Output Sig- or Allocations	0000 to 1717	_	0000	All	Immedi- ately	Setup	*1		
			Output Signa	al Monitor Allo	cation for	CN1-31 ar	nd CN1-32 (S	SVCMD_IO)				
Dp96A			0 to 7 The	settings are the	same as	the CN1-2	3/CN1-24 allo	ocations.		_		
PIIODA			CN1-31/CN1-32 Output Signal Monitor Enable/Disable Selection									
M3 *6		n.DDXD	CN1-31/CN1-32 Output Signal Monitor Enable/Disable Selection							-		
			1         Enable allocation for CN1-31/CN1-32 output signal monitor.							-		
			Bagameral	romotor (De	tohor	\	-			-		
			Reserved pa	rameter (Do ho	n change.	)				_		
		n.XDDD	Reserved pa	Reserved parameter (Do not change.)								

								Con	linued from		s page.	
Parameter No.	Size	Name Station Address Moni- tor (for maintenance, read only)			Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence	
Pn880	2	Station A tor (for ma read only)	ddress N aintenan	/oni- ce,	03 to EF	-	0	All	Immedi- ately	Setup	_	
Pn881	2	Set Trans Count Mo (for maint only)	mission onitor [by enance,	Byte /tes] read	17, 32, 48	_	0	All	Immedi- ately	Setup	-	
Pn882	2	Transmiss ting Monit (for maint only)	sion Cyc tor [× 0.2 enance,	le Set- 25 μs] read	0 to FFFF	_	0	All	Immedi- ately	Setup	-	
Pn883	2	Communi Setting M mission c maintena	cations onitor [t ycles] (fo nce, rea	Cycle rans- or d only)	0 to 32	_	0	All	Immedi- ately	Setup	-	
	2	Communi trols 2	cations	Con-	0000 to 0001	-	0000	All	Immedi- ately	Setup	*1	
			MECH	ATROLI	NK Communic	ations Err	or Holding	g Brake Signa	al Setting			
Dn894	n.		0	Mainta	in the status s	et by the E	BRK_ON o	r BRK_OFF co	ommand whe	en a MEC	HA-	
F11004			1		NK COMMUNICA	ations erro	MECHAT		munications	error occi	Ire	
M3 *6			-	дрру							10.	
	n.		Reserv	ed para	ameter (Do not change.)							
	n.		Reserv	ed para	meter (Do not change.)							
	n.	XDDD	Reserv	ed para	meter (Do not	change.)						
				•		<u> </u>						
Pn88A	2	MECHATE Receive E Monitor (for maint only)	ROLINK Error Cou enance,	unter read	0 to 65,535	_	0	All	Immedi- ately	Setup	_	
Pn890 to Pn8A6	4	Command tor during ing (for maint only)	d Data N ⊨Alarm/\ enance,	1oni- Varn- read	0 to FFFFFFF	_	0	All	Immedi- ately	Setup	*1	
Pn8A8 to Pn8BE	4	Response during Ala (for maint only)	e Data N arm/War enance,	lonitor ning read	0 to FFFFFFF	_	0	All	Immedi- ately	Setup	*1	
Pn900	2	Number o Banks	of Param	eter	0 to 16	-	0	All	After restart	Setup	*1	
Pn901	2	Number of Parameter Bank Members			0 to 15	-	0	All	After restart	Setup	*1	
Pn902 to Pn910	2	Parameter Bank Mem- ber Definition			0000 to 08FF	-	0	All	After restart	Setup	*1	
Pn920 to Pn95F	2	Parameter Bark Merri- ber Definition Parameter Bank Data (Not saved in nonvolatile memory.)			0000 to FFFF	-	0	All	Immedi- ately	Setup	*1	
*1 Refer to t	ho fo	llowing mai	nual for	dotaile								

Ω Σ-7-Series AC Servo Drive MECHATROLINK-III Communications Standard Servo Profile Command Manual (Manual No.: SIEP S800001 31)

\*2. Set a percentage of the motor rated torque.

\*3. Normally set this parameter to 0. If you use an External Regenerative Resistor, set the capacity (W) of the External Regenerative Resistor.

\*4. The upper limit is two times the maximum output capacity (W) of the SERVOPACK.

\*5. These parameters are for SERVOPACKs with the dynamic brake option. Refer to the following manual for details.

Ω Σ-7-Series AC Servo Drive Σ-7S/Σ-7W SERVOPACK with Dynamic Brake Hardware Option Specifications Prod-uct Manual (Manual No.: SIEP S800001 73)

- \*6. This parameter is valid only when the MECHATROLINK-III standard servo profile is used.
- \*7. The parameter setting is enabled after SENS\_ON command execution is completed.

\*8. Change the setting when the reference is stopped (i.e., while DEN is set to 1). If you change the setting during operation, the reference output will be affected.

\*9. The settings are updated only if the reference is stopped (i.e., only if DEN is set to 1).

- \*10.Refer to the following manual for details.
   Σ-7-Series AC Servo Drive MECHATROLINK-II Communications Command Manual (Manual No.: SIEP S800001 30)
- \*11. This parameter is valid only when the MECHATROLINK-II-compatible profile is used.
- \*12. The setting of Pn842 is valid while Pn817 is set to 0.
- \*13.The setting of Pn844 is valid while Pn818 is set to 0.

11.2.1 Interpreting the Parameter Lists

# 11.2 List of MECHATROLINK-III Common Parameters

# 11.2.1 Interpreting the Parameter Lists



# 11.2.2 List of MECHATROLINK-III Common Parameters

The following table lists the common MECHATROLINK-III parameters. These common parameters are used to make settings from the host controller via MECHATROLINK communications. Do not change the settings with the Digital Operator or any other device.

Parameter No.	Size	Nar	ne	Setting Range	Setting Unit [Resolution]	Default Setting	Applicable Motors	When Enabled	Classi- ficatior	
	4	Encoder Ty tion (read o	pe Selec- only)	0 to 1	-	-	All	-		
01										
PnA02		0000 hex	Absolute	encoder						
		0001 hex Increment		tal encoder						
									ion	
	4	Motor Type (read only)	Selection	0 to 1	-	-	All	-	ormat	
02									e infe	
PnA04		0000 hex	Rotary Se	ervomotor					evice.	
		0001 hex	Linear Se	rvomotor					De	
04 PnA08	4	Rated Motor Speed (read only)		0 to FFFFFFFF	1 min <sup>-1</sup>	-	All	_		
05 PnA0A	4	Maximum Output Speed (read only)		0 to FFFFFFFF	1 min <sup>-1</sup>	-	All	-		
				•			0			

Continued on next page.

						(	Continued fr	rom previou	us page.
Parameter No.	Size	Name		Setting Range	Setting Unit [Resolution]	Default Setting	Applicable Motors	When Enabled	Classi- fication
06 PnA0C	4	Speed Multiplie (read only)	r	-1,073,741,823 to 1,073,741,823	_	_	All	_	
07 PnA0E	4	Rated Torque (read only)		0 to FFFFFFFF	1 N∙m	-	All	-	
08 PnA10	4	Maximum Output Torque (read only)		0 to FFFFFFFF	1 N∙m	-	All	-	nation
09 PnA12	4	Torque Multiplie (read only)	Torque Multiplier (read only)		_	_	All	_	ce inforr
0A PnA14	4	Resolution (read only)		0 to FFFFFFFF	1 pulse/rev	_	Rotary	_	Devi
0B PnA16	4	Scale Pitch		0 to 65,536,000	1 nm [0.01 μm]	0	Linear	After restart <sup>*1</sup>	
0C PnA18	4	Pulses per Scale Pitch (read only)		0 to FFFFFFFF	1 pulse/ pitch	_	Linear	_	
21 PnA42	4	Electronic Gear (Numerator)	Electronic Gear Ratio (Numerator)		_	16	All	After restart	
22 PnA44	4	Electronic Gear Ratio (Denominator)		1 to 1,073,741,824	_	1	All	After restart	
23 PnA46	4	Absolute Encoder Origin Offset		-1,073,741,823 to 1,073,741,823	1 reference unit	0	All	Immedi- ately <sup>*1</sup>	
24 PnA48	4	Multiturn Limit Setting		0 to 65,535	1 Rev	65535	Rotary	After restart	
	4	Limit Setting		0 to 33 hex	-	0000 hex	All	After restart	
		Bit 0	P-OT	)T (0: Enabled, 1: Disabled)					
		Bit 1	N-OT	T (0: Enabled, 1: Disabled)					
25		Bit 2	Rese	rved.					
PnA4A		Bit 3	Rese	erved.					ds a
		Bit 4	P-SC	DT (0: Disabled, 1:	Enabled)				nine
		Bit 5	N-SC	DT (0: Disabled, 1:	Enabled)				/ac
		Bits 6 to 31	Rese	rved.					~
26 PnA4C	4	Forward Softwa Limit	re	-1,073,741,823 to 1,073,741,823	1 reference unit	10737418 23	All	Immedi- ately	-
27 PnA4E	4	Reserved paran (Do not change	neter .)	_	-	0	All	Immedi- ately	
28 PnA50	4	Reverse Softwa Limit	re	-1,073,741,823 to 1,073,741,823	1 reference unit	-1073741 823	All	Immedi- ately	
29 PnA52	4	Reserved paran (Do not change	neter .)	-	-	0	All	Immedi- ately	

Parameter No.	Size	Nan	ne	Setting Range	Setting Unit [Resolution]	Default Setting	Applicable Motors	When Enabled	Classi- fication
	4	Speed Unit Selection		0 to 4	-	0	All	After restart	
			I						
		0000 hex	Reference	e units/s					
41		0001 hex	Referenc	e units/min					
PnA82		0002 hex	Percenta	ge (%) of rated spe	eed <sup>*2</sup>				
		0003 hex	min <sup>-1*2</sup>						
		0004 hex	Maximum	n motor speed/400	000000 hex*3				
		Speed Base	e Unit						_
42 PnA84	4	Selection <sup>*2,</sup> (Set the value from the fol formula: Sp selection (4	*3 ue of n lowing eed unit 1 PnA82)	-3 to 3	_	0	All	After restart	
	4	× 10 <sup>n</sup> ) Position Un	it	0	_	0	All	After	
13		Selection						restart	_
PnA86		0000 hex	Reference	e units					
			11010101101						
		Position Ba Selection	se Unit						
44 PnA88	4	from the fol formula: Po selection (4 × 10 <sup>n</sup> )	lowing sition unit 3 PnA86)	0	_	0	All	After restart	Jnit settings
	4	Acceleration Selection	n Unit	0	-	0	All	After restart	
45 PnA8A		0000 hex	Reference	units/s <sup>2</sup>					
		:							_
46 PnA8C	4	Acceleration Unit Selecti (Set the value from the fol formula: Accurate and the selection PnA8A) × 1	n Base on ue of n lowing celeration on (45 0 <sup>n</sup> )	4 to 6	_	4	All	After restart	
	4	Torque Unit Selection		1 to 2	-	1	All	After restart	
17									
PnA8E		0001 hex	Percentag	ge (%) of rated toro	que				
		0002 hex	Maximum	torque/4000000	) hex <sup>*4</sup>				
48 PnA90	4	Torque Bas Selection <sup>*4</sup> (Set the vali from the fol formula: Tor selection (4 × 10 <sup>n</sup> )	e Unit ue of n lowing rque unit 7 PnA8E)	-5 to 0	_	0	All	After restart	

Continued from previous page.

Continued on next page.

							om previou	is page.		
Parameter No.	Size	Name	Setting Range	Setting Unit [Resolution]	Default Setting	Applicable Motors	When Enabled	Classi- fication		
	4	Supported Unit Systems (read only)	_	_	0601011F hex	All	-			
		Speed Units								
		Bit 0 Re	Bit 0 Reference units/s (1: Enabled)							
		Bit 1 Re	Reference units/min (1: Enabled)							
		Bit 2 Pe	ercentage (%) of rat	ed speed (1: E	nabled)					
		Bit 3 min <sup>-1</sup> (rpm) (1: Enabled)								
		Bit 4 M	Maximum motor speed/4000000 hex (1: Enabled)							
		Bits 5 to 7 Re	Reserved (0: Disabled).							
		Position Units						ngs		
49		Bit 8 Re	Reference units (1: Enabled)							
PnA92		Bits 9 to 15 Re			lit s					
		Acceleration Units								
		Bit 16 Re	eference units/s <sup>2</sup> (1	: Enabled)						
		Bit 17 m	s (acceleration time	required to re	ach rated sp	eed) (0: Disa	bled)			
		Bits 18 to 23 R	eserved (0: Disable	d).						
		Torque Units								
		Bit 24 N	m (0: Disabled)							
		Bit 25 Pe	ercentage (%) of rat	ed torque (1: E	Enabled)					
		Bit 26 M	aximum torque/400	000000 hex						
		Bits 27 to 31 R	eserved (0: Disabled	d).						

Continued from previous page.

					(	Continued fr	om previou	is page.
Parameter No.	Size	Name	Setting Range	Setting Unit [Resolution]	Default Setting	Applicable Motors	When Enabled	Classi- fication
61 PnAC2	4	Speed Loop Gain	1,000 to 2,000,000	0.001 Hz [0.1 Hz]	40000	All	Immedi- ately	
62 PnAC4	4	Speed Loop Integral Time Constant	150 to 512,000	1 μs [0.01 ms]	20000	All	Immedi- ately	
63 PnAC6	4	Position Loop Gain	1,000 to 2,000,000	0.001/s [0.1/s]	40000	All	Immedi- ately	
64 PnAC8	4	Feedforward Com- pensation	0 to 100	1%	0	All	Immedi- ately	
65 PnACA	4	Position Loop Inte- gral Time Constant	0 to 5,000,000	1 μs [0.1 ms]	0	All	Immedi- ately	
66 PnACC	4	Positioning Com- pleted Width	0 to 1,073,741,824	1 reference unit	7	All	Immedi- ately	
67 PnACE	4	Near Signal Width	1 to 1,073,741,824	1 reference unit	10737418 24	All	Immedi- ately	
81 PnB02	4	Exponential Acceler- ation/Deceleration Time Constant	0 to 510,000	1 μs [0.1 ms]	0	All	Immedi- ately <sup>*5</sup>	
82 PnB04	4	Movement Average Time	0 to 510,000	1 μs [0.1 ms]	0	All	Immedi- ately <sup>*5</sup>	_
83 PnB06	4	External Positioning Final Travel Distance	-1,073,741,823 to 1,073,741,823	1 reference unit	100	All	Immedi- ately	
84 PnB08	4	Origin Approach Speed	0 to 3FFFFFF hex	10 <sup>-3</sup> min <sup>-1</sup>	× 5,000 reference units/s con- verted to 10 <sup>-3</sup> min <sup>-1</sup>	All	Immedi- ately	
85 PnB0A	4	Origin Return Creep Speed	0 to 3FFFFFF hex	10 <sup>-3</sup> min <sup>-1</sup>	× 500 ref- erence units/s con- verted to 10 <sup>-3</sup> min <sup>-1</sup>	All	Immedi- ately	Tuning
86 PnB0C	4	Final Travel Distance for Origin Return	-1,073,741,823 to 1,073,741,823	1 reference unit	100	All	Immedi- ately	
	4	Fixed Monitor Selec- tion 1	0 to F	-	1	All	Immedi- ately	
87 PnB0E		0000 hexAPOS0001 hexCPOS0002 hexPERR0003 hexLPOS10004 hexLPOS20005 hexFSPD0006 hexCSPD0007 hexTRQ0008 hexALARM0009 hexMPOS0006 hexReserved0008 hexReserved0008 hexCMN1 (cr0008 hexCMN2 (cr0000 hexCMN2 (cr0000 hexOMN1 (cr0000 hexOMN2 (cr	(undefined value). (undefined value). ommon monitor 1) ommon monitor 2) ptional monitor 1) ptional monitor 2)					

je.

11

								C	Continued fr	rom previou	us page.					
Parameter No.	Size	Nan	ne	Setting Range	e	Setting Unit [Resolution]	Defa Sett	ault ing	Applicable Motors	When Enabled	Classi- fication					
	4	Fixed Monit	tor Selec-	0 to F		-	0		All	Immedi- ately						
88 PnB10		0000 to 000F hex	The setting	gs are the same	e as	s those for Fixe	d Mor	nitor S	election 1.							
		SEL MON	(CMN1)							Immedi-	-					
	4	Monitor Sel	ection 1	0 to 9		-	0		All	ately						
		0000 hex	TPOS (tar	rget position in	refe	erence coordina	ate sy	stem)								
		0001 hex	IPOS (refe	erence position	in r	reference coord	dinate	syster	n)							
		0002 hex	POS_OFF	SET (offset set	in	POS_SET (Set	Coord	dinate	System) com	nmand)						
		0003 hex	TSPD (tar	get speed)												
		0004 hex	SPD_LIM	(speed limit)												
		0005 hex	TRQ_LIM	(torque limit)												
			Byte 1: C 00 hex: 01 hex: 02 hex: 03 hex: Byte 2: C 00 hex: 01 hex: 01 hex: 01 hex: 02 hex: Byte 3: R Byte 4: E:	Byte 1: Current communications phase 00 hex: Phase 0 01 hex: Phase 1 02 hex: Phase 2 03 hex: Phase 3 Byte 2: Current control mode 00 hex: Position control mode 01 hex: Speed control mode 02 hex: Torque control mode Byte 3: Reserved Deta 4: Generative circul accenter												
			Bit	Name		Description		Value	Settin	g	ram					
		0006 hex	Bit 0		Pr lat	rocessing statu tch detection fo	s for or	0	Latch dete not yet pro cessed.	ction	elated pai					
89					LT D_	_REQ1 in SVC _CTRL region	M-	1	Processing detection in progress.	latch n	nmand-re					
PnB12			Dit 1	LT BDY1	Pr lat	Processing status f latch detection for LT_REQ2 in SVCM D_CTRL region	s for or	0	Latch dete not yet pro cessed.	ction -	Con					
			Dit		LI D <u>.</u>		M-	1	Processing detection in progress.	latch n						
								0	Phase C							
								1	External in	put						
			Bits 2 and 3	LT_SEL1R	La	atch signal	-	2	External in signal 2	put						
								3	External in signal 3	put						
								0	Phase C							
			Bite /				-	1	External in signal 1	put						
			and 5	LT_SEL2R	La	atch signal	-	2	External inp signal 2	put						
								3	External in signal 3	put						
			Bit 6	Reserved (0	).											
		0007 hex	Reserved													
		0008 hex	INIT_PGP	POS (Low)		Lower 32 bits verted to 64-k	of ini oit pos	tial end sition r	coder positio eference dat	n con- a						
		0009 hex	INIT_PGP	OS (High)		Upper 32 bits verted to 64-b	of ini oit pos	tial en sition r	coder positio eference dat	n con- a						

Continued from previous page.

Parameter No.	Size	Name	Setting Range	Setting Unit [Resolution]	Default Setting	Applicable Motors	When Enabled	Classi- fication
	4	SEL_MON (CMN2 Monitor Selection	) 2 0 to 9	_	0	All	Immedi- ately	
8A PnB14		0000 to 0009 The set hex	tings are the same as	those for SEL	_MON Monii	tor Selection	1.	
8B PnB16	4	Origin Detection Width	0 to 250	1 reference unit	10	All	Immedi- ately	
8C PnB18	4	Forward Torque Li	mit 0 to 800	1%	100	All	Immedi- ately	
8D PnB1A	4	Reverse Torque Li	mit 0 to 800	1%	100	All	Immedi- ately	
8E PnB1C	4	Zero Speed Detection Range	- 1,000 to 10,000,000	10 <sup>-3</sup> min <sup>-1</sup>	20000	All	Immedi- ately	
8F PnB1E	4	Speed Coincidence Signal Detection Width	0 to 100,000	10 <sup>-3</sup> min <sup>-1</sup>	10000	All	Immedi- ately	ameters
	4	Servo Command Control Field Enab Disable Selections (read only)		_	0FFF3F3F hex	All	_	elated par
			Γ					and-I
		Bit 0	CMD_PAUSE (1: En	abled)				L L
		Bit 1	CMD_CANCEL (1: E	Enabled)				S
		Bits 2 and 3	STOP_MODE (1: En	abled)				
		Bits 4 and 5	ACCFIL (1: Enabled)	)				
00		Bits 6 and 7	Reserved (0: Disable	ed).				
PnB20		Bit 0	LT_REQT (1: Enable	d)				
		Bits 10 and 11	LT_NEQ2 (1. Enabled	4) U)				
		Bits 12 and 13	LT_SEL2 (1: Enabled	(L) (L)				
		Bits 14 and 15	Reserved (0: Disable	ed).				
		Bits 16 to 19	SEL MON1 (1: Enat	oled)				
		Bits 20 to 23	SEL MON2 (1: Enat	oled)				
		Bits 24 to 27	SEL_MON3 (1: Enat	pled)				
		Bits 28 to 31	Reserved (0: Disable	ed).				

Dest								la paye.		
Parameter No.	Size	Name	Setting Range	Setting Unit [Resolution]	Default Setting	Applicable Motors	When Enabled	Classi- fication		
	4	Servo Status Field Enable/Disable Selections (read only)	-	0	0FFF3F33 hex	All	_			
		Bit 0	CMD_PAUSE_CMP	(1: Enabled)						
		Bit 1	CMD_CANCEL_CM	○ (1: Enabled)						
		Bit 2 and 3	Reserved (0: Disable	ed).						
		Bits 4 and 5	ACCFIL (1: Enabled)							
		Bits 6 and 7	Reserved (0: Disable	ed).						
		Bit 8	: 8 L_CMP1 (1: Enabled)							
91		Bit 9	L_CMP2 (1: Enabled	ł)						
PnB22		Bit 10	POS_RDY (1: Enable	ed)						
		Bit 11	PON (1: Enabled)							
		Bit 12	M_RDY (1: Enabled)							
		Bit 13	SV_ON (1: Enabled)							
		Bits 14 and 15	Reserved (0: Disable	ed).				ers		
		Bits 16 to 19	SEL_MON1 (1: Enab	oled)				net		
		Bits 20 to 23	SEL_MON2 (1: Enab	oled)				araı		
	Bits 24 to 27 SEL_MON3 (1: Enabled)									
	Bits 28 to 31 Reserved (0: Disabled).									
	4	Output Bit Enable/ Disable Selections (read only)	-	_	007F01F0 hex	All	_	Comn		
		Bits 0 to 3	Reserved (0: Disable	ed).						
		Bit 4	V_PPI (1: Enabled)							
		Bit 5	P_PPI (1: Enabled)							
		Bit 6	P_CL (1: Enabled)							
92		Bit 7	N_CL (1: Enabled)							
PnB24		Bit 8	G_SEL (1: Enabled)							
		Bits 9 to 11	G_SEL (0: Disabled)							
		Bits 12 to 15	Reserved (0: Disable	ed).						
		Bits 16 to 19	BANK_SEL (1: Enab	led)						
		Bits 20 to 22	SO1 to SO3 (1: Ena	bled)						
	Bit 23 Reserved (0: Disabled).									
		Bits 24 to 31	Reserved (0: Disable	ed).						

Continued from previous page.

Parameter No.	Size	Name	Setting Range	Setting Unit [Resolution]	Default Setting	Applicable Motors	When Enabled	Classi- fication
	4	Input Bit Enable/Dis- able Selections (read only)	-	-	FF0FFEFE hex	All	_	
93 PnB26		Bit 0       F         Bit 1       D         Bit 2       F         Bit 3       N         Bit 4       E         Bit 5       E         Bit 6       E         Bit 7       E         Bit 8       F         Bit 9       E         Bit 10       F         Bit 12       D         Bit 13       N         Bit 14       F         Bit 15       Z         Bit 16       T         Bit 17       N         Bit 18       N         Bit 19       Z         Bit 19       Z         Bit 19       Z         Bits 20 to 23       F         Bits 24 to 31       I	Reserved (0: Disable DEC (1: Enabled) P-OT (1: Enabled) EXT1 (1: Enabled) EXT2 (1: Enabled) EXT3 (1: Enabled) EXT3 (1: Enabled) EXT3 (1: Enabled) EXT3 (1: Enabled) EXT3 (1: Enabled) EXT3 (1: Enabled) Reserved (0: Disabled) DEN (1: Enabled) DEN (1: Enabled) DEN (1: Enabled) DEN (1: Enabled) POINT (1: Enabled) ZPOINT (1: Enabled)	ed).				Command-related parameters

Continued from previous page.

\*1. The parameter setting is enabled after SENS\_ON command execution is completed.

\*2. If you set the Speed Unit Selection (parameter 41) to either 0002 hex or 0003 hex, set the Speed Base Unit Selection (parameter 42) to a number between -3 and 0.

\*3. If you set the Speed Unit Selection (parameter 41) to 0004 hex, set the Speed Base Unit Selection (parameter 42) to 0.

\*4. If you set the Torque Unit Selection (parameter 47) to 0002 hex, set the Torque Base Unit Selection (parameter 48) to 0.

\*5. Change the setting when the reference is stopped (i.e., while DEN is set to 1). If you change the setting during operation, the reference output will be affected.

# 11.3 Parameter Recording Table

Use the following table to record the settings of the parameters.

Parameter No.	Default Setting		Name	When Enabled
Pn000	0000		Basic Function Selections 0	After restart
Pn001	0000		Application Function Selec- tions 1	After restart
Pn002	0011		Application Function Selec- tions 2	After restart
Pn006	0002		Application Function Selec- tions 6	Immediately
Pn007	0000		Application Function Selec- tions 7	Immediately
Pn008	4000		Application Function Selec- tions 8	After restart
Pn009	0010		Application Function Selec- tions 9	After restart
Pn00A	0001		Application Function Selec- tions A	After restart
Pn00B	0000		Application Function Selec- tions B	After restart
Pn00C	0000		Application Function Selections C	After restart
Pn00D	0000		Application Function Selections D	After restart
Pn00F	0000		Application Function Selec- tions F	After restart
Pn021	0000		Reserved parameter	_
Pn080	0000		Application Function Selec- tions 80	After restart
Pn100	400		Speed Loop Gain	Immediately
Pn101	2000		Speed Loop Integral Time Constant	Immediately
Pn102	400		Position Loop Gain	Immediately
Pn103	100		Moment of Inertia Ratio	Immediately
Pn104	400		Second Speed Loop Gain	Immediately
Pn105	2000		Second Speed Loop Inte- gral Time Constant	Immediately
Pn106	400		Second Position Loop Gain	Immediately
Pn109	0		Feedforward	Immediately
Pn10A	0		Feedforward Filter Time Constant	Immediately
Pn10B	0000		Gain Application Selections	*1
Pn10C	200		Mode Switching Level for Torque Reference	Immediately
Pn10D	0		Mode Switching Level for Speed Reference	Immediately
Pn10E	0		Mode Switching Level for Acceleration	Immediately
Pn10F	0		Mode Switching Level for Position Deviation	Immediately
Pn11F	0		Position Integral Time Con- stant	Immediately
Pn121	100		Friction Compensation Gain	Immediately

Continued from p	orevious	page.
------------------	----------	-------

Parameter No.	Default Setting	Name	When Enabled
Pn122	100	Second Friction Compen- sation Gain	Immediately
Pn123	0	Friction Compensation Coefficient	Immediately
Pn124	0	Friction Compensation Fre- quency Correction	Immediately
Pn125	100	Friction Compensation Gain Correction	Immediately
Pn131	0	Gain Switching Time 1	Immediately
Pn132	0	Gain Switching Time 2	Immediately
Pn135	0	Gain Switching Waiting Time 1	Immediately
Pn136	0	Gain Switching Waiting Time 2	Immediately
Pn139	0000	Automatic Gain Switching Selections 1	Immediately
Pn13D	2000	Current Gain Level	Immediately
Pn140	0100	Model Following Control- Related Selections	Immediately
Pn141	500	Model Following Control Gain	Immediately
Pn142	1000	Model Following Control Gain Correction	Immediately
Pn143	1000	Model Following Control Bias in the Forward Direc- tion	Immediately
Pn144	1000	Model Following Control Bias in the Reverse Direc- tion	Immediately
Pn145	500	Vibration Suppression 1 Frequency A	Immediately
Pn146	700	Vibration Suppression 1 Frequency B	Immediately
Pn147	1000	Model Following Control Speed Feedforward Com- pensation	Immediately
Pn148	500	Second Model Following Control Gain	Immediately
Pn149	1000	Second Model Following Control Gain Correction	Immediately
Pn14A	800	Vibration Suppression 2 Frequency	Immediately
Pn14B	100	Vibration Suppression 2 Correction	Immediately
Pn14F	0021	Control-Related Selections	After restart
Pn160	0010	Anti-Resonance Control- Related Selections	Immediately
Pn161	1000	Anti-Resonance Frequency	Immediately
Pn162	100	Anti-Resonance Gain Cor- rection	Immediately
Pn163	0	Anti-Resonance Damping Gain	Immediately
Pn164	0	Anti-Resonance Filter Time Constant 1 Correction	Immediately
Pn165	0	Anti-Resonance Filter Time Constant 2 Correction	Immediately

Continued on next page.

Parameter When **Default Setting** Name No. Enabled Anti-Resonance Damping Pn166 0 Immediately Gain 2 Tuning-less Function-Pn170 1401 \*1 Related Selections Mode Switching Level for Pn181 0 Immediately Speed Reference Mode Switching Level for Pn182 0 Immediately Acceleration Pn205 65535 Multiturn Limit After restart **Position Control Function** Pn207 0010 After restart Selections Electronic Gear Ratio Pn20E 16 After restart (Numerator) Electronic Gear Ratio Pn210 1 After restart (Denominator) Position Control Expansion Pn230 0000 After restart Function Selections Pn231 0 **Backlash Compensation** Immediately **Backlash Compensation** Pn233 0 Immediately Time Constant Pn282 0 Linear Encoder Scale Pitch After restart Pn304 500 Jogging Speed Immediately Soft Start Acceleration Pn305 0 Immediately Time Soft Start Deceleration 0 Pn306 Immediately Time Speed Feedback Filter Pn308 0 Immediately Time Constant Deceleration Time for Servo 0 Pn30A Immediately OFF and Forced Stops Speed Feedforward Aver-Pn30C 0 Immediately age Movement Time Vibration Detection Selec-Pn310 0000 Immediately tions Vibration Detection Sensi-Pn311 100 Immediately tivity Pn312 50 Vibration Detection Level Immediately Pn316 10000 Maximum Motor Speed After restart Moment of Inertia Calcula-Pn324 300 Immediately tion Starting Level Pn383 50 Jogging Speed Immediately Vibration Detection Level Pn384 10 Immediatelv Pn385 50 Maximum Motor Speed After restart First Stage First Torque Pn401 100 Reference Filter Time Con-Immediately stant Pn402 800 Forward Torque Limit Immediately Pn403 800 **Reverse Torque Limit** Immediately Forward External Torque Pn404 100 Immediately Limit Reverse External Torque Pn405 100 Immediately Limit Pn406 800 **Emergency Stop Torque** Immediately Speed Limit during Torque Pn407 10000 Immediately Control

Continued from previous page.

Continued from	previous	page.
----------------	----------	-------

Parameter No.	Default Setting			Name	When Enabled
Pn408	0000			Torque-Related Function Selections	*1
Pn409	5000			First Stage Notch Filter Fre- quency	Immediately
Pn40A	70			First Stage Notch Filter Q Value	Immediately
Pn40B	0			First Stage Notch Filter Depth	Immediately
Pn40C	5000			Second Stage Notch Filter Frequency	Immediately
Pn40D	70			Second Stage Notch Filter Q Value	Immediately
Pn40E	0			Second Stage Notch Filter Depth	Immediately
Pn40F	5000			Second Stage Second Torque Reference Filter Fre- quency	Immediately
Pn410	50			Second Stage Second Notch Filter Q Value	Immediately
Pn412	100			First Stage Second Torque Reference Filter Time Con- stant	Immediately
Pn416	0000			Torque-Related Function Selections 2	Immediately
Pn417	5000			Third Stage Notch Filter Frequency	Immediately
Pn418	70			Third Stage Notch Filter Q Value	Immediately
Pn419	0			Third Stage Notch Filter Depth	Immediately
Pn41A	5000			Fourth Stage Notch Filter Frequency	Immediately
Pn41B	70			Fourth Stage Notch Filter Q Value	Immediately
Pn41C	0			Fourth Stage Notch Filter Depth	Immediately
Pn41D	5000			Fifth Stage Notch Filter Fre- quency	Immediately
Pn41E	70			Fifth Stage Notch Filter Q Value	Immediately
Pn41F	0			Fifth Stage Notch Filter Depth	Immediately
Pn423	0000			Speed Ripple Compensa- tion Selections	*1
Pn424	50			Torque Limit at Main Circuit Voltage Drop	Immediately
Pn425	100			Release Time for Torque Limit at Main Circuit Voltage Drop	Immediately
Pn426	0			Torque Feedforward Aver- age Movement Time	Immediately
Pn427	0			Speed Ripple Compensa- tion Enable Speed	Immediately
Pn456	15			Sweep Torque Reference Amplitude	Immediately
Pn460	0101			Notch Filter Adjustment Selections 1	Immediately

Parameter Lists

11
Parameter When **Default Setting** Name No. Enabled Speed Limit during Force Pn480 10000 Immediately Control Polarity Detection Speed Pn481 400 Immediately Loop Gain Polarity Detection Speed Pn482 3000 Loop Integral Time Con-Immediately stant Pn483 30 Forward Force Limit Immediately Pn484 30 **Reverse Force Limit** Immediately Polarity Detection Refer-Pn485 20 Immediatelv ence Speed Polarity Detection Refer-Pn486 25 ence Acceleration/Deceler-Immediately ation Time Polarity Detection Con-Pn487 0 Immediately stant Speed Time Polarity Detection Refer-Pn488 100 Immediately ence Waiting Time Pn48E 10 Polarity Detection Range Immediately Polarity Detection Load Pn490 100 Immediately Level Polarity Detection Confir-Pn495 100 Immediately mation Force Reference Polarity Detection Allowable Pn498 10 Immediately Error Range Speed Ripple Compensa-Pn49F 0 Immediately tion Enable Speed Pn502 20 **Rotation Detection Level** Immediately Speed Coincidence Detec-Pn503 10 Immediately tion Signal Output Width Brake Reference-Servo 0 Pn506 Immediately OFF Delay Time Brake Reference Output Pn507 100 Immediatelv Speed Level Servo OFF-Brake Com-Pn508 50 Immediately mand Waiting Time Momentary Power Interrup-Pn509 20 Immediately tion Hold Time Pn50A 0881 After restart Input Signal Selections 1 Pn50B 8881 Input Signal Selections 2 After restart Pn50E 0000 **Output Signal Selections 1** After restart Pn50F 0100 **Output Signal Selections 2** After restart Pn510 0000 **Output Signal Selections 3** After restart Pn511 5432 Input Signal Selections 5 After restart Output Signal Inverse Set-Pn512 0000 After restart tings Pn514 Output Signal Selections 4 0000 After restart Pn516 8888 Input Signal Selections 7 After restart Position Deviation Over-Pn51E 100 Immediately flow Warning Level Position Deviation Over-Pn520 5242880 Immediately flow Alarm Level Positioning Completed Pn522 7 Immediately Width Pn524 1073741824 Near Signal Width Immediately

Continued from previous page.

Parameter No.	Default Setting		Name	When Enabled
Pn526	5242880		Position Deviation Over- flow Alarm Level at Servo ON	Immediately
Pn528	100		Position Deviation Over- flow Warning Level at Servo ON	Immediately
Pn529	10000		Speed Limit Level at Servo ON	Immediately
Pn52B	20		Overload Warning Level	Immediately
Pn52C	100		Base Current Derating at Motor Overload Detection	After restart
Pn52D	50		Reserved parameter	_
Pn530	0000		Program Jogging-Related Selections	Immediately
Pn531	32768		Program Jogging Travel Distance	Immediately
Pn533	500		Program Jogging Move- ment Speed	Immediately
Pn534	100		Program Jogging Accelera- tion/Deceleration Time	Immediately
Pn535	100		Program Jogging Waiting Time	Immediately
Pn536	1		Program Jogging Number of Movements	Immediately
Pn550	0		Analog Monitor 1 Offset Voltage	Immediately
Pn551	0		Analog Monitor 2 Offset Voltage	Immediately
Pn552	100		Analog Monitor 1 Magnifi- cation	Immediately
Pn553	100		Analog Monitor 2 Magnifi- cation	Immediately
Pn55A	1		Power Consumption Moni- tor Unit Time	Immediately
Pn560	400		Residual Vibration Detec- tion Width	Immediately
Pn561	100		Overshoot Detection Level	Immediately
Pn581	20		Zero Speed Level	Immediately
Pn582	10		Speed Coincidence Detec- tion Signal Output Width	Immediately
Pn583	10		Brake Reference Output Speed Level	Immediately
Pn584	10000		Speed Limit Level at Servo ON	Immediately
Pn585	50		Program Jogging Move- ment Speed	Immediately
Pn586	0		Motor Running Cooling Ratio	Immediately
Pn587	0000		Polarity Detection Execu- tion Selection for Absolute Linear Encoder	Immediately
Pn590	Axis A: 1003, Axis B: 1009		P-OT (Forward Drive Pro- hibit) Signal Allocation	After restart
Pn591	Axis A: 1004, Axis B: 1010		N-OT (Reverse Drive Pro- hibit) Signal Allocation	After restart

11

Parameter No.	Default Setting			Name	When Enabled
Pn592	Axis A: 1005, Axis B: 1011			/DEC (Origin Return Decel- eration Switch Input) Signal Allocation	After restart
Pn593	Axis A: 1006, Axis B: 1012			/EXT1 (External Latch Input 1) Signal Allocation	After restart
Pn594	Axis A: 1007, Axis B: 1013			/EXT2 (External Latch Input 2) Signal Allocation	After restart
Pn595	Axis A: 1008, Axis B: 1014			/EXT3 (External Latch Input 3) Signal Allocation	After restart
Pn597	0000			FSTP (Forced Stop Input) Signal Allocation	After restart
Pn598	0000			/P-CL (Forward External Torque Limit Input) Signal Allocation	After restart
Pn599	0000			/N-CL (Reverse External Torque Limit Input) Signal Allocation	After restart
Pn5B0	0000			/COIN (Positioning Comple- tion Output) Signal Alloca- tion	After restart
Pn5B1	0000			/V-CMP (Speed Coinci- dence Detection Output) Signal Allocation	After restart
Pn5B2	0000			/TGON (Rotation Detection Output) Signal Allocation	After restart
Pn5B3	0000			/S-RDY (Servo Ready) Sig- nal Allocation	After restart
Pn5B4	0000			/CLT (Torque Limit Detec- tion Output) Signal Alloca- tion	After restart
Pn5B5	0000			/VLT (Speed Limit Detec- tion) Signal Allocation	After restart
Pn5B6	Axis A: 1023, Axis B: 1025			/BK (Brake Output) Signal Allocation	After restart
Pn5B7	0000			/WARN (Warning Output) Signal Allocation	After restart
Pn5B8	0000			/NEAR (Near Output) Signal Allocation	After restart
Pn5BC	0000			/PM (Preventative Mainte- nance Output) Signal Allo- cation	After restart
Pn600	0			Regenerative Resistor Capacity	Immediately
Pn601	0			Dynamic Brake Resistor Allowable Energy Con- sumption	After restart
Pn603	0			Regenerative Resistance	Immediately
Pn604	0			Dynamic Brake Resistance	After restart
Pn800	1040			Communications Controls	Immediately
Pn801	0003			Application Function Selec- tions 6 (Software Limits)	Immediately
Pn803	10			Origin Range	Immediately
Pn804	1073741823			Forward Software Limit	Immediately
Pn806	-1073741823			Reverse Software Limit	Immediately
Pn808	0			Absolute Encoder Origin Offset	Immedi- ately <sup>*2</sup>

Parameter No.	Default Setting		Name	When Enabled
Pn80A	100		First Stage Linear Accelera- tion Constant	Immedi- ately <sup>*3</sup>
Pn80B	100		Second Stage Linear Acceleration Constant	Immedi- ately <sup>*3</sup>
Pn80C	0		Acceleration Constant Switching Speed	Immedi- ately <sup>*3</sup>
Pn80D	100		First Stage Linear Decelera- tion Constant	Immedi- ately <sup>*3</sup>
Pn80E	100		Second Stage Linear Deceleration Constant	Immedi- ately <sup>*3</sup>
Pn80F	0		Deceleration Constant Switching Speed	Immedi- ately <sup>*3</sup>
Pn810	0		Exponential Acceleration/ Deceleration Bias	Immedi- ately <sup>*3</sup>
Pn811	0		Exponential Acceleration/ Deceleration Time Constant	Immedi- ately <sup>*3</sup>
Pn812	0		Movement Average Time	Immedi- ately <sup>*3</sup>
Pn814	100		External Positioning Final Travel Distance	Immedi- ately <sup>*3</sup>
Pn816	0000		Origin Return Mode Set- tings	Immedi- ately <sup>*3</sup>
Pn817	50		Origin Approach Speed 1	Immedi- ately <sup>*3</sup>
Pn818	5		Origin Approach Speed 2	Immedi- ately <sup>*3</sup>
Pn819	100		Final Travel Distance for Origin Return	Immedi- ately <sup>*3</sup>
Pn81E	0000		Input Signal Monitor Selec- tions	Immediately
Pn81F	0010		Command Data Allocations	After restart
Pn820	0		Forward Latching Area	Immediately
Pn822	0		Reverse Latching Area	Immediately
Pn824	0000		Option Monitor 1 Selection	Immediately
Pn825	0000		Option Monitor 2 Selection	Immediately
Pn827	100		Linear Deceleration Con- stant 1 for Stopping	ately <sup>*3</sup>
Pn829	0		SVOFF Waiting Time (for SVOFF at Deceleration to Stop)	Immediately
Pn82A	1813		Option Field Allocations 1	After restart
Pn82B	1D1C		Option Field Allocations 2	After restart
Pn82C	1F1E		Option Field Allocations 3	After restart
Pn82D	0000		Option Field Allocations 4	After restart
Pn82E	0000		Option Field Allocations 5	After restart
Pn833	0000		Motion Settings	After restart
Pn834	100		First Stage Linear Accelera- tion Constant 2	Immedi- ately <sup>*3</sup>
Pn836	100		Second Stage Linear Acceleration Constant 2	Immedi- ately <sup>*3</sup>
Pn838	0		Acceleration Constant Switching Speed 2	Immedi- ately <sup>*3</sup>

11

Parameter Lists

Parameter When **Default Setting** Name No. Enabled Immedi-First Stage Linear Decelera-Pn83A 100 tion Constant 2 ately\*3 Immedi-Second Stage Linear Pn83C 100 Deceleration Constant 2 ately\*3 Immedi-**Deceleration Constant** Pn83E 0 Switching Speed 2 ately\*3 Linear Deceleration Con-Immedi-Pn840 100 stant 2 for Stopping ately\*3 Immedi-Second Origin Approach Pn842 0 Speed 1 ately\*3 Immedi-Second Origin Approach Pn844 0 ately\*3 Speed 2 **POSING Command Scurve** Immedi-Pn846 0 Acceleration/Deceleration ately\*3 Rate Number of Latch Pn850 0 Immediately Sequences Continuous Latch Pn851 0 Immediately Sequence Count Latch Sequence 1 to 4 Set-Pn852 0000 Immediately tings Latch Sequence 5 to 8 Set-Pn853 0000 Immediately tings SVCMD\_IO Input Signal Pn860 0000 Immediately Monitor Allocations 1 SVCMD\_IO Input Signal Pn861 0000 Immediately Monitor Allocations 2 SVCMD\_IO Input Signal Pn862 0000 Immediately Monitor Allocations 3 SVCMD\_IO Input Signal Pn863 0000 Immediately Monitor Allocations 4 SVCMD\_IO Input Signal Pn864 0000 Immediately Monitor Allocations 5 SVCMD\_IO Input Signal Pn865 0000 Immediately Monitor Allocations 6 SVCMD\_IO Output Signal Pn868 0000 Immediately Monitor Allocations 1 SVCMD\_IO Output Signal Pn869 0000 Immediately Monitor Allocations 2 SVCMD\_IO Output Signal Pn86A 0000 Immediately Monitor Allocations 3 Station Address Monitor Pn880 0 Immediately (for maintenance, read only) Set Transmission Byte Pn881 0 Count Monitor [bytes] (for Immediately maintenance, read only) Transmission Cycle Setting Monitor  $[\times 0.25 \mu s]$  (for Pn882 0 Immediately maintenance, read only) Communications Cycle Setting Monitor [transmis-Pn883 0 Immediately sion cycles] (for maintenance, read only) Pn884 0000 Communications Controls 2 Immediately

Continued from previous page.

Parameter No.	Default Setting			Name	When Enabled
Pn88A	0			MECHATROLINK Receive Error Counter Monitor (for maintenance, read only)	Immediately
Pn890 to Pn8A6	0			Command Data Monitor during Alarm/Warning (for maintenance, read only)	Immediately
Pn8A8 to Pn8BE	0			Response Data Monitor during Alarm/Warning (for maintenance, read only)	Immediately
Pn900	0			Number of Parameter Banks	After restart
Pn901	0			Number of Parameter Bank Members	After restart
Pn902 to Pn910	0			Parameter Bank Member Definition	After restart
Pn920 to Pn95F	0			Parameter Bank Data (Not saved in nonvolatile memory.)	Immediately
01 PnA02	-			Encoder Type Selection (read only)	_
02 PnA04	_			Motor Type Selection (read only)	_
04 PnA08	_			Rated Motor Speed (read only)	_
05 PnA0A	_			Maximum Output Speed (read only)	_
06 PnA0C	-			Speed Multiplier (read only)	_
07 PnA0E	_			Rated Torque (read only)	_
08 PnA10	_			Maximum Output Torque (read only)	_
09 PnA12	-			Torque Multiplier (read only)	_
0A PnA14	_			Resolution (read only)	_
0B PnA16	0			Scale Pitch	After restart
0C PnA18	_			Pulses per Scale Pitch (read only)	_
21 PnA42	16			Electronic Gear Ratio (Numerator)	After restart
22 PnA44	1			Electronic Gear Ratio (Denominator)	After restart
23 PnA46	0			Absolute Encoder Origin Offset	Immedi- ately <sup>*2</sup>
24 PnA48	65535			Multiturn Limit Setting	After restart
25 PnA4A	0000 hex			Limit Setting	After restart
26 PnA4C	1073741823			Forward Software Limit	Immediately
27 PnA4E	0			Reserved (Do not change.)	Immediately

11

			oonunded nom p	nevious page.
Parameter No.	Default Setting		Name	When Enabled
28 PnA50	-1073741823		Reverse Software Limit	Immediately
29 PnA52	0		Reserved (Do not change.)	Immediately
41 PnA82	0		Speed Unit Selection	After restart
42 PnA84	0		Speed Base Unit Selection	After restart
43 PnA86	0		Position Unit Selection	After restart
44 PnA88	0		Position Base Unit Selec- tion	After restart
45 PnA8A	0		Acceleration Unit Selection	After restart
46 PnA8C	4		Acceleration Base Unit Selection	After restart
47 PnA8E	1		Torque Unit Selection	After restart
48 PnA90	0		Torque Base Unit Selection	After restart
49 PnA92	0601011F hex		Supported Unit Systems (read only)	_
61 PnAC2	40000		Speed Loop Gain	Immediately
62 PnAC4	20000		Speed Loop Integral Time Constant	Immediately
63 PnAC6	40000		Position Loop Gain	Immediately
64 PnAC8	0		Feedforward Compensation	Immediately
65 PnACA	0		Position Loop Integral Time Constant	Immediately
66 PnACC	7		Positioning Completed Width	Immediately
67 PnACE	1073741824		Near Signal Width	Immediately
81 PnB02	0		Exponential Acceleration/ Deceleration Time Constant	Immedi- ately <sup>*3</sup>
82 PnB04	0		Movement Average Time	Immedi- ately <sup>*3</sup>
83 PnB06	100		External Positioning Final Travel Distance	Immediately
84 PnB08	$\times$ 5,000 reference units/s converted to $10^{-3}$ min <sup>-1</sup>		Origin Approach Speed	Immediately
85 PnB0A	× 500 reference units/s converted to 10 <sup>-3</sup> min <sup>-1</sup>		Origin Return Creep Speed	Immediately
86 PnB0C	100		Final Travel Distance for Origin Return	Immediately
87 PnB0E	1		Fixed Monitor Selection 1	Immediately
88 PnB10	0		Fixed Monitor Selection 2	Immediately

Parameter No.	Default Setting		Name	When Enabled
89 PnB12	0		SEL_MON (CMN1) Monitor Selection 1	Immediately
8A PnB14	0		SEL_MON (CMN2) Monitor Selection 2	Immediately
8B PnB16	10		Origin Detection Width	Immediately
8C PnB18	100		Forward Torque Limit	Immediately
8D PnB1A	100		Reverse Torque Limit	Immediately
8E PnB1C	20000		Zero Speed Detection Range	Immediately
8F PnB1E	10000		Speed Coincidence Signal Detection Width	Immediately
90 PnB20	0FFF3F3F hex		Servo Command Control Field Enable/Disable Selec- tions (read only)	_
91 PnB22	0FFF3F33 hex		Servo Status Field Enable/ Disable Selections (read only)	-
92 PnB24	007F01F0 hex		Output Bit Enable/Disable Selections (read only)	-
93 PnB26	FF0FFEFE hex		Input Bit Enable/Disable Selections (read only)	_

\*1. The enable timing depends on the digit that is changed. Refer to the following section for details.

\*2. The parameter setting is enabled after SENS\_ON command execution is completed.

\*3. Change the setting when the reference is stopped (i.e., while DEN is set to 1). If you change the setting during operation, the reference output will be affected.

11

# Appendices

The appendix provides information on interpreting panel displays, and tables of corresponding SERVOPACK and SigmaWin+ function names.

(12)

12.1	Interp	reting Panel Displays12-2
	12.1.1 12.1.2	Interpreting Status Displays
	12.1.3	Overtravel Display
	12.1.4	Forced Stop Display 12-2
12.2	Corresp	onding SERVOPACK and SigmaWin+ Function Names 12-3
12.2	<b>Corresp</b> 12.2.1	onding SERVOPACK and SigmaWin+ Function Names 12-3 Corresponding SERVOPACK Utility Function Names

12.1.1 Interpreting Status Displays

## 12.1 Interpreting Panel Displays

You can check the Servo Drive status on the panel display of the SERVOPACK. Also, if an alarm or warning occurs, the alarm or warning number will be displayed.

### 12.1.1 Interpreting Status Displays

The status is displayed as described below.

Display	Meaning	Display	Meaning
	/TGON (Rotation Detection) Signal Display Lit if the Servomotor speed is higher than the setting of Pn502 or Pn581 and not lit if the speed is lower than the setting. (The default set- ting is 20 min <sup>-1</sup> or 20 mm/s.)	8	Reference Input Display Lit while a reference is being input.
$\square$	Base Block Display Lit during the base block state (servo OFF). Not lit while the servo is ON.		Control Power Supply ON Display Lit while the control power is being supplied.

Information

The locations for the axes on the panel display are as follows:



### 12.1.2 Alarm and Warning Displays

If there is an alarm or warning, the display will change in the following order. Example: Alarm A.E60

-> Status Display --> Not lit. -->  $P_1$  --> Not lit. --> E --> Not lit. --> G --> Not lit. --> D --> Not lit. -->

### 12.1.3 Overtravel Display

If overtravel has occurred, the display will change in the following order.

Torward Overtravel (P-OT)
 Status Display - P
 Status Display - P
 Status Display - P
 Status Display - P
 Status Display - P

### 12.1.4 Forced Stop Display

During a forced stop, the following display will appear.

Status 
$$\longrightarrow$$
 Not lit.  $\longrightarrow F \longrightarrow$  Not lit.  $\longrightarrow 5 \longrightarrow$  Not lit.  $\longrightarrow b \longrightarrow$  Not lit.  $\longrightarrow$  Not lit.

12.2.1 Corresponding SERVOPACK Utility Function Names

## 12.2 Corresponding SERVOPACK and SigmaWin+ Function Names

This section gives the names and numbers of the utility functions and monitor display functions used by the SERVOPACKs and the names used by the SigmaWin+.

### 12.2.1 Corresponding SERVOPACK Utility Function Names

	SigmaWin+	SERVOPACK			
Menu Bar Button	Function Name	Fn No.	Function Name		
	Origin Search	Fn003	Origin Search		
	Absolute Encoder Reset	Fn008	Reset Absolute Encoder		
	Adjust the Apolog Maniter Output	Fn00C	Adjust Analog Monitor Output Offset		
	Adjust the Analog Monitor Output	Fn00D	Adjust Analog Monitor Output Gain		
	Adjust the Motor Current Datas-	Fn00E	Autotune Motor Current Detection Signal Offset		
	tion Signal Offsets	Fn00F	Manually Adjust Motor Current Detection Signal Offset		
Setup	Multiturn Limit Setting	Fn013	Multiturn Limit Setting after Multiturn Limit Dis- agreement Alarm		
	Initialize Vibration Detection Level	Fn01B	Initialize Vibration Detection Level		
	Set Origin	Fn020	Set Absolute Linear Encoder Origin		
	Reset Motor Type Alarm	Fn021	Reset Motor Type Alarm		
	Software Reset	Fn030	Software Reset		
	Polarity Detection	Fn080	Polarity Detection		
	Tuning-less Level Setting	Fn200	Tuning-less Level Setting		
	Easy FFT	Fn206	Easy FFT		
	Initialize	Fn005	Initializing Parameters		
Parameters	Write Prohibition Setting	Fn010	Write Prohibition Setting		
	Setup Wizard	-	-		
	Autotuning without Host Refer- ence	Fn201	Advanced Autotuning without Reference		
	Autotuning with Host Reference	Fn202	Advanced Autotuning with Reference		
Tuning	Custom Tuning	Fn203	One-Parameter Tuning		
	Adjust Anti-resonance Control	Fn204	Adjust Anti-resonance Control		
	Vibration Suppression	Fn205	Vibration Suppression		
	Moment of Inertia Estimation	-	-		
		Fn011	Display Servomotor Model		
Monitoring	Product Information	Fn012	Display Software Version		
		Fn01E	Display SERVOPACK and Servomotor IDs		
Test Opera-	Jog	Fn002	Jog		
tion	Jog Program	Fn004	Jog Program		
Alarms	Alarm Display	Fn000	Display Alarm History		
,		Fn006	Clear Alarm History		
Solutions	Mechanical Analysis	-	-		

12.2.2 Corresponding SERVOPACK Monitor Display Function Names

# 12.2.2 Corresponding SERVOPACK Monitor Display Function Names

If "All Axes" is given below the Un number, the monitor display applies to both axes. The total value for all axes or the contents for all axes are displayed on the monitor.

	SigmaWin+	SERVOPACK			
Menu Bar Button	Name [Unit]	Un No.	Name [Unit]		
	Motor Speed [min <sup>-1</sup> ]	Un000	Motor Speed [min <sup>-1</sup> ]		
	Speed Reference [min-1]	Un001	Speed Reference [min <sup>-1</sup> ]		
	Torque Reference [%]	Un002	Torque Reference [%] (percentage of rated torque)		
	<ul> <li>Rotary Servomotors: Rotational Angle 1 [encoder pulses] (number of encoder pulses from origin within one encoder rotation)</li> <li>Linear Servomotors: Electrical Angle 1 [linear encoder pulses] (linear encoder pulses from the polarity origin)</li> </ul>	Un003	<ul> <li>Rotary Servomotors: Rotational Angle 1 [encoder pulses] (number of encoder pulses from origin within one encoder rotation displayed in decimal)</li> <li>Linear Servomotors: Electrical Angle 1 [linear encoder pulses] (linear encoder pulses from the polarity origin displayed in decimal)</li> </ul>		
	<ul> <li>Rotary Servomotors: Rotational Angle 2 [deg] (electrical angle from origin within one encoder rotation)</li> <li>Linear Servomotors: Electrical Angle 2 [deg] (electrical angle from polarity ori- gin)</li> </ul>	Un004	<ul> <li>Rotary Servomotors: Rotational Angle 2 [deg] (electrical angle from polarity origin)</li> <li>Linear Servomotors: Electrical Angle 2 [deg] (electrical angle from polarity origin)</li> </ul>		
	Input Reference Pulse Speed [min-1]	Un007	Input Reference Pulse Speed [min <sup>-1</sup> ] (displayed only during position control)		
Motion	Position Deviation [reference units]	Un008	Position Error Amount [reference units] (displayed only during position control)		
Wohito	Accumulated Load Ratio [%]	Un009	Accumulated Load Ratio [%] (percentage of rated torque: effective torque in cycles of 10 seconds)		
	Regenerative Load Ratio [%]	Un00A All Axes	Regenerative Load Ratio [%] (percentage of processable regenerative power: regenerative power consumption in cycles of 10 seconds)		
	Dynamic Brake Resistor Power Con- sumption [%]	Un00B	Power Consumed by DB Resistance [%] (percentage of processable power at DB acti- vation: displayed in cycles of 10 seconds)		
	Input Reference Pulse Counter [ref- erence units]	Un00C	Input Reference Pulse Counter [reference units]		
	Feedback Pulse Counter [encoder pulses]	Un00D	Feedback Pulse Counter [encoder pulses]		
	Total Operation Time [100 ms]	Un012 All Axes	Total Operation Time [100 ms]		
	Feedback Pulse Counter [reference units]	Un013	Feedback Pulse Counter [reference units]		
	Current Backlash Compensation Value [0.1 reference units]	Un030	Current Backlash Compensation Value [0.1 reference units]		
	Backlash Compensation Value Set- ting Limit [0.1 reference units]	Un031	Backlash Compensation Value Setting Limit [0.1 reference units]		
	Power Consumption [W]	Un032 All Axes	Power Consumption [W]		

#### 12.2.2 Corresponding SERVOPACK Monitor Display Function Names

Continued from previous page.

	SigmaWin+	SERVOPACK			
Menu Bar Button	Name [Unit]	Un No.	Name [Unit]		
	Consumed Power [0.001 Wh]	Un033 All Axes	Consumed Power [0.001 Wh]		
	Cumulative Power Consumption [Wh]	Un034 All Axes	Cumulative Power Consumption [Wh]		
Motion	Absolute Encoder Multiturn Data	Un040	Absolute Encoder Multiturn Data		
Monitor	Position within One Rotation of Absolute Encoder [encoder pulses]	Un041	Position within One Rotation of Absolute Encoder [encoder pulses]		
	Lower Bits of Absolute Encoder Position [encoder pulses]	Un042	Lower Bits of Absolute Encoder Position [encoder pulses]		
	Upper Bits of Absolute Encoder Position [encoder pulses]	Un043	Upper Bits of Absolute Encoder Position [encoder pulses]		
Status	Polarity Sensor Signal Monitor	Un011	Polarity Sensor Signal Monitor		
Monitor	Active Gain Monitor	Un014	Effective Gain Monitor (gain settings $1 = 1$ , gain settings $2 = 2$ )		
		Un005	Input Signal Monitor		
Input Sig- nal Moni-	Input Signal Monitor	Un050 All Axes	All Input Signal Monitor 1		
tor		Un052 All Axes	All Input Signal Monitor 2		
Output		Un006	Output Signal Monitor		
Signal Monitor	Output Signal Monitor	Un051 All Axes	All Output Signal Monitor		
	Installation Environment Monitor – SERVOPACK	Un025 All Axes	SERVOPACK Installation Environment Monitor [%]		
	Installation Environment Monitor – Servomotor*	Un026*	Servomotor Installation Environment Monitor [%]		
Service	Service Life Prediction Monitor – Built-in Fan	Un027 All Axes	Built-in Fan Remaining Life Ratio [%]		
tor	Service Life Prediction Monitor – Capacitor	Un028 All Axes	Capacitor Remaining Life Ratio [%]		
	Service Life Prediction Monitor – Surge Prevention Circuit	Un029 All Axes	Surge Prevention Circuit Remaining Life Ratio [%]		
	Service Life Prediction Monitor – Dynamic Brake Circuit	Un02A	Dynamic Brake Circuit Remaining Life Ratio [%]		
Product	Motor Population	Un084	Linear Encoder Pitch (Scale pitch = Un084 × 10 <sup>Un085</sup> [pm])		
tion		Un085	Linear Encoder Pitch Exponent (Scale pitch = Un084 × 10 <sup>Un085</sup> [pm])		
	-	Un020	Rated Motor Speed [min-1]		
-	-	Un021	Maximum Motor Speed [min-1]		

\* This applies to the following motors. The display will show 0 for all other models. SGM7J, SGM7A, SGM7P, SGM7G, and SGMCV



### Symbols

/ВК	5-34
/BK (Brake) signal	5-34
/CLT (Torque Limit Detection) signal	6-26
/COIN	6-13
/COIN (Positioning Completion) signal	6-13
/N-CL	6-23
/N-CL (Reverse External Torque Limit) signal	6-23
/NEAR	6-14
/NEAR (Near) signal	6-14
/P-CL	6-23
/P-CL (Forward External Torque Limit) signal	6-23
/S-RDY	6-11
/TGON	6-10
/TGON (Rotation Detection) signal	6-10
/V-CMP	6-11
/V-CMP (Speed Coincidence Detection) signal	6-11
/VLT	6-15
/VLT (Speed Limit Detection) signal	6-15
/WARN	- 6-9
/WARN (Warning) signal	- 6-9

#### Α

A.CC0 6-30
absolute encoder 6-27
origin offset 5-49
resetting 5-46
wiring 4-20
AC power supply input
setting 5-13
additional adjustment functions 8-66
alarm reset possibility 10-5
alarm tracing 9-16
ALM 6-9
ALM (Servo Alarm) signal 6-9
Analog Monitor Connector 4-39
analog monitor factors 9-10
anti-resonance control 8-50
automatic detection of connected motor 5-15
automatic gain switching 8-67
automatic notch filters 8-31
autotuning with a host reference 8-35
autotuning without a host reference 8-24

#### В

backlash compensation 8-73
base block (BB) viii
battery
replacement10-3
block diagram2-7

#### С

CCW5-16
clearing alarm history10-38
CN14-31
CN2A4-19
CN2B4-19
CN34-39
CN54-39
CN6A4-38
CN6B4-38
CN74-39
coasting
coasting to a stop5-37
coefficient of speed fluctuation
compatible adjustment functions 8-89
Computer Connector4-39
countermeasures against noise
current gain level setting 8-72
custom tuning8-42
CW5-16

#### D

DC power supply input4-11
setting5-13
wiring example
DC Reactor
terminals4-10
wiring
decelerating to a stop
detection timing for Overload Alarms (A.720) 5-41
detection timing for Overload Warnings (A.910)5-40
diagnostic tools8-93
displaying alarm history 10-37
dynamic brake applied
dynamic brake stopping

#### Е

EasyFFT	8-95
electronic gear	5-42
encoder resolution	5-43
estimating the moment of inertia	8-16
External Regenerative Resistor	5-52
external torque limits	6-23

### F

feedforward 8-33, 8-8	39
feedforward compensation	39
FG 4-8, 4-3	32
forward rotation	6
friction compensation 8-33, 8-7	70

#### G

gain switching8-66
grounding 4-8
group 1 alarms
group 2 alarms
G-SEL

#### Н

holding brake	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-5	-30	3
---------------	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	----	-----	---

#### I

I/O signals
allocations 6-3
functions
monitoring 9-5
names
wiring example
initializing the vibration detection level
input signals
allocations 6-3
internal torque limits
I-P control

### J

	jogging	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	7-7
--	---------	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	-----

L
limiting torque6-22
Linear Encoder
wiring example
linear encoder
feedback resolution
scale pitch setting
Linear Servomotor viii
Linear Servomotor Overheat Protection Signal 4-31
list of alarms10-5
list of MECHATROLINK-III common parameters 11-53
list of parameters
MECHATROLINK-III common parameters 11-53
list of warnings 10-41

#### Μ

Main Circuit Cable viii
manual gain switching
mechanical analysis
mode switching
(changing between proportional and PI control) 8-90

Momentary Power Interruption Hold Time 6-17
monitor factors
Motion Monitor
motor current detection signal
automatic adjustment 6-41
manual adjustment
offset 6-41
motor direction setting5-16
motor maximum speed 6-20
motor overload detection level 5-40
multiturn limit 6-28
Multiturn Limit Disagreement 6-30

### Ν

Noise Filter
Noise Filter connection precautions 4-7
N-OT5-29
N-OT (Reverse Drive Prohibit) signal 5-29
notch filters 8-82, 8-85

### 0

operation for momentary power interruptions	6-17
origin search	7-19
overload warnings	5-40
overtravel	5-29
warnings	5-32

### Ρ

parameter settings recording table 11-62
parameters
classification
initializing parameter settings
notation (selecting functions) ix, 5-4
setting methods
write prohibition setting 5-6
photocoupler input circuits 4-36
photocoupler output circuits 4-37
Pl control 8-86
polarity detection5-26
polarity sensor 5-25
position integral 8-92
position loop gain 8-80
positioning completed width 6-13
P-OT5-29
P-OT (Forward Drive Prohibit) signal 5-29
program jogging 7-14
operation pattern7-14

#### R

reference unit5-4	2
Regenerative Resistor	
connection	7
regenerative resistor 5-5	2

regenerative resistor capacity 5-5	52
resetting alarms	37
Rotary Servomotor	viii

#### S

safety functions					
monitoring	- 9-5				
scale pitch	5-17				
selecting the phase sequence					
for a Linear Servomotor	5-23				
selecting torque limits	6-22				
SEMI F47 function	6-18				
Serial Communications Connector	4-39				
Serial Converter Unit	5-17				
Servo Drive	viii				
servo gains	8-79				
servo lock	viii				
servo OFF	viii				
servo ON	viii				
Servo System	viii				
Servomotor	viii				
Servomotor stopping method for alarms	5-38				
SERVOPACK	viii				
inspections and part replacement	10-2				
part names	- 1-4				
ratings	- 2-2				
specifications	- 2-4				
setting the origin	5-49				
setting the position deviation overflow alarm level	- 8-8				
setting the position deviation overflow alarm level					
setting the position deviation overflow alarm level at servo ON	8-10				
setting the position deviation overflow alarm level at servo ON	8-10 8-10				
setting the position deviation overflow alarm level at servo ON	8-10 8-10 - 5-3				
setting the position deviation overflow alarm level at servo ON	8-10 8-10 - 5-3 4-32				
setting the position deviation overflow alarm level at servo ON	8-10 8-10 - 5-3 4-32 viii				
setting the position deviation overflow alarm level at servo ON	8-10 8-10 - 5-3 4-32 viii - 6-3				
setting the position deviation overflow alarm level at servo ON	8-10 8-10 - 5-3 4-32 viii - 6-3				
setting the position deviation overflow alarm level at servo ON	8-10 8-10 - 5-3 4-32 viii - 6-3 5-14				
setting the position deviation overflow alarm level at servo ON	8-10 8-10 - 5-3 4-32 viii - 6-3 5-14				
setting the position deviation overflow alarm level at servo ON	8-10 8-10 - 5-3 4-32 viii - 6-3 5-14 4-14				
setting the position deviation overflow alarm level at servo ON	8-10 8-10 - 5-3 4-32 viii - 6-3 5-14 4-14 4-36				
setting the position deviation overflow alarm level at servo ON	8-10 8-10 - 5-3 4-32 viii - 6-3 5-14 4-14 4-36 6-21				
setting the position deviation overflow alarm level at servo ON	8-10 8-10 - 5-3 4-32 viii - 6-3 5-14 4-14 4-36 6-21 6-34				
setting the position deviation overflow alarm level at servo ON	8-10 8-10 - 5-3 4-32 viii - 6-3 5-14 4-14 4-36 6-21 6-34 4-36				
setting the position deviation overflow alarm level at servo ON	8-10 8-10 - 5-3 4-32 viii - 6-3 5-14 4-14 4-36 6-21 6-34 4-36 8-72				
setting the position deviation overflow alarm level at servo ON	8-10 8-10 - 5-3 4-32 viii - 6-3 5-14 4-14 4-36 6-21 6-34 4-36 8-72 6-15				
setting the position deviation overflow alarm level at servo ON	8-10 8-10 - 5-3 4-32 viii - 6-3 5-14 4-14 4-36 6-21 6-34 4-36 8-72 6-15 8-81				
setting the position deviation overflow alarm level at servo ON	8-10 8-10 - 5-3 4-32 viii - 6-3 5-14 4-14 4-36 6-21 6-34 4-36 8-72 6-15 8-81 8-81				
setting the position deviation overflow alarm level at servo ON	8-10 8-10 - 5-3 4-32 viii - 6-3 5-14 4-14 4-36 6-21 6-34 4-36 8-72 6-15 8-81 8-81 4-11				
setting the position deviation overflow alarm level at servo ON	8-10 8-10 - 5-3 4-32 viii - 6-3 5-14 4-14 4-36 6-21 6-34 4-36 8-72 6-15 8-81 8-81 4-11 - 9-3				
setting the position deviation overflow alarm level at servo ON	8-10 8-10 - 5-3 4-32 viii - 6-3 5-14 4-14 4-36 6-21 6-34 4-36 8-72 6-15 8-81 8-81 4-11 - 9-3 5-37				
setting the position deviation overflow alarm level at servo ON	8-10 8-10 - 5-3 4-32 viii - 6-3 5-14 4-14 4-36 6-21 6-34 4-36 8-72 6-15 8-81 4-11 8-81 4-11 - 9-3 5-37 5-37				

storage temperature
surrounding air humidity
surrounding air temperature2-4
switching condition A8-67

#### Т

test without a motor
TH_A4-31
TH_B4-31
three-phase AC power supply input
setting5-14
three-phase, 200-VAC power supply input 4-10
wiring example
time required to brake 5-33
time required to release brake
torque reference filter8-82
troubleshooting alarms10-10
troubleshooting warnings 10-43
tuning parameters
tuning-less
load level
rigidity level
tuning-less function8-12
V
vibration suppression8-55

#### W

writing parameters
Z
zero clamping

### **Revision History**

The revision dates and numbers of the revised manuals are given on the bottom of the back cover.

MANUAL NO. SIEP S800001 29B <1>-1 WEB revision number Revision number Published in Japan September 2014 Date of publication

Date of Publication	Rev. No.	Web Rev. No.	Section	Revised Contents
November 2015	<5>	0	Preface	Revision: Information on certification for standards
			4.4.3, 5.15.1	Addition: Information on SQ10 Linear Encoder from Magnescale Co., Ltd.
October 2015	<4>	0	All chapters	Revision: Information on SigmaWin+ procedures
			Preface, Chapter 1	Addition: Information on SGMMV Rotary Servomotors
			Preface, 9.4.1	Partly revised.
			1.5.2	Addition: Information on Direct Drive Servomotors (SGMCV-16D and -35D).
			9.5	Newly added.
			Chapter 10	Addition: A.bF5, A.bF6, A.bF7, A.bF8, and FL-6
			Back cover	Revision: Address
April 2015 <	<3>	0	All chapters	Addition: Information on dynamic brake option Addition: Information on HWBB option
			Preface, 6.1.10, 7.6.3, 8.3.3, 8.3.5, 10.3.2	Partly revised.
			10.2.2, 10.5, 11.1.2	Revision: Reference information
			11.1.2	Deletion: Pn51B Revision: Information on Pn601 and Pn604
			Front cover, back cover, spine	Revision: Format
March 2015	<2>	0	All chapters	Addition: Information on BTO specification Partly revised.
			Preface	Addition: Information on dynamic brake Revision: Information on certification for standards
			2.1.1	Revision: Power loss
			4.2, 4.4.3, 4.5.3	Addition: Information on Battery for absolute encoder
			5.15.1, 5.17.2	Addition: Information on Linear Encoders (ST1381 and ST1382) from Mitutoyo Corporation
			8.12.3, 11.1.2	Addition: Current Control Mode Selection
			Chapter 11	Addition: Pn846
			Back cover	Revision: Address
September 2014	<1>	1	10.5, 11.1.2	Partly revised.
July 2014		0	-	Based on Japanese user's manual, SIJP S800001 29B <1> printed in July 2014.
			All chapters	Addition: Information on SGD7S-330A, -470A, -550A, -590A, and -780A
				Addition: Information on supplementary document (Manual No.: SIEP S800001 50)
May 2014	-	-	-	First edition

### $\Sigma$ -7-Series AC Servo Drive $\Sigma$ -7W SERVOPACK with MECHATROLINK-III **Communications References** Product Manual

#### **IRUMA BUSINESS CENTER (SOLUTION CENTER)**

480, Kamifujisawa, Iruma, Saitama, 358-8555, Japan Phone 81-4-2962-5151 Fax 81-4-2962-6138 http://www.yaskawa.co.jp

#### YASKAWA AMERICA, INC.

2121, Norman Drive South, Waukegan, IL 60085, U.S.A. Phone 1-800-YASKAWA (927-5292) or 1-847-887-7000 Fax 1-847-887-7310 http://www.yaskawa.com

#### YASKAWA ELÉTRICO DO BRASIL LTDA.

#### 777, Avenida Piraporinha, Diadema, São Paulo, 09950-000, Brasil Phone 55-11-3585-1100 Fax 55-11-3585-1187 http://www.vaskawa.com.br

#### YASKAWA EUROPE GmbH

185, Hauptstraβe, Eschborn, 65760, Germany Phone 49-6196-569-300 Fax 49-6196-569-398 http://www.yaskawa.eu.com

YASKAWA ELECTRIC KOREA CORPORATION 9F, Kyobo Securities Bldg. 26-4, Yeouido-dong, Yeongdeungpo-gu, Seoul, 150-737, Korea Phone 82-2-784-7844 Fax 82-2-784-8495 http://www.yaskawa.co.kr

#### YASKAWA ELECTRIC (SINGAPORE) PTE. LTD.

151, Lorong Chuan, #04-02À, New Tech Park, 556741, Singapore Phone 65-6282-3003 Fax 65-6289-3003 http://www.yaskawa.com.sg

#### YASKAWA ELECTRIC (THAILAND) CO., LTD.

59, 1st-Sth Floor, Flourish Building, Soi Ratchadapisek 18, Ratchadapisek Road, Huaykwang, Bangkok, 10310, Thailand Phone 66-2-017-0099 Fax 66-2-017-0799 http://www.yaskawa.co.th

#### YASKAWA ELECTRIC (CHINA) CO., LTD.

22F, One Corporate Avenue, No.222, Hubin Road, Shanghai, 200021, China Phone 86-21-5385-2200 Fax 86-21-5385-3299 http://www.yaskawa.com.cn

#### YASKAWA ELECTRIC (CHINA) CO., LTD. BEIJING OFFICE

Room 1011, Tower W3 Oriental Plaza, No.1, East Chang An Ave., Dong Cheng District, Beijing, 100738, China Phone 86-10-8518-4086 Fax 86-10-8518-4082

#### YASKAWA ELECTRIC TAIWAN CORPORATION

9F, 16, Nanking E. Rd., Sec. 3, Taipei, 104, Taiwan Phone 886-2-2502-5003 Fax 886-2-2505-1280



YASKAWA ELECTRIC CORPORATION

In the event that the end user of this product is to be the military and said product is to be employed in any weapons systems or the manufacture thereof, the export will fall under the relevant regulations as stipulated in the Foreign Exchange and Foreign Trade Regulations. Therefore, be sure to follow all procedures and submit all relevant documentation according to any and all rules, regulations and laws that may apply. Specifications are subject to change without notice for ongoing product modifications and improvements

© 2014-2015 YASKAWA ELECTRIC CORPORATION

MANUAL NO. SIEP S800001 29F <5>-0 Published in Japan November 2015 15-8-11 Original instructions